Battery Charger

Application:

Battery charging set servers to recharge batteries rapidly and with less damage to the batteries, To maintain the fully-charged state of lead or nickel-cadmium batteries and to cover the Power requirement of continuous loads.

Setting Normal charger:

Disconnect terminal 6 and connect a voltmeter to terminals 5 and 6 . Set potentiometer Vo so that the following appropriate final charge voltage is indicated:

For 12 V lead-acid battery / Nickel Cadium batt setting 13,5 V dc / 14 V dc For 24 V lead-acid battery / Nickel Cadium batt setting 27,5 V dc / 28,5 V dc Equalizing charge :

The charging set is reconnected by connecting terminals 4 and 6 to high charge. The charging set is preset at the factory to **16V** (for BCxx12)/ **32V** (For BCxx24) dc if necessary.





BCS 0512 / 0524 / 0312

Technical Data.

Type	CS 0512 BCS 0524 BCS 0312	: B	
Rated Current / Voltage Input Voltage Power consumption Efficiency	A / 12 V dc 20 V ac ± 10 % 50 – 60 Hz c-load 10VA; full-load 100VA = 0.87 5 A / 24 V dc 220 V ac ± 10 % 50 – 60 Hz no-load 15VA; full-load 150VA n = 0.87 3 A / 12 V dc 220 Vac ± 10 % 50 – 60 Hz no-load 5VA; full-load 40VA n = 0.87	: 2 : n	
Vo Adjustment range Normal charge Output current	2 – 15 V dc 25 – 29 V dc 12 – 15 V dc aximum 5 A maximum 3 A		
Short-circuit behavior	device automatically switches device automatically switches off during short-circuit or incorrect polarity. device automatically switches device automatically switches off during short-circuit or incorrect polarity.	0 01	nes
Temperature	°C to 80 °C		
Connection terminal	3, max. wire 2.5 mm		
Permissible duty cycle	00 % 100 %		
Weight		: 3	
Maintenance	o maintenance required no maintenance required no maintenance required		
Dimensions	28 mm x 200 mm x 118 mm 128 mm x 200 mm x 135 mm 128 mm x 200 mm x 104 mm	: 1	nm