

CAT® CLASSIC™ PARTS PRODUCT BOOK

July 2010



Cat® Classic™ Parts Overview	1
Backhoe Loaders.....	3
Engines	7
Excavators	17
Motor Graders	55
Pipelayers	99
Scrapers	129
Track Loaders.....	145
Track-Type Tractors.....	177
Wheel Loaders	245
Literature References.....	271
Part Cross-Reference.....	273

Cat Classic Parts

Cat® Classic™ Parts provide owners of older Cat equipment with lower cost repair alternatives that minimize the risk associated with non-genuine parts. Cat machines and engines have long, productive lives. As the equipment ages, maintenance costs often need to be re-evaluated, taking the remaining market value into consideration. Cat Classic Parts are lower-cost, genuine Cat parts that provide acceptable service life for older Cat equipment. Not all Cat original parts have a Classic Parts option. The Classic Parts line generally contains parts that have a greater impact on the overall repair costs. Together with Cat original and remanufactured parts, Cat Classic Parts help Caterpillar offer value-priced repair alternatives over the entire product life cycle.

ALL YOUR OPTIONS.



The diagram illustrates four options for Cat parts, each with a representative image and a label below it. From left to right: 1. 'Original' shows several Cat part boxes. 2. 'Reman/Exchange' shows two pistons. 3. 'Classic™ Parts' shows two boxes, one labeled 'Classic Parts', and is enclosed in a large, light-gray bracket. 4. 'Quality Used' shows a large gear and a smaller component. Below these options, the text 'ONE LOCATION.' is displayed in large, bold letters. At the bottom, there is a 3D rendering of a 'DEALER CAT' sign on a post.

ONE LOCATION.

DEALER CAT

Benefits

Cat Classic Parts help manage the owning and operating costs for older equipment by offering a low cost repair alternative. Classic Parts minimize the risk associated with non-genuine parts since the parts are backed by the reliable Cat standard warranty and by the dependable Cat Dealer network. Cat Classic Parts are approved by Caterpillar engineers, who ensure that the product will meet form, fit, and function. Caterpillar approved suppliers manufacture these parts utilizing industry standard product quality assurance processes. Quality checks are performed by Cat parts stock locations to ensure that only the highest quality parts are being sent out to our customers. Ultimately the Cat brand provides peace of mind for the equipment owner.

Cat® Classic™ Parts Product Book



This Cat Classic Parts Product Book contains the line of Classic Parts available for Cat machines and engines. The Classic Parts Overview section of this manual provides you with detailed information to help your customer make an informed decision on which type of part to purchase. The next eight sections contain a cross reference between Cat Classic part numbers and Cat original part numbers categorized by product family and models. This section is further broken down into the model numbers of specific Cat machines and engines. The Literature Reference section provides a reference of available promotional material for Cat Classic Parts information. The Part Cross-Reference section at the end of the catalog details the available parts in numerical order.

Warranty

Cat Classic Parts are backed by the standard Caterpillar parts warranty. This warranty covers the parts for a six month time period. The customer warranty statement for these parts is SELF5426. It should be referenced for general information on the overall warranty terms. Dealers should reference the relevant parts warranty bulletin for additional specific details about Classic Parts warranty.

Undercarriage Assurance (3 years/4,000 hours) is now offered for Cat Classic major moving undercarriage parts. Enrollment requirements will be the same as for Cat premium undercarriage products.

Additional Information

For more information on the Cat Classic Parts product line, customers should visit the Classic Parts section of www.cat.com.

Dealers, please use your CWS ID to access the global Classic Parts websites. They are contained within the Product Support area of your Cat regional internet websites under Parts Products.

NACD - <https://nacd.cat.com>

APD - <https://apdnet.cat.com>

LACD - <https://lacd.cat.com>

EAME - <https://eame.cat.com>

Types of information that can be found on these pages include the following: advertising/promotional material, cost comparisons, presentations, a video explaining Classic parts, and appropriate Cat Classic parts contacts.

Contact Information

Classic Parts Email Address:

Classic_Parts_Support@cat.com

Customer Interaction Center:

USA: 1-877-CAT-CICO (228-2420)

International: 309-578-7372

Email: cic@cat.com

Cat® Classic™ Parts for Backhoe Loaders

Cat® backhoe loaders are designed for maximum performance and durability in any application. Caterpillar has been delivering industry-leading digging forces with this product line since its introduction. However, as with any aging equipment, maintenance costs need to be re-evaluated over time to ensure that maximum profitability is maintained. Cat Classic Parts are offered as another solution to help keep these maintenance costs down for Caterpillar equipment. They are released for several models of backhoe loaders as a competitively priced alternative to aftermarket parts.

Cat Classic Parts provide owners of older Caterpillar products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic Parts coverage for backhoe loaders includes:

- Engine
- Final Drive
- Hydraulics
- Steering
- Transmission
- ...and many more.



Sales Model 416

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
055-1260	Housing Bk - Outer	347-0479
130-1637	Shaft	347-0471
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484
186-4118	Gear - Planet	347-0483
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681
7W-5194	Muffler As	346-5682
9R-0080	Coupling	346-5683

Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0237	Pin As	346-5685
9R-0424	Pin	346-5686
9R-1726	Washer	346-5687
9R-2410	Retainer As	346-5688
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2476	Disc - Bk Rear	346-5691
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696

Original Part Number	Part Name	Classic Part Number
9R-3933	Pin	346-5697
9R-6158	Pin	346-5698
9R-6159	Pin	346-5699
9R-6160	Pin	346-5700
9R-6163	Pin	346-5701
9R-6475	Pad As	346-5702
9R-7158	Pin As	346-5704
9R-7894	Pin As	346-5706
9R-7895	Pin As	346-5707
9R-8715	Spider and Bearing As	346-5716
9R-9190	Rod Gp - Tie	346-5718
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9Y-9431	Precleaner As	361-1718

Sales Model 416B

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
127-8592	Muffler As	347-0463
130-1637	Shaft	347-0471
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484

Original Part Number	Part Name	Classic Part Number
186-4118	Gear - Planet	347-0483
1M-7250	Bowl - Pre-cleaner	360-2296
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
6E-1500	Piston	346-5677
6E-6153	Plate - Port	346-5678
6E-6163	Shaft	346-5679
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681

Original Part Number	Part Name	Classic Part Number
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-1726	Washer	346-5687
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695

(Continued)

Sales Model 416B (Continued)

Original Part Number	Part Name	Classic Part Number
9R-3161	Shaft - Sun Gear	346-5696
9R-3933	Pin	346-5697
9R-6163	Pin	346-5701
9R-7158	Pin As	346-5704
9R-7696	Pin	346-5705
9R-8202	Pin	346-5708

Original Part Number	Part Name	Classic Part Number
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8662	Pin	346-5713
9R-8715	Spider and Bearing As	346-5716
9R-9190	Rod Gp - Tie	346-5718

Original Part Number	Part Name	Classic Part Number
9R-9400	Case As	346-5719
9R-9402	Seal - Rax	347-0476
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9R-9812	Pin	347-0468
9Y-9431	Precleaner As	361-1718

Sales Model 416C

Original Part Number	Part Name	Classic Part Number
055-1986	Seal - Lip type	347-0465
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
112-9629	Pin	347-0470
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
122-1881	Plate - Clutch	347-0475
130-1637	Shaft	347-0471
130-6879	Seal	347-0482
160-1014	Pin As	347-0473
186-4118	Gear - Planet	347-0483

Original Part Number	Part Name	Classic Part Number
229-2949	Rod As - Track	347-0486
229-2950	Rod As - Track	347-0487
237-2252	Bearing - Sleeve	347-0474
6E-1500	Piston	346-5677
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693

Original Part Number	Part Name	Classic Part Number
9R-2956	Pin	346-5695
9R-3933	Pin	346-5697
9R-6163	Pin	346-5701
9R-7696	Pin	346-5705
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8662	Pin	346-5713
9R-9049	Pin	346-5717
9R-9403	Pinion	347-0477
9R-9812	Pin	347-0468
9T-2373	Head	347-0461
239-9956	Brake Disc	347-0485

Sales Model 428

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
055-1260	Housing Bk - Outer	347-0479
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484
186-4118	Gear - Planet	347-0483
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681
7W-5194	Muffler As	346-5682
9R-0080	Coupling	346-5683
9R-0097	Pin	346-5684
9R-0237	Pin As	346-5685

Original Part Number	Part Name	Classic Part Number
9R-0424	Pin	346-5686
9R-1726	Washer	346-5687
9R-2410	Retainer As	346-5688
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2476	Disc - Bk Rear	346-5691
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696
9R-3933	Pin	346-5697
9R-6158	Pin	346-5698

Original Part Number	Part Name	Classic Part Number
9R-6159	Pin	346-5699
9R-6160	Pin	346-5700
9R-6163	Pin	346-5701
9R-6475	Pad As	346-5702
9R-6545	Pin	346-5703
9R-7158	Pin As	346-5704
9R-7894	Pin As	346-5706
9R-7895	Pin As	346-5707
9R-8639	Cylinder	346-5712
9R-8715	Spider and Bearing As	346-5716
9R-9190	Rod Gp - Tie	346-5718
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9Y-9431	Precleaner As	361-1718

Sales Model 428B

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
127-8592	Muffler As	347-0463
160-1014	Pin As	347-0473
175-4070	Bushing - Sleeve	347-0484
186-4118	Gear - Planet	347-0483
1M-7250	Bowl - Pre-cleaner	360-2296
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
6E-1500	Piston	346-5677
6E-6153	Plate - Port	346-5678
6E-6163	Shaft	346-5679

Original Part Number	Part Name	Classic Part Number
7T-3173	Piston	346-5680
7T-3194	Yoke	346-5681
9R-0097	Pin	346-5684
9R-0424	Pin	346-5686
9R-1726	Washer	346-5687
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2846	Pin	346-5694
9R-2956	Pin	346-5695
9R-3161	Shaft - Sun Gear	346-5696
9R-3933	Pin	346-5697
9R-6159	Pin	346-5699
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7158	Pin As	346-5704

Original Part Number	Part Name	Classic Part Number
9R-7696	Pin	346-5705
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8639	Cylinder	346-5712
9R-8662	Pin	346-5713
9R-8707	Pin	346-5714
9R-8709	Pin	346-5715
9R-8715	Spider and Bearing As	346-5716
9R-9049	Pin	346-5717
9R-9190	Rod Gp - Tie	346-5718
9R-9400	Case As	346-5719
9R-9402	Seal - Rax	347-0476
9R-9403	Pinion	347-0477
9R-9631	Pin	347-0467
9R-9812	Pin	347-0468
9Y-9431	Precleaner As	361-1718

Sales Model 428C

Original Part Number	Part Name	Classic Part Number
055-1986	Seal - Lip type	347-0465
102-4560	Bearing - Sleeve	347-0469
112-1773	Piston	347-0462
112-9629	Pin	347-0470
119-7042	Shaft	347-0480
119-7047	Seal	347-0481
122-1881	Plate - Clutch	347-0475
130-6879	Seal	347-0482
160-1014	Pin As	347-0473
167-2329	Seal - U-cup	347-0466
186-4118	Gear - Planet	347-0483

Original Part Number	Part Name	Classic Part Number
229-2949	Rod As - Track	347-0486
229-2950	Rod As - Track	347-0487
237-2252	Bearing - Sleeve	347-0474
239-9956	Brake Disc	347-0485
6E-1500	Piston	346-5677
9R-0097	Pin	346-5684
9R-2421	Shaft	346-5689
9R-2424	Gear - Planet Sun	346-5690
9R-2477	Disc As	346-5692
9R-2491	Spider	346-5693
9R-2956	Pin	346-5695

Original Part Number	Part Name	Classic Part Number
9R-3933	Pin	346-5697
9R-6159	Pin	346-5699
9R-6163	Pin	346-5701
9R-6545	Pin	346-5703
9R-7696	Pin	346-5705
9R-8202	Pin	346-5708
9R-8206	Pin	346-5709
9R-8523	Pin	346-5710
9R-8579	Pin	346-5711
9R-8639	Cylinder	346-5712
9R-8662	Pin	346-5713
9R-9190	Rod Gp - Tie	346-5718
9R-9403	Pinion	347-0477
9R-9812	Pin	347-0468
9T-2373	Head	347-0461

Cat® Classic™ Parts for Older Engines


Cat® Classic™ parts are available for the following engine models: D353C/D/E; D379/B; D398/B; D399; G353D; G379; G398; G399. First produced by Caterpillar more than four decades ago, thousands of these engines are still heavily relied upon in a variety of petroleum, marine, and prime power applications. As these engines age, maintenance costs sometimes need to be re-evaluated.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts offerings for engines include:

- Air, Manifold, & Outlet Elbows
- Cooler Core
- Cylinder Liner
- Front & Upper Manifolds
- Fuel Injection Lines & Pumps
- Fuel Transfer Pumps
- Gaskets
- Inlet & Exhaust Valves
- Pistons
- ...and many more.

Sales Model D353C, D353D, D353E



Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2F-5721	Bearing - Ball	311-9354
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-9297	Retainer - Spring	314-8535
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3N-3368	Pipe - Exhaust	311-9434
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5F-7404	Nut - Bearing Lock	308-9878
5H-5553	Screw - Tappet Adjustable	311-9451
5L-8856	Coupling - Exhaust	311-9379
5L-9371	Connector - Inlet	311-9375
5L-9738	Coupling - Exhaust	311-9380
5M-6211	Shaft - Planet	219-9684

Original Part Number	Part Name	Classic Part Number
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-6969	Chamber As	247-3299
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
7T-2036	Cap As - Filter	361-1721
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511

Sales Model D353C, D353D, D353E (Continued)

Original Part Number	Part Name	Classic Part Number
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537

Original Part Number	Part Name	Classic Part Number
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472

Original Part Number	Part Name	Classic Part Number
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp	311-9443
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D379, D379B

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
1W-9205	Line As - Fuel Injector	311-9415
1W-9206	Line As - Fuel Injector	311-9416
1W-9207	Line As - Fuel Injector	311-9417
1W-9208	Line As - Fuel Injector	311-9418
1W-9209	Line As - Fuel Injector	311-9419
1W-9210	Line As - Fuel Injector	311-9420
1W-9211	Line As - Fuel Injector	311-9421
1W-9212	Line As - Fuel Injector	311-9422
2D-5658	Bearing - Ball	301-4628

Original Part Number	Part Name	Classic Part Number
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2P-1757	Hub - Fan Pulley	296-1357
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3L-1425	Bearing - Ball	311-9356
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459

Original Part Number	Part Name	Classic Part Number
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
3S-9466	Bearing - Sleeve	314-8509
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-6302	Belt Set - Vee	314-8495
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5550	Core As - Oil Cooler	311-9377
5H-5553	Screw - Tappet Adjustable	311-9451
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363

(Continued)

Sales Model D379, D379B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5L-2894	Bearing - Sleeve	311-9364	6L-3910	Line As - Fuel	311-9424	7S-5787	Chamber As	247-3300
5L-3980	V - Belt Set	314-8498	6L-4714	Panel - Air Cleaner Filter	314-8532	7S-7809	Cap As - Radiator	295-6417
5L-5656	Belt Set - Vee	314-8499	6L-6481	Elbow - Air Inlet	311-9385	8B-5972	Bearing - Ball	314-8503
5L-8856	Coupling - Exhaust	311-9379	6L-6482	Elbow - Air Outlet	311-9386	8F-5104	Screen As - Oil Pan	314-8539
5L-9370	Elbow - Manifold Inlet	311-9388	6L-6491	Pipe - Cross-over	311-9433	8F-8858	Button Valve	314-8511
5L-9371	Connector - Inlet	311-9375	6L-7816	Seal - o-Ring	314-8542	8L-3972	Baffle	311-9345
5L-9738	Coupling - Exhaust	311-9380	6L-8585	Gear - Gov Drive	314-8526	8M-0874	Plunger As - Valve	311-9439
5M-7900	Bolt - Hex Head	311-9349	6L-8968	Coupling - Exhaust	311-9381	8M-2549	Rod As - Connector	314-8537
5N-2691	Elbow - Air Transfer	311-9383	6N-8847	Guide - Valve	314-8523	8M-4014	Insert - Seat Exhaust	311-9398
5N-2692	Elbow - Air Transfer	311-9384	7B-2420	Ferrule - Director	314-8517	8N-2275	Bearing - Sleeve	311-9365
5N-2902	Seal - Oil	314-8540	7C-5920	Insert - Seat	314-8528	8N-3723	Valve - Exhaust	311-9472
5N-3009	Tube As - Inlet Lh	311-9465	7C-5921	Insert - Seat	314-8529	8N-7769	Bearing - Conn Rod	314-8505
5N-3012	Tube As - Inlet	311-9466	7C-5922	Insert - Seat	314-8530	8N-7770	Bearing - Conn Rod	314-8506
5N-3050	Elbow - Outlet	311-9389	7H-0602	Dog - Clutch	314-8515	8N-7771	Bearing - Conn Rod	314-8507
5N-4378	Shaft As - Pump	311-9456	7L-0104	Impeller - Pump	311-9395	8N-7780	Shield - Oil	314-8544
5P-7807	Bearing - Ball	314-8502	7M-4603	Body - Fuel Valve	311-9348	8N-9174	Liner - Cylinder	314-8531
5S-1757	Insert - Seat	311-9401	7M-4926	Retainer - Pin	314-8538	8S-3617	Chamber As	247-3302
5S-4557	Bearing	311-9360	7M-7431	Service Gp - Valve	314-8550	9H-2256	Pump Gp	311-9443
6H-3217	Shaft As - Rocker	311-9457	7M-7817	Valve - Inlet	311-9474	9K-8757	Rod End - Bearing	311-9361
6H-3957	Bearing - Ball	311-9358	7N-4515	Body As - Piston	311-9346	9S-8493	Bolt - Connecting Rod	311-9351
			7N-9810	Pin - Piston	311-9432			

Sales Model D398, D398B

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431	1P-8005	Gasket - Chamber	314-8527	1W-9204	Line As - Fuel Injector	311-9414
102-1561	Lifter As - Valve	311-9402	1S-5738	Insert - Seat Exhaust	311-9396	1W-9205	Line As - Fuel Injector	311-9415
1F-2254	Bushing - Stem	314-8510	1S-7114	Bolt	314-8500	1W-9206	Line As - Fuel Injector	311-9416
1F-4419	Gasket - Cover	311-9393	1W-3062	Retainer As	311-9445	1W-9207	Line As - Fuel Injector	311-9417
1N-5943	Manifold - Upper	311-9429	1W-5105	Ring Gp - Piston	311-9446	1W-9208	Line As - Fuel Injector	311-9418
1N-7478	Manifold - Front	311-9428	1W-9201	Line As - Fuel Injector	311-9411	1W-9209	Line As - Fuel Injector	311-9419
1P-0009	Rod As - Conn	311-9450	1W-9202	Line As - Fuel Injector	311-9412	1W-9210	Line As - Fuel Injector	311-9420
1P-1758	Bushing - Stem	311-9350	1W-9203	Line As - Fuel Injector	311-9413	1W-9211	Line As - Fuel Injector	311-9421

(Continued)

Sales Model D398, D398B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1W-9212	Line As - Fuel Injector	311-9422	4L-7820	Rod Assembly	311-9449	5N-4378	Shaft As - Pump	311-9456
2D-5658	Bearing - Ball	301-4628	4M-9215	Gear - Pump Idler	311-9391	5P-7807	Bearing - Ball	314-8502
2F-5721	Bearing - Ball	311-9354	4M-9216	Gear - Pump Drive	311-9390	5S-1757	Insert - Seat	311-9401
2K-3592	Boss	314-8501	4N-3664	Guide - Valve	314-8524	5S-4557	Bearing	311-9360
2L-4731	Adapter - Housing	311-9343	4N-7526	Seal As - Pump	311-9454	6H-3217	Shaft As - Rocker	311-9457
2N-3220	Gear - Oil Pump Drive	311-9392	4N-9180	Seal As - Pump	311-9455	6H-3957	Bearing - Ball	311-9358
2N-3227	Bracket - Lft Guide	311-9367	4S-8906	Insert	311-9397	6L-3902	Line As - Fuel	311-9423
2N-7194	Cap - Main Bearing	311-9369	4S-8908	Insert	311-9399	6L-3910	Line As - Fuel	311-9424
2N-7224	Cap As - Main Bearing	311-9370	4S-8909	Insert - Valve Seat	311-9400	6L-4714	Panel - Air Cleaner Filter	314-8532
2N-8519	Guide - Spring	314-8525	4W-2606	Seal Gp - Camshaft	311-9452	6L-6481	Elbow - Air Inlet	311-9385
2N-9297	Retainer - Spring	314-8535	4W-2607	Seal Gp - Camshaft	311-9453	6L-6482	Elbow - Air Outlet	311-9386
2S-2781	Plunger - Relief	311-9435	4W-5549	Core As - Oil Cooler	311-9376	6L-6491	Pipe - Cross-over	311-9433
2S-3966	Ring - Seal	297-7237	5H-5553	Screw - Tap-pet Adjustable	311-9451	6L-7816	Seal - o-Ring	314-8542
2S-4015	Plunger As - Valve	311-9438	5L-2648	Bearing - Sleeve	311-9362	6L-8585	Gear - Gov Drive	314-8526
2S-7264	Pump As - Fuel Injector	311-9442	5L-2660	Bearing - Sleeve	311-9363	6L-8968	Coupling - Exhaust	311-9381
2W-3211	Valve - Exhaust	311-9471	5L-2894	Bearing - Sleeve	311-9364	6N-6969	Chamber As	247-3299
3F-7445	Bearing - Sleeve	314-8508	5L-3980	V - Belt Set	314-8498	6N-8847	Guide - Valve	314-8523
3N-2078	Pump Gp - Fuel Transfer	311-9444	5L-5656	Belt Set - Vee	314-8499	7B-2420	Ferrule - Director	314-8517
3N-3148	Tube As	311-9461	5L-8856	Coupling - Exhaust	311-9379	7C-5920	Insert - Seat	314-8528
3N-3368	Pipe - Exhaust	311-9434	5L-9370	Elbow - Manifold Inlet	311-9388	7C-5921	Insert - Seat	314-8529
3N-6841	Tube As - Inlet Rh	311-9464	5L-9371	Connector - Inlet	311-9375	7C-5922	Insert - Seat	314-8530
3N-7326	Thrower - Camshaft Oil	311-9458	5L-9738	Coupling - Exhaust	311-9380	7H-0602	Dog - Clutch	314-8515
3N-7327	Thrower - Camshaft Oil	311-9459	5M-7900	Bolt - Hex Head	311-9349	7L-0104	Impeller - Pump	311-9395
3N-9160	Ring - Camshaft Seal	311-9447	5N-2691	Elbow - Air Transfer	311-9383	7M-4603	Body - Fuel Valve	311-9348
3P-0651	Seal - o-Ring	314-8541	5N-2692	Elbow - Air Transfer	311-9384	7M-4926	Retainer - Pin	314-8538
3S-9466	Bearing - Sleeve	314-8509	5N-2902	Seal - Oil	314-8540	7M-7431	Service Gp - Valve	314-8550
4F-4974	Clamp	311-9373	5N-3009	Tube As - Inlet Lh	311-9465	7M-7817	Valve - Inlet	311-9474
4L-3307	Elbow - Manifold Inlet	311-9387	5N-3012	Tube As - Inlet	311-9466	7N-4515	Body As - Piston	311-9346
4L-3756	Bearing - Thrust	311-9366	5N-3050	Elbow - Outlet	311-9389	7N-9810	Pin - Piston	311-9432
4L-4653	Plate - Thrust	311-9440				7S-5787	Chamber As	247-3300
						7S-7809	Cap As - Radiator	295-6417
						8B-5972	Bearing - Ball	314-8503
						8F-5104	Screen As - Oil Pan	314-8539
						8F-8858	Button Valve	314-8511
						8H-2810	Case As - Filter	314-8512
						8L-3972	Baffle	311-9345

(Continued)

Sales Model D398, D398B (Continued)

Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365

Original Part Number	Part Name	Classic Part Number
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507

Original Part Number	Part Name	Classic Part Number
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9H-2256	Pump Gp	311-9443
9K-8757	Rod End - Bearing	311-9361
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D399

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1N-5943	Manifold - Upper	311-9429
1N-7478	Manifold - Front	311-9428
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-7114	Bolt	314-8500
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
1W-9191	Line As - Fuel Injector	311-9403
1W-9192	Line As - Fuel Injector	311-9404
1W-9193	Line As - Fuel Injector	311-9405
1W-9194	Line As - Fuel Injector	311-9406
1W-9195	Line As - Fuel Injector	311-9407
1W-9196	Line As - Fuel Injector	311-9408
1W-9197	Line As - Fuel Injector	311-9409
1W-9198	Line As - Fuel Injector	311-9410
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2L-4731	Adapter - Housing	311-9343
2N-3220	Gear - Oil Pump Drive	311-9392

Original Part Number	Part Name	Classic Part Number
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7264	Pump As - Fuel Injector	311-9442
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-2078	Pump Gp - Fuel Transfer	311-9444
3N-3148	Tube As	311-9461
3N-3368	Pipe - Exhaust	311-9434
3N-6841	Tube As - Inlet Rh	311-9464
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541
3S-9466	Bearing - Sleeve	314-8509
4F-4974	Clamp	311-9373
4L-3756	Bearing - Thrust	311-9366

Original Part Number	Part Name	Classic Part Number
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5551	Core As - Oil Cooler	311-9378
5D-0470	Valve Gp	314-8549
5H-5553	Screw - Tappet Adjustable	311-9451
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375

(Continued)

Sales Model D399 (Continued)

Original Part Number	Part Name	Classic Part Number
5L-9738	Coupling - Exhaust	311-9380
5M-7900	Bolt - Hex Head	311-9349
5N-2691	Elbow - Air Transfer	311-9383
5N-2692	Elbow - Air Transfer	311-9384
5N-2902	Seal - Oil	314-8540
5N-3009	Tube As - Inlet Lh	311-9465
5N-3012	Tube As - Inlet	311-9466
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
6H-3217	Shaft As - Rocker	311-9457
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385

Original Part Number	Part Name	Classic Part Number
6L-6482	Elbow - Air Outlet	311-9386
6L-6491	Pipe - Cross-over	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7L-0104	Impeller - Pump	311-9395
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7N-4515	Body As - Piston	311-9346
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417

Original Part Number	Part Name	Classic Part Number
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-0874	Plunger As - Valve	311-9439
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9K-8757	Rod End - Bearing	311-9361
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model G353D

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1P-1758	Bushing - Stem	311-9350
1S-5738	Insert - Seat Exhaust	311-9396
1W-5105	Ring Gp - Piston	311-9446
2F-5721	Bearing - Ball	311-9354
2N-9297	Retainer - Spring	314-8535
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-3368	Pipe - Exhaust	311-9434
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4N-3664	Guide - Valve	314-8524

Original Part Number	Part Name	Classic Part Number
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5F-7404	Nut - Bearing Lock	308-9878
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517

Original Part Number	Part Name	Classic Part Number
7C-4297	Seal As - Camshaft	325-6192
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-9174	Liner - Cylinder	314-8531
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model G379

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2P-1757	Hub - Fan Pulley	296-1357
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3L-1425	Bearing - Ball	311-9356
3N-3368	Pipe - Exhaust	311-9434
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447

Original Part Number	Part Name	Classic Part Number
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4N-3664	Guide - Valve	314-8524
4N-6302	Belt Set - Vee	314-8495
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5550	Core As - Oil Cooler	311-9377
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358

Original Part Number	Part Name	Classic Part Number
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6491	Pipe - Cross-over	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302

Sales Model G398

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-3368	Pipe - Exhaust	311-9434
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447
3P-0651	Seal - o-Ring	314-8541

Original Part Number	Part Name	Classic Part Number
4F-4974	Clamp	311-9373
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5549	Core As - Oil Cooler	311-9376
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-5656	Belt Set - Vee	314-8499
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6L-4714	Panel - Air Cleaner Filter	314-8532

Original Part Number	Part Name	Classic Part Number
6L-6481	Elbow - Air Inlet	311-9385
6L-6491	Pipe - Cross-over	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7H-0602	Dog - Clutch	314-8515
7L-0104	Impeller - Pump	311-9395
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302

Sales Model G399

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1F-4419	Gasket - Cover	311-9393
1P-0009	Rod As - Conn	311-9450
1P-1758	Bushing - Stem	311-9350
1P-8005	Gasket - Chamber	314-8527
1S-5738	Insert - Seat Exhaust	311-9396
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2F-5721	Bearing - Ball	311-9354
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2W-3211	Valve - Exhaust	311-9471
3F-7445	Bearing - Sleeve	314-8508
3N-3368	Pipe - Exhaust	311-9434
3N-7326	Thrower - Camshaft Oil	311-9458
3N-7327	Thrower - Camshaft Oil	311-9459
3N-9160	Ring - Camshaft Seal	311-9447

Original Part Number	Part Name	Classic Part Number
3P-0651	Seal - o-Ring	314-8541
4F-4974	Clamp	311-9373
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440
4L-7820	Rod Assembly	311-9449
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5551	Core As - Oil Cooler	311-9378
5D-0470	Valve Gp	314-8549
5L-2648	Bearing - Sleeve	311-9362
5L-2660	Bearing - Sleeve	311-9363
5L-2894	Bearing - Sleeve	311-9364
5L-3980	V - Belt Set	314-8498
5L-8856	Coupling - Exhaust	311-9379
5L-9370	Elbow - Manifold Inlet	311-9388
5L-9371	Connector - Inlet	311-9375
5N-3050	Elbow - Outlet	311-9389
5N-4378	Shaft As - Pump	311-9456
5P-7807	Bearing - Ball	314-8502
5S-1757	Insert - Seat	311-9401
6H-3217	Shaft As - Rocker	311-9457

Original Part Number	Part Name	Classic Part Number
6L-4714	Panel - Air Cleaner Filter	314-8532
6L-6481	Elbow - Air Inlet	311-9385
6L-6491	Pipe - Cross-over	311-9433
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7L-0104	Impeller - Pump	311-9395
7M-4926	Retainer - Pin	314-8538
7M-7817	Valve - Inlet	311-9474
7N-9810	Pin - Piston	311-9432
7S-5787	Chamber As	247-3300
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8L-3972	Baffle	311-9345
8M-4014	Insert - Seat Exhaust	311-9398
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302

Cat® Classic™ Parts for Excavators

Cat® excavators are built to last; however, as the machine ages, the cost to repair the machine is often re-evaluated. This is why Caterpillar offers the Cat® Classic™ parts product line. They are intended to help you manage your owning and operating costs towards the end of a product's life cycle. Cat Classic parts are available for several older models of excavators.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for excavators includes:

- Engine
- Final Drive
- Linkage Pin
- Transmission Shafts/Gears
- Non-Moving U/C
- Pump Drive
- ...and many more.

Sales Model 215

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	172-7767	Pump Gp - Water	296-1365	1W-4405	Gear - Crankshaft	279-4982
104-4253	Line As - Fuel Injector	279-4988	190-8609	Valve - Fill	360-2288	1W-5912	Tappet As - Guide	325-6223
104-4254	Line As - Fuel Injector	279-4989	1M-7250	Bowl - Pre-cleaner	360-2296	1W-6541	Plunger As	325-6173
111-8015	Gasket As - Head	279-4977	1N-3576	Block Gp - Cylinder	279-4978	244-1090	Alarm - Backup	360-2345
112-3818	Shaft - Input	302-2698	1N-3958	Elbow	325-6087	2D-5658	Bearing - Ball	301-4628
112-5585	Shaft - Planet	308-9932	1N-4304	Head Gp - Cylinder	269-8761	2F-5721	Bearing - Ball	311-9354
112-8041	Carrier - Planet	295-5681	1P-1216	Manifold - Exhaust	261-0902	2K-3592	Boss	314-8501
115-7550	Gasket - Plate	314-8667	1P-1721	Gear - Balance	298-2769	2P-1170	Shaft As - Gear	296-1367
121-7746	Precleaner As	360-2311	1P-1722	Gear - Balance	298-2770	2P-1757	Hub - Fan Pulley	296-1357
131-3815	Seal Gp - Basic	325-6193	1P-9946	Shaft - Fan	325-6194	2P-1781	Spacer - Oil Pump	325-6214
148-7455	Valve - Exhaust	270-4361	1S-4701	Pulley - Alt	264-5866	2P-2519	Tube As - Inlet	325-6230
165-4262	Body As - Piston	270-4353 (Liner Kit)	1S-5331	Cylinder - Adjustable	226-0214	2P-6245	Shaft As - Pump	325-6197
172-5185	Shaft - Water Pump	325-6201	1V-6342	Gear As	308-9847	2P-7828	Pan - Oil	314-8691
172-5188	Shaft - Water Pump	325-6202	1W-1219	Trunnion As	314-8724	2V-0707	Bearing - Sleeve	360-2328
172-5189	Impeller - Pump	295-5687	1W-1669	Piston	325-6158	2V-0961	Driver	231-0255
172-5190	Impeller - Pump	325-6111	1W-1695	Pump Gp	279-4980	2W-1086	Cover As - Cylinder Head	325-6049
172-6712	Impeller - Pump	325-6112	1W-1698	Housing - Transfer Pump	296-1356	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
			1W-2870	Shaft As - Balance	314-8715	2W-7255	Shaft - Water Pump	325-6203
			1W-2871	Shaft As - Balance	314-8716	2W-7458	Crankshaft As	242-3439
			1W-4402	Gear - Camshaft	279-4981			



(Continued)

Sales Model 215 (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
2W-7678	Gear - Water Pump	325-6088
3L-1425	Bearing - Ball	311-9356
3T-2145	Carrier As	325-6041
3T-9153	Rim - Sprocket	322-6303
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-6648	Pin As	308-9884
3V-9439	Retainer As	231-0257
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Camshaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-9236	Plate - Pressure	231-0260
4V-9577	Shaft - Planet	231-0001
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
5C-0451	Gear Gp - Bearing	235-5053
5C-0949	Link As.	290-3452

Original Part Number	Part Name	Classic Part Number
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-4701	Gear	231-0231
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6A-7539	Sprocket - Track	322-6304
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3495	Sprocket - Track	322-6302
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422

Original Part Number	Part Name	Classic Part Number
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
6T-0511	Link As.	290-3449
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
6Y-2054	Plate As	302-2695
6Y-4819	Carrier - Planet	296-1348
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier - Planet	283-5205
7G-7724	Piston - Clutch	283-5206
7J-9708	Bearing - Sleeve	299-1964
7K-0252	Gear - Ring	231-0008
7K-7237	Gear - Planet	231-0009
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0061	Muffler As	360-7889
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7T-3370	Yoke As	302-2702

(Continued)

Sales Model 215 (Continued)

Original Part Number	Part Name	Classic Part Number
7T-5038	Housing As	297-7202
7T-9370	Gear - Sun	283-5207
7V-5981	Driver	231-0256
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Camshaft	314-8684
8E-3332	Shoe - Track	175-8184
8E-7494	Roller Gp - SF	175-8185
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0323	Link As.	290-3450
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-4699	Link As.	290-3451
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435

Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8P-0953	Turbine - Converter	297-7269
8P-1121	Ring - Clamp	299-2049
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-2646	Sprocket - Track	289-9674

Original Part Number	Part Name	Classic Part Number
9C-6244	Gear	231-0230
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-2413	Shaft - Output	297-7255
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9K-8757	Rod End - Bearing	311-9361
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9P-7757	Gear - Sun	283-5218
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-9031	Gear - Sun	283-5220
9P-9517	Stator - Converter	297-7262
9P-9610	Pump Gp	283-5221
9P-9790	Shaft - Output	302-2696
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9W-3605	Carrier - Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 215B

Excavators

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866

Original Part Number	Part Name	Classic Part Number
1S-5331	Cylinder - Adjustable	226-0214
1V-6342	Gear As	308-9847
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0961	Driver	231-0255
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678

Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3T-2145	Carrier As	325-6041
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-6648	Pin As	308-9884
3V-9439	Retainer As	231-0257
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003

(Continued)

Sales Model 215B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5C-3714	Gear	231-0222	6T-1706	Gear - Pump Drive	283-5202	7W-0450	Gear - Water Pump	279-4997
5C-3715	Gear	231-0223	6W-2398	Retainer	231-0014	7W-0507	Gear - Oil Pump Drive	279-4998
5C-3716	Gear	231-0224	6W-3674	Gear	231-0228	7W-0508	Gear - Fuel Pump Drive	296-1351
5C-3717	Gear	231-0225	6Y-2054	Plate As	302-2695	7W-3042	Tube As - Drain	325-6231
5C-3784	Pin As	241-2512	6Y-4819	Carrier - Planet	296-1348	7W-5687	Hub - Cam-shaft	314-8684
5C-5038	Pin As	241-2506	7C-3567	Mount As	314-8689	8H-2810	Case As - Filter	314-8512
5C-5153	Cartridge	231-0011	7G-2516	Gear - Planet	283-5203	8H-7980	Piston	226-0249
5C-5236	Gear	231-0226	7G-2830	Ring - Seal	295-6441	8K-0665	Cage - Bearing	231-0262
5C-5829	Pin As	241-2510	7G-5618	Manifold As	283-5204	8K-1749	Shaft - Sprocket	231-0242
5C-5837	Retainer - Pin	299-2047	7G-7218	Carrier - Planet	283-5205	8K-1754	Spacer	231-0247
5C-5937	Gear	231-0004	7G-7724	Piston - Clutch	283-5206	8K-1755	Retainer - Cap	231-0246
5C-6690	Pin As	241-2508	7J-9708	Bearing - Sleeve	299-1964	8K-1756	Cage - Bearing	231-0263
5C-8172	Pin As	241-2515	7M-1851	Bolt - Spring	226-0223	8K-2518	Joint As	231-0267
5C-8582	Shaft - Planet	231-0241	7M-1856	Pilot - Recoil Spring	226-0225	8K-2682	Adapter	231-0268
5C-8583	Gear - Ring	231-0005	7N-0061	Muffler As	360-7889	8M-6191	Sleeve - Bolt	226-0234
5C-8584	Gear - Planet	231-0006	7N-0128	Core As - Oil Cooler	299-1994	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
5C-8586	Gear	231-0007	7N-0165	Core As - Oil Cooler	295-5670	8N-1187	Head Gp - Cylinder	242-3435
5C-8587	Cover	231-0243	7N-1164	Mount As	295-5451	8N-1188	Head Gp - Cylinder	242-3436
5C-8966	Gear	231-0227	7N-2949	Pulley	264-5887	8N-1721	Rod As - Conn	269-5291
5J-6421	Bearing	256-4801	7N-3515	Gear - Cam-shaft	314-8669	8N-2510	Shaft	325-6208
5P-7807	Bearing - Ball	314-8502	7N-5910	Impeller - Pump	314-8686	8N-2641	Sleeve	325-6210
5P-8194	Ring - Retaining	308-9920	7N-9145	Gear - Fly-wheel	279-4994	8N-3251	Shaft As - Rocker Arm	314-8711
5S-4557	Bearing	311-9360	7N-9146	Gear - Fly-wheel Starter	279-4995	8N-3312	Shaft As - Rocker Arm	325-6200
5S-6795	Chamber As	242-3437	7N-9312	Damper As - Camshaft	299-2005	8N-3325	Arm Gp - Rocker	314-8623
5S-9080	Pulley - Alt Drive	264-5883	7N-9805	Pin - Piston	295-6438	8N-3327	Arm Gp - Rocker	314-8624
5V-7207	Pinion - Final Drive	231-0252	7S-3161	Lifter - Valve	279-4996	8N-5929	Cover - Water Pump	296-1349
5V-7222	Gear - Final Drive	231-0237	7S-6723	Bracket - Alternator	299-1978	8N-6796	Head Gp - Cylinder	269-5290
6A-7129	Bearing - Sleeve	301-3130	7S-7809	Cap As - Radiator	295-6417	8N-7315	Tube As - Outlet	325-6232
6A-7534	Retainer	231-0244	7T-3370	Yoke As	302-2702	8N-8225	Bearing - Main	314-8652
6C-0739	Carrier As	231-0012	7T-5038	Housing As	297-7202			
6C-1573	Rod	297-7238	7T-9370	Gear - Sun	283-5207			
6C-3740	Shaft As	231-0013	7V-5981	Driver	231-0256			
6C-5062	Pinion	231-0016	7V-7973	Gear Final Drive	231-0239			
6H-3957	Bearing - Ball	311-9358	7V-7974	Pinion Final Drive	231-0253			
6I-1346	Pump Gp - Oil	295-5674						
6N-1036	Gear - Oil Pump	279-4991						
6N-1553	Coupling - Exhaust	295-6422						
6N-3256	Mount As	314-8688						
6N-8413	Housing - Pump	325-6110						
6P-7704	Carrier - Ring	314-8658						
6T-1705	Shaft - Pump Drive	283-5201						

Excavators

(Continued)

Sales Model 215B (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
8P-0953	Turbine - Converter	297-7269
8P-1121	Ring - Clamp	299-2049
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230

Original Part Number	Part Name	Classic Part Number
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-2413	Shaft - Output	297-7255
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9P-7757	Gear - Sun	283-5218
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219

Original Part Number	Part Name	Classic Part Number
9P-9031	Gear - Sun	283-5220
9P-9517	Stator - Converter	297-7262
9P-9610	Pump Gp	283-5221
9P-9790	Shaft - Output	302-2696
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9W-3605	Carrier - Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 215C

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687

Original Part Number	Part Name	Classic Part Number
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980

Original Part Number	Part Name	Classic Part Number
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214

(Continued)

Sales Model 215C (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As - Inlet	325-6230	5C-5038	Pin As	241-2506	7V-5981	Driver	231-0256
2P-6245	Shaft As - Pump	325-6197	5C-5153	Cartridge	231-0011	7W-0450	Gear - Water Pump	279-4997
2P-7828	Pan - Oil	314-8691	5C-5236	Gear	231-0226	7W-0507	Gear - Oil Pump Drive	279-4998
2V-0707	Bearing - Sleeve	360-2328	5C-5829	Pin As	241-2510	7W-0508	Gear - Fuel Pump Drive	296-1351
2V-0961	Driver	231-0255	5C-5837	Retainer - Pin	299-2047	7W-3042	Tube As - Drain	325-6231
2V-1722	Pin As	241-2525	5C-5937	Gear	231-0004	7W-5687	Hub - Cam-shaft	314-8684
2W-1086	Cover As - Cylinder Head	325-6049	5C-6690	Pin As	241-2508	8G-4189	Bearing - Aligning	295-6411
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	5C-8172	Pin As	241-2515	8H-2810	Case As - Filter	314-8512
2W-7255	Shaft - Water Pump	325-6203	5C-8582	Shaft - Planet	231-0241	8K-0665	Cage - Bearing	231-0262
2W-7458	Crankshaft As	242-3439	5C-8583	Gear - Ring	231-0005	8K-2518	Joint As	231-0267
3L-1425	Bearing - Ball	311-9356	5C-8584	Gear - Planet	231-0006	8K-2682	Adapter	231-0268
4E-1065	Pin As	241-2538	5C-8586	Gear	231-0007	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
4E-9426	Collar	231-0000	5C-8587	Cover	231-0243	8N-1187	Head Gp - Cylinder	242-3435
4F-4974	Clamp	311-9373	5C-8966	Gear	231-0227	8N-1188	Head Gp - Cylinder	242-3436
4N-4539	Sleeve	314-8720	5J-6421	Bearing	256-4801	8N-1721	Rod As - Conn	269-5291
4N-7692	Crankshaft As	242-3440	5P-7807	Bearing - Ball	314-8502	8N-2510	Shaft	325-6208
4N-7693	Crankshaft As	242-3439	5S-6795	Chamber As	242-3437	8N-2641	Sleeve	325-6210
4P-3546	Valve As - Relief	325-6236	5S-9080	Pulley - Alt Drive	264-5883	8N-3251	Shaft As - Rocker Arm	314-8711
4P-4010	Muffler As	298-2788	6A-7129	Bearing - Sleeve	301-3130	8N-3312	Shaft As - Rocker Arm	325-6200
4P-9381	Line As - Fuel Injector	279-4984	6A-7534	Retainer	231-0244	8N-3325	Arm Gp - Rocker	314-8623
4P-9382	Line As - Fuel Injector	279-4985	6C-0739	Carrier As	231-0012	8N-3327	Arm Gp - Rocker	314-8624
4P-9961	Line As - Fuel Injector	325-6115	6C-1573	Rod	297-7238	8N-5929	Cover - Water Pump	296-1349
4P-9962	Line As - Fuel Injector	325-6116	6C-3740	Shaft As	231-0013	8N-6796	Head Gp - Cylinder	269-5290
4P-9963	Line As - Fuel Injector	298-2777	6C-5062	Pinion	231-0016	8N-7315	Tube As - Outlet	325-6232
4P-9964	Line As - Fuel Injector	298-2778	6H-3957	Bearing - Ball	311-9358	8N-8225	Bearing - Main	314-8652
4T-5172	Seal As	325-6189	6I-1346	Pump Gp - Oil	295-5674	8R-7336	Bearing	301-3394
4W-0452	Seal As - Camshaft	325-6191	6N-1036	Gear - Oil Pump	279-4991	8S-0493	Shaft As - Pump	325-6198
5C-0451	Gear Gp - Bearing	235-5053	6N-1553	Coupling - Exhaust	295-6422	8S-3970	Chamber As	242-3438
5C-1834	Gear	231-0002	6N-3256	Mount As	314-8688	9C-1618	Gear	231-0229
5C-3712	Gear	231-0003	6N-8413	Housing - Pump	325-6110	9C-6244	Gear	231-0230
5C-3714	Gear	231-0222	6W-2398	Retainer	231-0014			
5C-3715	Gear	231-0223	6W-3674	Gear	231-0228			
5C-3716	Gear	231-0224	7C-3567	Mount As	314-8689			
5C-3717	Gear	231-0225	7N-0165	Core As - Oil Cooler	295-5670			
5C-3784	Pin As	241-2512	7N-1164	Mount As	295-5451			
			7N-2949	Pulley	264-5887			
			7N-5910	Impeller - Pump	314-8686			
			7N-9145	Gear - Fly-wheel	279-4994			
			7N-9805	Pin - Piston	295-6438			
			7S-3161	Lifter - Valve	279-4996			
			7S-6723	Bracket - Alternator	299-1978			

(Continued)

Sales Model 215C (Continued)

Original Part Number	Part Name	Classic Part Number
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050

Original Part Number	Part Name	Classic Part Number
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Original Part Number	Part Name	Classic Part Number
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 215D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769

Original Part Number	Part Name	Classic Part Number
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049

Original Part Number	Part Name	Classic Part Number
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
4E-0183	Pin	301-7976
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4W-0452	Seal As - Camshaft	325-6191
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512

(Continued)

Sales Model 215D (Continued)

Original Part Number	Part Name	Classic Part Number
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228

Original Part Number	Part Name	Classic Part Number
7C-3567	Mount As	314-8689
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5981	Driver	231-0256
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Cam-shaft	314-8684
8G-4189	Bearing - Aligning	295-6411
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435

Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Excavators

Sales Model 219

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193

Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202

(Continued)

Sales Model 219 (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214

Original Part Number	Part Name	Classic Part Number
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9025	Link As.	289-4946
3V-9439	Retainer As	231-0257
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-9236	Plate - Pressure	231-0260

Original Part Number	Part Name	Classic Part Number
4W-0452	Seal As - Camshaft	325-6191
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6W-2398	Retainer	231-0014

(Continued)

Sales Model 219 (Continued)

Original Part Number	Part Name	Classic Part Number
6W-3674	Gear	231-0228
6Y-8184	Link As.	289-4948
7C-3567	Mount As	314-8689
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5981	Driver	231-0256
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231

Original Part Number	Part Name	Classic Part Number
7W-5687	Hub - Cam-shaft	314-8684
8G-4189	Bearing - Aligning	295-6411
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210

Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Excavators

Sales Model 219D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193

Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112

Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp - Water	296-1365
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770

(Continued)

Sales Model 219D (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9439	Retainer As	231-0257
4E-0183	Pin	301-7976
4E-1065	Pin As	241-2538
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-0451	Gear Gp - Bearing	235-5053
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8172	Pin As	241-2515
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006

Original Part Number	Part Name	Classic Part Number
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5J-6421	Bearing	256-4801
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6W-2398	Retainer	231-0014
6W-3674	Gear	231-0228
7C-3567	Mount As	314-8689
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5981	Driver	231-0256
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253

(Continued)

Sales Model 219D (Continued)

Original Part Number	Part Name	Classic Part Number
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Cam-shaft	314-8684
8G-4189	Bearing - Aligning	295-6411
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263

Original Part Number	Part Name	Classic Part Number
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624

Original Part Number	Part Name	Classic Part Number
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8R-7336	Bearing	301-3394
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9C-1618	Gear	231-0229
9C-6244	Gear	231-0230
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-2400	Housing As	231-0249
9Y-2992	Bearing - Sleeve	325-6032

Excavators

Sales Model 225

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202

Original Part Number	Part Name	Classic Part Number
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769

Original Part Number	Part Name	Classic Part Number
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1P-9952	Impeller - Pump	314-8685
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716

(Continued)

Sales Model 225 (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1W-4402	Gear - Camshaft	279-4981	3V-4622	Bracket - Carriage Roller	297-7148	4V-9236	Plate - Pressure	231-0260
1W-4405	Gear - Crankshaft	279-4982	3V-4874	Pin	241-2544	4W-0452	Seal As - Camshaft	325-6191
1W-5912	Tappet As - Guide	325-6223	3V-5148	Pinion - Swing Gr	231-0251	5C-1834	Gear	231-0002
1W-6541	Plunger As	325-6173	3V-5257	Bracket - Carriage Roller	297-7149	5C-5937	Gear	231-0004
244-1090	Alarm - Backup	360-2345	3V-5317	Gear	231-0010	5C-8582	Shaft - Planet	231-0241
246-5228	Rim	289-2207	3V-5378	Gear - Output	231-0235	5C-8583	Gear - Ring	231-0005
2D-5658	Bearing - Ball	301-4628	3V-8927	Pin	241-2545	5C-8584	Gear - Planet	231-0006
2F-5721	Bearing - Ball	311-9354	3V-9025	Link As.	289-4946	5C-8586	Gear	231-0007
2K-3592	Boss	314-8501	3V-9281	Bearing	314-8631	5C-8587	Cover	231-0243
2K-6413	Pin	360-2270	3V-9285	Pin	241-2546	5C-8966	Gear	231-0227
2P-1170	Shaft As - Gear	296-1367	3V-9439	Retainer As	231-0257	5P-7807	Bearing - Ball	314-8502
2P-1757	Hub - Fan Pulley	296-1357	4E-9426	Collar	231-0000	5S-6795	Chamber As	242-3437
2P-1781	Spacer - Oil Pump	325-6214	4F-4974	Clamp	311-9373	5S-9080	Pulley - Alt Drive	264-5883
2P-2519	Tube As - Inlet	325-6230	4N-2954	Sleeve - Camshaft	299-2059	5V-4969	Sprocket - Track	289-2205
2P-6245	Shaft As - Pump	325-6197	4N-3281	Line As - Fuel Injector	247-3362	5V-7207	Pinion - Final Drive	231-0252
2P-7828	Pan - Oil	314-8691	4N-3282	Line As - Fuel Injector	247-3363	5V-7214	Pin As	241-2522
2V-0705	Pin As	241-2524	4N-3283	Line As - Fuel Injector	247-3364	5V-7222	Gear - Final Drive	231-0237
2V-0707	Bearing - Sleeve	360-2328	4N-3284	Line As - Fuel Injector	247-3365	6A-7534	Retainer	231-0244
2V-0812	Pinion - Final Drive	231-0250	4N-4539	Sleeve	314-8720	6C-0739	Carrier As	231-0012
2V-0813	Gear - Sec Cluster	231-0232	4N-4782	Pulley	325-6176	6H-3957	Bearing - Ball	311-9358
2V-0814	Gear - Output	231-0233	4N-7692	Crankshaft As	242-3440	6I-1346	Pump Gp - Oil	295-5674
2V-0816	Pinion - Swing Drive	231-0017	4N-7693	Crankshaft As	242-3439	6N-1036	Gear - Oil Pump	279-4991
2V-0817	Gear - Cluster	231-0234	4N-7977	Shaft As - Balance	314-8709	6N-1553	Coupling - Exhaust	295-6422
2V-0961	Driver	231-0255	4N-7978	Shaft As - Balance	314-8710	6N-3256	Mount As	314-8688
2V-1722	Pin As	241-2525	4N-9587	Shield - Heat	297-7260	6N-3964	Muffler As	360-7884
2W-1086	Cover As - Cylinder Head	325-6049	4P-3546	Valve As - Relief	325-6236	6N-8413	Housing - Pump	325-6110
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4P-9381	Line As - Fuel Injector	279-4984	6W-2451	Sprocket - Track	322-6376
2W-7255	Shaft - Water Pump	325-6203	4P-9382	Line As - Fuel Injector	279-4985	6Y-8184	Link As.	289-4948
2W-7458	Crankshaft As	242-3439	4P-9961	Line As - Fuel Injector	325-6115	7C-4297	Seal As - Camshaft	325-6192
2Y-4213	Pulley	314-8703	4P-9962	Line As - Fuel Injector	325-6116	7E-5663	Muffler As	247-2667
3L-1425	Bearing - Ball	311-9356	4P-9963	Line As - Fuel Injector	298-2777	7M-1851	Bolt - Spring	226-0223
3T-9152	Rim - Sprocket	322-6377	4P-9964	Line As - Fuel Injector	298-2778	7M-1856	Pilot - Recoil Spring	226-0225
3V-1133	Strip	226-0203	4V-5608	Pin As	241-2529	7N-0128	Core As - Oil Cooler	299-1994
						7N-0165	Core As - Oil Cooler	295-5670
						7N-1164	Mount As	295-5451
						7N-2871	Line As - Fuel Injector	319-8172

(Continued)

Sales Model 225 (Continued)

Original Part Number	Part Name	Classic Part Number
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7T-2036	Cap As - Filter	361-1721
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Cam-shaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0393	Pin	241-2548
8K-0442	Gear	231-0240
8K-0455	Pin	241-2547
8K-0518	Pin	241-2549
8K-0533	Bearing - Sleeve	314-8637
8K-0576	Cage - Bearing	231-0261

Original Part Number	Part Name	Classic Part Number
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-1317	Shaft	231-0019
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-2743	Sprocket - Track	289-2206
8K-2779	Cage - Bearing	231-0483
8K-2956	Pin	241-2550
8K-4127	Gear Gp - Bearing & Basic	235-5055
8M-6191	Sleeve - Bolt	226-0234
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210

Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-3187	Pin As	314-8694
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-5060	Link As - Bearing	299-2022
9C-6187	Pin As	241-2521
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 225B

Excavators

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724

Original Part Number	Part Name	Classic Part Number
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0705	Pin As	241-2524
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing - Ball	311-9356
3V-4874	Pin	241-2544
3V-5148	Pinion - Swing Gr	231-0251
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-8927	Pin	241-2545
3V-9281	Bearing	314-8631
3V-9285	Pin	241-2546
3V-9439	Retainer As	231-0257
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Cam-shaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-1834	Gear	231-0002
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243

(Continued)

Sales Model 225B (Continued)

Original Part Number	Part Name	Classic Part Number
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522
5V-7222	Gear - Final Drive	231-0237
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6C-0739	Carrier As	231-0012
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7E-5663	Muffler As	247-2667
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254

Original Part Number	Part Name	Classic Part Number
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7W-5687	Hub - Cam-shaft	314-8684
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8K-0442	Gear	231-0240
8K-0533	Bearing - Sleeve	314-8637
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-2779	Cage - Bearing	231-0483
8K-3712	Pin As	241-2541
8K-4127	Gear Gp - Bearing & Basic	235-5055
8M-6191	Sleeve - Bolt	226-0234
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
9C-3187	Pin As	314-8694
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-4912	Pin As	241-2517
9C-5060	Link As - Bearing	299-2022
9C-6187	Pin As	241-2521
9K-8425	Bearing - Sleeve	314-8638
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 225D

Excavators

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158

Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3V-5148	Pinion - Swing Gr	231-0251
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-9439	Retainer As	231-0257
4E-0183	Pin	301-7976
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Cam-shaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-5172	Seal As	325-6189
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-1834	Gear	231-0002
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437

(Continued)

Sales Model 225D (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5S-9080	Pulley - Alt Drive	264-5883	7W-0450	Gear - Water Pump	279-4997	8N-1187	Head Gp - Cylinder	242-3435
5V-7207	Pinion - Final Drive	231-0252	7W-0507	Gear - Oil Pump Drive	279-4998	8N-1188	Head Gp - Cylinder	242-3436
5V-7222	Gear - Final Drive	231-0237	7W-0508	Gear - Fuel Pump Drive	296-1351	8N-1721	Rod As - Conn	269-5291
6A-7129	Bearing - Sleeve	301-3130	7W-3042	Tube As - Drain	325-6231	8N-2510	Shaft	325-6208
6A-7534	Retainer	231-0244	7W-5687	Hub - Cam-shaft	314-8684	8N-2641	Sleeve	325-6210
6C-0739	Carrier As	231-0012	8H-2810	Case As - Filter	314-8512	8N-3251	Shaft As - Rocker Arm	314-8711
6H-3957	Bearing - Ball	311-9358	8H-7980	Piston	226-0249	8N-3312	Shaft As - Rocker Arm	325-6200
6I-1346	Pump Gp - Oil	295-5674	8K-0442	Gear	231-0240	8N-3325	Arm Gp - Rocker	314-8623
6N-1036	Gear - Oil Pump	279-4991	8K-0576	Cage - Bearing	231-0261	8N-3327	Arm Gp - Rocker	314-8624
6N-1553	Coupling - Exhaust	295-6422	8K-0578	Spacer	231-0248	8N-5929	Cover - Water Pump	296-1349
6N-3256	Mount As	314-8688	8K-0579	Retainer	231-0245	8N-6796	Head Gp - Cylinder	269-5290
6N-8413	Housing - Pump	325-6110	8K-0665	Cage - Bearing	231-0262	8N-7315	Tube As - Outlet	325-6232
7E-5663	Muffler As	247-2667	8K-1749	Shaft - Sprocket	231-0242	8N-8225	Bearing - Main	314-8652
7M-1851	Bolt - Spring	226-0223	8K-1754	Spacer	231-0247	8R-7336	Bearing	301-3394
7M-1856	Pilot - Recoil Spring	226-0225	8K-1755	Retainer - Cap	231-0246	8S-0248	Breather As	325-6033
7N-0165	Core As - Oil Cooler	295-5670	8K-1756	Cage - Bearing	231-0263	8S-0493	Shaft As - Pump	325-6198
7N-1164	Mount As	295-5451	8K-1940	Retainer As	231-0258	8S-3970	Chamber As	242-3438
7N-2949	Pulley	264-5887	8K-1944	Case As - Swing Drive	231-0265	8V-2631	Pin As	241-2526
7N-5910	Impeller - Pump	314-8686	8K-1945	Shaft As - Output	231-0266	8V-2632	Pin As	241-2523
7N-9145	Gear - Fly-wheel	279-4994	8K-1946	Retainer As	231-0259	8V-2634	Pin As	241-2518
7N-9805	Pin - Piston	295-6438	8K-2518	Joint As	231-0267	9C-3187	Pin As	314-8694
7S-3161	Lifter - Valve	279-4996	8K-2779	Cage - Bearing	231-0483	9C-4211	Pin As	241-2519
7S-6723	Bracket - Alternator	299-1978	8K-3712	Pin As	241-2541	9C-4737	Pin As	241-2520
7T-2036	Cap As - Filter	361-1721	8K-4127	Gear Gp - Bearing & Basic	235-5055	9C-5060	Link As - Bearing	299-2022
7V-5979	Gear	231-0238	8M-6191	Sleeve - Bolt	226-0234	9C-6187	Pin As	241-2521
7V-5981	Driver	231-0256	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	9K-8757	Rod End - Bearing	311-9361
7V-7017	Pinion Swing	231-0018				9N-5769	Cover - Housing	325-6050
7V-7973	Gear Final Drive	231-0239				9S-6129	Pulley - Alternator Drive	264-5891
7V-7974	Pinion Final Drive	231-0253				9S-8679	Chamber As	325-6042
7V-7976	Pinion - Swing Drive	231-0254				9Y-2992	Bearing - Sleeve	325-6032

Sales Model 229

Excavators

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-8554	Coupling - Exhaust	325-6052
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1V-9148	Bearing - Sleeve	308-9811

Original Part Number	Part Name	Classic Part Number
1W-1219	Trunnion As	314-8724
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0705	Pin As	241-2524
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-0961	Driver	231-0255
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3V-4874	Pin	241-2544
3V-5148	Pinion - Swing Gr	231-0251

Original Part Number	Part Name	Classic Part Number
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-8927	Pin	241-2545
3V-9281	Bearing	314-8631
3V-9285	Pin	241-2546
3V-9439	Retainer As	231-0257
4E-9426	Collar	231-0000
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Cam-shaft	299-2059
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-5608	Pin As	241-2529
4V-9236	Plate - Pressure	231-0260
4W-0452	Seal As - Camshaft	325-6191
5C-1834	Gear	231-0002
5C-5937	Gear	231-0004
5C-8582	Shaft - Planet	231-0241
5C-8583	Gear - Ring	231-0005
5C-8584	Gear - Planet	231-0006
5C-8586	Gear	231-0007
5C-8587	Cover	231-0243
5C-8966	Gear	231-0227
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522

(Continued)

Sales Model 229 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5V-7222	Gear - Final Drive	231-0237	7W-3042	Tube As - Drain	325-6231	8N-1188	Head Gp - Cylinder	242-3436
6A-7534	Retainer	231-0244	7W-5687	Hub - Cam-shaft	314-8684	8N-1721	Rod As - Conn	269-5291
6C-0739	Carrier As	231-0012	8E-4576	Roller Gp - SF	288-3690	8N-2510	Shaft	325-6208
6H-3957	Bearing - Ball	311-9358	8E-4713	Link As.	288-3705	8N-3251	Shaft As - Rocker Arm	314-8711
6I-1346	Pump Gp - Oil	295-5674	8E-4714	Link As.	288-3693	8N-3312	Shaft As - Rocker Arm	325-6200
6N-1036	Gear - Oil Pump	279-4991	8H-2810	Case As - Filter	314-8512	8N-3325	Arm Gp - Rocker	314-8623
6N-1553	Coupling - Exhaust	295-6422	8H-7980	Piston	226-0249	8N-3327	Arm Gp - Rocker	314-8624
6N-3256	Mount As	314-8688	8K-0442	Gear	231-0240	8N-5929	Cover - Water Pump	296-1349
6N-8413	Housing - Pump	325-6110	8K-0533	Bearing - Sleeve	314-8637	8N-6796	Head Gp - Cylinder	269-5290
7E-5663	Muffler As	247-2667	8K-0576	Cage - Bearing	231-0261	8N-7315	Tube As - Outlet	325-6232
7M-1851	Bolt - Spring	226-0223	8K-0578	Spacer	231-0248	8N-8225	Bearing - Main	314-8652
7M-1856	Pilot - Recoil Spring	226-0225	8K-0579	Retainer	231-0245	8P-5197	Bearing As	295-6413
7N-0165	Core As - Oil Cooler	295-5670	8K-0665	Cage - Bearing	231-0262	8S-0248	Breather As	325-6033
7N-1164	Mount As	295-5451	8K-1749	Shaft - Sprocket	231-0242	8S-0493	Shaft As - Pump	325-6198
7N-2949	Pulley	264-5887	8K-1754	Spacer	231-0247	8S-3970	Chamber As	242-3438
7N-5910	Impeller - Pump	314-8686	8K-1755	Retainer - Cap	231-0246	8V-2631	Pin As	241-2526
7N-9145	Gear - Fly-wheel	279-4994	8K-1756	Cage - Bearing	231-0263	8V-2632	Pin As	241-2523
7N-9805	Pin - Piston	295-6438	8K-1940	Retainer As	231-0258	8V-2634	Pin As	241-2518
7S-3161	Lifter - Valve	279-4996	8K-1944	Case As - Swing Drive	231-0265	9C-3187	Pin As	314-8694
7S-6723	Bracket - Alternator	299-1978	8K-1945	Shaft As - Output	231-0266	9C-4211	Pin As	241-2519
7V-5979	Gear	231-0238	8K-1946	Retainer As	231-0259	9C-4737	Pin As	241-2520
7V-5981	Driver	231-0256	8K-2518	Joint As	231-0267	9C-4912	Pin As	241-2517
7V-7017	Pinion Swing	231-0018	8K-2779	Cage - Bearing	231-0483	9C-5060	Link As - Bearing	299-2022
7V-7973	Gear Final Drive	231-0239	8K-4127	Gear Gp - Bearing & Basic	235-5055	9C-6187	Pin As	241-2521
7V-7974	Pinion Final Drive	231-0253	8M-6191	Sleeve - Bolt	226-0234	9K-8425	Bearing - Sleeve	314-8638
7V-7976	Pinion - Swing Drive	231-0254	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	9K-8757	Rod End - Bearing	311-9361
7W-0450	Gear - Water Pump	279-4997	8N-1187	Head Gp - Cylinder	242-3435	9N-5769	Cover - Housing	325-6050
7W-0507	Gear - Oil Pump Drive	279-4998				9S-6129	Pulley - Alternator Drive	264-5891
7W-0508	Gear - Fuel Pump Drive	296-1351				9S-8679	Chamber As	325-6042
						9U-0654	Coupling	297-7167
						9Y-2992	Bearing - Sleeve	325-6032

Sales Model 229D

Excavators

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980

Original Part Number	Part Name	Classic Part Number
1W-1698	Housing - Transfer Pump	296-1356
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2V-0707	Bearing - Sleeve	360-2328
2V-0814	Gear - Output	231-0233
2V-0816	Pinion - Swing Drive	231-0017
2V-0817	Gear - Cluster	231-0234
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
4F-4974	Clamp	311-9373
4N-4539	Sleeve	314-8720
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439

Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4W-0452	Seal As - Camshaft	325-6191
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2949	Pulley	264-5887
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7T-2036	Cap As - Filter	361-1721
7V-7017	Pinion Swing	231-0018
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351

(Continued)

Sales Model 229D (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7W-3042	Tube As - Drain	325-6231	8N-1188	Head Gp - Cylinder	242-3436	8P-5197	Bearing As	295-6413
7W-5687	Hub - Cam-shaft	314-8684	8N-1721	Rod As - Conn	269-5291	8S-0248	Breather As	325-6033
8H-2810	Case As - Filter	314-8512	8N-2510	Shaft	325-6208	8S-0493	Shaft As - Pump	325-6198
8K-0576	Cage - Bearing	231-0261	8N-2641	Sleeve	325-6210	8S-3970	Chamber As	242-3438
8K-0578	Spacer	231-0248	8N-3251	Shaft As - Rocker Arm	314-8711	8V-2632	Pin As	241-2523
8K-0579	Retainer	231-0245	8N-3312	Shaft As - Rocker Arm	325-6200	8V-2634	Pin As	241-2518
8K-0665	Cage - Bearing	231-0262	8N-3325	Arm Gp - Rocker	314-8623	9C-3187	Pin As	314-8694
8K-1940	Retainer As	231-0258	8N-3327	Arm Gp - Rocker	314-8624	9C-4211	Pin As	241-2519
8K-1944	Case As - Swing Drive	231-0265	8N-5929	Cover - Water Pump	296-1349	9C-4737	Pin As	241-2520
8K-1946	Retainer As	231-0259	8N-6796	Head Gp - Cylinder	269-5290	9C-5060	Link As - Bearing	299-2022
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8N-7315	Tube As - Outlet	325-6232	9K-8757	Rod End - Bearing	311-9361
8N-1187	Head Gp - Cylinder	242-3435	8N-8225	Bearing - Main	314-8652	9N-5769	Cover - Housing	325-6050
						9S-6129	Pulley - Alternator Drive	264-5891
						9S-8679	Chamber As	325-6042
						9U-0654	Coupling	297-7167
						9Y-2992	Bearing - Sleeve	325-6032

Sales Model 231D

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723	2V-1722	Pin As	241-2525	5S-9080	Pulley - Alt Drive	264-5883
115-6427	Spring	301-4776	3V-4622	Bracket - Carriage Roller	297-7148	5V-7207	Pinion - Final Drive	231-0252
115-6429	Cylinder	301-4679	3V-5317	Gear	231-0010	5V-7222	Gear - Final Drive	231-0237
121-7746	Precleaner As	360-2311	3V-5378	Gear - Output	231-0235	6A-7534	Retainer	231-0244
122-5076	Rod	301-4569	3V-9439	Retainer As	231-0257	6C-0739	Carrier As	231-0012
122-5077	Cylinder	301-4673	4E-1035	Pin	241-2553	6C-1573	Rod	297-7238
122-5178	Piston As	301-5252	4E-9426	Collar	231-0000	6N-3256	Mount As	314-8688
131-3815	Seal Gp - Basic	325-6193	4F-4974	Clamp	311-9373	7E-5663	Muffler As	247-2667
190-8609	Valve - Fill	360-2288	4N-2954	Sleeve - Cam-shaft	299-2059	7T-2036	Cap As - Filter	361-1721
1M-7250	Bowl - Pre-cleaner	360-2296	4N-4539	Sleeve	314-8720	7V-7017	Pinion Swing	231-0018
1P-8554	Coupling - Exhaust	325-6052	4V-9236	Plate - Pressure	231-0260	7V-7973	Gear Final Drive	231-0239
1S-2268	Piston	226-2726	5C-1834	Gear	231-0002	7V-7974	Pinion Final Drive	231-0253
1S-4701	Pulley - Alt	264-5866	5C-5937	Gear	231-0004	7V-7976	Pinion - Swing Drive	231-0254
244-1090	Alarm - Back up	360-2345	5C-8582	Shaft - Planet	231-0241	7Y-0223	Shaft - Planet	301-4625
2D-5658	Bearing - Ball	301-4628	5C-8583	Gear - Ring	231-0005	7Y-0225	Shaft - Planet	301-4571
2F-5721	Bearing - Ball	311-9354	5C-8584	Gear - Planet	231-0006	7Y-1427	Gear - Sun	288-8727
2V-0814	Gear - Output	231-0233	5C-8586	Gear	231-0007	7Y-1428	Gear - Planet	288-8728
2V-0816	Pinion - Swing Drive	231-0017	5C-8587	Cover	231-0243	7Y-1430	Gear - Sun	314-8671
2V-0817	Gear - Cluster	231-0234	5C-8966	Gear	231-0227	7Y-1431	Gear - Planet	288-8729
			5P-7807	Bearing - Ball	314-8502			

(Continued)

Sales Model 231D (Continued)

Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier	314-8659
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1749	Shaft - Sprocket	231-0242

Original Part Number	Part Name	Classic Part Number
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265
8K-1946	Retainer As	231-0259

Original Part Number	Part Name	Classic Part Number
8K-3712	Pin As	241-2541
8P-5197	Bearing As	295-6413
8V-2631	Pin As	241-2526
9C-3187	Pin As	314-8694
9K-8425	Bearing - Sleeve	314-8638
9K-8430	Pin As	241-2540
9K-8757	Rod End - Bearing	311-9361
9U-0654	Coupling	297-7167

Sales Model 235

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1N-3576	Block Gp - Cylinder	279-4978

Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1P-0963	Guard As - Roller	226-0179
1P-9952	Impeller - Pump	314-8685
1Q-4983	Shoe - Track	289-5117
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1V-0557	Shoe - Track	288-6678
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
244-1090	Alarm - Back up	360-2345
248-2041	Rim	289-2211
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367

Original Part Number	Part Name	Classic Part Number
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2V-0705	Pin As	241-2524
2V-1722	Pin As	241-2525
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-3428	Muffler As	298-2784
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3L-1425	Bearing - Ball	311-9356
3N-6815	Shoe - Track	288-6681
3Q-5391	Shoe - Track	292-5634
3V-1133	Strip	226-0203
3V-4527	Sprocket - Track	289-2209
3V-4622	Bracket - Carriage Roller	297-7148

(Continued)

Sales Model 235 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
3V-5317	Gear	231-0010	5C-8586	Gear	231-0007	7N-3515	Gear - Camshaft	314-8669
3V-5378	Gear - Output	231-0235	5C-8587	Cover	231-0243	7N-3536	Gear - Fuel	279-4993
3V-9439	Retainer As	231-0257	5C-8966	Gear	231-0227	7N-5910	Impeller - Pump	314-8686
3Y-9984	Manifold - Exhaust	325-6123	5P-7807	Bearing - Ball	314-8502	7N-9146	Gear - Fly-wheel Starter	279-4995
3Y-9985	Manifold - Exhaust	325-6124	5S-4557	Bearing	311-9360	7N-9312	Damper As - Camshaft	299-2005
4E-1035	Pin	241-2553	5S-6795	Chamber As	242-3437	7N-9805	Pin - Piston	295-6438
4E-1065	Pin As	241-2538	5S-9080	Pulley - Alt Drive	264-5883	7S-3161	Lifter - Valve	279-4996
4E-1285	Link As	299-2021	5V-7207	Pinion - Final Drive	231-0252	7S-6723	Bracket - Alternator	299-1978
4E-8500	Idler Gp -Track	288-3691	5V-7214	Pin As	241-2522	7S-7809	Cap As - Radiator	295-6417
4E-9426	Collar	231-0000	5V-7222	Gear - Final Drive	231-0237	7T-2036	Cap As - Filter	361-1721
4N-2954	Sleeve - Camshaft	299-2059	6A-7534	Retainer	231-0244	7V-6898	Pin As	241-2539
4N-3281	Line As - Fuel Injector	247-3362	6C-0739	Carrier As	231-0012	7V-7973	Gear Final Drive	231-0239
4N-3282	Line As - Fuel Injector	247-3363	6H-3957	Bearing - Ball	311-9358	7V-7974	Pinion Final Drive	231-0253
4N-3283	Line As - Fuel Injector	247-3364	6I-1346	Pump Gp - Oil	295-5674	7W-0450	Gear - Water Pump	279-4997
4N-3284	Line As - Fuel Injector	247-3365	6N-1036	Gear - Oil Pump	279-4991	7W-0507	Gear - Oil Pump Drive	279-4998
4N-4539	Sleeve	314-8720	6N-1965	Line As - Fuel Injector	250-7535	7W-0508	Gear - Fuel Pump Drive	296-1351
4N-4782	Pulley	325-6176	6N-1966	Line As - Fuel Injector	250-7536	7W-5687	Hub - Camshaft	314-8684
4N-7693	Crankshaft As	242-3439	6N-3256	Mount As	314-8688	7Y-1517	Pipe As - Tail	301-5246
4N-8591	Coupling - Exhaust	325-6053	6N-8413	Housing - Pump	325-6110	8E-4275	Link As.	288-3694
4N-8814	Line As - Fuel Injector	247-3366	6Y-2192	Shoe - Track	288-6668	8E-4426	Shoe -Track	288-6671
4N-9587	Shield - Heat	297-7260	6Y-6405	Shoe - Track	290-9938	8E-4427	Shoe -Track	288-6670
4P-3546	Valve As - Relief	325-6236	6Y-6407	Shoe - Track	288-6679	8E-4428	Shoe -Track	288-6669
4P-9381	Line As - Fuel Injector	279-4984	7C-4297	Seal As - Camshaft	325-6192	8E-4429	Shoe - Track	288-6677
4P-9382	Line As - Fuel Injector	279-4985	7N-0110	Core As - Oil Cooler	319-3435	8E-4430	Shoe - Track	288-6676
4P-9385	Line As - Fuel Injector	279-4986	7N-0128	Core As - Oil Cooler	299-1994	8E-4579	Roller Gp - SF	175-8216
4P-9386	Line As - Fuel Injector	279-4987	7N-0165	Core As - Oil Cooler	295-5670	8E-6135	Idler Gp -Track	288-3691
4V-5608	Pin As	241-2529	7N-1164	Mount As	295-5451	8E-7868	Shoe - Track	290-9940
4V-9236	Plate - Pressure	231-0260	7N-2871	Line As - Fuel Injector	319-8172	8E-8643	Link As.	288-5754
4W-0452	Seal As - Camshaft	325-6191	7N-2872	Line As - Fuel Injector	319-8173	8E-8644	Link As.	288-5755
4W-2446	Damper As	279-4990	7N-2874	Line As - Fuel Injector	298-2779	8H-2810	Case As - Filter	314-8512
5C-1834	Gear	231-0002	7N-2875	Line As - Fuel Injector	298-2780	8K-0665	Cage - Bearing	231-0262
5C-5937	Gear	231-0004	7N-2876	Line As - Fuel Injector	298-2781	8K-1749	Shaft - Sprocket	231-0242
5C-8582	Shaft - Planet	231-0241	7N-2949	Pulley	264-5887	8K-1754	Spacer	231-0247
5C-8583	Gear - Ring	231-0005	7N-3486	Manifold - Exhaust	261-0899	8K-1755	Retainer - Cap	231-0246
5C-8584	Gear - Planet	231-0006						

(Continued)

Sales Model 235 (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
8K-1756	Cage - Bearing	231-0263
8K-2860	Flange - Coupling	297-7171
8K-3712	Pin As	241-2541
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711

Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-5197	Bearing As	295-6413
8R-3787	Shaft	299-2058
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-5439	Pin As	241-2531

Original Part Number	Part Name	Classic Part Number
9K-3565	Shoe - Track	290-9941
9K-3568	Shoe - Track	290-9942
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8428	Pin As	241-2533
9K-8430	Pin As	241-2540
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167
9W-6483	Shoe - Track	288-6672, 288-6673

Sales Model 235B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201

Original Part Number	Part Name	Classic Part Number
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1W-1669	Piston	325-6158

Original Part Number	Part Name	Classic Part Number
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501

(Continued)

Sales Model 235B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270	4N-4539	Sleeve	314-8720	7N-2872	Line As - Fuel Injector	319-8173
2P-1170	Shaft As - Gear	296-1367	4N-4782	Pulley	325-6176	7N-2874	Line As - Fuel Injector	298-2779
2P-1438	Pipe - Exhaust Ext	325-6157	4N-7693	Crankshaft As	242-3439	7N-2875	Line As - Fuel Injector	298-2780
2P-1738	Plate As - Oil Pan	325-6164	4N-8591	Coupling - Exhaust	325-6053	7N-2876	Line As - Fuel Injector	298-2781
2P-1739	Tube As - Pump	325-6229	4N-8814	Line As - Fuel Injector	247-3366	7N-2949	Pulley	264-5887
2P-1757	Hub - Fan Pulley	296-1357	4N-9587	Shield - Heat	297-7260	7N-3486	Manifold - Exhaust	261-0899
2P-1781	Spacer - Oil Pump	325-6214	4P-3546	Valve As - Relief	325-6236	7N-3515	Gear - Camshaft	314-8669
2P-2406	Pulley	264-5870	4P-9381	Line As - Fuel Injector	279-4984	7N-3536	Gear - Fuel	279-4993
2P-2519	Tube As - Inlet	325-6230	4P-9382	Line As - Fuel Injector	279-4985	7N-5511	Gear As - Idler	233-2180
2P-6128	Pulley	264-5872	4P-9385	Line As - Fuel Injector	279-4986	7N-5910	Impeller - Pump	314-8686
2P-6245	Shaft As - Pump	325-6197	4P-9386	Line As - Fuel Injector	279-4987	7N-9145	Gear - Fly-wheel	279-4994
2W-1086	Cover As - Cylinder Head	325-6049	4V-5608	Pin As	241-2529	7N-9146	Gear - Fly-wheel Starter	279-4995
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4W-0452	Seal As - Camshaft	325-6191	7N-9312	Damper As - Camshaft	299-2005
2W-3428	Muffler As	298-2784	4W-2446	Damper As	279-4990	7N-9805	Pin - Piston	295-6438
2W-6757	Trunnion As	295-5678	5P-7807	Bearing - Ball	314-8502	7S-3161	Lifter - Valve	279-4996
2W-7255	Shaft - Water Pump	325-6203	5S-1211	Cover - Valve	314-8665	7S-6723	Bracket - Alternator	299-1978
2W-7458	Crankshaft As	242-3439	5S-4557	Bearing	311-9360	7S-7809	Cap As - Radiator	295-6417
2W-7678	Gear - Water Pump	325-6088	5S-6795	Chamber As	242-3437	7T-2036	Cap As - Filter	361-1721
2W-9978	Core As - Oil Cooler	279-4983	5S-9080	Pulley - Alt Drive	264-5883	7W-0450	Gear - Water Pump	279-4997
3L-1425	Bearing - Ball	311-9356	6H-3957	Bearing - Ball	311-9358	7W-0507	Gear - Oil Pump Drive	279-4998
3V-4622	Bracket - Carriage Roller	297-7148	6I-1346	Pump Gp - Oil	295-5674	7W-0508	Gear - Fuel Pump Drive	296-1351
3Y-9984	Manifold - Exhaust	325-6123	6N-1036	Gear - Oil Pump	279-4991	7W-5687	Hub - Camshaft	314-8684
3Y-9985	Manifold - Exhaust	325-6124	6N-1965	Line As - Fuel Injector	250-7535	7Y-1517	Pipe As - Tail	301-5246
4E-1035	Pin	241-2553	6N-1966	Line As - Fuel Injector	250-7536	8H-2810	Case As - Filter	314-8512
4E-1065	Pin As	241-2538	6N-2789	Pulley	264-5886	8K-0665	Cage - Bearing	231-0262
4E-1285	Link As	299-2021	6N-3256	Mount As	314-8688	8K-2860	Flange - Coupling	297-7171
4N-2954	Sleeve - Camshaft	299-2059	6N-8413	Housing - Pump	325-6110	8K-3712	Pin As	241-2541
4N-3281	Line As - Fuel Injector	247-3362	7C-4297	Seal As - Camshaft	325-6192	8N-0002	Trunnion As	314-8728
4N-3282	Line As - Fuel Injector	247-3363	7N-0110	Core As - Oil Cooler	319-3435	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
4N-3283	Line As - Fuel Injector	247-3364	7N-0128	Core As - Oil Cooler	299-1994			
			7N-0165	Core As - Oil Cooler	295-5670			
			7N-1164	Mount As	295-5451			
			7N-2871	Line As - Fuel Injector	319-8172			

(Continued)

Sales Model 235B (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349

Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8R-3787	Shaft	299-2058
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416

Original Part Number	Part Name	Classic Part Number
8V-5439	Pin As	241-2531
9C-6544	Drum - Brake	297-7169
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8428	Pin As	241-2533
9K-8430	Pin As	241-2540
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-7079	Muffler As	247-2669
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167

Sales Model 235C

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202

Original Part Number	Part Name	Classic Part Number
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1N-3576	Block Gp - Cylinder	279-4978
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981

Original Part Number	Part Name	Classic Part Number
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357

(Continued)

Sales Model 235C (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer - Oil Pump	325-6214	4N-8591	Coupling - Exhaust	325-6053	7C-4297	Seal As - Camshaft	325-6192
2P-2406	Pulley	264-5870	4N-8814	Line As - Fuel Injector	247-3366	7N-0110	Core As - Oil Cooler	319-3435
2P-2519	Tube As - Inlet	325-6230	4N-9587	Shield - Heat	297-7260	7N-0128	Core As - Oil Cooler	299-1994
2P-6128	Pulley	264-5872	4P-3546	Valve As - Relief	325-6236	7N-0165	Core As - Oil Cooler	295-5670
2P-6245	Shaft As - Pump	325-6197	4P-9381	Line As - Fuel Injector	279-4984	7N-1164	Mount As	295-5451
2W-1086	Cover As - Cylinder Head	325-6049	4P-9382	Line As - Fuel Injector	279-4985	7N-2871	Line As - Fuel Injector	319-8172
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4P-9385	Line As - Fuel Injector	279-4986	7N-2872	Line As - Fuel Injector	319-8173
2W-6757	Trunnion As	295-5678	4P-9386	Line As - Fuel Injector	279-4987	7N-2874	Line As - Fuel Injector	298-2779
2W-7255	Shaft - Water Pump	325-6203	4V-9236	Plate - Pressure	231-0260	7N-2875	Line As - Fuel Injector	298-2780
2W-7458	Crankshaft As	242-3439	4W-0452	Seal As - Camshaft	325-6191	7N-2876	Line As - Fuel Injector	298-2781
2W-7678	Gear - Water Pump	325-6088	4W-2446	Damper As	279-4990	7N-2949	Pulley	264-5887
2W-9978	Core As - Oil Cooler	279-4983	5C-1834	Gear	231-0002	7N-3486	Manifold - Exhaust	261-0899
3F-4971	Pin	295-5693	5C-5937	Gear	231-0004	7N-3515	Gear - Camshaft	314-8669
3L-1425	Bearing - Ball	311-9356	5C-8582	Shaft - Planet	231-0241	7N-3536	Gear - Fuel	279-4993
3P-0651	Seal - o-Ring	314-8541	5C-8583	Gear - Ring	231-0005	7N-5511	Gear As - Idler	233-2180
3V-4622	Bracket - Carriage Roller	297-7148	5C-8584	Gear - Planet	231-0006	7N-5910	Impeller - Pump	314-8686
3V-5317	Gear	231-0010	5C-8586	Gear	231-0007	7N-9145	Gear - Flywheel	279-4994
3V-5378	Gear - Output	231-0235	5C-8587	Cover	231-0243	7N-9146	Gear - Flywheel Starter	279-4995
3V-9439	Retainer As	231-0257	5C-8966	Gear	231-0227	7N-9312	Damper As - Camshaft	299-2005
3Y-9984	Manifold - Exhaust	325-6123	5P-7807	Bearing - Ball	314-8502	7N-9805	Pin - Piston	295-6438
3Y-9985	Manifold - Exhaust	325-6124	5S-1211	Cover - Valve	314-8665	7S-3161	Lifter - Valve	279-4996
4E-1035	Pin	241-2553	5S-4557	Bearing	311-9360	7S-6723	Bracket - Alternator	299-1978
4E-1065	Pin As	241-2538	5S-6795	Chamber As	242-3437	7S-7809	Cap As - Radiator	295-6417
4E-1285	Link As	299-2021	5S-9080	Pulley - Alt Drive	264-5883	7V-7973	Gear Final Drive	231-0239
4E-9426	Collar	231-0000	5V-7207	Pinion - Final Drive	231-0252	7V-7974	Pinion Final Drive	231-0253
4K-6810	Retainer - Seal	300-2586	5V-7222	Gear - Final Drive	231-0237	7W-0450	Gear - Water Pump	279-4997
4N-2954	Sleeve - Camshaft	299-2059	6A-7534	Retainer	231-0244	7W-0507	Gear - Oil Pump Drive	279-4998
4N-3281	Line As - Fuel Injector	247-3362	6C-0739	Carrier As	231-0012	7W-0508	Gear - Fuel Pump Drive	296-1351
4N-3282	Line As - Fuel Injector	247-3363	6H-3957	Bearing - Ball	311-9358	7W-5687	Hub - Camshaft	314-8684
4N-3283	Line As - Fuel Injector	247-3364	6I-1346	Pump Gp - Oil	295-5674			
4N-4539	Sleeve	314-8720	6N-1036	Gear - Oil Pump	279-4991			
4N-4782	Pulley	325-6176	6N-1965	Line As - Fuel Injector	250-7535			
4N-7693	Crankshaft As	242-3439	6N-1966	Line As - Fuel Injector	250-7536			
			6N-2789	Pulley	264-5886			
			6N-3256	Mount As	314-8688			
			6N-8413	Housing - Pump	325-6110			

(Continued)

Sales Model 235C (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
7Y-1517	Pipe As - Tail	301-5246
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-2779	Cage - Bearing	231-0483
8K-2860	Flange - Coupling	297-7171
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291

Original Part Number	Part Name	Classic Part Number
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-5197	Bearing As	295-6413
8R-3787	Shaft	299-2058
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198

Original Part Number	Part Name	Classic Part Number
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8V-5439	Pin As	241-2531
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8430	Pin As	241-2540
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-7079	Muffler As	247-2669
9S-8679	Chamber As	325-6042
9U-0654	Coupling	297-7167

Sales Model 235D

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222

Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
190-8609	Valve - Fill	360-2288
1N-3576	Block Gp - Cylinder	279-4978
1S-2268	Piston	226-2726
1S-4701	Pulley - Alt	264-5866
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980

Original Part Number	Part Name	Classic Part Number
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-9229	Muffler As	302-4282

(Continued)

Sales Model 235D (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
244-1090	Alarm - Back up	360-2345	4P-9381	Line As - Fuel Injector	279-4984	8K-2779	Cage - Bearing	231-0483
2F-5721	Bearing - Ball	311-9354	4P-9382	Line As - Fuel Injector	279-4985	8K-2860	Flange - Coupling	297-7171
2K-3592	Boss	314-8501	4P-9385	Line As - Fuel Injector	279-4986	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
2K-6413	Pin	360-2270	4P-9386	Line As - Fuel Injector	279-4987	8N-1187	Head Gp - Cylinder	242-3435
2P-1170	Shaft As - Gear	296-1367	4W-0452	Seal As - Camshaft	325-6191	8N-1721	Rod As - Conn	269-5291
2P-1738	Plate As - Oil Pan	325-6164	4W-2446	Damper As	279-4990	8N-2510	Shaft	325-6208
2P-1739	Tube As - Pump	325-6229	5P-7807	Bearing - Ball	314-8502	8N-2641	Sleeve	325-6210
2P-1757	Hub - Fan Pulley	296-1357	5S-4557	Bearing	311-9360	8N-3251	Shaft As - Rocker Arm	314-8711
2P-1781	Spacer - Oil Pump	325-6214	5S-6795	Chamber As	242-3437	8N-3325	Arm Gp - Rocker	314-8623
2P-2519	Tube As - Inlet	325-6230	5S-9080	Pulley - Alt Drive	264-5883	8N-3327	Arm Gp - Rocker	314-8624
2P-6245	Shaft As - Pump	325-6197	6H-3957	Bearing - Ball	311-9358	8N-5929	Cover - Water Pump	296-1349
2W-1086	Cover As - Cylinder Head	325-6049	6I-1346	Pump Gp - Oil	295-5674	8N-6796	Head Gp - Cylinder	269-5290
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	6N-1036	Gear - Oil Pump	279-4991	8N-7315	Tube As - Outlet	325-6232
2W-6757	Trunnion As	295-5678	6N-3256	Mount As	314-8688	8N-8225	Bearing - Main	314-8652
2W-7255	Shaft - Water Pump	325-6203	7C-4297	Seal As - Camshaft	325-6192	8R-3787	Shaft	299-2058
2W-7458	Crankshaft As	242-3439	7N-0110	Core As - Oil Cooler	319-3435	8S-0248	Breather As	325-6033
3F-4971	Pin	295-5693	7N-1164	Mount As	295-5451	8S-0493	Shaft As - Pump	325-6198
3L-1425	Bearing - Ball	311-9356	7N-2949	Pulley	264-5887	8S-3970	Chamber As	242-3438
3P-0651	Seal - o-Ring	314-8541	7N-5910	Impeller - Pump	314-8686	8S-7716	Manifold - Exhaust	295-0415
3V-4622	Bracket - Carriage Roller	297-7148	7N-9146	Gear - Fly-wheel Starter	279-4995	8S-7717	Manifold - Exhaust	261-0894
3Y-9984	Manifold - Exhaust	325-6123	7N-9805	Pin - Piston	295-6438	8S-7718	Manifold - Exhaust	295-0416
3Y-9985	Manifold - Exhaust	325-6124	7S-3161	Lifter - Valve	279-4996	8V-5439	Pin As	241-2531
4E-1035	Pin	241-2553	7S-6723	Bracket - Alternator	299-1978	9C-6544	Drum - Brake	297-7169
4E-1065	Pin As	241-2538	7S-7809	Cap As - Radiator	295-6417	9K-0092	Pinion	231-0484
4E-1285	Link As	299-2021	7W-0450	Gear - Water Pump	279-4997	9K-8425	Bearing - Sleeve	314-8638
4K-6810	Retainer - Seal	300-2586	7W-0507	Gear - Oil Pump Drive	279-4998	9K-8427	Pin As	241-2527
4N-4539	Sleeve	314-8720	7W-0508	Gear - Fuel Pump Drive	296-1351	9K-8430	Pin As	241-2540
4N-4782	Pulley	325-6176	7W-5687	Hub - Camshaft	314-8684	9K-8757	Rod End - Bearing	311-9361
4N-7693	Crankshaft As	242-3439	7Y-1517	Pipe As - Tail	301-5246	9N-5769	Cover - Housing	325-6050
4N-8591	Coupling - Exhaust	325-6053	8H-2810	Case As - Filter	314-8512	9S-6129	Pulley - Alternator Drive	264-5891
4P-3546	Valve As - Relief	325-6236	8K-0665	Cage - Bearing	231-0262	9S-8679	Chamber As	325-6042
			8K-1107	Rack - Disconnect	231-0264			

(Continued)

Sales Model 235D (Continued)

Original Part Number	Part Name	Classic Part Number
9U-0654	Coupling	297-7167

Sales Model 245

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1V-5744	Pin	241-2554
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1757	Hub - Fan Pulley	296-1357
3F-4971	Pin	295-5693
3L-1425	Bearing - Ball	311-9356
3P-0651	Seal - o-Ring	314-8541

Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing - Sleeve	295-6407
4K-6810	Retainer - Seal	300-2586
4N-4539	Sleeve	314-8720
4N-6302	Belt Set - Vee	314-8495
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
5G-3612	Cap Gp	295-6419
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6N-3256	Mount As	314-8688
7C-0942	Adapter As	302-2636
7C-6398	Muffler As	360-7885
7S-7809	Cap As - Radiator	295-6417
7T-1310	Rim -Track Sprocket	290-0861
7T-2036	Cap As - Filter	361-1721
7W-1902	Adapter - Fuel Nozzle	299-1955

Original Part Number	Part Name	Classic Part Number
7W-2164	Core As - Oil Cooler	299-1996
8E-7857	Link As.	290-0819
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-2779	Cage - Bearing	231-0483
8K-2860	Flange - Coupling	297-7171
8K-3712	Pin As	241-2541
8K-4296	Pin	241-2555
8K-4753	Link As.	290-0837
8K-4764	Pin	241-2556
8M-0874	Plunger As - Valve	311-9439
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8V-2639	Pin As	241-2542
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9Y-2988	Breather As	361-1716

Sales Model 245B

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1S-4701	Pulley - Alt	264-5866
1V-5744	Pin	241-2554
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356

Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1757	Hub - Fan Pulley	296-1357
3F-4971	Pin	295-5693
3L-1425	Bearing - Ball	311-9356
3P-0651	Seal - o-Ring	314-8541
4J-6374	Bearing - Sleeve	295-6407
4K-6810	Retainer - Seal	300-2586

Original Part Number	Part Name	Classic Part Number
4N-4539	Sleeve	314-8720
4N-6302	Belt Set - Vee	314-8495
4P-1463	Muffler As	360-7876
4P-9961	Line As - Fuel Injector	325-6115
5G-3612	Cap Gp	295-6419
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
6N-3256	Mount As	314-8688
7C-0942	Adapter As	302-2636
7C-6398	Muffler As	360-7885

(Continued)

Sales Model 245B (Continued)

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7Y-0223	Shaft - Planet	301-4625
7Y-0225	Shaft - Planet	301-4571
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729

Original Part Number	Part Name	Classic Part Number
7Y-1432	Carrier	314-8659
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-2779	Cage - Bearing	231-0483
8K-3712	Pin As	241-2541
8K-4296	Pin	241-2555

Original Part Number	Part Name	Classic Part Number
8K-4764	Pin	241-2556
8M-0874	Plunger As - Valve	311-9439
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8V-2639	Pin As	241-2542
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9Y-2988	Breather As	361-1716

Sales Model 245D

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1S-4701	Pulley - Alt	264-5866
1V-5744	Pin	241-2554
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
3F-4971	Pin	295-5693

Original Part Number	Part Name	Classic Part Number
4J-6374	Bearing - Sleeve	295-6407
4K-6810	Retainer - Seal	300-2586
4N-4539	Sleeve	314-8720
4P-1463	Muffler As	360-7876
4P-9961	Line As - Fuel Injector	325-6115
5G-3612	Cap Gp	295-6419
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
6N-3256	Mount As	314-8688
7C-0942	Adapter As	302-2636
7S-7809	Cap As - Radiator	295-6417

Original Part Number	Part Name	Classic Part Number
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-3712	Pin As	241-2541
8K-4296	Pin	241-2555
8K-4764	Pin	241-2556
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8V-2639	Pin As	241-2542
9C-6544	Drum - Brake	297-7169
9K-0092	Pinion	231-0484
9K-8757	Rod End - Bearing	311-9361
9Y-2988	Breather As	361-1716

Sales Model 320

Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5499	Bearing - Sleeve	314-8640
087-5533	Bearing - Sleeve	314-8628
087-5802	Link - Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969

Original Part Number	Part Name	Classic Part Number
087-5847	Bearing - Sleeve	314-8629
094-1509	Shaft - Planet	360-2273
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
096-7911	Bearing - Sleeve	314-8653
096-7912	Bearing - Sleeve	314-8654
096-7913	Bearing - Sleeve	314-8655

Original Part Number	Part Name	Classic Part Number
099-0718	Bearing - Sleeve	360-2313
099-0721	Bearing - Sleeve	314-8641
102-8112	Cylinder - Adjustable	360-2276
108-0980	Pin As	314-8692
110-7058	Carrier - Planet	301-4630
110-7059	Carrier - Planet	301-4636

(Continued)

Sales Model 320 (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
110-7209	Carrier As	301-5237
115-4204	Pulley As - Idler	301-5219
115-6427	Spring	301-4776
115-6429	Cylinder	301-4679
119-2863	Pin	314-8698
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
122-5178	Piston As	301-5252
125-2950	Gear As	301-4762
126-5061	Shoe -Track	335-5478
126-5062	Shoe -Track	286-9827
127-5969	Gear - Sun	301-4761
127-5970	Gear - Planet	301-3398
128-9863	Bearing - Sleeve	314-8630
128-9882	Bearing - Sleeve	314-8642
128-9884	Bearing - Sleeve	360-2315
129-7768	Bearing - Sleeve	360-2316
130-9293	Rod	314-8708
137-2819	Bearing - Sleeve	360-2317
137-2820	Bearing - Sleeve	360-2318
137-2919	Bearing - Sleeve	360-2319
145-3030	Cylinder	360-2260
148-4634	Shaft - Planet	360-2274
163-4143	Roller Gp - SF	286-9823
190-8609	Valve - Fill	360-2288
194-1608	Link As.	308-6230
194-1609	Link As.	308-6229
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing - Sleeve	360-2322
236-6271	Bearing - Sleeve	360-2324
240-2913	Bearing - Sleeve	360-2325
244-1090	Alarm - Back up	360-2345
248-7143	Idler Gp	286-9830
250-2402	Pin As	360-2351

Original Part Number	Part Name	Classic Part Number
253-4393	Muffler - Converter	301-7975
253-4426	Muffler - Converter	301-7974
2D-5658	Bearing - Ball	301-4628
2K-6413	Pin	360-2270
3P-1849	Ring - Sealing	360-2259
4E-0183	Pin	301-7976
4I-0453	Bearing - Sleeve	360-2331
4I-0704	Bearing Sleeve	360-2332
4I-3954	Tube As	301-4779
4I-3955	Tube As	301-4802
4I-3956	Tube As	301-4780
4I-3957	Tube As	301-4801
4I-8881	Tube As	301-4777
4W-2042	Spacer	325-6217
5C-5837	Retainer - Pin	299-2047
5I-7619	Pulley	301-4772
5I-7694	Impeller	301-4763
5I-7959	Pulley As	301-5256
5I-8628	Plate - Valve	301-4771
6A-7129	Bearing - Sleeve	301-3130
6C-6374	Tube As	301-4778
6E-3535	Bearing - Sleeve	360-2333
6I-9454	Shoe -Track	286-9826
7I-6843	Pin	301-4766
7K-9639	Bearing - Sleeve	314-8643
7Y-0212	Gear - Ring	301-4681
7Y-0213	Gear - Planet	301-4760
7Y-0221	Gear - Planet	301-4758
7Y-0223	Shaft - Planet	301-4625
7Y-0224	Gear - Planet	301-4759
7Y-0225	Shaft - Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear - Sun	301-4689
7Y-0241	Carrier	301-4635
7Y-0242	Carrier	301-4637
7Y-0249	Gear - Sun	301-4694
7Y-0680	Piston	360-2262
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659

Original Part Number	Part Name	Classic Part Number
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As - Exhaust	301-5249
7Y-1517	Pipe As - Tail	301-5246
7Y-1643	Gear - Sun	314-8670
7Y-1644	Gear - Planet	301-3406
7Y-1646	Shaft - Planet	301-4624
7Y-1687	Piston As	360-2266
7Y-1751	Carrier - Planet	314-8660
7Y-1752	Carrier - Planet	314-8661
7Y-1764	Shaft - Planet	314-8717
7Y-1775	Shaft - Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
7Y-3553	Bearing - Sleeve	301-0433
7Y-4666	Bearing - Sleeve	314-8636
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
7Y-6627	Pin As	314-8693
8E-5600	Roller Gp - Carrier	286-9824
8E-9805	Sprocket	286-9821
8H-2810	Case As - Filter	314-8512
8R-7336	Bearing	301-3394
8S-0248	Breather As	325-6033
9G-9349	Retainer	295-0411
9W-3361	Nut - Track	200-9127
9W-3619	Bolt - Track	286-9828
9W-9351	Shoe -Track	286-9825

Sales Model 320B

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
094-1509	Shaft - Planet	360-2273	137-2820	Bearing - Sleeve	360-2318	244-1090	Alarm - Back up	360-2345
095-2927	Valve - Fill	360-2292	137-2919	Bearing - Sleeve	360-2319	250-2402	Pin As	360-2351
095-9291	Valve - Fill	360-2293	137-3060	Bearing - Sleeve	360-2320	2K-6413	Pin	360-2270
099-0718	Bearing - Sleeve	360-2313	190-8609	Valve - Fill	360-2288	2V-0707	Bearing - Sleeve	360-2328
102-8112	Cylinder - Adjustable	360-2276	223-3095	Gauge As	360-2295	3P-1849	Ring - Sealing	360-2259
107-2139	Pin As	360-2352	227-0620	Gauge As	360-2295	3W-8239	Sleeve - Wear	360-2342
118-9906	Muffler As	360-7865	227-6789	Bearing - Sleeve	360-2322	4I-0453	Bearing - Sleeve	360-2331
128-9883	Bearing - Sleeve	360-2314	236-6271	Bearing - Sleeve	360-2324	4I-0704	Bearing Sleeve	360-2332
128-9884	Bearing - Sleeve	360-2315	240-2913	Bearing - Sleeve	360-2325	6E-3535	Bearing - Sleeve	360-2333
129-7768	Bearing - Sleeve	360-2316	240-2915	Bearing - Sleeve	360-2326	6Y-9930	Mount As	360-2353
137-2819	Bearing - Sleeve	360-2317				7Y-0680	Piston	360-2262

Sales Model 320C

Part Number	Part Name	Classic Part Number	Part Number	Part Name	Classic Part Number	Part Number	Part Name	Classic Part Number
094-1509	Shaft - Planet	360-2273	223-3095	Gauge As	360-2295	250-2402	Pin As	360-2351
095-2927	Valve - Fill	360-2292	227-0620	Gauge As	360-2295	2K-6413	Pin	360-2270
099-0718	Bearing - Sleeve	360-2313	227-6228	Cage	360-2343	2V-0707	Bearing - Sleeve	360-2328
107-2139	Pin As	360-2352	227-6789	Bearing - Sleeve	360-2322	3P-1849	Ring - Sealing	360-2259
128-9884	Bearing - Sleeve	360-2315	228-5621	Bearing - Sleeve	360-2323	3W-8239	Sleeve - Wear	360-2342
129-7768	Bearing - Sleeve	360-2316	236-6271	Bearing - Sleeve	360-2324	4I-0453	Bearing - Sleeve	360-2331
137-2819	Bearing - Sleeve	360-2317	240-2913	Bearing - Sleeve	360-2325	4I-0704	Bearing Sleeve	360-2332
137-2820	Bearing - Sleeve	360-2318	240-2915	Bearing - Sleeve	360-2326	6E-3535	Bearing - Sleeve	360-2333
137-3060	Bearing - Sleeve	360-2320	240-2916	Bearing - Sleeve	360-2327	7J-1309	Bearing - Aligning	360-2275
145-3030	Cylinder	360-2260	244-1090	Alarm - Back up	360-2345	7K-9592	Bearing - Sleeve	360-2336
148-4634	Shaft - Planet	360-2274				7Y-3549	Pin	360-2349

Sales Model 320S

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
087-5499	Bearing - Sleeve	314-8640	087-5845	Pin	301-7969	110-7058	Carrier - Planet	301-4630
087-5533	Bearing - Sleeve	314-8628	087-5847	Bearing - Sleeve	314-8629	110-7059	Carrier - Planet	301-4636
087-5802	Link - Rh	301-7964	094-1509	Shaft - Planet	360-2273	110-7209	Carrier As	301-5237
087-5803	Link As	301-7966	095-2927	Valve - Fill	360-2292	115-4204	Pulley As - Idler	301-5219
087-5805	Pin	301-7967	095-9291	Valve - Fill	360-2293	119-2863	Pin	314-8698
087-5806	Pin	301-7968	102-8112	Cylinder - Adjustable	360-2276			

(Continued)

Sales Model 320S (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
129-7768	Bearing - Sleeve	360-2316
130-9293	Rod	314-8708
137-2819	Bearing - Sleeve	360-2317
137-2820	Bearing - Sleeve	360-2318
137-2919	Bearing - Sleeve	360-2319
190-8609	Valve - Fill	360-2288
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6789	Bearing - Sleeve	360-2322
236-6271	Bearing - Sleeve	360-2324
250-2402	Pin As	360-2351
253-4393	Muffler - Converter	301-7975
2D-5658	Bearing - Ball	301-4628
3P-1849	Ring - Sealing	360-2259
4E-0183	Pin	301-7976
4I-0453	Bearing - Sleeve	360-2331

Original Part Number	Part Name	Classic Part Number
4I-0704	Bearing Sleeve	360-2332
4W-2042	Spacer	325-6217
5C-5837	Retainer - Pin	299-2047
5I-8628	Plate - Valve	301-4771
6C-6374	Tube As	301-4778
7Y-0212	Gear - Ring	301-4681
7Y-0213	Gear - Planet	301-4760
7Y-0221	Gear - Planet	301-4758
7Y-0223	Shaft - Planet	301-4625
7Y-0224	Gear - Planet	301-4759
7Y-0225	Shaft - Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear - Sun	301-4689
7Y-0241	Carrier	301-4635
7Y-0242	Carrier	301-4637
7Y-0249	Gear - Sun	301-4694
7Y-0680	Piston	360-2262
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
7Y-1461	Coupling	301-4649

Original Part Number	Part Name	Classic Part Number
7Y-1513	Pipe As - Exhaust	301-5249
7Y-1517	Pipe As - Tail	301-5246
7Y-1764	Shaft - Planet	314-8717
7Y-1775	Shaft - Pinion	314-8718
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
7Y-4666	Bearing - Sleeve	314-8636
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
8H-2810	Case As - Filter	314-8512
8S-0248	Breather As	325-6033

Sales Model 330

Original Part Number	Part Name	Classic Part Number
086-0523	Pin	314-8696
087-5533	Bearing - Sleeve	314-8628
087-5802	Link - Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing - Sleeve	314-8629
099-0721	Bearing - Sleeve	314-8641
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989

Original Part Number	Part Name	Classic Part Number
110-7058	Carrier - Planet	301-4630
110-7059	Carrier - Planet	301-4636
110-7209	Carrier As	301-5237
111-8015	Gasket As - Head	279-4977
115-4204	Pulley As - Idler	301-5219
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
128-9863	Bearing - Sleeve	314-8630
128-9882	Bearing - Sleeve	314-8642
130-9293	Rod	314-8708
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361

Original Part Number	Part Name	Classic Part Number
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1N-3576	Block Gp - Cylinder	279-4978

(Continued)

Sales Model 330 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1S-4701	Pulley - Alt	264-5866	4P-9381	Line As - Fuel Injector	279-4984	7W-2164	Core As - Oil Cooler	299-1996
1V-8241	Bearing - Sleeve	308-9808	4P-9382	Line As - Fuel Injector	279-4985	7W-5687	Hub - Cam-shaft	314-8684
1W-1669	Piston	325-6158	4P-9385	Line As - Fuel Injector	279-4986	7Y-0212	Gear - Ring	301-4681
1W-1695	Pump Gp	279-4980	4P-9386	Line As - Fuel Injector	279-4987	7Y-0213	Gear - Planet	301-4760
1W-1698	Housing - Transfer Pump	296-1356	4P-9961	Line As - Fuel Injector	325-6115	7Y-0221	Gear - Planet	301-4758
1W-4402	Gear - Cam-shaft	279-4981	4V-8520	Bearing - Sleeve	307-1527	7Y-0223	Shaft - Planet	301-4625
1W-4405	Gear - Crank-shaft	279-4982	4W-0452	Seal As - Camshaft	325-6191	7Y-0224	Gear - Planet	301-4759
1W-4738	Bearing - Sleeve	325-6020	4W-2042	Spacer	325-6217	7Y-0225	Shaft - Planet	301-4571
1W-4740	Gear As - Drive	295-5689	4W-2446	Damper As	279-4990	7Y-0228	Carrier As	301-5239
1W-4746	Retainer - Gear	295-5690	5P-7807	Bearing - Ball	314-8502	7Y-0238	Gear - Sun	301-4689
1W-5912	Tappet As - Guide	325-6223	5S-4557	Bearing	311-9360	7Y-0241	Carrier	301-4635
2D-5658	Bearing - Ball	301-4628	5S-6795	Chamber As	242-3437	7Y-0242	Carrier	301-4637
2F-5721	Bearing - Ball	311-9354	5S-9080	Pulley - Alt Drive	264-5883	7Y-0249	Gear - Sun	301-4694
2P-1170	Shaft As - Gear	296-1367	6H-3957	Bearing - Ball	311-9358	7Y-1427	Gear - Sun	288-8727
2P-1738	Plate As - Oil Pan	325-6164	6I-1346	Pump Gp - Oil	295-5674	7Y-1428	Gear - Planet	288-8728
2P-1739	Tube As - Pump	325-6229	6N-1036	Gear - Oil Pump	279-4991	7Y-1430	Gear - Sun	314-8671
2P-1757	Hub - Fan Pulley	296-1357	6N-8413	Housing - Pump	325-6110	7Y-1431	Gear - Planet	288-8729
2P-1781	Spacer - Oil Pump	325-6214	7C-0942	Adapter As	302-2636	7Y-1432	Carrier	314-8659
2P-2519	Tube As - Inlet	325-6230	7I-6843	Pin	301-4766	7Y-1461	Coupling	301-4649
2P-6128	Pulley	264-5872	7J-6461	Crown	325-6054	7Y-1513	Pipe As - Exhaust	301-5249
2P-6245	Shaft As - Pump	325-6197	7J-9884	Bearing - Sleeve	325-6016	7Y-1517	Pipe As - Tail	301-5246
2W-1086	Cover As - Cylinder Head	325-6049	7N-0110	Core As - Oil Cooler	319-3435	7Y-2348	Pin	314-8697
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	7N-2949	Pulley	264-5887	7Y-2349	Pin	301-4556
2W-6757	Trunnion As	295-5678	7N-5910	Impeller - Pump	314-8686	7Y-2357	Pin	301-4564
2W-7255	Shaft - Water Pump	325-6203	7N-9146	Gear - Fly-wheel Starter	279-4995	7Y-2391	Link As	301-5240
2W-7458	Crankshaft As	242-3439	7N-9805	Pin - Piston	295-6438	7Y-2392	Link - Rh	301-4765
3L-1425	Bearing - Ball	311-9356	7S-3161	Lifter - Valve	279-4996	7Y-2395	Bearing - Sleeve	314-8646
3P-0651	Seal - o-Ring	314-8541	7S-6723	Bracket - Alternator	299-1978	7Y-2396	Bearing - Sleeve	314-8634
4N-4782	Pulley	325-6176	7S-8443	Muffler	247-2675	7Y-3427	Bearing - Sleeve	314-8635
4N-7693	Crankshaft As	242-3439	7W-0450	Gear - Water Pump	279-4997	7Y-3428	Bearing - Sleeve	314-8647
4P-3546	Valve As - Relief	325-6236	7W-0507	Gear - Oil Pump Drive	279-4998	7Y-3553	Bearing - Sleeve	301-0433
			7W-0508	Gear - Fuel Pump Drive	296-1351	7Y-4666	Bearing - Sleeve	314-8636
			7W-1902	Adapter - Fuel Nozzle	299-1955	7Y-5128	Bearing - Sleeve	314-8648
						7Y-5131	Bearing - Sleeve	301-4626
						7Y-6608	Bearing	314-8649
						7Y-6626	Bearing	314-8650
						7Y-6627	Pin As	314-8693
						8H-2810	Case As - Filter	314-8512

(Continued)

Sales Model 330 (Continued)

Excavators

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5779	Coupling - Exhaust	325-6047

Original Part Number	Part Name	Classic Part Number
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9J-7964	Bearing - Spherical	325-6017
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891

Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042
102-8112	Cylinder - Adjustable	360-2276
109-9463	Muffler As	360-7864
137-2819	Bearing - Sleeve	360-2317
190-8609	Valve - Fill	360-2288
244-1090	Alarm - Back up	360-2345
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
228-5621	Bearing - Sleeve	360-2323
2K-6413	Pin	360-2270
7Y-0680	Piston	360-2262

Cat® Classic™ Parts for Motor Graders

Cat® motor graders have long, productive lives, and maintenance costs need to be evaluated as these machines age. Cat® Classic™ parts are a repair option targeted at the end of the product life cycle when lower cost options are more desired. Caterpillar offers the Classic parts line for several older models of motor graders. Cat Classic parts is a repair option that is priced to allow the machines to continue to be operated profitably as they age.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for motor graders includes:

- Axle
- Engine
- Final Drive
- Flywheel Clutch
- Linkage Pin
- Steering
- Transmission
- Trunnion/Blade Support
- ...and many more.



Sales Model 12

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
121-7746	Precleaner As	360-2311
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-7250	Bowl - Pre-cleaner	360-2296
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342

Original Part Number	Part Name	Classic Part Number
2D-5961	Pin - Axle Pivot	228-9438
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2K-6413	Pin	360-2270
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438

Original Part Number	Part Name	Classic Part Number
3B-5067	Shaft - Shift Worm	228-8907
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4442	Shaft - Rev Worm	243-0354
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451

(Continued)

Sales Model 12 (Continued)

Original Part Number	Part Name	Classic Part Number
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6680	Shaft - Steering Rear	228-9560
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334

Original Part Number	Part Name	Classic Part Number
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Fly-wheel	229-1608
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5S-1211	Cover - Valve	314-8665
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419

Original Part Number	Part Name	Classic Part Number
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9Y-9431	Precleaner As	361-1718

Sales Model 12E

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	1W-1695	Pump Gp	279-4980	2F-8001	Shaft - Worm	228-9445
104-4253	Line As - Fuel Injector	279-4988	1W-1698	Housing - Transfer Pump	296-1356	2F-9047	Block - Pivot	228-9446
104-4254	Line As - Fuel Injector	279-4989	1W-4402	Gear - Cam-shaft	279-4981	2F-9074	Link - Tie Bar	228-9447
111-8015	Gasket As - Head	279-4977	1W-4405	Gear - Crank-shaft	279-4982	2G-4187	Shell - Bearing	245-5794
115-7550	Gasket - Plate	314-8667	1W-5912	Tappet As - Guide	325-6223	2K-4507	Bearing - Sleeve	325-6021
121-7746	Precleaner As	360-2311	1W-6541	Plunger As	325-6173	2K-6413	Pin	360-2270
122-9405	Bracket As	325-6005	2D-1345	Drum - Brake	228-9430	2P-1170	Shaft As - Gear	296-1367
131-3815	Seal Gp - Basic	325-6193	2D-1659	Rack - Shift	228-9431	2P-1738	Plate As - Oil Pan	325-6164
148-7455	Valve - Exhaust	270-4361	2D-3467	Hub - Final Drive Gear	228-9396	2P-1757	Hub - Fan Pulley	296-1357
165-4262	Body As - Piston	270-4353 (Liner Kit)	2D-3609	Shaft - Final Drive Pinion	228-8919	2P-1781	Spacer - Oil Pump	325-6214
172-5185	Shaft - Water Pump	325-6201	2D-4010	Adjuster - Bearing	228-8916	2P-2406	Pulley	264-5870
172-5188	Shaft - Water Pump	325-6202	2D-4205	Block - Pivot	228-9432	2P-2519	Tube As - Inlet	325-6230
172-5189	Impeller - Pump	295-5687	2D-4209	Pin - Pivot	228-9434	2P-6128	Pulley	264-5872
172-5190	Impeller - Pump	325-6111	2D-4211	Arm - Steering	228-9435	2P-6245	Shaft As - Pump	325-6197
172-6712	Impeller - Pump	325-6112	2D-4215	Knuckle - Rh	228-9436	2P-7830	Pump Gp	314-8533
172-7767	Pump Gp - Water	296-1365	2D-4216	Knuckle - Lh	228-9437	2S-4015	Plunger As - Valve	311-9438
1A-2846	Cap As - Filler	311-9368	2D-5795	Sleeve - Thrust	243-0360	2S-6739	Pulley - Tightener	298-2794
1D-3996	Fork - Knuckle	228-9428	2D-5799	Pinion - Reverse	243-0342	2W-1086	Cover As - Cylinder Head	325-6049
1H-8037	Yoke - Fitting	228-9415	2D-5961	Pin - Axle Pivot	228-9438	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
1M-6128	Manifold - Exhaust	261-0906	2D-6381	Pinion	228-8915	2W-7255	Shaft - Water Pump	325-6203
1N-3576	Block Gp - Cylinder	279-4978	2D-6382	Gear - Worm	228-9558	2W-7458	Crankshaft As	242-3439
1N-3958	Elbow	325-6087	2D-7933	Cover - Circle Rev	243-0340	3B-5067	Shaft - Shift Worm	228-8907
1P-4303	Head As - Cylinder	242-3434	2D-8212	Plate As - Press	229-1582	3B-6218	Muffler As	247-2672
1P-9945	Bracket As - Fan	296-1344	2F-5721	Bearing - Ball	311-9354	3B-6695	Gear - Worm	228-9448
1P-9946	Shaft - Fan	325-6194	2F-5894	Drum - Brake	228-9439	3B-9970	Worm	228-8908
1P-9952	Impeller - Pump	314-8685	2F-5969	Collar - Coupling	228-9440	3D-0409	Arm - Pitman	228-9397
1S-1888	Bracket - Lamp	297-7147	2F-5970	Collar - Coupling	228-9441	3D-2136	Sprocket	228-9398
1S-4701	Pulley - Alt	264-5866	2F-6046	Pinion - Reduction	228-9442	3D-2149	Pinion	228-9450
1W-1219	Trunnion As	314-8724	2F-6050	Gear - Reduction	229-1584	3D-2236	Sprocket As	228-9399
1W-1669	Piston	325-6158	2F-6051	Gear	229-1585	3D-4442	Shaft - Rev Worm	243-0354
			2F-6053	Gear - Reduction	228-9443	3D-4443	Shaft - Rev Worm	243-0351
			2F-6057	Gear - Reduction	228-9444	3D-4498	Shaft - Lower	243-0348
						3D-4718	Bearing - Sleeve	245-5795

(Continued)

Sales Model 12E (Continued)

Original Part Number	Part Name	Classic Part Number
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349

Original Part Number	Part Name	Classic Part Number
4D-6680	Shaft - Steering Rear	228-9560
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-2954	Sleeve - Camshaft	299-2059
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816

Original Part Number	Part Name	Classic Part Number
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Fly-wheel	229-1608
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251

(Continued)

Sales Model 12E (Continued)

Original Part Number	Part Name	Classic Part Number
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779

Original Part Number	Part Name	Classic Part Number
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8N-0002	Trunnion As	314-8728

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891

(Continued)

Sales Model 12E (Continued)

Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042

Sales Model 12F

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
130-6856	Precleaner As	361-1717
131-3815	Seal Gp - Basic	325-6193
153-3580	Shaft	299-2055
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
1A-2846	Cap As - Filler	311-9368
1H-8037	Yoke - Fitting	228-9415
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434
1P-5480	Cover As - End	299-1998
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982

Original Part Number	Part Name	Classic Part Number
244-1090	Alarm - Back up	360-2345
2D-1345	Drum - Brake	228-9430
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2G-2858	Cap - Pivot	243-0345
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2S-4015	Plunger As - Valve	311-9438
2W-1086	Cover As - Cylinder Head	325-6049

Original Part Number	Part Name	Classic Part Number
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3B-5067	Shaft - Shift Worm	228-8907
3B-6218	Muffler As	247-2672
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2236	Sprocket As	228-9399
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593

(Continued)

Sales Model 12F (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
4D-2198	Cage - Bearing	229-1594	4S-6707	Piston - Clutch	215-1686	5T-8501	Shoe - Circle Drive	243-0358
4D-2218	Gear - Coupling	229-1595	4S-8708	Housing - Clutch	216-3557	6D-0687	Gear - Bevel	228-8922
4D-2219	Gear - Reverse	229-1597	4S-8718	Cage - Carrier Bearing	217-7724	6D-0708	Pinion	228-8923
4D-2220	Pinion - Transmission & Bevel	228-8920	4W-0452	Seal As - Camshaft	325-6191	6D-1599	Block - Link Pivot	228-9414
4D-2229	Cage - Bearing	229-1598	5B-0577	Collar	299-1992	6D-1644	Shaft - Rod Pivot	228-9562
4D-2268	Cover - Shaft	228-9454	5D-0034	Plate - Retainer	228-9456	6D-1777	Gear - Planet	245-5799
4D-3462	Pin - Pivot	247-4440	5D-0395	Bracket - Rail Rh	243-0335	6D-1778	Gear - Planet	245-5800
4D-3898	Gear - Bevel	228-8921	5D-0396	Bracket - Rail Lh	243-0334	6D-1779	Gear - Planet	245-5801
4D-3966	Gear - Reduction	228-8924	5D-0927	Shaft - Reduction	229-1605	6D-2362	Worm	243-0361
4D-4863	Pinion	229-1599	5D-4010	Rack	228-8909	6D-6114	Cap	245-5822
4D-6698	Bearing - Tandem Housing	228-9405	5D-5039	Ballstud	228-8910	6D-6201	Ballstud	228-9103
4D-7213	Coupling	228-9406	5D-6375	Shaft - Final Drive Pinion	228-9409	6D-6943	Housing - Axle	228-9416
4D-7282	Shaft - Axle	228-9408	5D-7461	Pin	247-4441	6D-8671	Bolt - Draft	243-0333
4D-9934	Trunnion	229-1601	5D-9548	Hub - Final Drive Gear	228-9412	6D-9193	Hub - Final Drive Gear	228-9417
4F-4974	Clamp	311-9373	5D-9906	Shaft - Axle	228-9413	6D-9294	Shaft	228-9418
4H-2029	Gear - Reverse	229-1602	5D-9972	Shaft	229-1607	6F-6992	Cap - Ball-socket	297-7160
4J-3015	Shaft	325-6204	5H-0049	Hub - Fly-wheel	229-1608	6G-1633	Chain Gp	282-6565
4K-3004	Bearing - Trunnion Support	314-8632	5H-0051	Plate - Fly-wheel	229-1610	6G-1664	Adapter	297-7135
4K-3128	Bearing - Sleeve	314-8633	5H-0057	Ring - Bearing Thrust	229-1613	6G-1919	Cap - Pivot	243-0337
4N-2954	Sleeve - Camshaft	299-2059	5M-6120	Gear - Sun	213-8740	6G-2947	Shaft	243-0346
4N-3281	Line As - Fuel Injector	247-3362	5M-6210	Shaft - Planet	219-9683	6G-4525	Strip - Wear	282-6624
4N-3282	Line As - Fuel Injector	247-3363	5M-6211	Shaft - Planet	219-9684	6H-3957	Bearing - Ball	311-9358
4N-3283	Line As - Fuel Injector	247-3364	5M-7841	Gear - Ring	214-0525	6I-1346	Pump Gp - Oil	295-5674
4N-3284	Line As - Fuel Injector	247-3365	5M-7869	Gear - Ring	214-0530	6N-1036	Gear - Oil Pump	279-4991
4N-4864	Pump Gp - Fuel Transfer	242-3442	5M-7875	Carrier - Front	213-4495	6N-1965	Line As - Fuel Injector	250-7535
4N-5503	Adapter - Exhaust	299-1954	5M-7900	Bolt - Hex Head	311-9349	6N-1966	Line As - Fuel Injector	250-7536
4N-7693	Crankshaft As	242-3439	5P-7807	Bearing - Ball	314-8502	6N-2789	Pulley	264-5886
4N-8814	Line As - Fuel Injector	247-3366	5S-1211	Cover - Valve	314-8665	6N-8413	Housing - Pump	325-6110
4N-9587	Shield - Heat	297-7260	5S-1822	Chamber As	248-5406	7B-2420	Ferrule - Director	314-8517
4P-0660	Muffler As	298-2787	5S-1833	Chamber As	247-3298	7B-5036	Shaft - Bracket	297-7251
4P-3546	Valve As - Relief	325-6236	5S-4557	Bearing	311-9360	7C-4297	Seal As - Camshaft	325-6192
			5S-6795	Chamber As	242-3437	7D-2199	Sleeve As	228-9563
			5S-7609	Pulley - Alt Drive	264-5881	7D-2267	Link As	228-9564
			5S-9080	Pulley - Alt Drive	264-5883	7D-2637	Gear - Worm	231-8761
			5T-8500	Shoe - Circle Drive	243-0359	7D-3815	Gear - Final Drive	228-9419
						7D-4519	Shaft	245-5807
						7D-4523	Coupling	245-5817

(Continued)

Sales Model 12F (Continued)

Original Part Number	Part Name	Classic Part Number
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6436	Pinion - Reverse	243-0344
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7D-7385	Shaft	228-9420
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7D-7854	Support - Rack	228-8913
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686

Original Part Number	Part Name	Classic Part Number
7N-9145	Gear - Fly-wheel	279-4994
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0926	Rod As - Tie Lh	228-9422
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5347	Shaft - Drive Pinion	243-0352
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-8623	Gear - Sun	213-8755
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9D-6638	Strip - Wear	297-7263
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2049	Gear - Ring	214-0533
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891

(Continued)

Sales Model 12F (Continued)

Original Part Number	Part Name	Classic Part Number
9S-8679	Chamber As	325-6042

Sales Model 12G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
109-5562	Shaft	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear - Planet	275-5274
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365

Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
236-7724	Retainer	299-2048
244-1090	Alarm - Backup	360-2345
2F-5721	Bearing - Ball	311-9354
2G-2858	Cap - Pivot	243-0345
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560

Original Part Number	Part Name	Classic Part Number
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293
2P-5609	Muffler As	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2P-7830	Pump Gp	314-8533
2P-9632	Damper As	299-2004
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9094	Adapter - Exhaust	299-2534
2W-9978	Core As - Oil Cooler	279-4983
312-0782	Worm - Circle Drive	282-6623
3B-6218	Muffler As	247-2672
3J-6575	Trunnion	297-7265
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356

(Continued)

Sales Model 12G (Continued)

Original Part Number	Part Name	Classic Part Number
3P-0114	Elbow - Exhaust	314-8516
3P-0165	Pulley - Fan Drive	298-2775
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-3713	Gear As	275-5288
3P-5349	Piston As	275-5292
3P-5359	Piston - Clutch	299-2037
3P-5737	Shaft As - Clutch	275-5273
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5503	Adapter - Exhaust	299-1954
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-8942	Muffler As	298-2786
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236

Original Part Number	Part Name	Classic Part Number
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8472	Hood As	296-1355
4T-0998	Lever	314-8687
4V-0015	Plate - Lock	282-6563
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0470	Valve Gp	314-8549
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap - Lower	319-3433
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-3475	Shaft	297-7247
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-1878	Muffler As	360-7883

Original Part Number	Part Name	Classic Part Number
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6Y-0305	Cage As - Bearing	297-7150
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-5861	Adapter	243-0364
7D-6568	Cover As	228-9457
7D-7889	Gear - Ring	275-5276
7G-3450	Gear - Planet	275-5289
7G-3451	Gear - Planet	297-7188
7G-3452	Gear - Planet	275-5290
7G-3461	Gear - Planet	275-5291
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-9348	Pin	252-6872
7M-2167	Ring - Governor Control	308-9919
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9146	Gear - Fly-wheel Starter	279-4995

(Continued)

Sales Model 12G (Continued)

Original Part Number	Part Name	Classic Part Number
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-8631	Shaft As	275-5296
7T-2036	Cap As - Filter	361-1721
7T-9647	Piston - Clutch	275-5294
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft - Drive	275-5280
8D-3591	Carrier - Planet	301-4769
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8D-5344	Gear - Worm	243-0341
8D-7096	Pin - Axle Leaning	297-7219
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-9804	Housing - Drive	302-2682
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439

Original Part Number	Part Name	Classic Part Number
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7718	Manifold - Exhaust	295-0416
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8317	Sprocket	275-5287
9D-4441	Housing	297-7195
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9H-2256	Pump Gp	311-9443
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Motor Graders

Sales Model 14B

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428

Original Part Number	Part Name	Classic Part Number
1H-8037	Yoke - Fitting	228-9415
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431

Original Part Number	Part Name	Classic Part Number
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916

(Continued)

Sales Model 14B (Continued)

Original Part Number	Part Name	Classic Part Number
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-4187	Shell - Bearing	245-5794
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
3B-5067	Shaft - Shift Worm	228-8907
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-2149	Pinion	228-9450
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559

Original Part Number	Part Name	Classic Part Number
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6926	Segment - Control	228-9455
4D-7282	Shaft - Axle	228-9408
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Fly-wheel	229-1608

Original Part Number	Part Name	Classic Part Number
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5S-1211	Cover - Valve	314-8665
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9193	Hub - Final Drive Gear	228-9417
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6568	Cover As	228-9457
7D-6841	Joint As - Univ	228-9566
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350

(Continued)

Sales Model 14B (Continued)

Original Part Number	Part Name	Classic Part Number
8F-7422	Gear - Worm	228-9461
9D-2731	Spindle - Wheel	228-9423

Sales Model 14C

Original Part Number	Part Name	Classic Part Number
2D-1345	Drum - Brake	228-9430
2K-4507	Bearing - Sleeve	325-6021
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
5B-0577	Collar	299-1992

Original Part Number	Part Name	Classic Part Number
5D-3283	Coupling - Shaft	243-0339
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6F-6992	Cap - Ball-socket	297-7160
7D-6841	Joint As - Univ	228-9566
7M-7358	Valve - Inlet	298-2774

Original Part Number	Part Name	Classic Part Number
7N-0128	Core As - Oil Cooler	299-1994
7S-9749	Pulley - Gen Drive	264-5888
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
2K-6413	Pin	360-2270

Sales Model 14D

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1H-8037	Yoke - Fitting	228-9415
1M-6128	Manifold - Exhaust	261-0906
1S-4701	Pulley - Alt	264-5866
1W-4405	Gear - Crankshaft	279-4982
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-5795	Sleeve - Thrust	243-0360
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440

Original Part Number	Part Name	Classic Part Number
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2S-4015	Plunger As - Valve	311-9438
3B-5067	Shaft - Shift Worm	228-8907
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2149	Pinion	228-9450
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795

Original Part Number	Part Name	Classic Part Number
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597

(Continued)

Sales Model 14D (Continued)

Original Part Number	Part Name	Classic Part Number
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3462	Pin - Pivot	247-4440
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6680	Shaft - Steering Rear	228-9560
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334

Original Part Number	Part Name	Classic Part Number
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-7461	Pin	247-4441
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Fly-wheel	229-1608
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-9080	Pulley - Alt Drive	264-5883
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564

Original Part Number	Part Name	Classic Part Number
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6568	Cover As	228-9457
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7F-6269	Gear - Worm	245-5798
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
8D-0926	Rod As - Tie Lh	228-9422
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
2K-6413	Pin	360-2270

Sales Model 14E

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977	2G-4187	Shell - Bearing	245-5794	4D-0913	Arm - Steering	228-9402
131-3815	Seal Gp - Basic	325-6193	2K-4507	Bearing - Sleeve	325-6021	4D-0926	Pin	247-4439
172-5188	Shaft - Water Pump	325-6202	2P-1170	Shaft As - Gear	296-1367	4D-0930	Rod End - Tie	228-9404
172-6712	Impeller - Pump	325-6112	2P-1738	Plate As - Oil Pan	325-6164	4D-2184	Shaft - Low Pinion	229-1592
1A-2846	Cap As - Filler	311-9368	2P-1739	Tube As - Pump	325-6229	4D-2185	Shaft - Rev Idler	229-1593
1H-8037	Yoke - Fitting	228-9415	2P-1757	Hub - Fan Pulley	296-1357	4D-2198	Cage - Bearing	229-1594
1M-6128	Manifold - Exhaust	261-0906	2P-1781	Spacer - Oil Pump	325-6214	4D-2218	Gear - Coupling	229-1595
1N-3576	Block Gp - Cylinder	279-4978	2P-2406	Pulley	264-5870	4D-2219	Gear - Reverse	229-1597
1P-4303	Head As - Cylinder	242-3434	2P-2519	Tube As - Inlet	325-6230	4D-2220	Pinion - Transmission & Bevel	228-8920
1P-8554	Coupling - Exhaust	325-6052	2P-5609	Muffler As	247-2665	4D-2227	Pinion	228-9453
1P-9945	Bracket As - Fan	296-1344	2P-6128	Pulley	264-5872	4D-2229	Cage - Bearing	229-1598
1P-9946	Shaft - Fan	325-6194	2P-6245	Shaft As - Pump	325-6197	4D-2268	Cover - Shaft	228-9454
1P-9952	Impeller - Pump	314-8685	2P-7830	Pump Gp	314-8533	4D-3462	Pin - Pivot	247-4440
1S-1888	Bracket - Lamp	297-7147	2S-4015	Plunger As - Valve	311-9438	4D-3898	Gear - Bevel	228-8921
1S-4701	Pulley - Alt	264-5866	2W-1086	Cover As - Cylinder Head	325-6049	4D-3966	Gear - Reduction	228-8924
1W-4405	Gear - Crankshaft	279-4982	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4D-4863	Pinion	229-1599
2D-1345	Drum - Brake	228-9430	2W-7458	Crankshaft As	242-3439	4D-7213	Coupling	228-9406
2D-3467	Hub - Final Drive Gear	228-9396	2W-9978	Core As - Oil Cooler	279-4983	4D-7282	Shaft - Axle	228-9408
2D-3609	Shaft - Final Drive Pinion	228-8919	3B-5067	Shaft - Shift Worm	228-8907	4D-9934	Trunnion	229-1601
2D-4010	Adjuster - Bearing	228-8916	3B-9970	Worm	228-8908	4F-4974	Clamp	311-9373
2D-8212	Plate As - Press	229-1582	3D-0409	Arm - Pitman	228-9397	4H-2029	Gear - Reverse	229-1602
2F-5721	Bearing - Ball	311-9354	3D-4718	Bearing - Sleeve	245-5795	4J-3015	Shaft	325-6204
2F-5894	Drum - Brake	228-9439	3D-5457	Cage - Bearing	228-9400	4K-3004	Bearing - Trunnion Support	314-8632
2F-5969	Collar - Coupling	228-9440	3D-6672	Gear	229-1586	4K-3128	Bearing - Sleeve	314-8633
2F-5970	Collar - Coupling	228-9441	3D-9932	Cage - Bearing	228-9401	4N-4864	Pump Gp - Fuel Transfer	242-3442
2F-6046	Pinion - Reduction	228-9442	3F-0017	Gear - Coupling	229-1587	4N-7693	Crankshaft As	242-3439
2F-6050	Gear - Reduction	229-1584	3F-0018	Gear - Coupling	229-1588	4P-3546	Valve As - Relief	325-6236
2F-6051	Gear	229-1585	3F-0019	Collar - Coupling	229-1589	4S-6707	Piston - Clutch	215-1686
2F-6053	Gear - Reduction	228-9443	3L-1425	Bearing - Ball	311-9356	4S-8708	Housing - Clutch	216-3557
2F-6057	Gear - Reduction	228-9444	4B-5806	Shaft - Upper	243-0347	4S-8718	Cage - Carrier Bearing	217-7724
2G-2858	Cap - Pivot	243-0345				4W-0452	Seal As - Camshaft	325-6191
						5B-0577	Collar	299-1992

(Continued)

Sales Model 14E (Continued)

Original Part Number	Part Name	Classic Part Number
5D-0034	Plate - Re-tainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Re-duction	229-1605
5D-4010	Rack	228-8909
5D-5039	Ballstud	228-8910
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7461	Pin	247-4441
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5H-0049	Hub - Fly-wheel	229-1608
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-1777	Gear - Planet	245-5799
6D-1778	Gear - Planet	245-5800
6D-1779	Gear - Planet	245-5801
6D-2362	Worm	243-0361

Original Part Number	Part Name	Classic Part Number
6D-6114	Cap	245-5822
6D-6201	Ballstud	228-9103
6D-6943	Housing - Axle	228-9416
6D-8671	Bolt - Draft	243-0333
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-6992	Cap - Ball-socket	297-7160
6G-1664	Adapter	297-7135
6G-1919	Cap - Pivot	243-0337
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-2637	Gear - Worm	231-8761
7D-3815	Gear - Final Drive	228-9419
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6436	Pinion - Re-verse	243-0344
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7D-7385	Shaft	228-9420
7D-7442	Hub - Final Drive Gear	228-8918

Original Part Number	Part Name	Classic Part Number
7D-7854	Support - Rack	228-8913
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
4D-0929	Rod End - Tie	228-9403
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0926	Rod As - Tie Lh	228-9422
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5347	Shaft - Drive Pinion	243-0352
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-8623	Gear - Sun	213-8755

(Continued)

Sales Model 14E (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
8M-8642	Housing - Clutch	219-9669	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)	9M-1500	Shaft - Planet	219-9685
8M-8644	Housing - Clutch	215-1782	8N-3325	Arm Gp - Rocker	314-8623	9M-1995	Gear - Sun	213-8756
8M-8646	Plate As - Center	216-3583	8N-3327	Arm Gp - Rocker	314-8624	9M-1996	Shaft - Planet	215-1875
8M-8650	Piston - Clutch	217-9778	8N-5929	Cover - Water Pump	296-1349	9M-2049	Gear - Ring	214-0533
8M-8677	Carrier - Planet	213-4449	8N-7315	Tube As - Outlet	325-6232	9M-4163	Valve - Exhaust	298-2773
8N-0002	Trunnion As	314-8728	8N-8225	Bearing - Main	314-8652	9M-4789	Shaft - Gov Control	297-7256
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8S-0248	Breather As	325-6033	9M-4955	Pump Gp - Fuel Transfer	242-3443
8N-1187	Head Gp - Cylinder	242-3435	8S-0493	Shaft As - Pump	325-6198	9N-5769	Cover - Housing	325-6050
8N-1721	Rod As - Conn	269-5291	8S-0905	Muffler As	302-2690	9S-2354	Manifold - Exhaust	261-0888
8N-1984	Rod As - Conn	242-3441	8S-3970	Chamber As	242-3438	9S-2355	Manifold - Exhaust	261-0891
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)	9D-2716	Spindle - Wheel	228-9463	9S-6129	Pulley - Alternator Drive	264-5891
			9D-2731	Spindle - Wheel	228-9423	9S-8679	Chamber As	325-6042
			9D-6638	Strip - Wear	297-7263	244-1090	Alarm - Backup	360-2345
			9H-2256	Pump Gp	311-9443	2K-6413	Pin	360-2270
						4B-1455	Cap As - Filter	361-1719

Sales Model 14G

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	172-5188	Shaft - Water Pump	325-6202	1W-1698	Housing - Transfer Pump	296-1356
104-4253	Line As - Fuel Injector	279-4988	172-5189	Impeller - Pump	295-5687	1W-4402	Gear - Camshaft	279-4981
104-4254	Line As - Fuel Injector	279-4989	172-5190	Impeller - Pump	325-6111	1W-4405	Gear - Crankshaft	279-4982
105-3196	Motor Gp - Gerotor	282-6547	172-6712	Impeller - Pump	325-6112	1W-5912	Tappet As - Guide	325-6223
111-8015	Gasket As - Head	279-4977	1N-3576	Block Gp - Cylinder	279-4978	1W-6541	Plunger As	325-6173
112-3249	Muffler As	247-2661	1N-3958	Elbow	325-6087	2F-5721	Bearing - Ball	311-9354
115-7550	Gasket - Plate	314-8667	1P-5480	Cover As - End	299-1998	2G-5876	Housing - Drive	302-2684
122-9405	Bracket As	325-6005	1P-8554	Coupling - Exhaust	325-6052	2G-8609	Pin	319-3450
131-3815	Seal Gp - Basic	325-6193	1P-9945	Bracket As - Fan	296-1344	2G-8618	Pin	299-2031
141-6137	Socket Gp	325-6212	1P-9946	Shaft - Fan	325-6194	2G-8622	Pin	299-2032
141-6138	Socket Gp	325-6213	1P-9952	Impeller - Pump	314-8685	2K-4507	Bearing - Sleeve	325-6021
148-7455	Valve - Exhaust	270-4361	1S-4701	Pulley - Alt	264-5866	2P-1170	Shaft As - Gear	296-1367
165-4262	Body As - Piston	270-4353 (Liner Kit)	1W-1219	Trunnion As	314-8724	2P-1738	Plate As - Oil Pan	325-6164
172-5185	Shaft - Water Pump	325-6201	1W-1669	Piston	325-6158	2P-1739	Tube As - Pump	325-6229
			1W-1695	Pump Gp	279-4980			

(Continued)

Sales Model 14G (Continued)

Original Part Number	Part Name	Classic Part Number
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4435	Plate	275-5295
2P-4443	Coupling - Flywheel	301-0233
2P-4510	Piston - Clutch	275-5293
2P-5609	Muffler As	247-2665
2P-6245	Shaft As - Pump	325-6197
2P-9632	Damper As	299-2004
2V-4332	Collar	299-1993
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3L-1425	Bearing - Ball	311-9356
3P-0165	Pulley - Fan Drive	298-2775
3P-0862	Carrier - Input	301-4764
3P-0894	Shaft As - Planet	302-3446
3P-1609	Carrier - Planet	302-4292
3P-1626	Hub As - Clutch	302-2687
3P-1651	Piston As	302-4296
3P-2692	Cage - Bearing	302-2663
3P-2769	Support As	299-2064
3P-2852	Clutch - Hub	301-4902
3P-2856	Plate - Clutch	302-2693
3P-2859	Drum As	301-4644
3P-6880	Housing As	302-2685
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633

Original Part Number	Part Name	Classic Part Number
4K-6558	Pin - Lower	302-2710
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-8561	Pin	299-2036
4K-8734	Bearing - Sleeve	299-1962
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4782	Pulley	325-6176
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-8472	Hood As	296-1355
4S-8670	Shaft - Planet	300-2590
4T-0998	Lever	314-8687
4V-0015	Plate - Lock	282-6563
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-7404	Nut - Bearing Lock	308-9878
5K-8330	Holder - Tooth	299-2013
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5T-3475	Shaft	297-7247
5T-5222	Shoe - Circle Guide	297-7261
5T-6298	Lever	299-2018
6D-4909	Cap - Pivot	297-7159
6D-8671	Bolt - Draft	243-0333

Original Part Number	Part Name	Classic Part Number
6G-4680	Adapter	302-2633
6G-6241	Gear - Worm	299-2010
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6Y-0580	Carrier - Planet	301-4768
7C-4297	Seal As - Camshaft	325-6192
7D-5859	Adapter	297-7136
7G-3454	Gear - Planet	300-2578
7G-3455	Gear - Planet	300-2582
7G-3456	Gear - Planet	300-2583
7J-9708	Bearing - Sleeve	299-1964
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978

(Continued)

Sales Model 14G (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7T-9647	Piston - Clutch	275-5294	8N-1721	Rod As - Conn	269-5291	8S-7716	Manifold - Exhaust	295-0415
7W-0450	Gear - Water Pump	279-4997	8N-1984	Rod As - Conn	242-3441	8S-7717	Manifold - Exhaust	261-0894
7W-0507	Gear - Oil Pump Drive	279-4998	8N-2510	Shaft	325-6208	8S-7718	Manifold - Exhaust	295-0416
7W-0508	Gear - Fuel Pump Drive	296-1351	8N-2641	Sleeve	325-6210	8W-5293	Pin	282-6570
7Y-1517	Pipe As - Tail	301-5246	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)	9D-5741	Worm - Circle Drive	297-7270
8D-2351	Pin	297-7217	8N-3251	Shaft As - Rocker Arm	314-8711	9D-5746	Gear - Worm	299-2011
8D-2452	Gear - Sun	297-7180	8N-3325	Arm Gp - Rocker	314-8623	9D-5921	Shaft - Drive Pinion	297-7254
8D-2459	Gear - Planet	297-7181	8N-3327	Arm Gp - Rocker	314-8624	9N-5769	Cover - Housing	325-6050
8D-2519	Shaft - Planet	300-2591	8N-5779	Coupling - Exhaust	325-6047	9S-2354	Manifold - Exhaust	261-0888
8D-2532	Carrier - Planet	301-4773	8N-5929	Cover - Water Pump	296-1349	9S-2355	Manifold - Exhaust	261-0891
8D-3665	Pin	297-7218	8N-6796	Head Gp - Cylinder	269-5290	9S-6129	Pulley - Alternator Drive	264-5891
8D-4673	Pin - Cylinder	302-2711	8N-7315	Tube As - Outlet	325-6232	9S-8679	Chamber As	325-6042
8D-9479	Gear - Diff Bevel	302-2670	8N-8225	Bearing - Main	314-8652	9T-4761	Head	325-6108
8D-9482	Gear - Diff Bevel	302-2673	8N-9733	Line As - Fuel Injector	319-8174	2K-6413	Pin	360-2270
8H-2810	Case As - Filter	314-8512	8S-0248	Breather As	325-6033	9D-7924	Mounting	360-2356
8N-0002	Trunnion As	314-8728	8S-0493	Shaft As - Pump	325-6198	244-1090	Alarm - Back up	360-2345
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8S-3970	Chamber As	242-3438	4B-1455	Cap As - Filter	361-1719
8N-1187	Head Gp - Cylinder	242-3435				8W-4167	Bearing - Sleeve	361-1694
						7T-2036	Cap As - Filter	361-1721

Sales Model 112

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431	2D-1345	Drum - Brake	228-9430	2F-5894	Drum - Brake	228-9439
121-7746	Precleaner As	360-2311	2D-1659	Rack - Shift	228-9431	2F-5969	Collar - Coupling	228-9440
1A-2846	Cap As - Filler	311-9368	2D-3467	Hub - Final Drive Gear	228-9396	2F-5970	Collar - Coupling	228-9441
1D-3996	Fork - Knuckle	228-9428	2D-4010	Adjuster - Bearing	228-8916	2F-6051	Gear	229-1585
1H-8037	Yoke - Fitting	228-9415	2D-4205	Block - Pivot	228-9432	2F-8001	Shaft - Worm	228-9445
1M-7250	Bowl - Pre-cleaner	360-2296	2D-4209	Pin - Pivot	228-9434	2F-9047	Block - Pivot	228-9446
1P-1721	Gear - Balance	298-2769	2D-4211	Arm - Steering	228-9435	2F-9074	Link - Tie Bar	228-9447
1P-1722	Gear - Balance	298-2770	2D-4215	Knuckle - Rh	228-9436	2G-4187	Shell - Bearing	245-5794
1S-1967	Chamber As	247-3291	2D-4216	Knuckle - Lh	228-9437	2S-1273	Chamber As	319-3434
1S-1970	Chamber As	247-3292	2D-5961	Pin - Axle Pivot	228-9438	2S-4015	Plunger As - Valve	311-9438
1W-4405	Gear - Crankshaft	279-4982	2D-6382	Gear - Worm	228-9558	3B-5067	Shaft - Shift Worm	228-8907
			2D-8212	Plate As - Press	229-1582	3B-6218	Muffler As	247-2672
			2F-5721	Bearing - Ball	311-9354	3B-6695	Gear - Worm	228-9448

(Continued)

Sales Model 112 (Continued)

Original Part Number	Part Name	Classic Part Number
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2149	Pinion	228-9450
3D-4442	Shaft - Rev Worm	243-0354
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-9194	Gear	245-5796
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6680	Shaft - Steering Rear	228-9560
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4H-7969	Bearing - Worm	245-5811
4N-7526	Seal As - Pump	311-9454

Original Part Number	Part Name	Classic Part Number
4N-9180	Seal As - Pump	311-9455
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5H-0049	Hub - Fly-wheel	229-1608
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-9164	Shaft - Pinion	243-0353
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564

Original Part Number	Part Name	Classic Part Number
7D-4688	Shaft As - Steering	228-9565
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7386	Shaft	228-9567
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9Y-9431	Precleaner As	361-1718

Sales Model 112E

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1D-3996	Fork - Knuckle	228-9428	3D-0409	Arm - Pitman	228-9397	4D-6680	Shaft - Steering Rear	228-9560
1H-8037	Yoke - Fitting	228-9415	3D-2136	Sprocket	228-9398	4D-6698	Bearing - Tandem Housing	228-9405
1P-1721	Gear - Balance	298-2769	3D-2149	Pinion	228-9450	4D-6926	Segment - Control	228-9455
1P-1722	Gear - Balance	298-2770	3D-2236	Sprocket As	228-9399	4D-7213	Coupling	228-9406
1W-4405	Gear - Crankshaft	279-4982	3D-4442	Shaft - Rev Worm	243-0354	4D-7282	Shaft - Axle	228-9408
2D-1345	Drum - Brake	228-9430	3D-4498	Shaft - Lower	243-0348	4D-9934	Trunnion	229-1601
2D-1659	Rack - Shift	228-9431	3D-4718	Bearing - Sleeve	245-5795	4H-2029	Gear - Reverse	229-1602
2D-3467	Hub - Final Drive Gear	228-9396	3D-5457	Cage - Bearing	228-9400	4H-7969	Bearing - Worm	245-5811
2D-4010	Adjuster - Bearing	228-8916	3D-6672	Gear	229-1586	5B-0577	Collar	299-1992
2D-4205	Block - Pivot	228-9432	3D-9194	Gear	245-5796	5D-0034	Plate - Retainer	228-9456
2D-4209	Pin - Pivot	228-9434	3D-9932	Cage - Bearing	228-9401	5D-0927	Shaft - Reduction	229-1605
2D-4211	Arm - Steering	228-9435	3F-0017	Gear - Coupling	229-1587	5D-3283	Coupling - Shaft	243-0339
2D-4215	Knuckle - Rh	228-9436	3F-0018	Gear - Coupling	229-1588	5D-3961	Block - Brake	245-5813
2D-4216	Knuckle - Lh	228-9437	3F-0019	Collar - Coupling	229-1589	5D-6201	Shoe - Yoke	243-0356
2D-5961	Pin - Axle Pivot	228-9438	3F-6334	End-tie Rod - Rh	228-9451	5D-7339	Coupling	245-5816
2D-6382	Gear - Worm	228-9558	3F-6338	End-tie Rod - Lh	228-9452	5D-7462	Pin	247-4442
2D-8212	Plate As - Press	229-1582	3K-3124	Muffler - Trap	247-2673	5D-9548	Hub - Final Drive Gear	228-9412
2F-5894	Drum - Brake	228-9439	4B-5806	Shaft - Upper	243-0347	5H-0049	Hub - Fly-wheel	229-1608
2F-5969	Collar - Coupling	228-9440	4B-7064	Shaft - Worm	245-5803	5H-0051	Plate - Fly-wheel	229-1610
2F-5970	Collar - Coupling	228-9441	4D-1626	Shaft - Lift Arm	245-5805	5H-0057	Ring - Bearing Thrust	229-1613
2F-6046	Pinion - Reduction	228-9442	4D-2184	Shaft - Low Pinion	229-1592	5S-1211	Cover - Valve	314-8665
2F-6050	Gear - Reduction	229-1584	4D-2185	Shaft - Rev Idler	229-1593	5S-1822	Chamber As	248-5406
2F-6051	Gear	229-1585	4D-2198	Cage - Bearing	229-1594	5S-1833	Chamber As	247-3298
2F-6053	Gear - Reduction	228-9443	4D-2220	Pinion - Transmission & Bevel	228-8920	6B-3158	Shoe - Yoke Lh	243-0357
2F-6057	Gear - Reduction	228-9444	4D-2227	Pinion	228-9453	6B-6911	Worm - Rh	245-5819
2F-8001	Shaft - Worm	228-9445	4D-2229	Cage - Bearing	229-1598	6B-6912	Worm - Lh	245-5820
2F-9047	Block - Pivot	228-9446	4D-2268	Cover - Shaft	228-9454	6B-6941	Bearing - Worm	245-5812
2F-9074	Link - Tie Bar	228-9447	4D-3898	Gear - Bevel	228-8921	6D-0687	Gear - Bevel	228-8922
2G-4187	Shell - Bearing	245-5794	4D-3966	Gear - Reduction	228-8924	6D-0708	Pinion	228-8923
2S-4015	Plunger As - Valve	311-9438	4D-4863	Pinion	229-1599	6D-1599	Block - Link Pivot	228-9414
3B-5067	Shaft - Shift Worm	228-8907	4D-5997	Pinion	245-5809	6D-1644	Shaft - Rod Pivot	228-9562
3B-6218	Muffler As	247-2672	4D-6664	Coupling - Shaft	243-0338	6D-6943	Housing - Axle	228-9416
3B-6695	Gear - Worm	228-9448	4D-6665	Shaft - Circle Rev	243-0349	6D-9164	Shaft - Pinion	243-0353
3B-9970	Worm	228-8908						

(Continued)

Sales Model 112E (Continued)

Original Part Number	Part Name	Classic Part Number
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457

Original Part Number	Part Name	Classic Part Number
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806

Original Part Number	Part Name	Classic Part Number
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8N-8225	Bearing - Main	314-8652
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9Y-9431	Precleaner As	361-1718

Sales Model 112F

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770

Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3467	Hub - Final Drive Gear	228-9396
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437

Original Part Number	Part Name	Classic Part Number
2D-5961	Pin - Axle Pivot	228-9438
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446

(Continued)

Sales Model 112F (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2F-9074	Link - Tie Bar	228-9447	3F-6611	Socket - Joint	256-4829	4N-7978	Shaft As - Balance	314-8710
2G-4187	Shell - Bearing	245-5794	3F-6612	Cap - Ball Joint	297-7155	4P-3546	Valve As - Relief	325-6236
2P-1170	Shaft As - Gear	296-1367	3K-3124	Muffler - Trap	247-2673	4W-0452	Seal As - Camshaft	325-6191
2P-1757	Hub - Fan Pulley	296-1357	3L-1425	Bearing - Ball	311-9356	5B-0577	Collar	299-1992
2P-1781	Spacer - Oil Pump	325-6214	4B-5806	Shaft - Upper	243-0347	5D-0034	Plate - Retainer	228-9456
2P-2519	Tube As - Inlet	325-6230	4B-7064	Shaft - Worm	245-5803	5D-0927	Shaft - Reduction	229-1605
2P-6245	Shaft As - Pump	325-6197	4D-1626	Shaft - Lift Arm	245-5805	5D-3283	Coupling - Shaft	243-0339
2P-6255	Muffler As	247-2666	4D-2184	Shaft - Low Pinion	229-1592	5D-3961	Block - Brake	245-5813
2P-7828	Pan - Oil	314-8691	4D-2185	Shaft - Rev Idler	229-1593	5D-6201	Shoe - Yoke	243-0356
2P-7830	Pump Gp	314-8533	4D-2198	Cage - Bearing	229-1594	5D-7339	Coupling	245-5816
2S-4015	Plunger As - Valve	311-9438	4D-2220	Pinion - Transmission & Bevel	228-8920	5D-7462	Pin	247-4442
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4D-2227	Pinion	228-9453	5D-9548	Hub - Final Drive Gear	228-9412
3B-5067	Shaft - Shift Worm	228-8907	4D-2229	Cage - Bearing	229-1598	5H-0049	Hub - Fly-wheel	229-1608
3B-6218	Muffler As	247-2672	4D-2268	Cover - Shaft	228-9454	5H-0051	Plate - Fly-wheel	229-1610
3B-6695	Gear - Worm	228-9448	4D-3898	Gear - Bevel	228-8921	5H-0057	Ring - Bearing Thrust	229-1613
3B-9970	Worm	228-8908	4D-3966	Gear - Reduction	228-8924	5P-7807	Bearing - Ball	314-8502
3D-0409	Arm - Pitman	228-9397	4D-4863	Pinion	229-1599	5S-1211	Cover - Valve	314-8665
3D-2149	Pinion	228-9450	4D-5997	Pinion	245-5809	5S-1822	Chamber As	248-5406
3D-4442	Shaft - Rev Worm	243-0354	4D-6664	Coupling - Shaft	243-0338	5S-1833	Chamber As	247-3298
3D-4498	Shaft - Lower	243-0348	4D-6665	Shaft - Circle Rev	243-0349	5S-4557	Bearing	311-9360
3D-4718	Bearing - Sleeve	245-5795	4D-6680	Shaft - Steering Rear	228-9560	5S-6795	Chamber As	242-3437
3D-5457	Cage - Bearing	228-9400	4D-6698	Bearing - Tandem Housing	228-9405	5S-7609	Pulley - Alt Drive	264-5881
3D-6672	Gear	229-1586	4D-6926	Segment - Control	228-9455	5S-8038	Pulley - Crankshaft	264-5882
3D-9194	Gear	245-5796	4D-7213	Coupling	228-9406	5S-9080	Pulley - Alt Drive	264-5883
3D-9502	Bolt - Draft	243-0332	4D-7282	Shaft - Axle	228-9408	6B-3158	Shoe - Yoke Lh	243-0357
3D-9932	Cage - Bearing	228-9401	4D-9934	Trunnion	229-1601	6B-6911	Worm - Rh	245-5819
3F-0017	Gear - Coupling	229-1587	4F-4974	Clamp	311-9373	6B-6912	Worm - Lh	245-5820
3F-0018	Gear - Coupling	229-1588	4H-2029	Gear - Reverse	229-1602	6B-6941	Bearing - Worm	245-5812
3F-0019	Collar - Coupling	229-1589	4H-7969	Bearing - Worm	245-5811	6D-0687	Gear - Bevel	228-8922
3F-6334	End-tie Rod - Rh	228-9451	4N-4864	Pump Gp - Fuel Transfer	242-3442	6D-0708	Pinion	228-8923
3F-6338	End-tie Rod - Lh	228-9452	4N-7692	Crankshaft As	242-3440	6D-1599	Block - Link Pivot	228-9414
3F-6523	Pin - Clevis	256-4818	4N-7977	Shaft As - Balance	314-8709	6D-1644	Shaft - Rod Pivot	228-9562
						6D-6943	Housing - Axle	228-9416
						6D-9164	Shaft - Pinion	243-0353

(Continued)

Sales Model 112F (Continued)

Original Part Number	Part Name	Classic Part Number
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Re-verse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907

Original Part Number	Part Name	Classic Part Number
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0508	Gear - Fuel Pump Drive	296-1351
8B-5972	Bearing - Ball	314-8503
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8N-0002	Trunnion As	314-8728

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1188	Head Gp - Cylinder	242-3436
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 120

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	1S-4701	Pulley - Alt	264-5866	2F-6051	Gear	229-1585
104-4253	Line As - Fuel Injector	279-4988	1W-1219	Trunnion As	314-8724	2F-6053	Gear - Reduction	228-9443
104-4254	Line As - Fuel Injector	279-4989	1W-1669	Piston	325-6158	2F-6057	Gear - Reduction	228-9444
111-8015	Gasket As - Head	279-4977	1W-1695	Pump Gp	279-4980	2F-8001	Shaft - Worm	228-9445
112-3249	Muffler As	247-2661	1W-1698	Housing - Transfer Pump	296-1356	2F-9047	Block - Pivot	228-9446
115-7550	Gasket - Plate	314-8667	1W-4402	Gear - Camshaft	279-4981	2F-9074	Link - Tie Bar	228-9447
121-7746	Precleaner As	360-2311	1W-4405	Gear - Crankshaft	279-4982	2G-4187	Shell - Bearing	245-5794
122-9405	Bracket As	325-6005	1W-5912	Tappet As - Guide	325-6223	2K-3592	Boss	314-8501
131-3815	Seal Gp - Basic	325-6193	1W-6541	Plunger As	325-6173	2P-1170	Shaft As - Gear	296-1367
148-7455	Valve - Exhaust	270-4361	244-1090	Alarm - Back up	360-2345	2P-1738	Plate As - Oil Pan	325-6164
153-3580	Shaft	299-2055	2D-1345	Drum - Brake	228-9430	2P-1739	Tube As - Pump	325-6229
165-4262	Body As - Piston	270-4353 (Liner Kit)	2D-1659	Rack - Shift	228-9431	2P-1757	Hub - Fan Pulley	296-1357
172-5185	Shaft - Water Pump	325-6201	2D-3467	Hub - Final Drive Gear	228-9396	2P-1781	Spacer - Oil Pump	325-6214
172-5188	Shaft - Water Pump	325-6202	2D-3609	Shaft - Final Drive Pinion	228-8919	2P-2406	Pulley	264-5870
172-5189	Impeller - Pump	295-5687	2D-4010	Adjuster - Bearing	228-8916	2P-2519	Tube As - Inlet	325-6230
172-5190	Impeller - Pump	325-6111	2D-4205	Block - Pivot	228-9432	2P-6128	Pulley	264-5872
172-6712	Impeller - Pump	325-6112	2D-4209	Pin - Pivot	228-9434	2P-6245	Shaft As - Pump	325-6197
172-7767	Pump Gp - Water	296-1365	2D-4211	Arm - Steering	228-9435	2P-7830	Pump Gp	314-8533
1D-3996	Fork - Knuckle	228-9428	2D-4215	Knuckle - Rh	228-9436	2S-4015	Plunger As - Valve	311-9438
1H-8037	Yoke - Fitting	228-9415	2D-4216	Knuckle - Lh	228-9437	2W-1086	Cover As - Cylinder Head	325-6049
1M-6128	Manifold - Exhaust	261-0906	2D-5795	Sleeve - Thrust	243-0360	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
1M-7250	Bowl - Pre-cleaner	360-2296	2D-5799	Pinion - Reverse	243-0342	2W-7255	Shaft - Water Pump	325-6203
1N-3576	Block Gp - Cylinder	279-4978	2D-5961	Pin - Axle Pivot	228-9438	2W-7458	Crankshaft As	242-3439
1N-3958	Elbow	325-6087	2D-6381	Pinion	228-8915	2W-9978	Core As - Oil Cooler	279-4983
1P-4303	Head As - Cylinder	242-3434	2D-6382	Gear - Worm	228-9558	3B-5067	Shaft - Shift Worm	228-8907
1P-9945	Bracket As - Fan	296-1344	2D-7933	Cover - Circle Rev	243-0340	3B-6218	Muffler As	247-2672
1P-9946	Shaft - Fan	325-6194	2D-8212	Plate As - Press	229-1582	3B-6695	Gear - Worm	228-9448
1P-9952	Impeller - Pump	314-8685	2F-5721	Bearing - Ball	311-9354	3B-9970	Worm	228-8908
1S-1888	Bracket - Lamp	297-7147	2F-5894	Drum - Brake	228-9439	3D-0409	Arm - Pitman	228-9397
			2F-5969	Collar - Coupling	228-9440	3D-2136	Sprocket	228-9398
			2F-5970	Collar - Coupling	228-9441	3D-2149	Pinion	228-9450
			2F-6046	Pinion - Reduction	228-9442	3D-2236	Sprocket As	228-9399
			2F-6050	Gear - Reduction	229-1584	3D-4442	Shaft - Rev Worm	243-0354

(Continued)

Sales Model 120 (Continued)

Original Part Number	Part Name	Classic Part Number
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809

Original Part Number	Part Name	Classic Part Number
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6680	Shaft - Steering Rear	228-9560
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8708	Housing - Clutch	216-3557

Original Part Number	Part Name	Classic Part Number
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819

(Continued)

Sales Model 120 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
6B-6912	Worm - Lh	245-5820	7D-6524	Shaft - Axle	228-8917	7S-6723	Bracket - Alternator	299-1978
6B-6941	Bearing - Worm	245-5812	7D-6568	Cover As	228-9457	7S-6902	Gear - Sun	229-1619
6D-0687	Gear - Bevel	228-8922	7D-6588	Worm	243-0362	7S-6964	Gear - Ring	214-0532
6D-0708	Pinion	228-8923	7D-6841	Joint As - Univ	228-9566	7S-7809	Cap As - Radiator	295-6417
6D-1599	Block - Link Pivot	228-9414	7D-7075	Worm	243-0363	7S-9749	Pulley - Gen Drive	264-5888
6D-1644	Shaft - Rod Pivot	228-9562	7D-7078	Shaft - Rev Worm	243-0355	7W-0450	Gear - Water Pump	279-4997
6D-2362	Worm	243-0361	7D-7289	Hub As Brake	229-1617	7W-0507	Gear - Oil Pump Drive	279-4998
6D-6943	Housing - Axle	228-9416	7D-7386	Shaft	228-9567	7W-0508	Gear - Fuel Pump Drive	296-1351
6D-9164	Shaft - Pinion	243-0353	7D-7427	Sprocket	228-9458	7W-5687	Hub - Camshaft	314-8684
6D-9193	Hub - Final Drive Gear	228-9417	7D-7442	Hub - Final Drive Gear	228-8918	7Y-1517	Pipe As - Tail	301-5246
6D-9294	Shaft	228-9418	7F-6269	Gear - Worm	245-5798	8D-0527	Gear	229-1621
6F-5201	Gear - Worm	245-5797	7F-9263	Cap - Pivot	243-0336	8D-0682	Shaft	245-5806
6F-6992	Cap - Ball-socket	297-7160	7G-2475	Gear - Planet	223-4815	8D-0994	Rod As - Tie Rh	228-9459
6G-1633	Chain Gp	282-6565	7G-2476	Gear - Planet	223-4816	8D-0995	Rod As - Tie Lh	228-9460
6G-2947	Shaft	243-0346	7G-2513	Gear - Planet	215-1734	8D-1769	Plate - Driving	229-1622
6H-3957	Bearing - Ball	311-9358	7M-2167	Ring - Governor Control	308-9919	8D-5344	Gear - Worm	243-0341
6I-1346	Pump Gp - Oil	295-5674	7M-4603	Body - Fuel Valve	311-9348	8D-5346	Shaft - Drive Pinion	243-0350
6N-1036	Gear - Oil Pump	279-4991	7M-4926	Retainer - Pin	314-8538	8F-7422	Gear - Worm	228-9461
6N-1965	Line As - Fuel Injector	250-7535	7M-7358	Valve - Inlet	298-2774	8H-2810	Case As - Filter	314-8512
6N-1966	Line As - Fuel Injector	250-7536	7N-0128	Core As - Oil Cooler	299-1994	8H-9806	Gear - Shaft Drive	325-6091
6N-2789	Pulley	264-5886	7N-0165	Core As - Oil Cooler	295-5670	8M-0874	Plunger As - Valve	311-9439
6N-8413	Housing - Pump	325-6110	7N-2871	Line As - Fuel Injector	319-8172	8M-8623	Gear - Sun	213-8755
6T-1980	Collar - Idler End	226-0210	7N-2872	Line As - Fuel Injector	319-8173	8M-8642	Housing - Clutch	219-9669
7B-2420	Ferrule - Director	314-8517	7N-2874	Line As - Fuel Injector	298-2779	8M-8644	Housing - Clutch	215-1782
7B-5036	Shaft - Bracket	297-7251	7N-2875	Line As - Fuel Injector	298-2780	8M-8646	Plate As - Center	216-3583
7C-4297	Seal As - Camshaft	325-6192	7N-2876	Line As - Fuel Injector	298-2781	8M-8650	Piston - Clutch	217-9778
7D-2199	Sleeve As	228-9563	7N-3486	Manifold - Exhaust	261-0899	8M-8677	Carrier - Planet	213-4449
7D-2267	Link As	228-9564	7N-3515	Gear - Camshaft	314-8669	8N-0002	Trunnion As	314-8728
7D-3815	Gear - Final Drive	228-9419	7N-3536	Gear - Fuel	279-4993	8N-0875	Valve - Exhaust (Valve), 241-3381 (Valve Kit)	
7D-4688	Shaft As - Steering	228-9565	7N-5910	Impeller - Pump	314-8686	8N-1187	Head Gp - Cylinder	242-3435
7D-5446	Shaft As - Control Drive	229-1616	7N-9146	Gear - Fly-wheel Starter	279-4995			
7D-5813	Gear - Worm	228-8911	7N-9312	Damper As - Camshaft	299-2005			
7D-5847	Pinion	228-8912	7N-9805	Pin - Piston	295-6438			
7D-6516	Pinion - Reverse	243-0343	7S-3161	Lifter - Valve	279-4996			

(Continued)

Sales Model 120 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349

Original Part Number	Part Name	Classic Part Number
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443

Original Part Number	Part Name	Classic Part Number
9M-1500	Shaft - Planet	219-9685
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2049	Gear - Ring	214-0533
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 120B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111

Original Part Number	Part Name	Classic Part Number
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981

Original Part Number	Part Name	Classic Part Number
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Backup	360-2345
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558

(Continued)

Sales Model 120B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2D-7933	Cover - Circle Rev	243-0340	3B-6695	Gear - Worm	228-9448	4D-2229	Cage - Bearing	229-1598
2D-8212	Plate As - Press	229-1582	3B-9970	Worm	228-8908	4D-2268	Cover - Shaft	228-9454
2F-5721	Bearing - Ball	311-9354	3D-0409	Arm - Pitman	228-9397	4D-3898	Gear - Bevel	228-8921
2F-5894	Drum - Brake	228-9439	3D-2136	Sprocket	228-9398	4D-3966	Gear - Reduction	228-8924
2F-5969	Collar - Coupling	228-9440	3D-2149	Pinion	228-9450	4D-4863	Pinion	229-1599
2F-5970	Collar - Coupling	228-9441	3D-2236	Sprocket As	228-9399	4D-5997	Pinion	245-5809
2F-6046	Pinion - Reduction	228-9442	3D-4442	Shaft - Rev Worm	243-0354	4D-6664	Coupling - Shaft	243-0338
2F-6050	Gear - Reduction	229-1584	3D-4443	Shaft - Rev Worm	243-0351	4D-6665	Shaft - Circle Rev	243-0349
2F-6051	Gear	229-1585	3D-4498	Shaft - Lower	243-0348	4D-6680	Shaft - Steering Rear	228-9560
2F-6053	Gear - Reduction	228-9443	3D-4718	Bearing - Sleeve	245-5795	4D-6698	Bearing - Tandem Housing	228-9405
2F-6057	Gear - Reduction	228-9444	3D-5457	Cage - Bearing	228-9400	4D-6926	Segment - Control	228-9455
2F-8001	Shaft - Worm	228-9445	3D-6672	Gear	229-1586	4D-7213	Coupling	228-9406
2F-9047	Block - Pivot	228-9446	3D-9194	Gear	245-5796	4D-7282	Shaft - Axle	228-9408
2F-9074	Link - Tie Bar	228-9447	3D-9502	Bolt - Draft	243-0332	4D-9934	Trunnion	229-1601
2G-4187	Shell - Bearing	245-5794	3D-9786	Ballstud	228-9559	4F-4974	Clamp	311-9373
2K-3592	Boss	314-8501	3D-9932	Cage - Bearing	228-9401	4H-2029	Gear - Reverse	229-1602
2P-1170	Shaft As - Gear	296-1367	3F-0017	Gear - Coupling	229-1587	4H-7969	Bearing - Worm	245-5811
2P-1738	Plate As - Oil Pan	325-6164	3F-0018	Gear - Coupling	229-1588	4N-2954	Sleeve - Camshaft	299-2059
2P-1757	Hub - Fan Pulley	296-1357	3F-0019	Collar - Coupling	229-1589	4N-3281	Line As - Fuel Injector	247-3362
2P-1781	Spacer - Oil Pump	325-6214	3F-6334	End-tie Rod - Rh	228-9451	4N-3282	Line As - Fuel Injector	247-3363
2P-2406	Pulley	264-5870	3F-6338	End-tie Rod - Lh	228-9452	4N-3283	Line As - Fuel Injector	247-3364
2P-2519	Tube As - Inlet	325-6230	3K-3124	Muffler - Trap	247-2673	4N-3284	Line As - Fuel Injector	247-3365
2P-6128	Pulley	264-5872	3L-1425	Bearing - Ball	311-9356	4N-4864	Pump Gp - Fuel Transfer	242-3442
2P-6245	Shaft As - Pump	325-6197	4B-5806	Shaft - Upper	243-0347	4N-7693	Crankshaft As	242-3439
2P-7830	Pump Gp	314-8533	4B-7064	Shaft - Worm	245-5803	4N-8591	Coupling - Exhaust	325-6053
2W-1086	Cover As - Cylinder Head	325-6049	4D-1626	Shaft - Lift Arm	245-5805	4N-8814	Line As - Fuel Injector	247-3366
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4D-2184	Shaft - Low Pinion	229-1592	4N-9587	Shield - Heat	297-7260
2W-7255	Shaft - Water Pump	325-6203	4D-2185	Shaft - Rev Idler	229-1593	4P-0660	Muffler As	298-2787
2W-7458	Crankshaft As	242-3439	4D-2198	Cage - Bearing	229-1594	4P-3546	Valve As - Relief	325-6236
3B-5067	Shaft - Shift Worm	228-8907	4D-2218	Gear - Coupling	229-1595	4P-9381	Line As - Fuel Injector	279-4984
3B-6218	Muffler As	247-2672	4D-2219	Gear - Reverse	229-1597	4P-9382	Line As - Fuel Injector	279-4985
			4D-2220	Pinion - Transmission & Bevel	228-8920			
			4D-2227	Pinion	228-9453			

(Continued)

Sales Model 120B (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5H-0049	Hub - Fly-wheel	229-1608
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361

Original Part Number	Part Name	Classic Part Number
6D-6943	Housing - Axle	228-9416
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336

Original Part Number	Part Name	Classic Part Number
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622

(Continued)

Sales Model 120B (Continued)

Original Part Number	Part Name	Classic Part Number
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441

Original Part Number	Part Name	Classic Part Number
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652

Original Part Number	Part Name	Classic Part Number
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 120G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626

Original Part Number	Part Name	Classic Part Number
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
147-3309	Spindle	282-6628
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087

Original Part Number	Part Name	Classic Part Number
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715

(Continued)

Sales Model 120G (Continued)

Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2G-2858	Cap - Pivot	243-0345
2G-6157	Pin	282-6550
2G-6336	Hub - Brake	282-6551
2G-6375	Shaft - Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7829	Housing As - Drive	297-7196
2G-8239	Yoke As	282-6632
2G-8609	Pin	319-3450
2G-8612	Pin	282-6552
2G-8616	Pin	282-6554
2G-8620	Pin	282-6556
2G-8628	Pin	282-6559
2G-8633	Pin	282-6561
2G-8736	Bearing - Sleeve	299-1959
2G-8769	Pin	282-6562
2G-8872	Shaft - Bevel	275-5271
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tight-ener	298-2794
2W-1086	Cover As - Cylinder Head	325-6049

Original Part Number	Part Name	Classic Part Number
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
312-0782	Worm - Circle Drive	282-6623
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Ex-haust	314-8516
3P-0165	Pulley - Fan Drive	298-2775
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-3713	Gear As	275-5288
3P-5349	Piston As	275-5292
3P-5359	Piston - Clutch	299-2037
3P-5737	Shaft As - Clutch	275-5273
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4N-2954	Sleeve - Cam-shaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-7526	Seal As - Pump	311-9454
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710

Original Part Number	Part Name	Classic Part Number
4N-8942	Muffler As	298-2786
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4T-0998	Lever	314-8687
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0470	Valve Gp	314-8549
5K-0990	Pin	299-2035
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-2925	Strip - Wear	282-6564
5T-2926	Shoe - Circle Guide	302-2699
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359
5T-8501	Shoe - Circle Drive	243-0358
6F-6992	Cap - Ball-socket	297-7160
6G-1100	Shaft - Drive	297-7248
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198

(Continued)

Sales Model 120G (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
6G-1919	Cap - Pivot	243-0337	7N-5910	Impeller - Pump	314-8686	8N-1187	Head Gp - Cylinder	242-3435
6G-2947	Shaft	243-0346	7N-6677	Core As - Oil Cooler	299-1995	8N-1188	Head Gp - Cylinder	242-3436
6G-4525	Strip - Wear	282-6624	7N-9145	Gear - Fly-wheel	279-4994	8N-1721	Rod As - Conn	269-5291
6H-3957	Bearing - Ball	311-9358	7N-9146	Gear - Fly-wheel Starter	279-4995	8N-1984	Rod As - Conn	242-3441
6I-1346	Pump Gp - Oil	295-5674	7N-9805	Pin - Piston	295-6438	8N-2510	Shaft	325-6208
6K-4190	Cap - Lower	297-7161	7S-3161	Lifter - Valve	279-4996	8N-2641	Sleeve	325-6210
6K-4191	Cap - Upper	300-2576	7S-6723	Bracket - Alternator	299-1978	8N-3183	Piston Gp - Basic (Liner Kit)	250-6556
6K-4193	Plate - Lock	282-6566	7S-7809	Cap As - Radiator	295-6417	8N-3251	Shaft As - Rocker Arm	314-8711
6N-1036	Gear - Oil Pump	279-4991	7S-8631	Shaft As	275-5296	8N-3311	Shaft As - Rocker Arm	325-6199
6N-1553	Coupling - Exhaust	295-6422	7S-9749	Pulley - Gen Drive	264-5888	8N-3312	Shaft As - Rocker Arm	325-6200
6N-1878	Muffler As	360-7883	7T-2036	Cap As - Filter	361-1721	8N-3325	Arm Gp - Rocker	314-8623
6N-8413	Housing - Pump	325-6110	7T-9647	Piston - Clutch	275-5294	8N-3327	Arm Gp - Rocker	314-8624
6Y-0305	Cage As - Bearing	297-7150	7W-0450	Gear - Water Pump	279-4997	8N-5929	Cover - Water Pump	296-1349
7B-2420	Ferrule - Director	314-8517	7W-0507	Gear - Oil Pump Drive	279-4998	8N-6796	Head Gp - Cylinder	269-5290
7B-5036	Shaft - Bracket	297-7251	7W-0508	Gear - Fuel Pump Drive	296-1351	8N-7315	Tube As - Outlet	325-6232
7C-4297	Seal As - Camshaft	325-6192	7W-3042	Tube As - Drain	325-6231	8N-8225	Bearing - Main	314-8652
7D-5861	Adapter	243-0364	7Y-1517	Pipe As - Tail	301-5246	8N-9733	Line As - Fuel Injector	319-8174
7F-9547	Pin As - Drawbar	295-0414	8D-2429	Pin As	319-3445	8S-0248	Breather As	325-6033
7G-3450	Gear - Planet	275-5289	8D-5344	Gear - Worm	243-0341	8S-0493	Shaft As - Pump	325-6198
7G-3451	Gear - Planet	297-7188	8D-7174	Cover As	299-1997	8S-3970	Chamber As	242-3438
7G-3452	Gear - Planet	275-5290	8D-7427	Shaft - Drive Pinion	282-6568	8W-1751	Bracket As	288-8732
7G-3461	Gear - Planet	275-5291	8D-8633	Shaft - Drive	275-5281	8W-1752	Bracket - Rail	288-8733
7J-9884	Bearing - Sleeve	325-6016	8D-8634	Gear - Planet	275-5275	8W-1753	Bracket - Rail	288-8734
7M-4204	Manifold - Exhaust	261-0901	8D-8638	Gear - Sun	275-5279	8W-2307	Shaft - Planet	275-5284
7M-4603	Body - Fuel Valve	311-9348	8D-8639	Gear - Ring	275-5277	8W-4066	Bracket - Rail	288-8735
7M-7358	Valve - Inlet	298-2774	8D-8805	Cover	299-2002	8W-4067	Bracket - Rail	288-8736
7N-0128	Core As - Oil Cooler	299-1994	8D-9804	Housing - Drive	302-2682	8W-5092	Pinion - Circle Drive	282-6569
7N-0165	Core As - Oil Cooler	295-5670	8D-9815	Pin - Cylinder	297-7220	8W-5293	Pin	282-6570
7N-2871	Line As - Fuel Injector	319-8172	8H-2810	Case As - Filter	314-8512	8W-6497	Pin	319-3465
7N-2872	Line As - Fuel Injector	319-8173	8H-9806	Gear - Shaft Drive	325-6091	8W-8286	Sprocket	299-2061
7N-2874	Line As - Fuel Injector	298-2779	8N-0002	Trunnion As	314-8728	8W-8288	Sprocket	299-2062
7N-3515	Gear - Camshaft	314-8669	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8W-8289	Sprocket	282-6629
7N-3536	Gear - Fuel	279-4993				8W-8628	Spindle - Front Axle	282-6571
7N-5511	Gear As - Idler	233-2180						

(Continued)

Sales Model 120G (Continued)

Original Part Number	Part Name	Classic Part Number
9D-1177	Shaft - Drive Pinion	297-7253
9D-1487	Housing - Drive	297-7194
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980

Original Part Number	Part Name	Classic Part Number
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151

Original Part Number	Part Name	Classic Part Number
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 130G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
109-5562	Shaft	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
115-7550	Gasket - Plate	314-8667
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear - Planet	275-5274
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202

Original Part Number	Part Name	Classic Part Number
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982

Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
236-7724	Retainer	299-2048
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2G-2858	Cap - Pivot	243-0345
2G-7829	Housing As - Drive	297-7196
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049

(Continued)

Sales Model 130G (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4N-8942	Muffler As	298-2786	6G-4525	Strip - Wear	282-6624
2W-7255	Shaft - Water Pump	325-6203	4N-9587	Shield - Heat	297-7260	6H-3957	Bearing - Ball	311-9358
2W-7458	Crankshaft As	242-3439	4P-3546	Valve As - Relief	325-6236	6I-1346	Pump Gp - Oil	295-5674
2W-7678	Gear - Water Pump	325-6088	4P-9381	Line As - Fuel Injector	279-4984	6N-1036	Gear - Oil Pump	279-4991
312-0782	Worm - Circle Drive	282-6623	4P-9382	Line As - Fuel Injector	279-4985	6N-1553	Coupling - Exhaust	295-6422
3F-6523	Pin - Clevis	256-4818	4P-9961	Line As - Fuel Injector	325-6115	6N-1878	Muffler As	360-7883
3L-1425	Bearing - Ball	311-9356	4P-9962	Line As - Fuel Injector	325-6116	6N-8413	Housing - Pump	325-6110
3P-0114	Elbow - Exhaust	314-8516	4P-9963	Line As - Fuel Injector	298-2777	6Y-0305	Cage As - Bearing	297-7150
3P-0165	Pulley - Fan Drive	298-2775	4P-9964	Line As - Fuel Injector	298-2778	7B-5036	Shaft - Bracket	297-7251
3P-0297	Shaft As	275-5297	4T-0998	Lever	314-8687	7C-4297	Seal As - Camshaft	325-6192
3P-0307	Cage As - Bearing	300-2572	4V-0015	Plate - Lock	282-6563	7D-5861	Adapter	243-0364
3P-0324	Coupling	301-0234	4W-0452	Seal As - Camshaft	325-6191	7D-6568	Cover As	228-9457
3P-0335	Platepress	297-7228	5B-0577	Collar	299-1992	7D-7889	Gear - Ring	275-5276
3P-0726	Shaft As	275-5298	5D-0470	Valve Gp	314-8549	7F-9547	Pin As - Drawbar	295-0414
3P-0785	Hub As - Clutch	302-2688	5K-0871	Pin - Lower	282-6630	7G-3450	Gear - Planet	275-5289
3P-3713	Gear As	275-5288	5K-0989	Cap - Upper	297-7158	7G-3451	Gear - Planet	297-7188
3P-5349	Piston As	275-5292	5K-0990	Pin	299-2035	7G-3452	Gear - Planet	275-5290
3P-5359	Piston - Clutch	299-2037	5K-0991	Cap - Lower	319-3433	7G-3461	Gear - Planet	275-5291
3P-5737	Shaft As - Clutch	275-5273	5P-7807	Bearing - Ball	314-8502	7J-6461	Crown	325-6054
4B-1455	Cap As - Filter	361-1719	5S-6795	Chamber As	242-3437	7J-9884	Bearing - Sleeve	325-6016
4F-4974	Clamp	311-9373	5S-7944	Shaft - Planet	297-7246	7N-0128	Core As - Oil Cooler	299-1994
4K-3004	Bearing - Trunnion Support	314-8632	5S-7945	Shaft As - Planet	275-5299	7N-0165	Core As - Oil Cooler	295-5670
4N-2954	Sleeve - Camshaft	299-2059	5S-9080	Pulley - Alt Drive	264-5883	7N-2871	Line As - Fuel Injector	319-8172
4N-3281	Line As - Fuel Injector	247-3362	5T-0906	Cover	282-6625	7N-2872	Line As - Fuel Injector	319-8173
4N-3282	Line As - Fuel Injector	247-3363	5T-1362	Bearing - Spider	325-6011	7N-2874	Line As - Fuel Injector	298-2779
4N-3283	Line As - Fuel Injector	247-3364	5T-2925	Strip - Wear	282-6564	7N-3515	Gear - Camshaft	314-8669
4N-3284	Line As - Fuel Injector	247-3365	5T-2926	Shoe - Circle Guide	302-2699	7N-3536	Gear - Fuel	279-4993
4N-7692	Crankshaft As	242-3440	5T-6298	Lever	299-2018	7N-5910	Impeller - Pump	314-8686
4N-7693	Crankshaft As	242-3439	5T-8500	Shoe - Circle Drive	243-0359	7N-9145	Gear - Fly-wheel	279-4994
4N-7977	Shaft As - Balance	314-8709	5T-8501	Shoe - Circle Drive	243-0358	7N-9805	Pin - Piston	295-6438
4N-7978	Shaft As - Balance	314-8710	6F-6992	Cap - Ball-socket	297-7160	7S-3161	Lifter - Valve	279-4996
			6G-1633	Chain Gp	282-6565	7S-6723	Bracket - Alternator	299-1978
			6G-1664	Adapter	297-7135	7S-8631	Shaft As	275-5296
			6G-1908	Housing As - Drive	297-7198	7T-2036	Cap As - Filter	361-1721
			6G-1919	Cap - Pivot	243-0337			
			6G-2947	Shaft	243-0346			

(Continued)

Sales Model 130G (Continued)

Original Part Number	Part Name	Classic Part Number
7T-9647	Piston - Clutch	275-5294
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
7Y-1517	Pipe As - Tail	301-5246
8D-1784	Pin	282-6567
8D-2429	Pin As	319-3445
8D-2469	Shaft - Drive	275-5280
8D-3591	Carrier - Planet	301-4769
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8D-5344	Gear - Worm	243-0341
8D-7096	Pin - Axle Leaning	297-7219
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-9804	Housing - Drive	302-2682
8H-2810	Case As - Filter	314-8512
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198

Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8317	Sprocket	275-5287
9D-1177	Shaft - Drive Pinion	297-7253
9D-1487	Housing - Drive	297-7194
9D-4441	Housing	297-7195
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 140

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415

Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1P-4303	Head As - Cylinder	242-3434
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685

Original Part Number	Part Name	Classic Part Number
1S-4701	Pulley - Alt	264-5866
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Backup	360-2345
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919

(Continued)

Sales Model 140 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2D-4010	Adjuster - Bearing	228-8916	2P-2519	Tube As - Inlet	325-6230	4B-7064	Shaft - Worm	245-5803
2D-4205	Block - Pivot	228-9432	2P-5609	Muffler As	247-2665	4D-0913	Arm - Steering	228-9402
2D-4209	Pin - Pivot	228-9434	2P-6128	Pulley	264-5872	4D-0926	Pin	247-4439
2D-4211	Arm - Steering	228-9435	2P-6245	Shaft As - Pump	325-6197	4D-0929	Rod End - Tie	228-9403
2D-4215	Knuckle - Rh	228-9436	2P-7830	Pump Gp	314-8533	4D-0930	Rod End - Tie	228-9404
2D-4216	Knuckle - Lh	228-9437	2W-1086	Cover As - Cylinder Head	325-6049	4D-1626	Shaft - Lift Arm	245-5805
2D-5795	Sleeve - Thrust	243-0360	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4D-2184	Shaft - Low Pinion	229-1592
2D-5799	Pinion - Reverse	243-0342	2W-7458	Crankshaft As	242-3439	4D-2185	Shaft - Rev Idler	229-1593
2D-5961	Pin - Axle Pivot	228-9438	2W-9978	Core As - Oil Cooler	279-4983	4D-2198	Cage - Bearing	229-1594
2D-6381	Pinion	228-8915	3B-5067	Shaft - Shift Worm	228-8907	4D-2218	Gear - Coupling	229-1595
2D-6382	Gear - Worm	228-9558	3B-6218	Muffler As	247-2672	4D-2219	Gear - Reverse	229-1597
2D-7933	Cover - Circle Rev	243-0340	3B-6695	Gear - Worm	228-9448	4D-2220	Pinion - Transmission & Bevel	228-8920
2D-8212	Plate As - Press	229-1582	3B-9970	Worm	228-8908	4D-2227	Pinion	228-9453
2F-5721	Bearing - Ball	311-9354	3D-0409	Arm - Pitman	228-9397	4D-2229	Cage - Bearing	229-1598
2F-5894	Drum - Brake	228-9439	3D-2136	Sprocket	228-9398	4D-2268	Cover - Shaft	228-9454
2F-5969	Collar - Coupling	228-9440	3D-2149	Pinion	228-9450	4D-3462	Pin - Pivot	247-4440
2F-5970	Collar - Coupling	228-9441	3D-2236	Sprocket As	228-9399	4D-3898	Gear - Bevel	228-8921
2F-6046	Pinion - Reduction	228-9442	3D-4443	Shaft - Rev Worm	243-0351	4D-3966	Gear - Reduction	228-8924
2F-6050	Gear - Reduction	229-1584	3D-4498	Shaft - Lower	243-0348	4D-4863	Pinion	229-1599
2F-6051	Gear	229-1585	3D-4718	Bearing - Sleeve	245-5795	4D-5997	Pinion	245-5809
2F-6053	Gear - Reduction	228-9443	3D-5457	Cage - Bearing	228-9400	4D-6664	Coupling - Shaft	243-0338
2F-6057	Gear - Reduction	228-9444	3D-6672	Gear	229-1586	4D-6665	Shaft - Circle Rev	243-0349
2F-8001	Shaft - Worm	228-9445	3D-9194	Gear	245-5796	4D-6680	Shaft - Steering Rear	228-9560
2F-9047	Block - Pivot	228-9446	3D-9502	Bolt - Draft	243-0332	4D-6698	Bearing - Tandem Housing	228-9405
2F-9074	Link - Tie Bar	228-9447	3D-9786	Ballstud	228-9559	4D-6926	Segment - Control	228-9455
2G-4187	Shell - Bearing	245-5794	3D-9932	Cage - Bearing	228-9401	4D-7213	Coupling	228-9406
2P-1170	Shaft As - Gear	296-1367	3F-0017	Gear - Coupling	229-1587	4D-7282	Shaft - Axle	228-9408
2P-1738	Plate As - Oil Pan	325-6164	3F-0018	Gear - Coupling	229-1588	4D-9934	Trunnion	229-1601
2P-1739	Tube As - Pump	325-6229	3F-0019	Collar - Coupling	229-1589	4F-4974	Clamp	311-9373
2P-1757	Hub - Fan Pulley	296-1357	3F-6334	End-tie Rod - Rh	228-9451	4H-2029	Gear - Reverse	229-1602
2P-1781	Spacer - Oil Pump	325-6214	3F-6338	End-tie Rod - Lh	228-9452	4H-7969	Bearing - Worm	245-5811
2P-2406	Pulley	264-5870	3K-3124	Muffler - Trap	247-2673	4N-4864	Pump Gp - Fuel Transfer	242-3442
			3L-1425	Bearing - Ball	311-9356			
			4B-1455	Cap As - Filter	361-1719			
			4B-5806	Shaft - Upper	243-0347			

(Continued)

Sales Model 140 (Continued)

Original Part Number	Part Name	Classic Part Number
4N-7693	Crankshaft As	242-3439
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-6707	Piston - Clutch	215-1686
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-6375	Shaft - Final Drive Pinion	228-9409
5D-7339	Coupling	245-5816
5D-7461	Pin	247-4441
5D-7462	Pin	247-4442
5D-9548	Hub - Final Drive Gear	228-9412
5D-9906	Shaft - Axle	228-9413
5D-9972	Shaft	229-1607
5H-0049	Hub - Fly-wheel	229-1608
5H-0051	Plate - Fly-wheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360

Original Part Number	Part Name	Classic Part Number
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-2362	Worm	243-0361
6D-6943	Housing - Axle	228-9416
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6G-1633	Chain Gp	282-6565
6G-2947	Shaft	243-0346
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
7B-5036	Shaft - Bracket	297-7251
7C-4297	Seal As - Camshaft	325-6192
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-3815	Gear - Final Drive	228-9419
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362

Original Part Number	Part Name	Classic Part Number
7D-6841	Joint As - Univ	228-9566
7D-7289	Hub As Brake	229-1617
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6902	Gear - Sun	229-1619
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0926	Rod As - Tie Lh	228-9422
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460
8D-1769	Plate - Driving	229-1622

(Continued)

Sales Model 140 (Continued)

Original Part Number	Part Name	Classic Part Number
8D-5344	Gear - Worm	243-0341
8D-5346	Shaft - Drive Pinion	243-0350
8F-7422	Gear - Worm	228-9461
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-8623	Gear - Sun	213-8755
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2049	Gear - Ring	214-0533
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Sales Model 140B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687

Original Part Number	Part Name	Classic Part Number
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
1D-3996	Fork - Knuckle	228-9428
1H-8037	Yoke - Fitting	228-9415
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356

Original Part Number	Part Name	Classic Part Number
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7933	Cover - Circle Rev	243-0340

(Continued)

Sales Model 140B (Continued)

Original Part Number	Part Name	Classic Part Number
2D-8212	Plate As - Press	229-1582
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-8001	Shaft - Worm	228-9445
2G-4187	Shell - Bearing	245-5794
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7830	Pump Gp	314-8533
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3B-5067	Shaft - Shift Worm	228-8907
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2149	Pinion	228-9450
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795

Original Part Number	Part Name	Classic Part Number
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588
3F-0019	Collar - Coupling	229-1589
3L-1425	Bearing - Ball	311-9356
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3462	Pin - Pivot	247-4440
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338
4D-6665	Shaft - Circle Rev	243-0349
4D-6926	Segment - Control	228-9455
4D-9934	Trunnion	229-1601
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-7969	Bearing - Worm	245-5811
4K-3004	Bearing - Trunnion Support	314-8632

Original Part Number	Part Name	Classic Part Number
4K-3128	Bearing - Sleeve	314-8633
4N-2954	Sleeve - Camshaft	299-2059
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
5B-0577	Collar	299-1992
5D-0034	Plate - Retainer	228-9456
5D-0395	Bracket - Rail Rh	243-0335
5D-0396	Bracket - Rail Lh	243-0334
5D-0927	Shaft - Reduction	229-1605
5D-3283	Coupling - Shaft	243-0339
5D-3961	Block - Brake	245-5813
5D-4010	Rack	228-8909
5D-6201	Shoe - Yoke	243-0356
5D-7339	Coupling	245-5816
5D-7461	Pin	247-4441
5H-0049	Hub - Flywheel	229-1608
5H-0051	Plate - Flywheel	229-1610
5H-0057	Ring - Bearing Thrust	229-1613
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5T-8500	Shoe - Circle Drive	243-0359
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414

(Continued)

Sales Model 140B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
6D-1644	Shaft - Rod Pivot	228-9562	7N-2871	Line As - Fuel Injector	319-8172	8N-0002	Trunnion As	314-8728
6D-2362	Worm	243-0361	7N-2872	Line As - Fuel Injector	319-8173	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
6D-6943	Housing - Axle	228-9416	7N-2874	Line As - Fuel Injector	298-2779	8N-1187	Head Gp - Cylinder	242-3435
6F-5201	Gear - Worm	245-5797	7N-2875	Line As - Fuel Injector	298-2780	8N-1721	Rod As - Conn	269-5291
6F-6992	Cap - Ball-socket	297-7160	7N-2876	Line As - Fuel Injector	298-2781	8N-1984	Rod As - Conn	242-3441
6G-2947	Shaft	243-0346	7N-3486	Manifold - Exhaust	261-0899	8N-2510	Shaft	325-6208
6G-4525	Strip - Wear	282-6624	7N-3515	Gear - Camshaft	314-8669	8N-2641	Sleeve	325-6210
6H-3957	Bearing - Ball	311-9358	7N-3536	Gear - Fuel	279-4993	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
6N-1036	Gear - Oil Pump	279-4991	7N-5910	Impeller - Pump	314-8686	8N-3251	Shaft As - Rocker Arm	314-8711
6N-2789	Pulley	264-5886	7N-9146	Gear - Fly-wheel Starter	279-4995	8N-3325	Arm Gp - Rocker	314-8623
6N-8413	Housing - Pump	325-6110	7N-9312	Damper As - Camshaft	299-2005	8N-3327	Arm Gp - Rocker	314-8624
7B-5036	Shaft - Bracket	297-7251	7N-9805	Pin - Piston	295-6438	8N-5929	Cover - Water Pump	296-1349
7D-2199	Sleeve As	228-9563	7S-3161	Lifter - Valve	279-4996	8N-6796	Head Gp - Cylinder	269-5290
7D-2267	Link As	228-9564	7S-7809	Cap As - Radiator	295-6417	8N-7315	Tube As - Outlet	325-6232
7D-3815	Gear - Final Drive	228-9419	7W-0450	Gear - Water Pump	279-4997	8N-8225	Bearing - Main	314-8652
7D-5446	Shaft As - Control Drive	229-1616	7W-0508	Gear - Fuel Pump Drive	296-1351	8N-9733	Line As - Fuel Injector	319-8174
7D-5813	Gear - Worm	228-8911	7W-3042	Tube As - Drain	325-6231	8S-0248	Breather As	325-6033
7D-5847	Pinion	228-8912	7W-5687	Hub - Camshaft	314-8684	8S-0493	Shaft As - Pump	325-6198
7D-6516	Pinion - Reverse	243-0343	7Y-1517	Pipe As - Tail	301-5246	8S-0905	Muffler As	302-2690
7D-6524	Shaft - Axle	228-8917	8D-0682	Shaft	245-5806	8S-3970	Chamber As	242-3438
7D-6568	Cover As	228-9457	8D-0926	Rod As - Tie Lh	228-9422	9D-2716	Spindle - Wheel	228-9463
7D-6588	Worm	243-0362	8D-1769	Plate - Driving	229-1622	9N-5769	Cover - Housing	325-6050
7D-6841	Joint As - Univ	228-9566	8D-5344	Gear - Worm	243-0341	9S-2355	Manifold - Exhaust	261-0891
7D-7289	Hub As Brake	229-1617	8D-5346	Shaft - Drive Pinion	243-0350	9S-6129	Pulley - Alternator Drive	264-5891
7D-7442	Hub - Final Drive Gear		8F-7422	Gear - Worm	228-9461	9S-8679	Chamber As	325-6042
7F-6269	Gear - Worm	245-5798	8H-2810	Case As - Filter	314-8512			
7F-9263	Cap - Pivot	243-0336						
7N-0128	Core As - Oil Cooler	299-1994						
7N-0165	Core As - Oil Cooler	295-5670						

Sales Model 140G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
109-5562	Shaft	275-5272
110-4652	Housing	302-2683
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5495	Joint Gp - Univ	297-4858
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
124-3240	Pin	282-6548
126-7130	Shaft As	275-5300
129-2381	Gear - Planet	275-5274
131-3736	Socket Gp - Basic	325-6211
131-3737	Socket As	282-6626
131-3738	Socket As	282-6627
131-3815	Seal Gp - Basic	325-6193
147-3400	Spindle	282-6549
148-7455	Valve - Exhaust	270-4361
153-3580	Shaft	299-2055
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-5480	Cover As - End	299-1998
1P-8554	Coupling - Exhaust	325-6052

Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
236-7724	Retainer	299-2048
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2G-2858	Cap - Pivot	243-0345
2G-8238	Yoke As	282-6631
2G-8609	Pin	319-3450
2G-8613	Pin	282-6553
2G-8617	Pin	282-6555
2G-8621	Pin	282-6557
2G-8625	Pin	282-6558
2G-8629	Pin	282-6560
2G-8633	Pin	282-6561
2G-9098	Cap	300-2573
2K-3592	Boss	314-8501
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-4435	Plate	275-5295
2P-4510	Piston - Clutch	275-5293

Original Part Number	Part Name	Classic Part Number
2P-5609	Muffler As	247-2665
2P-6245	Shaft As - Pump	325-6197
2P-9632	Damper As	299-2004
2S-6739	Pulley - Tightener	298-2794
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
312-0782	Worm - Circle Drive	282-6623
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
3P-0165	Pulley - Fan Drive	298-2775
3P-0297	Shaft As	275-5297
3P-0307	Cage As - Bearing	300-2572
3P-0324	Coupling	301-0234
3P-0335	Platepress	297-7228
3P-0726	Shaft As	275-5298
3P-0785	Hub As - Clutch	302-2688
3P-3713	Gear As	275-5288
3P-5349	Piston As	275-5292
3P-5359	Piston - Clutch	299-2037
3P-5737	Shaft As - Clutch	275-5273
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4K-3004	Bearing - Trunnion Support	314-8632
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364

(Continued)

Sales Model 140G (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
4N-4782	Pulley	325-6176	6G-1919	Cap - Pivot	243-0337	7N-9145	Gear - Fly-wheel	279-4994
4N-7693	Crankshaft As	242-3439	6G-2947	Shaft	243-0346	7N-9312	Damper As - Camshaft	299-2005
4N-8591	Coupling - Exhaust	325-6053	6G-4525	Strip - Wear	282-6624	7N-9805	Pin - Piston	295-6438
4N-8814	Line As - Fuel Injector	247-3366	6H-3957	Bearing - Ball	311-9358	7S-3161	Lifter - Valve	279-4996
4N-9587	Shield - Heat	297-7260	6I-1346	Pump Gp - Oil	295-5674	7S-6723	Bracket - Alternator	299-1978
4P-3546	Valve As - Relief	325-6236	6N-1036	Gear - Oil Pump	279-4991	7S-8631	Shaft As	275-5296
4P-9381	Line As - Fuel Injector	279-4984	6N-1965	Line As - Fuel Injector	250-7535	7T-2036	Cap As - Filter	361-1721
4P-9382	Line As - Fuel Injector	279-4985	6N-1966	Line As - Fuel Injector	250-7536	7T-9647	Piston - Clutch	275-5294
4P-9385	Line As - Fuel Injector	279-4986	6N-8413	Housing - Pump	325-6110	7W-0450	Gear - Water Pump	279-4997
4P-9386	Line As - Fuel Injector	279-4987	6Y-0305	Cage As - Bearing	297-7150	7W-0507	Gear - Oil Pump Drive	279-4998
4S-8472	Hood As	296-1355	7B-5036	Shaft - Bracket	297-7251	7W-0508	Gear - Fuel Pump Drive	296-1351
4T-0998	Lever	314-8687	7C-4297	Seal As - Camshaft	325-6192	7Y-1517	Pipe As - Tail	301-5246
4V-0015	Plate - Lock	282-6563	7D-5861	Adapter	243-0364	8D-1784	Pin	282-6567
4W-0452	Seal As - Camshaft	325-6191	7D-6568	Cover As	228-9457	8D-2429	Pin As	319-3445
5B-0577	Collar	299-1992	7D-7889	Gear - Ring	275-5276	8D-2469	Shaft - Drive	275-5280
5D-0470	Valve Gp	314-8549	7G-3450	Gear - Planet	275-5289	8D-2532	Carrier - Planet	301-4773
5K-0871	Pin - Lower	282-6630	7G-3451	Gear - Planet	297-7188	8D-3591	Carrier - Planet	301-4769
5K-0989	Cap - Upper	297-7158	7G-3452	Gear - Planet	275-5290	8D-3744	Shaft - Drive	275-5283
5K-0990	Pin	299-2035	7G-3461	Gear - Planet	275-5291	8D-3877	Gear - Sun	275-5278
5K-0991	Cap - Lower	319-3433	7J-6461	Crown	325-6054	8D-5344	Gear - Worm	243-0341
5P-7807	Bearing - Ball	314-8502	7J-9884	Bearing - Sleeve	325-6016	8D-7096	Pin - Axle Leaning	297-7219
5S-4557	Bearing	311-9360	7K-9348	Pin	252-6872	8D-7174	Cover As	299-1997
5S-6795	Chamber As	242-3437	7N-0128	Core As - Oil Cooler	299-1994	8D-7427	Shaft - Drive Pinion	282-6568
5S-7944	Shaft - Planet	297-7246	7N-0165	Core As - Oil Cooler	295-5670	8D-9804	Housing - Drive	302-2682
5S-7945	Shaft As - Planet	275-5299	7N-2871	Line As - Fuel Injector	319-8172	8H-2810	Case As - Filter	314-8512
5S-9080	Pulley - Alt Drive	264-5883	7N-2872	Line As - Fuel Injector	319-8173	8N-0002	Trunnion As	314-8728
5T-0906	Cover	282-6625	7N-2874	Line As - Fuel Injector	298-2779	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
5T-1362	Bearing - Spider	325-6011	7N-2875	Line As - Fuel Injector	298-2780	8N-1187	Head Gp - Cylinder	242-3435
5T-3475	Shaft	297-7247	7N-2876	Line As - Fuel Injector	298-2781	8N-1721	Rod As - Conn	269-5291
5T-6298	Lever	299-2018	7N-3486	Manifold - Exhaust	261-0899	8N-1984	Rod As - Conn	242-3441
5T-8500	Shoe - Circle Drive	243-0359	7N-3515	Gear - Camshaft	314-8669	8N-2510	Shaft	325-6208
5T-8501	Shoe - Circle Drive	243-0358	7N-3536	Gear - Fuel	279-4993	8N-2641	Sleeve	325-6210
6F-6992	Cap - Ball-socket	297-7160	7N-5910	Impeller - Pump	314-8686			
6G-1633	Chain Gp	282-6565						
6G-1664	Adapter	297-7135						
6G-1908	Housing As - Drive	297-7198						

(Continued)

Sales Model 140G (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7718	Manifold - Exhaust	295-0416
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8317	Sprocket	275-5287
9D-4441	Housing	297-7195

Original Part Number	Part Name	Classic Part Number
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980
9N-5769	Cover - Housing	325-6050
9P-4859	Cage As - Bearing	297-7151
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-9742	Cage As - Bearing	297-7153
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042

Cat® Classic™ Parts for Pipelayers

Cat® pipelayers are built to be heavy, strong, and durable. They are built to last many years. As the machines age, owning and operating costs are often re-evaluated. To help you manage these costs, Caterpillar offers Classic parts for several models of pipelayers. Cat® Classic™ parts are a repair option targeted at the end of the product life cycle when lower cost options are more desired.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for pipelayers includes:

- Engine
- Final Drive
- Flywheel Clutch
- Moving Undercarriage
- Non-Moving Undercarriage
- Steering
- Transmission
- ...and many more.

Sales Model 561B



Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311	2H-4338	Plate - Pressure	226-8010	4H-9040	Nut	226-7996
190-8609	Valve - Fill	360-2288	2H-4450	Washer - Thrust	325-6237	4K-4780	Strip As - Wear	299-2063
1A-2846	Cap As - Filler	311-9368	2H-4482	Collar	229-8218	4S-8005	Pinion - Final Drive	226-6076
1H-8262	Shaft	226-8016	2H-5046	Link - Flycam	299-2024	5A-9551	Gear - Final Drive	226-7979
1H-8382	Gear - Oil Pump Drive	226-6103	2M-2290	Bracket - Ring	299-1979	5F-0689	Pin	256-4821
1H-8937	Drumbrake	226-7993	2P-7622	Bolt - Spring	226-4850	5F-2256	Cage - Bearing	226-7973
1H-8938	Lever	226-8028	2P-9660	Gear - Final Drive	226-5995	5H-5500	Collar - Flywheel	302-2704
1M-0176	Flange - Drum	223-4810	2S-1477	Holder As - Cage	226-7985	5M-5244	Hub - Gear	219-2982
1M-5165	Pinion - Final Drive	231-8766	2S-4015	Plunger As - Valve	311-9438	5P-7807	Bearing - Ball	314-8502
1M-6128	Manifold - Exhaust	261-0906	3B-6218	Muffler As	247-2672	5S-0726	Hub As - Sprocket	227-4769
1M-7250	Bowl - Precleaner	360-2296	3F-1956	Cap - Frame Sup	226-7987	5S-1211	Cover - Valve	314-8665
1M-9177	Flywheel	226-6112	3F-1972	Retainer As	226-7988	5S-1822	Chamber As	248-5406
1P-1931	Shaft - Steer	227-4772	3H-3378	Gear As - Pump	298-2795	5S-1833	Chamber As	247-3298
1P-7044	Cage	226-7975	3K-3124	Muffler - Trap	247-2673	6B-7178	Fork - Band Adjustable	299-2009
1S-1888	Bracket - Lamp	297-7147	3L-1425	Bearing - Ball	311-9356	6P-0169	Hub - Flywheel Clutch	297-7204
1S-5315	Cap As - Brace Bearing	226-4848	3P-3623	Lock - Adjustable Nut	226-7989	7B-2420	Ferrule - Director	314-8517
1S-6422	Pilot As - Spring	226-4849	3P-5754	Hub - Gear	219-2976	7B-5088	Drum - Steering	223-4813
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014	3S-0311	Rod Gp	226-4953	7F-9547	Pin As - Drawbar	295-0414
1W-4405	Gear - Crankshaft	279-4982	3S-7153	Gear - Sliding	227-0024	7G-6044	Cage As	216-7857
2F-7576	Shaft - Sprocket	226-6071	3S-8800	Gear - Driven	325-6090	7H-1318	Coupling - Steering	226-8002
			4F-4974	Clamp	311-9373			
			4H-4021	Plate As - Loading	229-8219			

Sales Model 561B (Continued)

Original Part Number	Part Name	Classic Part Number
7H-2424	Sleeve - Spring	226-4852
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-7602	Pump Gp	226-0174

Original Part Number	Part Name	Classic Part Number
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676

Original Part Number	Part Name	Classic Part Number
8M-6676	Cylinder - Adjustable	226-4960
8N-8225	Bearing - Main	314-8652
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8117	Shaft - Flywheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9S-3321	Cage - Pinion Bearing	226-7974

Sales Model 561C

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993

Original Part Number	Part Name	Classic Part Number
1M-0176	Flange - Drum	223-4810
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1636	Lever As	226-8013
1P-1931	Shaft - Steer	227-4772
1P-4303	Head As - Cylinder	242-3434
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849

Original Part Number	Part Name	Classic Part Number
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2M-2290	Bracket - Ring	299-1979

(Continued)

Sales Model 561C (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As - Gear	296-1367	4K-4780	Strip As - Wear	299-2063	6B-7178	Fork - Band Adjustable	299-2009
2P-1738	Plate As - Oil Pan	325-6164	4N-2954	Sleeve - Camshaft	299-2059	6H-3957	Bearing - Ball	311-9358
2P-1739	Tube As - Pump	325-6229	4N-3281	Line As - Fuel Injector	247-3362	6I-1346	Pump Gp - Oil	295-5674
2P-1757	Hub - Fan Pulley	296-1357	4N-3282	Line As - Fuel Injector	247-3363	6N-1036	Gear - Oil Pump	279-4991
2P-1781	Spacer - Oil Pump	325-6214	4N-3283	Line As - Fuel Injector	247-3364	6N-1965	Line As - Fuel Injector	250-7535
2P-2519	Tube As - Inlet	325-6230	4N-3284	Line As - Fuel Injector	247-3365	6N-1966	Line As - Fuel Injector	250-7536
2P-6245	Shaft As - Pump	325-6197	4N-4864	Pump Gp - Fuel Transfer	242-3442	6N-8413	Housing - Pump	325-6110
2P-7622	Bolt - Spring	226-4850	4N-7693	Crankshaft As	242-3439	6P-0169	Hub - Fly-wheel Clutch	297-7204
2P-9667	Cage - Shaft Bearing	226-7971	4N-7982	Pulley	264-5880	6T-6053	Pinion - Shaft & Gear	226-6079
2S-1477	Holder As - Cage	226-7985	4N-8814	Line As - Fuel Injector	247-3366	7B-2420	Ferrule - Director	314-8517
2S-4015	Plunger As - Valve	311-9438	4N-9587	Shield - Heat	297-7260	7B-5088	Drum - Steering	223-4813
2W-1086	Cover As - Cylinder Head	325-6049	4P-0660	Muffler As	298-2787	7C-4297	Seal As - Camshaft	325-6192
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4P-3546	Valve As - Relief	325-6236	7F-9547	Pin As - Drawbar	295-0414
2W-7255	Shaft - Water Pump	325-6203	4S-6189	Pinion - Reverse	226-6077	7G-2037	Joint Gp - Univ	226-8017
2W-7458	Crankshaft As	242-3439	4S-6190	Pinion - Forward	226-6078	7G-2038	Tube - Univ Joint	297-7268
3B-6218	Muffler As	247-2672	4S-8005	Pinion - Final Drive	226-6076	7G-3815	Pump Gp	226-0171
3F-1956	Cap - Frame Sup	226-7987	4W-0452	Seal As - Camshaft	325-6191	7G-6044	Cage As	216-7857
3F-1972	Retainer As	226-7988	5A-9551	Gear - Final Drive	226-7979	7H-1318	Coupling - Steering	226-8002
3H-3378	Gear As - Pump	298-2795	5F-2256	Cage - Bearing	226-7973	7H-2424	Sleeve - Spring	226-4852
3K-3124	Muffler - Trap	247-2673	5G-3612	Cap Gp	295-6419	7M-0820	Gear - Sliding	226-6086
3L-1425	Bearing - Ball	311-9356	5H-5500	Collar - Fly-wheel	302-2704	7M-2167	Ring - Governor Control	308-9919
3P-3623	Lock - Adjustable Nut	226-7989	5M-7342	Flange - Shaft	215-1696	7M-4204	Manifold - Exhaust	261-0901
3P-5754	Hub - Gear	219-2976	5P-7807	Bearing - Ball	314-8502	7M-4603	Body - Fuel Valve	311-9348
3P-5755	Extension - Final Drive	226-7990	5S-0726	Hub As - Sprocket	227-4769	7M-5002	Drum - Steering	226-7992
3S-0311	Rod Gp	226-4953	5S-1211	Cover - Valve	314-8665	7M-5050	Collar - Front Idler	226-4958
3S-5396	Shaft - Fly-wheel	226-8015	5S-1822	Chamber As	248-5406	7M-7358	Valve - Inlet	298-2774
3S-7153	Gear - Sliding	227-0024	5S-1833	Chamber As	247-3298	7M-9398	Plate - Guide	297-7230
3S-7504	Gear - Idler	226-6084	5S-4557	Bearing	311-9360	7N-0128	Core As - Oil Cooler	299-1994
4F-4974	Clamp	311-9373	5S-6795	Chamber As	242-3437	7N-0165	Core As - Oil Cooler	295-5670
4H-4021	Plate As - Loading	229-8219	5S-7609	Pulley - Alt Drive	264-5881	7N-2871	Line As - Fuel Injector	319-8172
4H-9040	Nut	226-7996	5S-8767	Gear - First	226-6085			
			5S-9080	Pulley - Alt Drive	264-5883			

Sales Model 561C (Continued)

Original Part Number	Part Name	Classic Part Number
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8B-5972	Bearing - Ball	314-8503

Original Part Number	Part Name	Classic Part Number
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-1853	Nut - Adjusting	226-7997

Original Part Number	Part Name	Classic Part Number
8P-1855	Hub As - Sprocket	227-4770
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-2140	Trunnion - Gear	226-8020
8S-3970	Chamber As	242-3438
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8117	Shaft - Fly-wheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-3321	Cage - Pinion Bearing	226-7974
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8353	Strip - Track	226-4854
9S-8354	Strip - Track	226-4855
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9S-8679	Chamber As	325-6042

Sales Model 561D

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	1W-4402	Gear - Cam-shaft	279-4981	3S-2712	Gear - Transfer	226-7977
111-8015	Gasket As - Head	279-4977	1W-4405	Gear - Crank-shaft	279-4982	3T-1900	Drum - Steering Clutch	226-7991 (Drum), 230-7111 (Steering Clutch Kit)
115-7550	Gasket - Plate	314-8667	244-1090	Alarm - Back up	360-2345	4F-4974	Clamp	311-9373
121-7746	Precleaner As	360-2311	2F-5721	Bearing - Ball	311-9354	4H-9040	Nut	226-7996
131-3815	Seal Gp - Basic	325-6193	2F-7576	Shaft - Sprocket	226-6071	4K-4780	Strip As - Wear	299-2063
148-7455	Valve - Exhaust	270-4361	2P-1170	Shaft As - Gear	296-1367	4N-2954	Sleeve - Cam-shaft	299-2059
165-4262	Body As - Piston	270-4353 (Liner Kit)	2P-1738	Plate As - Oil Pan	325-6164	4N-3281	Line As - Fuel Injector	247-3362
172-5185	Shaft - Water Pump	325-6201	2P-1739	Tube As - Pump	325-6229	4N-3282	Line As - Fuel Injector	247-3363
172-5188	Shaft - Water Pump	325-6202	2P-1757	Hub - Fan Pulley	296-1357	4N-3283	Line As - Fuel Injector	247-3364
172-5189	Impeller - Pump	295-5687	2P-1781	Spacer - Oil Pump	325-6214	4N-3284	Line As - Fuel Injector	247-3365
172-5190	Impeller - Pump	325-6111	2P-2519	Tube As - Inlet	325-6230	4N-4864	Pump Gp - Fuel Transfer	242-3442
172-6712	Impeller - Pump	325-6112	2P-6245	Shaft As - Pump	325-6197	4N-7693	Crankshaft As	242-3439
172-7767	Pump Gp - Water	296-1365	2P-7622	Bolt - Spring	226-4850	4N-7982	Pulley	264-5880
190-8609	Valve - Fill	360-2288	2P-9660	Gear - Final Drive	226-5995	4N-8814	Line As - Fuel Injector	247-3366
1M-7250	Bowl - Pre-cleaner	360-2296	2P-9672	Cage - Pinion Bearing	226-7972	4N-9587	Shield - Heat	297-7260
1M-9444	Retainer - Spring	299-2046	2S-1477	Holder As - Cage	226-7985	4P-0660	Muffler As	298-2787
1N-3576	Block Gp - Cylinder	279-4978	2W-1086	Cover As - Cylinder Head	325-6049	4P-3546	Valve As - Relief	325-6236
1N-3958	Elbow	325-6087	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4S-5943	Piston - Clutch	221-9112
1P-9945	Bracket As - Fan	296-1344	2W-7255	Shaft - Water Pump	325-6203	4S-5944	Gear - Sun	221-9078
1P-9946	Shaft - Fan	325-6194	2W-7458	Crankshaft As	242-3439	4S-5945	Gear - Sun	221-9079
1P-9952	Impeller - Pump	314-8685	2W-9978	Core As - Oil Cooler	279-4983	4S-5947	Gear - Ring	221-9080
1S-1888	Bracket - Lamp	297-7147	3F-1956	Cap - Frame Sup	226-7987	4S-5948	Gear - Ring	221-9082
1S-4701	Pulley - Alt	264-5866	3F-1972	Retainer As	226-7988	4S-5979	Carrier As	216-7843
1S-6422	Pilot As - Spring	226-4849	3L-1425	Bearing - Ball	311-9356	4S-5981	Gear - Ring	221-9084
1T-0521	Retainer - Bearing	325-6180	3P-3623	Lock - Adjustable Nut	226-7989	4S-8530	Shaft - Planet	221-9111
1T-1350	Torque Converter	235-0912 (Repair Kit)	3P-5754	Hub - Gear	219-2976	4S-8534	Shaft As - Planet	221-9116
1T-1993	Wheel - Turbine	235-0920	3P-5755	Extension - Final Drive	226-7990	4S-8716	Gear - Transfer	226-7978
1T-2052	Stator As	295-5683	3S-0311	Rod Gp	226-4953	4W-0452	Seal As - Camshaft	325-6191
1W-1219	Trunnion As	314-8724	3S-1167	Gear - Planet	221-9101	5A-6897	Guard - Idler Rh	226-4951
						5A-6898	Guard - Idler Lh	226-4952
						5A-9551	Gear - Final Drive	226-7979
						5P-7807	Bearing - Ball	314-8502

Sales Model 561D (Continued)

Original Part Number	Part Name	Classic Part Number
5S-0726	Hub As - Sprocket	227-4769
5S-4493	Carrier - Planet	223-6321
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6T-0443	Pinion - Shaft & Bevel	226-7999
7F-9547	Pin As - Drawbar	295-0414
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-6044	Cage As	216-7857
7G-8459	Hub - Gear	221-1070
7H-2424	Sleeve - Spring	226-4852
7M-2167	Ring - Governor Control	308-9919
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779

Original Part Number	Part Name	Classic Part Number
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8572	Gear - Ring	221-9095
7S-8660	Pump Gp - Transmission	226-0175
7T-0203	Guide	226-4959
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8B-5972	Bearing - Ball	314-8503
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960

Original Part Number	Part Name	Classic Part Number
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0203	Drum	226-8004
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-1324	Cage - Gr Shift Bearing	229-8239
8P-1325	Hub - Steering	226-8005
8P-1326	Pilot - Piston	226-6097
8P-1327	Pinion - Final Drive	226-8000
8P-1328	Flange - Drive Drum	226-8006
8P-1353	Piston - Steering	226-8007
8P-1774	Pinion - Final Drive	226-8001
8P-1853	Nut - Adjusting	226-7997
8P-1855	Hub As - Sprocket	227-4770
8P-2430	Shaft As	297-7258

(Continued)

Sales Model 561D (Continued)

Original Part Number	Part Name	Classic Part Number
8P-8570	Pilot As - Piston	226-6097
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948
8S-3970	Chamber As	242-3438

Original Part Number	Part Name	Classic Part Number
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-8757	Rod End - Bearing	311-9361
9M-2049	Gear - Ring	214-0533
9M-4789	Shaft - Gov Control	297-7256
9M-8281	Gear As - Oil Pump	325-6089

Original Part Number	Part Name	Classic Part Number
9N-5769	Cover - Housing	325-6050
9S-2355	Manifold - Exhaust	261-0891
9S-3321	Cage - Pinion Bearing	226-7974
9S-8258	Guard As - Guiding	226-0239
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9S-8679	Chamber As	325-6042

Sales Model 561H

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978

Original Part Number	Part Name	Classic Part Number
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1428	Retainer - Bearing	300-2587
1T-1691	Impeller - Converter	297-4863
1T-1987	Housing - Rotating	297-4864
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358

Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Backup	360-2345
2F-5721	Bearing - Ball	311-9354
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3T-3447	Gear As - Sun	302-2676
3T-6795	Piston - Clutch	281-1693
4F-4974	Clamp	311-9373
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439

(Continued)

Sales Model 561H (Continued)

Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4W-0452	Seal As - Camshaft	325-6191
5K-7995	Bearing - Sleeve	308-9820
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5T-1362	Bearing - Spider	325-6011
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8005	Gear - Planet	281-1691

Original Part Number	Part Name	Classic Part Number
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-4302	Housing - Clutch	302-2708
7G-4758	Gear - Planet	288-8723
7G-5444	Carrier - Planet	297-7165
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7N-0165	Core As - Oil Cooler	295-5670
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-3042	Tube As - Drain	325-6231
8G-3102	Piston	325-6162
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435

Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9G-1231	Plate	297-7232
9M-1328	Bearing - Aligning	325-6018
9N-5769	Cover - Housing	325-6050
9S-8679	Chamber As	325-6042
9W-9930	Mount As	295-6437
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 571A

Original Part Number	Part Name	Classic Part Number
112-3249	Muffler As	247-2661
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458

Original Part Number	Part Name	Classic Part Number
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046

Original Part Number	Part Name	Classic Part Number
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-7590	Support As	213-4400
1S-0876	Bolt - Spring	226-0224
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0256	Gear - Pump Drive	239-7930

(Continued)

Sales Model 571A (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2F-0025	Tube	325-6233	3P-6561	Stop - Recoil Spring	226-0233	5S-9080	Pulley - Alt Drive	264-5883
2F-5721	Bearing - Ball	311-9354	3S-3917	Guard As - Sprocket	226-0188	6H-3957	Bearing - Ball	311-9358
2K-4502	Bearing - Sleeve	299-1986	3S-3918	Guard As - Sprocket	226-4950	6L-7816	Seal - o-Ring	314-8542
2M-0125	Cylinder - Adjustable	226-0215	3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)	6P-4948	Cap - Final Drive Bearing	226-0205
2M-0365	Stop - Spring Rh	226-0230	3T-4482	Guide - Front Idler	226-0248	6P-6653	Plate - Guide	226-0208
2M-0366	Stop - Spring Lh	226-0231	4F-4974	Clamp	311-9373	6T-1980	Collar - Idler End	226-0210
2M-0369	Pilot - Spring Recoil	226-0226	4M-7099	Gear - Ring	214-0521	7B-2420	Ferrule - Director	314-8517
2M-0398	Sleeve - Bolt	226-0235	4M-7100	Gear - Ring	214-0522	7F-9541	Pin As - Drawbar	296-1361
2P-0483	Chamber As	256-4760	4M-7102	Gear - Ring	214-0523	7G-2517	Gear - Planet	213-8747
2P-0484	Chamber As	247-3296	4M-9215	Gear - Pump Idler	311-9391	7G-2521	Gear - Planet	213-8749
2P-3424	Gear - First Reduction	215-1675	4N-7000	Head As - Cylinder	325-6105	7G-6576	Cage As	216-7859
2P-3425	Pinion - Sec Reduction	217-7697	4N-7526	Seal As - Pump	311-9454	7H-0602	Dog - Clutch	314-8515
2P-3992	Gear - Bevel	219-9666	4N-9180	Seal As - Pump	311-9455	7M-4603	Body - Fuel Valve	311-9348
2S-3946	Gear - Final Drive	215-1678	5G-3612	Cap Gp	295-6419	7M-4926	Retainer - Pin	314-8538
2S-3966	Ring - Seal	297-7237	5M-1988	Piston - Steer	219-9691	7M-8453	Piston - Clutch	215-1755
2S-4015	Plunger As - Valve	311-9438	5M-1990	Pilot - Piston	229-8233	7N-0128	Core As - Oil Cooler	299-1994
2S-7063	Nut	300-2584	5M-1998	Drum Steering	213-6952	7S-7809	Cap As - Radiator	295-6417
2S-7064	Cap - Shaft Bearing	299-1991	5M-2026	Hubdriving	216-4471	7S-7973	Guard - Final Drive Wear	213-9110
2S-7099	Hub - Gear	219-2962	5M-3470	Gear - Transmission	224-1305	7T-0119	Support As	299-2066
2S-7527	Flange - Drum	213-8163	5M-3474	Shaft - Output	215-1690	7T-0204	Bearing - Brace	247-4126
2S-7596	Retainer	215-1679	5M-3499	Shaft - Planet	319-3475	7T-2036	Cap As - Filter	361-1721
2S-7873	Pump Gp	226-0162	5M-3906	Gear - Ring	214-0526	8F-5104	Screen As - Oil Pan	314-8539
2S-7917	Gear - Pump Drive	247-4119	5M-3907	Carrier - Planet	210-8475	8H-1383	Rod - Tie	299-2051
2S-7920	Pump Gp - Scavenge	217-2594	5M-3941	Shaft - Planet	215-1691	8H-1993	Valve - Inlet	256-4765
2S-8356	Rod Gp - Track Adjustable	226-0199	5M-3942	Shaft - Planet	215-1692	8H-1994	Valve - Exhaust	256-4765
3B-1464	Cap - Bearing	226-0206	5M-5037	Hub - Gear	219-2980	8H-2810	Case As - Filter	314-8512
3F-7445	Bearing - Sleeve	314-8508	5M-7900	Bolt - Hex Head	311-9349	8H-7980	Piston	226-0249
3H-3378	Gear As - Pump	298-2795	5P-7807	Bearing - Ball	314-8502	8M-2549	Rod As - Connector	314-8537
3K-2230	Gear - Planet	219-9658	5S-0073	Plate - Steering	302-2692	8M-7166	Housing - Screen	297-7192
3L-1425	Bearing - Ball	311-9356	5S-1211	Cover - Valve	314-8665	8P-0187	Nut - Adjusting	219-9676
3P-3623	Lock - Adjustable Nut	226-7989	5S-4863	Holder As - Cage	215-1732	8P-6274	Guard As - Lh	226-4949
3P-6293	Pump Gp	217-2597	5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)	8P-6275	Guard As - Rh	226-0191
3P-6560	Stop - Recoil Spring	226-0232				8S-0905	Muffler As	302-2690
						8S-1061	Pilot As - Spring	226-0227

(Continued)

Sales Model 571A (Continued)

Original Part Number	Part Name	Classic Part Number
8S-7818	Bracket	226-0211
8S-9071	Cage - Bearing	216-7869
9P-0418	Cage	223-6311

Original Part Number	Part Name	Classic Part Number
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874

Original Part Number	Part Name	Classic Part Number
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 571F

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
190-8609	Valve - Fill	360-2288
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-2187	Pump Gp	299-2044
1P-4303	Head As - Cylinder	242-3434
1P-7590	Support As	213-4400
1P-8835	Shaft As	215-1672
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673

Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4502	Bearing - Sleeve	299-1986
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357

Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4701	Shaft As - Gear	297-7257
2P-6245	Shaft As - Pump	325-6197
2S-3946	Gear - Final Drive	215-1678
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-8356	Rod Gp - Track Adjustable	226-0199
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7458	Crankshaft As	242-3439
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-0214	Gear - Transfer	219-9681
3P-0215	Gear - Transfer	219-9682

(Continued)

Sales Model 571F (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
3P-0395	Cage - Carrier Bearing	217-7723	5M-3474	Shaft - Output	215-1690	6P-6653	Plate - Guide	226-0208
3P-6560	Stop - Recoil Spring	226-0232	5M-3499	Shaft - Planet	319-3475	6T-1980	Collar - Idler End	226-0210
3P-6561	Stop - Recoil Spring	226-0233	5M-3906	Gear - Ring	214-0526	7C-4297	Seal As - Camshaft	325-6192
3P-8283	Spacer	325-6215	5M-3907	Carrier - Planet	210-8475	7F-9541	Pin As - Drawbar	296-1361
3S-3917	Guard As - Sprocket	226-0188	5M-3941	Shaft - Planet	215-1691	7G-2037	Joint Gp - Univ	226-8017
3S-3918	Guard As - Sprocket	226-4950	5M-3942	Shaft - Planet	215-1692	7G-2038	Tube - Univ Joint	297-7268
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)	5M-5822	Gear - Pump Drive	247-4120	7G-2474	Gear - Planet	300-2577
3T-4482	Guide - Front Idler	226-0248	5M-6120	Gear - Sun	213-8740	7G-2475	Gear - Planet	223-4815
4M-7099	Gear - Ring	214-0521	5M-6198	Shaft - Planet	297-7245	7G-2476	Gear - Planet	223-4816
4M-7100	Gear - Ring	214-0522	5M-6199	Shaft As - Planet	215-1694	7G-2513	Gear - Planet	215-1734
4M-7102	Gear - Ring	214-0523	5M-6208	Gear - Ring	247-4121	7G-2517	Gear - Planet	213-8747
4N-2954	Sleeve - Camshaft	299-2059	5M-6210	Shaft - Planet	219-9683	7G-2521	Gear - Planet	213-8749
4N-3281	Line As - Fuel Injector	247-3362	5M-6211	Shaft - Planet	219-9684	7G-6576	Cage As	216-7859
4N-3282	Line As - Fuel Injector	247-3363	5M-7841	Gear - Ring	214-0525	7M-2167	Ring - Governor Control	308-9919
4N-3283	Line As - Fuel Injector	247-3364	5M-7864	Pump Gp - Scavenge	226-0169	7M-8453	Piston - Clutch	215-1755
4N-4356	Pulley - Camshaft	264-5878	5M-7869	Gear - Ring	214-0530	7N-0165	Core As - Oil Cooler	295-5670
4N-4864	Pump Gp - Fuel Transfer	242-3442	5M-7875	Carrier - Front	213-4495	7N-2949	Pulley	264-5887
4N-7693	Crankshaft As	242-3439	5M-7900	Bolt - Hex Head	311-9349	7N-3515	Gear - Camshaft	314-8669
4N-8814	Line As - Fuel Injector	247-3366	5P-7807	Bearing - Ball	314-8502	7N-3536	Gear - Fuel	279-4993
4N-9587	Shield - Heat	297-7260	5S-0073	Plate - Steering	302-2692	7N-5810	Gear As - Idler	233-2179
4P-3546	Valve As - Relief	325-6236	5S-1211	Cover - Valve	314-8665	7N-5815	Gear - Camshaft Rr	233-2181
4S-6707	Piston - Clutch	215-1686	5S-4470	Gear - Transfer	224-1304	7N-5819	Gear - Hyd Pump Drive	215-1758
4S-8472	Hood As	296-1355	5S-4557	Bearing	311-9360	7N-9146	Gear - Fly-wheel Starter	279-4995
4S-8708	Housing - Clutch	216-3557	5S-4863	Holder As - Cage	215-1732	7N-9312	Damper As - Camshaft	299-2005
4W-0452	Seal As - Camshaft	325-6191	5S-6795	Chamber As	242-3437	7N-9805	Pin - Piston	295-6438
5G-3612	Cap Gp	295-6419	5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)	7S-3161	Lifter - Valve	279-4996
5M-1988	Piston - Steer	219-9691	5S-9080	Pulley - Alt Drive	264-5883	7S-6723	Bracket - Alternator	299-1978
5M-1990	Pilot - Piston	229-8233	6H-3957	Bearing - Ball	311-9358	7S-6964	Gear - Ring	214-0532
5M-1998	Drum Steering	213-6952	6I-1346	Pump Gp - Oil	295-5674	7S-7809	Cap As - Radiator	295-6417
5M-2026	Hubdriving	216-4471	6N-0714	Pulley - Alt	264-5884	7S-7973	Guard - Final Drive Wear	213-9110
5M-3470	Gear - Transmission	224-1305	6N-1036	Gear - Oil Pump	279-4991	7T-0119	Support As	299-2066
			6N-1965	Line As - Fuel Injector	250-7535	7T-2036	Cap As - Filter	361-1721
			6N-1966	Line As - Fuel Injector	250-7536	7W-0450	Gear - Water Pump	279-4997
			6N-8413	Housing - Pump	325-6110			
			6P-4948	Cap - Final Drive Bearing	226-0205			

(Continued)

Sales Model 571F (Continued)

Original Part Number	Part Name	Classic Part Number
7W-0507	Gear - Oil Pump Drive	279-4998
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291

Original Part Number	Part Name	Classic Part Number
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-0187	Nut - Adjusting	219-9676
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
9H-2256	Pump Gp	311-9443
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686

Original Part Number	Part Name	Classic Part Number
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-5277	Gear - Transfer	213-8758
9S-6129	Pulley - Alternator Drive	264-5891
9S-6788	Pump Gp - Oil	217-2602
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-8802	Gear - Ring	214-0952

Sales Model 571G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
115-7550	Gasket - Plate	314-8667

Original Part Number	Part Name	Classic Part Number
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202

Original Part Number	Part Name	Classic Part Number
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046

(Continued)

Sales Model 571G (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp - Cylinder	279-4978	2K-4502	Bearing - Sleeve	299-1986	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
1N-3958	Elbow	325-6087	2M-0125	Cylinder - Adjustable	226-0215	2W-7255	Shaft - Water Pump	325-6203
1P-0579	Housing As	219-9678	2M-0365	Stop - Spring Rh	226-0230	2W-7458	Crankshaft As	242-3439
1P-0965	Gear - Bevel	213-8215	2M-0366	Stop - Spring Lh	226-0231	3L-1425	Bearing - Ball	311-9356
1P-7590	Support As	213-4400	2M-0369	Pilot - Spring Recoil	226-0226	3P-0395	Cage - Carrier Bearing	217-7723
1P-8554	Coupling - Exhaust	325-6052	2M-0398	Sleeve - Bolt	226-0235	3P-4157	Yoke As - Idler	226-0221
1P-8835	Shaft As	215-1672	2P-1170	Shaft As - Gear	296-1367	3P-6560	Stop - Recoil Spring	226-0232
1P-9945	Bracket As - Fan	296-1344	2P-1738	Plate As - Oil Pan	325-6164	3P-6561	Stop - Recoil Spring	226-0233
1P-9946	Shaft - Fan	325-6194	2P-1739	Tube As - Pump	325-6229	3P-8283	Spacer	325-6215
1P-9952	Impeller - Pump	314-8685	2P-1757	Hub - Fan Pulley	296-1357	3S-3917	Guard As - Sprocket	226-0188
1S-0876	Bolt - Spring	226-0224	2P-1781	Spacer - Oil Pump	325-6214	3S-3918	Guard As - Sprocket	226-4950
1S-1888	Bracket - Lamp	297-7147	2P-2519	Tube As - Inlet	325-6230	3T-1921	Drum - Inner (Drum), 230-7116 (Steering Clutch Kit)	229-8227
1S-4701	Pulley - Alt	264-5866	2P-2922	Gear - Transfer	219-9679	3T-4482	Guide - Front Idler	226-0248
1T-0421	Flange As - Output	295-5442	2P-2923	Gear - Transfer	219-9680	4J-6167	Bearing - Sleeve	325-6009
1T-0436	Gear - Pump Drive	247-3367	2P-3424	Gear - First Reduction	215-1675	4N-2954	Sleeve - Camshaft	299-2059
1T-0437	Housing - Rotating	295-5685	2P-3425	Pinion - Sec Reduction	217-7697	4N-3281	Line As - Fuel Injector	247-3362
1T-0438	Retainer - Bearing	295-0410	2P-3598	Shaft - Output	215-1676	4N-3282	Line As - Fuel Injector	247-3363
1T-0443	Carrier As - Guide	247-3368	2P-3669	Pinion - Bevel	215-1677	4N-3283	Line As - Fuel Injector	247-3364
1T-0447	Carrier - Ring	295-0409	2P-3992	Gear - Bevel	219-9666	4N-4356	Pulley - Camshaft	264-5878
1T-0930	Torque Converter	235-0913 (Repair Kit)	2P-4701	Shaft As - Gear	297-7257	4N-4864	Pump Gp - Fuel Transfer	242-3442
1T-1993	Wheel - Turbine	235-0920	2P-6245	Shaft As - Pump	325-6197	4N-5191	Muffler As	298-2785
1T-2052	Stator As	295-5683	2S-3946	Gear - Final Drive	215-1678	4N-7693	Crankshaft As	242-3439
1W-1219	Trunnion As	314-8724	2S-6739	Pulley - Tightener	298-2794	4N-8814	Line As - Fuel Injector	247-3366
1W-1669	Piston	325-6158	2S-7063	Nut	300-2584	4N-9587	Shield - Heat	297-7260
1W-1695	Pump Gp	279-4980	2S-7064	Cap - Shaft Bearing	299-1991	4P-3546	Valve As - Relief	325-6236
1W-1698	Housing - Transfer Pump	296-1356	2S-7099	Hub - Gear	219-2962	4P-9381	Line As - Fuel Injector	279-4984
1W-4402	Gear - Camshaft	279-4981	2S-7527	Flange - Drum	213-8163	4P-9382	Line As - Fuel Injector	279-4985
1W-4405	Gear - Crankshaft	279-4982	2S-7596	Retainer	215-1679			
1W-5912	Tappet As - Guide	325-6223	2S-8356	Rod Gp - Track Adjustable	226-0199			
1W-6541	Plunger As	325-6173	2W-1086	Cover As - Cylinder Head	325-6049			
244-1090	Alarm - Back up	360-2345						
2F-0025	Tube	325-6233						
2F-5721	Bearing - Ball	311-9354						

Sales Model 571G (Continued)

Original Part Number	Part Name	Classic Part Number
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-0714	Pulley - Alt	264-5884

Original Part Number	Part Name	Classic Part Number
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-4948	Cap - Final Drive Bearing	226-0205
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-6576	Cage As	216-7859
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-4827	Yoke	299-2070
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758

Original Part Number	Part Name	Classic Part Number
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728

(Continued)

Sales Model 571G (Continued)

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652

Original Part Number	Part Name	Classic Part Number
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
9K-8757	Rod End - Bearing	311-9361
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533

Original Part Number	Part Name	Classic Part Number
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-6875	Pinion - Final Drive	217-7705
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 572C, 572D

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Precleaner	360-2296
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3P-3623	Lock - Adjustable Nut	226-7989
3S-2420	Pilot As - Spring	226-2733
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-2256	Cage - Bearing	226-7973
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6H-3957	Bearing - Ball	311-9358
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515

Original Part Number	Part Name	Classic Part Number
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5002	Drum - Steering	226-7992
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-0493	Cage - Outer Bearing	216-7866
8S-5722	Plate - Pressure	226-8009
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 572E

Original Part Number	Part Name	Classic Part Number
112-3249	Muffler As	247-2661
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-7590	Support As	213-4400
1S-0876	Bolt - Spring	226-0224
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0256	Gear - Pump Drive	239-7930
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-3424	Gear - First Reduction	215-1675

Original Part Number	Part Name	Classic Part Number
2P-3425	Pinion - Sec Reduction	217-7697
2P-3992	Gear - Bevel	219-9666
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-2230	Gear - Planet	219-9658
3P-3623	Lock - Adjustable Nut	226-7989
3P-6293	Pump Gp	217-2597
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-4974	Clamp	311-9373
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4M-9215	Gear - Pump Idler	311-9391
4N-7000	Head As - Cylinder	325-6105
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233

Original Part Number	Part Name	Classic Part Number
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5037	Hub - Gear	219-2980
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4863	Holder As - Cage	215-1732
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7B-2420	Ferrule - Director	314-8517
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-8453	Piston - Clutch	215-1755
7N-0128	Core As - Oil Cooler	299-1994
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721

(Continued)

Sales Model 572E (Continued)

Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249

Original Part Number	Part Name	Classic Part Number
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8P-0187	Nut - Adjusting	219-9676
8S-0905	Muffler As	302-2690
8S-1061	Pilot As - Spring	226-0227
8S-7818	Bracket	226-0211

Original Part Number	Part Name	Classic Part Number
8S-9071	Cage - Bearing	216-7869
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 572F

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
131-3815	Seal Gp - Basic	325-6193
172-5188	Shaft - Water Pump	325-6202
172-6712	Impeller - Pump	325-6112
190-8609	Valve - Fill	360-2288
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-2187	Pump Gp	299-2044
1P-4303	Head As - Cylinder	242-3434
1P-7590	Support As	213-4400
1P-8835	Shaft As	215-1672

Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-0125	Cylinder - Adjustable	226-0215

Original Part Number	Part Name	Classic Part Number
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4701	Shaft As - Gear	297-7257
2P-6245	Shaft As - Pump	325-6197
2S-3946	Gear - Final Drive	215-1678
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tightener	298-2794
2S-7063	Nut	300-2584

(Continued)

Sales Model 572F (Continued)

Original Part Number	Part Name	Classic Part Number
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7458	Crankshaft As	242-3439
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-0214	Gear - Transfer	219-9681
3P-0215	Gear - Transfer	219-9682
3P-0395	Cage - Carrier Bearing	217-7723
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-6707	Piston - Clutch	215-1686

Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4470	Gear - Transfer	224-1304
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883

Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-6653	Plate - Guide	226-0208
6T-1980	Collar - Idler End	226-0210
7C-4297	Seal As - Camshaft	325-6192
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7M-2167	Ring - Governor Control	308-9919
7M-8453	Piston - Clutch	215-1755
7N-0165	Core As - Oil Cooler	295-5670
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417

(Continued)

Sales Model 572F (Continued)

Original Part Number	Part Name	Classic Part Number
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-0187	Nut - Adjusting	219-9676
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
9H-2256	Pump Gp	311-9443

Original Part Number	Part Name	Classic Part Number
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-5277	Gear - Transfer	213-8758
9S-6129	Pulley - Alternator Drive	264-5891
9S-6788	Pump Gp - Oil	217-2602
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-8802	Gear - Ring	214-0952

Sales Model 572G

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361

Original Part Number	Part Name	Classic Part Number
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687

(Continued)

Sales Model 572G (Continued)

Original Part Number	Part Name	Classic Part Number
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-2187	Pump Gp	299-2044
1P-7590	Support As	213-4400
1P-8554	Coupling - Exhaust	325-6052
1P-8835	Shaft As	215-1672
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-0876	Bolt - Spring	226-0224
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356

Original Part Number	Part Name	Classic Part Number
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2K-5073	Bushing	299-1989
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2922	Gear - Transfer	219-9679
2P-2923	Gear - Transfer	219-9680
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4701	Shaft As - Gear	297-7257
2P-6245	Shaft As - Pump	325-6197
2S-3946	Gear - Final Drive	215-1678

Original Part Number	Part Name	Classic Part Number
2S-6739	Pulley - Tight-ener	298-2794
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3L-1425	Bearing - Ball	311-9356
3P-0395	Cage - Carrier Bearing	217-7723
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4J-6167	Bearing - Sleeve	325-6009
4N-2954	Sleeve - Cam-shaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Cam-shaft	264-5878
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5191	Muffler As	298-2785
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236

(Continued)

Sales Model 572G (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
4P-9381	Line As - Fuel Injector	279-4984	6H-3957	Bearing - Ball	311-9358	7N-9146	Gear - Fly-wheel Starter	279-4995
4P-9382	Line As - Fuel Injector	279-4985	6I-1346	Pump Gp - Oil	295-5674	7N-9312	Damper As - Camshaft	299-2005
4P-9385	Line As - Fuel Injector	279-4986	6N-0714	Pulley - Alt	264-5884	7N-9805	Pin - Piston	295-6438
4P-9386	Line As - Fuel Injector	279-4987	6N-1036	Gear - Oil Pump	279-4991	7S-3161	Lifter - Valve	279-4996
4S-6707	Piston - Clutch	215-1686	6N-1965	Line As - Fuel Injector	250-7535	7S-6723	Bracket - Alternator	299-1978
4S-8472	Hood As	296-1355	6N-1966	Line As - Fuel Injector	250-7536	7S-6964	Gear - Ring	214-0532
4S-8708	Housing - Clutch	216-3557	6N-8413	Housing - Pump	325-6110	7S-7809	Cap As - Radiator	295-6417
4W-0452	Seal As - Camshaft	325-6191	6P-6653	Plate - Guide	226-0208	7S-7973	Guard - Final Drive Wear	213-9110
4W-2446	Damper As	279-4990	6T-1980	Collar - Idler End	226-0210	7T-0119	Support As	299-2066
5G-3612	Cap Gp	295-6419	7C-4297	Seal As - Camshaft	325-6192	7T-2036	Cap As - Filter	361-1721
5M-1988	Piston - Steer	219-9691	7G-2474	Gear - Planet	300-2577	7W-0450	Gear - Water Pump	279-4997
5M-1990	Pilot - Piston	229-8233	7G-2475	Gear - Planet	223-4815	7W-0507	Gear - Oil Pump Drive	279-4998
5M-1998	Drum Steering	213-6952	7G-2476	Gear - Planet	223-4816	7W-0508	Gear - Fuel Pump Drive	296-1351
5M-2026	Hubdriving	216-4471	7G-2513	Gear - Planet	215-1734	7W-5687	Hub - Camshaft	314-8684
5M-5822	Gear - Pump Drive	247-4120	7G-6576	Cage As	216-7859	8H-1383	Rod - Tie	299-2051
5M-6120	Gear - Sun	213-8740	7J-1333	Bearing - Sleeve	295-6408	8H-2810	Case As - Filter	314-8512
5M-6198	Shaft - Planet	297-7245	7J-1334	Bearing - Sleeve	325-6015	8H-7980	Piston	226-0249
5M-6199	Shaft As - Planet	215-1694	7J-4827	Yoke	299-2070	8H-9806	Gear - Shaft Drive	325-6091
5M-6208	Gear - Ring	247-4121	7N-0165	Core As - Oil Cooler	295-5670	8J-2652	Shaft	299-2054
5M-6210	Shaft - Planet	219-9683	7N-2871	Line As - Fuel Injector	319-8172	8J-2653	Lever As	299-2015
5M-6211	Shaft - Planet	219-9684	7N-2872	Line As - Fuel Injector	319-8173	8J-2654	Lever As	299-2016
5M-7841	Gear - Ring	214-0525	7N-2874	Line As - Fuel Injector	298-2779	8J-2880	Cap - Bearing	295-6420
5M-7864	Pump Gp - Scavenge	226-0169	7N-2875	Line As - Fuel Injector	298-2780	8M-0874	Plunger As - Valve	311-9439
5M-7869	Gear - Ring	214-0530	7N-2876	Line As - Fuel Injector	298-2781	8M-7166	Housing - Screen	297-7192
5M-7875	Carrier - Front	213-4495	7N-2949	Pulley	264-5887	8M-8619	Cage - Bearing	217-7725
5M-7900	Bolt - Hex Head	311-9349	7N-3515	Gear - Camshaft	314-8669	8M-8623	Gear - Sun	213-8755
5P-7807	Bearing - Ball	314-8502	7N-3536	Gear - Fuel	279-4993	8M-8628	Flange - Joint	217-9776
5S-0073	Plate - Steering	302-2692	7N-5810	Gear As - Idler	233-2179	8M-8642	Housing - Clutch	219-9669
5S-1211	Cover - Valve	314-8665	7N-5815	Gear - Camshaft Rr	233-2181	8M-8644	Housing - Clutch	215-1782
5S-4557	Bearing	311-9360	7N-5819	Gear - Hyd Pump Drive	215-1758	8M-8646	Plate As - Center	216-3583
5S-4863	Holder As - Cage	215-1732	7N-5825	Gear - Drive	215-1759	8M-8650	Piston - Clutch	217-9778
5S-6795	Chamber As	242-3437	7N-5910	Impeller - Pump	314-8686	8M-8652	Shaft	297-7252
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)				8M-8677	Carrier - Planet	213-4449
5S-9080	Pulley - Alt Drive	264-5883						

(Continued)

Sales Model 572G (Continued)

Original Part Number	Part Name	Classic Part Number
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232

Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001

Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-6875	Pinion - Final Drive	217-7705
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 583

Original Part Number	Part Name	Classic Part Number
2S-2140	Nut (7/8-14)	188-5857
2S-6346	Shoe -Track	188-5311
2S-6347	Shoe -Track	188-5613
2S-6357	Shoe -Track	281-6373
2S-6364	Shoe -Track	188-5615
6L-9212	Idler Gp	200-9238
6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
7H-3599	Bolt - Track	188-5639
7S-9093	Shoe -Track	188-5617
7S-9094	Shoe -Track	188-5313

Original Part Number	Part Name	Classic Part Number
7S-9096	Shoe -Track	281-6370
7S-9101	Shoe -Track	281-6372
8P-6256	Roller Gp - Carrier	188-5612
8S-0386	Shoe -Track Master	188-5312
8S-0387	Shoe -Track Master	188-5614
8S-0388	Shoe -Track Master	188-5616

Original Part Number	Part Name	Classic Part Number
8S-0390	Shoe -Track Master	281-6371
8S-0391	Shoe -Track Master	188-5618
8S-0392	Shoe -Track Master	188-5314
8S-0394	Shoe -Track Master	315-6693
8S-0395	Bolt Master	188-5640
8S-0915	Shoe -Track Master	281-6374
9S-7221	Idler As.	188-5610
9W-8937	Link As.	188-5310

Sales Model 583C, 583E

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9444	Retainer - Spring	299-2046

Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438

Original Part Number	Part Name	Classic Part Number
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3S-2420	Pilot As - Spring	226-2733

(Continued)

Sales Model 583C, 583E (Continued)

Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5S-1211	Cover - Valve	314-8665

Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 583H

Original Part Number	Part Name	Classic Part Number
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-6603	Gear - Transfer	217-7720
1M-6604	Gear - Transfer	217-7715
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-4145	Valve Gp - Press	247-4436
1S-1888	Bracket - Lamp	297-7147
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929

Original Part Number	Part Name	Classic Part Number
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0670	Converter As	235-1805 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-3632	Yoke As	297-4866
2M-3339	Piston - Clutch	221-7944
2N-9297	Retainer - Spring	314-8535
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-9038	Drum - Steering	216-7821
2S-3913	Cage - Gear Bearing	217-7722
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-4357	Pinion - Final Drive	217-7706
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8892	Pulley - Fan Drive	264-5874

Original Part Number	Part Name	Classic Part Number
3B-6218	Muffler As	247-2672
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-9394	Shaft - Planet	215-1680
3S-1262	Retainer	308-9915
3S-1274	Shaft - Center	215-1681
3S-2252	Manifold - Exhaust	261-0887
3S-2420	Pilot As - Spring	226-2733
3S-6989	Nut - Spanner	219-9701
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-7517	Pulley - Belt Adjustable	264-5876
3S-7519	Pulley - Damper As	264-5877
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-9919	Shaft As	239-7959
4F-4974	Clamp	311-9373
4M-0503	Gear As - Oil Pump	297-7184
4M-8967	Gear - Sun	219-9661
4M-9215	Gear - Pump Idler	311-9391
4N-4577	Muffler As	308-9877

(Continued)

Sales Model 583H (Continued)

Original Part Number	Part Name	Classic Part Number
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8472	Hood As	296-1355
5G-3612	Cap Gp	295-6419
5H-1719	Pump Gp - Final Drive Oil	226-0168
5L-8856	Coupling - Exhaust	311-9379
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3998	Gear - Ring	214-0528
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7953	Carrier As	239-7977
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5P-7807	Bearing - Ball	314-8502
5S-0135	Cage - Pinion Bearing	222-1766
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-1211	Cover - Valve	314-8665

Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-8847	Guide - Valve	314-8523
6P-0549	Guard - Final Drive Wear	223-4812
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-0602	Dog - Clutch	314-8515
7H-7630	Spacer	239-7962
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5289	Hub - Steering	217-7736
7M-5756	Gear - Ring	214-0531
7M-6621	Pump Gp - Oil	226-0172
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7Y-1517	Pipe As - Tail	301-5246
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948

Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-6004	Head As - Cylinder	247-3369
8P-5849	Plate As	223-6323
8P-8221	Plate - Guide	226-2748
8S-2123	Cage - Final Drive Bearing	217-7726
8S-2126	Spacer - Hub Bearing	222-1767
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-1026	Cage - Gear Bearing	216-7873
9S-8493	Bolt - Connecting Rod	311-9351

Original Part Number	Part Name	Classic Part Number
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520

Original Part Number	Part Name	Classic Part Number
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-6603	Gear - Transfer	217-7720

Original Part Number	Part Name	Classic Part Number
1M-6604	Gear - Transfer	217-7715
1M-9444	Retainer - Spring	299-2046
1P-4145	Valve Gp - Press	247-4436

(Continued)

Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket - Lamp	297-7147
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0670	Converter As	235-1805 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-3339	Piston - Clutch	221-7944
2N-9297	Retainer - Spring	314-8535
2P-0484	Chamber As	247-3296
2P-1126	Pulley - Camshaft	264-5868
2P-1129	Pulley - Tightener	264-5869
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-9037	Drum - Steering Clutch	219-9696
2P-9038	Drum - Steering	216-7821
2P-9039	Hub - Steering	219-9697
2S-3913	Cage - Gear Bearing	217-7722
2S-3966	Ring - Seal	297-7237
2S-4357	Pinion - Final Drive	217-7706
2S-7917	Gear - Pump Drive	247-4119

Original Part Number	Part Name	Classic Part Number
3H-3378	Gear As - Pump	298-2795
3L-1425	Bearing - Ball	311-9356
3P-1757	Yoke As - Idler	226-2729
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-9394	Shaft - Planet	215-1680
3S-1262	Retainer	308-9915
3S-1274	Shaft - Center	215-1681
3S-2252	Manifold - Exhaust	261-0887
3S-2420	Pilot As - Spring	226-2733
3S-6989	Nut - Spanner	219-9701
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-9919	Shaft As	239-7959
4M-0503	Gear As - Oil Pump	297-7184
4M-8967	Gear - Sun	219-9661
4N-4577	Muffler As	308-9877
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-5390	Pulley - Alt Drive	264-5879
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8472	Hood As	296-1355
5G-3612	Cap Gp	295-6419
5H-1719	Pump Gp - Final Drive Oil	226-0168
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-6673	Guard - F Idler Rh	226-2735

Original Part Number	Part Name	Classic Part Number
5M-6674	Guard - F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7953	Carrier As	239-7977
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5P-7807	Bearing - Ball	314-8502
5S-0135	Cage - Pinion Bearing	222-1766
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-0762	Pulley - Fan	264-5885
6N-5437	Muffler As	247-2674
6P-0549	Guard - Final Drive Wear	223-4812
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6T-1933	Collar - Idler End	226-2746
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-7630	Spacer	239-7962
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-8395	Piston - Clutch	223-6322

Sales Model 583K (Continued)

Original Part Number	Part Name	Classic Part Number
7N-3350	Gear As - Pump Drive	319-3437
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091

Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-6004	Head As - Cylinder	247-3369
8P-5849	Plate As	223-6323
8P-8221	Plate - Guide	226-2748
8S-2123	Cage - Final Drive Bearing	217-7726
8S-2126	Spacer - Hub Bearing	222-1767
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950

Original Part Number	Part Name	Classic Part Number
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-1026	Cage - Gear Bearing	216-7873
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model 594

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
1A-2846	Cap As - Filler	311-9368
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939

Original Part Number	Part Name	Classic Part Number
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-9297	Retainer - Spring	314-8535
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948

Original Part Number	Part Name	Classic Part Number
2P-1607	Pilot - Piston	239-7975
2P-6159	Pulley - Fan Drive	264-5873
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8961	Pulley - Tightener	264-5875
3F-7445	Bearing - Sleeve	314-8508
3P-2811	Flange	239-7976
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-9919	Shaft As	239-7959
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184

(Continued)

Sales Model 594 (Continued)

Original Part Number	Part Name	Classic Part Number
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5G-3612	Cap Gp	295-6419
5H-5553	Screw -Tap-pet Adjustable	311-9451
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7953	Carrier As	239-7977
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883

Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8847	Guide - Valve	314-8523
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-0602	Dog - Clutch	314-8515
7H-7630	Spacer	239-7962
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-1249	Piston - Clutch	215-1748
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7M-8395	Piston - Clutch	223-6322
7M-8397	Housing As	239-7956
7N-9810	Pin - Piston	311-9432
7S-1579	Nut - Spanner	239-7964
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-7975	Guard - Final Drive Wear	239-7966
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948

Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8P-5849	Plate As	223-6323
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
8S-3617	Chamber As	247-3302
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9M-3025	Cover As	299-2001
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-8493	Bolt - Connecting Rod	311-9351
7T-2036	Cap As - Filter	361-1721
8S-5438	Muffler As	360-7896
190-8609	Valve - Fill	360-2288

Sales Model 594H

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3632	Yoke As	297-4866
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942

Original Part Number	Part Name	Classic Part Number
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-9297	Retainer - Spring	314-8535
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-6159	Pulley - Fan Drive	264-5873
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2S-7917	Gear - Pump Drive	247-4119
2S-8961	Pulley - Tightener	264-5875
3F-7445	Bearing - Sleeve	314-8508
3P-2811	Flange	239-7976
3P-3259	Cage - Bearing	217-7728
3P-4089	Gear As - Ring	239-7952
3P-4094	Housing As	239-7954
3P-4096	Gear As - Ring	239-7953
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-9919	Shaft As	239-7959
4M-0433	Shaft - Steer	239-7960
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-5184	Muffler As	360-7874

Original Part Number	Part Name	Classic Part Number
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5G-3612	Cap Gp	295-6419
5H-5553	Screw - Tap-pet Adjustable	311-9451
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7953	Carrier As	239-7977
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8847	Guide - Valve	314-8523
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7H-0602	Dog - Clutch	314-8515
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707

(Continued)

Sales Model 594H (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7M-4603	Body - Fuel Valve	311-9348	8H-2810	Case As - Filter	314-8512	8P-4735	Piston - Clutch	239-7949
7M-4926	Retainer - Pin	314-8538	8M-0874	Plunger As - Valve	311-9439	8P-7396	Hub - Planet Gear	239-7967
7M-7817	Valve - Inlet	311-9474	8M-2549	Rod As - Connector	314-8537	8P-7595	Washer - Thrust	239-7940
7N-9810	Pin - Piston	311-9432	8M-4014	Insert - Seat Exhaust	311-9398	8P-7639	Gear - Planet	239-7935
7S-1579	Nut - Spanner	239-7964	8M-7166	Housing - Screen	297-7192	8S-3617	Chamber As	247-3302
7S-5787	Chamber As	247-3300	8M-8161	Flange - Shaft	215-1781	9G-7993	Cage - Gr Bearing Rh	239-7973
7S-6104	Gear - Sun	239-7934	8N-0597	Pulley	264-5890	9H-5233	Piston - Clutch	219-9708
7S-7400	Pump Gp	226-0173	8N-2275	Bearing - Sleeve	311-9365	9H-5433	Spacer	239-7963
7S-7809	Cap As - Radiator	295-6417	8N-3723	Valve - Exhaust	311-9472	9M-3025	Cover As	299-2001
7S-7975	Guard - Final Drive Wear	239-7966	8N-7780	Shield - Oil	314-8544	9P-3663	Carrier - Planet	213-6939
7T-2036	Cap As - Filter	361-1721	8N-9174	Liner - Cylinder	314-8531	9P-6592	Gear - Planet	215-1915
8E-7455	Gear - Planet	221-7947	8P-4734	Housing As	239-7955	9P-6594	Gear - Planet	215-1921
8E-7456	Gear - Planet	221-7948				9S-8493	Bolt - Connecting Rod	311-9351
8F-8858	Button Valve	314-8511						

Cat® Classic™ Parts for Scrapers

Scrapers have long, productive lives. They are designed to load, haul, dump, and compact at maximum efficiency. Maintenance costs, to keep the machines running efficiently at all times, need to be re-evaluated as the machine ages. To help you manage your maintenance costs, Caterpillar offers Classic parts for several models of scrapers.

Cat® Classic™ parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for scrapers includes:

- Differential
- Engine
- Final Drive
- Hitch
- Moving Undercarriage
- Transmission
- ...and many more.

Sales Model 613

Original Part Number	Part Name	Classic Part Number
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-1687	Wheel	226-5990
1V-2281	Carrier - Planet	226-5984
1V-2992	Gear - Diff Bevel	224-1301
1V-5724	Diff Gp	260-0776
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2V-6220	Shaft - Planet	221-9073
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3P-5672	Yoke	223-6313
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3V-8777	Gear - Spiral	297-7176
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4K-6212	Shaft - Bevel Pinion	223-4806

Original Part Number	Part Name	Classic Part Number
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Cam-shaft	299-2059
4N-4539	Sleeve	314-8720
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4W-2042	Spacer	325-6217
5D-0470	Valve Gp	314-8549
5K-1068	Retainer - Seal	260-0786
5K-5933	Cover As	247-4125
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
6K-2085	Shaft - Bevel Pinion	221-9102
6P-7704	Carrier - Ring	314-8658
6W-1629	Shaft - Bevel Pinion	297-7250
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-6883	Shaft	256-4778
7J-6886	Pin	256-4787

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
8B-5972	Bearing - Ball	314-8503
8D-2628	Nut	299-2027
8H-2810	Case As - Filter	314-8512
8J-3431	Pin	256-4789
8K-6015	Gear - Bevel Ring	221-9076
8K-6283	Gear - Sun	221-9077
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-4811	Hub As	224-1300
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672
9K-3413	Gear - Bevel Ring	223-4807
121-7746	Precleaner As	360-2311
3J-9133	Bearing - Sleeve	361-1691
4B-1455	Cap As - Filter	361-1719
7J-1309	Bearing - Aligning	360-2275
7T-2036	Cap As - Filter	361-1721
244-1090	Alarm - Back up	360-2345

(Continued)



Sales Model 613 (Continued)

Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl - Pre-cleaner	360-2296
2P-5081	Muffler As	360-7872

Sales Model 613B

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1M-7250	Bowl - Pre-cleaner	360-2296
1T-0020	Wheel - Turbine	297-4862
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-1687	Wheel	226-5990
1V-2281	Carrier - Planet	226-5984
1V-2992	Gear - Diff Bevel	224-1301
1V-5724	Diff Gp	260-0776
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2K-0535	Nut	299-2026
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-5081	Muffler As	360-7872
2V-6220	Shaft - Planet	221-9073
3J-9133	Bearing - Sleeve	361-1691
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3P-5672	Yoke	223-6313

Original Part Number	Part Name	Classic Part Number
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3V-8777	Gear - Spiral	297-7176
4B-1455	Cap As - Filter	361-1719
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4K-6212	Shaft - Bevel Pinion	223-4806
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Cam-shaft	299-2059
4N-4539	Sleeve	314-8720
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4W-2042	Spacer	325-6217
5K-1068	Retainer - Seal	260-0786
5K-5933	Cover As	247-4125
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
6K-2085	Shaft - Bevel Pinion	221-9102
6P-7704	Carrier - Ring	314-8658

Original Part Number	Part Name	Classic Part Number
6W-1629	Shaft - Bevel Pinion	297-7250
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-1309	Bearing - Aligning	360-2275
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As - Filter	361-1721
8D-2628	Nut	299-2027
8H-2810	Case As - Filter	314-8512
8J-3431	Pin	256-4789
8K-6015	Gear - Bevel Ring	221-9076
8K-6283	Gear - Sun	221-9077
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-4811	Hub As	224-1300
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672
9K-3413	Gear - Bevel Ring	223-4807

Sales Model 613C

Original Part Number	Part Name	Classic Part Number
176-9273	Piston	297-4860
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1987	Housing - Rotating	297-4864
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026

Original Part Number	Part Name	Classic Part Number
2V-5715	Bushing	299-1987
3P-5672	Yoke	223-6313
3T-9496	Plate - Retainer	299-2042
3V-8777	Gear - Spiral	297-7176
4E-8534	Retainer - Seal	300-2588
4K-9598	Retainer	297-7235

Original Part Number	Part Name	Classic Part Number
4N-2954	Sleeve - Cam-shaft	299-2059
4N-4539	Sleeve	314-8720
4V-7543	Retainer	281-1699
4V-8534	Shaft - Planet	281-1700
4V-8538	Gear - Ring	288-8720
4W-2042	Spacer	325-6217
5D-0470	Valve Gp	314-8549

(Continued)

Sales Model 613C (Continued)

Original Part Number	Part Name	Classic Part Number
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
5T-1362	Bearing - Spider	325-6011
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
6P-7742	Shaft - Planet	281-1695
6P-8003	Gear - Planet	281-1689
6T-3009	Piston - Clutch	297-7226
6T-6987	Piston - Clutch	297-7227

Original Part Number	Part Name	Classic Part Number
6W-1629	Shaft - Bevel Pinion	297-7250
7G-3454	Gear - Planet	300-2578
7G-3707	Piston - Clutch	302-2691
7G-4281	Housing As - Support	297-7201
7J-6461	Crown	325-6054
8B-5972	Bearing - Ball	314-8503
8D-2628	Nut	299-2027
8H-2810	Case As - Filter	314-8512
8K-6282	Gear - Sun	281-1698
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783

Original Part Number	Part Name	Classic Part Number
8V-3136	Gear - Differential Bevel	253-1442
9C-1528	Gear - Planet	223-4802
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672
9G-1231	Plate	297-7232
9G-8117	Housing As	302-2686
9G-9764	Yoke As	319-3478
9N-4460	Housing As	297-7203
244-1090	Alarm - Back up	360-2345
1W-4623	Muffler As	360-9622
3J-9133	Bearing - Sleeve	361-1691
7T-2036	Cap As - Filter	361-1721

Sales Model 621

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112

Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp - Water	296-1365
1A-2846	Cap As - Filler	311-9368
1J-6746	Pin	256-4817
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2D-7694	Shaft - Pivot	256-4774
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5531	Collar	256-4780
2J-5662	Shaft - Pivot	256-4775

Original Part Number	Part Name	Classic Part Number
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2S-2781	Plunger - Relief	311-9435
2S-4015	Plunger As - Valve	311-9438
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088

(Continued)

Sales Model 621 (Continued)

Scrapers

Original Part Number	Part Name	Classic Part Number
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3J-5190	Cap - Bearing	256-4837
3J-6497	Screw - Adjusting	256-4825
3J-9710	Bearing - Sleeve	256-4793
3L-1425	Bearing - Ball	311-9356
3S-2710	Shaft - Planet	260-0779
3S-9466	Bearing - Sleeve	314-8509
3S-9975	Piston - Clutch	260-0778
4E-0403	Gear - Planet	260-0781
4M-9215	Gear - Pump Idler	311-9391
4N-2954	Sleeve - Camshaft	299-2059
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5J-8052	Trunnion	256-4843
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674

Original Part Number	Part Name	Classic Part Number
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
7B-0503	Ballstud	308-9801
7C-4297	Seal As - Camshaft	325-6192
7G-2500	Gear - Planet	296-1350
7J-3390	Pin - Hitch	256-4786
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-1300	Pin As	256-4788
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-8652	Shaft	297-7252

Original Part Number	Part Name	Classic Part Number
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-6949	Plate - Retainer	260-0787
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785
9J-3346	Plate As - Trunnion	256-4839
9J-9543	Pin As	256-4791
9M-4789	Shaft - Gov Control	297-7256
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
244-1090	Alarm - Back up	360-2345

(Continued)

Sales Model 621 (Continued)

Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing - Sleeve	361-1691
4B-1455	Cap As - Filter	361-1719
9J-9427	Bearing - Sleeve	361-1695

Sales Model 621B

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977	2P-1170	Shaft As - Gear	296-1367	5F-6393	Shaft	308-9928
115-7550	Gasket - Plate	314-8667	2P-1738	Plate As - Oil Pan	325-6164	5L-8856	Coupling - Exhaust	311-9379
131-3815	Seal Gp - Basic	325-6193	2P-1739	Tube As - Pump	325-6229	5P-7807	Bearing - Ball	314-8502
167-8123	Damper As	299-2006	2P-1757	Hub - Fan Pulley	296-1357	5S-1211	Cover - Valve	314-8665
172-5185	Shaft - Water Pump	325-6201	2P-1781	Spacer - Oil Pump	325-6214	5S-4557	Bearing	311-9360
172-5188	Shaft - Water Pump	325-6202	2P-2519	Tube As - Inlet	325-6230	5S-6795	Chamber As	242-3437
172-5189	Impeller - Pump	295-5687	2P-5680	Turbine - Converter	308-9942	5S-9080	Pulley - Alt Drive	264-5883
172-5190	Impeller - Pump	325-6111	2P-6245	Shaft As - Pump	325-6197	6H-3957	Bearing - Ball	311-9358
172-6712	Impeller - Pump	325-6112	2S-4015	Plunger As - Valve	311-9438	6I-1346	Pump Gp - Oil	295-5674
172-7767	Pump Gp - Water	296-1365	2W-1086	Cover As - Cylinder Head	325-6049	6N-1036	Gear - Oil Pump	279-4991
177-9024	Adapter - Damper	299-1956	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	6N-8413	Housing - Pump	325-6110
180-3767	Adapter - Damper	299-1957	2W-7255	Shaft - Water Pump	325-6203	6N-9743	Support - Muffler	308-9940
1N-3576	Block Gp - Cylinder	279-4978	2W-7458	Crankshaft As	242-3439	7C-0942	Adapter As	302-2636
1N-3958	Elbow	325-6087	2W-7678	Gear - Water Pump	325-6088	7G-2500	Gear - Planet	296-1350
1P-9945	Bracket As - Fan	296-1344	3L-1425	Bearing - Ball	311-9356	7N-0110	Core As - Oil Cooler	319-3435
1P-9946	Shaft - Fan	325-6194	3S-2710	Shaft - Planet	260-0779	7N-1164	Mount As	295-5451
1S-4701	Pulley - Alt	264-5866	3S-9975	Piston - Clutch	260-0778	7N-3515	Gear - Camshaft	314-8669
1T-0665	Ring - Clamp	308-9918	4B-1455	Cap As - Filter	361-1719	7N-3536	Gear - Fuel	279-4993
1W-1219	Trunnion As	314-8724	4E-0403	Gear - Planet	260-0781	7N-5910	Impeller - Pump	314-8686
1W-1669	Piston	325-6158	4N-4864	Pump Gp - Fuel Transfer	242-3442	7N-9146	Gear - Flywheel Starter	279-4995
1W-1698	Housing - Transfer Pump	296-1356	4N-7693	Crankshaft As	242-3439	7N-9805	Pin - Piston	295-6438
1W-2491	Muffler As	360-7871	4P-3546	Valve As - Relief	325-6236	7S-3161	Lifter - Valve	279-4996
1W-4402	Gear - Camshaft	279-4981	4S-8472	Hood As	296-1355	7S-6723	Bracket - Alternator	299-1978
1W-4405	Gear - Crankshaft	279-4982	4W-0452	Seal As - Camshaft	325-6191	7S-7809	Cap As - Radiator	295-6417
244-1090	Alarm - Back up	360-2345				7T-2036	Cap As - Filter	361-1721
2F-5721	Bearing - Ball	311-9354				7W-0450	Gear - Water Pump	279-4997
						7W-0507	Gear - Oil Pump Drive	279-4998
						7W-0508	Gear - Fuel Pump Drive	296-1351

(Continued)

Sales Model 621B (Continued)

Scrapers

Original Part Number	Part Name	Classic Part Number
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8D-8829	Bearing - Sleeve	361-1692
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-7596	Bearing - Sleeve	361-1693
8M-0874	Plunger As - Valve	311-9439
8M-8652	Shaft	297-7252

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349

Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-6949	Plate - Retainer	260-0787
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-9184	Gear As	260-0785
9J-8323	Trunnion	361-1713
9J-9427	Bearing - Sleeve	361-1695
9M-4789	Shaft - Gov Control	297-7256
9S-8679	Chamber As	325-6042
9W-4702	Stator - Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716

Sales Model 621E

Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-2491	Muffler As	360-7871
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2P-5680	Turbine - Converter	308-9942
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3S-2710	Shaft - Planet	260-0779
4E-0403	Gear - Planet	260-0781
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
5D-0470	Valve Gp	314-8549
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
7C-0942	Adapter As	302-2636
7G-2500	Gear - Planet	296-1350
7G-2516	Gear - Planet	283-5203
7N-1164	Mount As	295-5451
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721

Original Part Number	Part Name	Classic Part Number
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8D-8829	Bearing - Sleeve	361-1692
8H-2810	Case As - Filter	314-8512
8J-7596	Bearing - Sleeve	361-1693
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8P-6949	Plate - Retainer	260-0787
8S-9184	Gear As	260-0785
9J-8323	Trunnion	361-1713
9J-9427	Bearing - Sleeve	361-1695
9W-4702	Stator - Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716

Sales Model 627

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977	2W-1086	Cover As - Cylinder Head	325-6049	5S-6795	Chamber As	242-3437
131-3815	Seal Gp - Basic	325-6193	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	5S-9080	Pulley - Alt Drive	264-5883
172-5188	Shaft - Water Pump	325-6202	2W-7458	Crankshaft As	242-3439	6H-3957	Bearing - Ball	311-9358
172-6712	Impeller - Pump	325-6112	2W-7678	Gear - Water Pump	325-6088	6I-1346	Pump Gp - Oil	295-5674
1J-6746	Pin	256-4817	2W-9978	Core As - Oil Cooler	279-4983	6N-1036	Gear - Oil Pump	279-4991
1N-3576	Block Gp - Cylinder	279-4978	3F-6185	Pin	295-5694	6N-8413	Housing - Pump	325-6110
1P-4303	Head As - Cylinder	242-3434	3H-7161	Pin	256-4819	6P-6739	Shaft - Planet	308-9929
1P-9945	Bracket As - Fan	296-1344	3H-7162	Collar	256-4830	7B-0503	Ballstud	308-9801
1P-9946	Shaft - Fan	325-6194	3J-5190	Cap - Bearing	256-4837	7C-4297	Seal As - Camshaft	325-6192
1P-9952	Impeller - Pump	314-8685	3J-6497	Screw - Adjusting	256-4825	7G-2476	Gear - Planet	223-4816
1S-4701	Pulley - Alt	264-5866	3J-6559	Cap - Bearing	296-1346	7G-2500	Gear - Planet	296-1350
1T-0665	Ring - Clamp	308-9918	3J-9710	Bearing - Sleeve	256-4793	7J-3390	Pin - Hitch	256-4786
1T-1993	Wheel - Turbine	235-0920	3L-1425	Bearing - Ball	311-9356	7M-2167	Ring - Governor Control	308-9919
1T-2052	Stator As	295-5683	3S-1262	Retainer	308-9915	7N-0110	Core As - Oil Cooler	319-3435
1W-4405	Gear - Crankshaft	279-4982	3S-2710	Shaft - Planet	260-0779	7N-1164	Mount As	295-5451
2D-7694	Shaft - Pivot	256-4774	3S-9466	Bearing - Sleeve	314-8509	7N-9145	Gear - Fly-wheel	279-4994
2F-5721	Bearing - Ball	311-9354	3S-9975	Piston - Clutch	260-0778	7N-9146	Gear - Fly-wheel Starter	279-4995
2J-5394	Collar	256-4779	4E-0403	Gear - Planet	260-0781	7N-9312	Damper As - Camshaft	299-2005
2J-5531	Collar	256-4780	4J-2414	Trunnion	296-1370	7N-9805	Pin - Piston	295-6438
2J-5662	Shaft - Pivot	256-4775	4J-6374	Bearing - Sleeve	295-6407	7S-3161	Lifter - Valve	279-4996
2P-1170	Shaft As - Gear	296-1367	4M-9215	Gear - Pump Idler	311-9391	7S-6723	Bracket - Alternator	299-1978
2P-1738	Plate As - Oil Pan	325-6164	4N-7693	Crankshaft As	242-3439	7S-7809	Cap As - Radiator	295-6417
2P-1739	Tube As - Pump	325-6229	4P-3546	Valve As - Relief	325-6236	7W-0450	Gear - Water Pump	279-4997
2P-1757	Hub - Fan Pulley	296-1357	4S-8472	Hood As	296-1355	7W-0507	Gear - Oil Pump Drive	279-4998
2P-1781	Spacer - Oil Pump	325-6214	4W-0452	Seal As - Camshaft	325-6191	7W-5687	Hub - Camshaft	314-8684
2P-2519	Tube As - Inlet	325-6230	5D-0470	Valve Gp	314-8549	7Y-1517	Pipe As - Tail	301-5246
2P-6128	Pulley	264-5872	5F-6393	Shaft	308-9928	8H-9806	Gear - Shaft Drive	325-6091
2P-6245	Shaft As - Pump	325-6197	5J-4924	Shaft - Pivot	256-4777	8J-1300	Pin As	256-4788
2S-2781	Plunger - Relief	311-9435	5J-4929	Bearing	256-4796	8M-0874	Plunger As - Valve	311-9439
2S-4015	Plunger As - Valve	311-9438	5J-7980	Pin	256-4783	8M-2549	Rod As - Connector	314-8537
2S-6739	Pulley - Tightener	298-2794	5J-7981	Pin	256-4784	8M-7166	Housing - Screen	297-7192
			5J-7983	Pin	256-4785	8M-8652	Shaft	297-7252
			5J-8052	Trunnion	256-4843	8N-0002	Trunnion As	314-8728
			5M-7841	Gear - Ring	214-0525			
			5P-7807	Bearing - Ball	314-8502			
			5S-1211	Cover - Valve	314-8665			
			5S-4557	Bearing	311-9360			

Scrapers

(Continued)

Sales Model 627 (Continued)

Scrapers

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-7315	Tube As - Outlet	325-6232

Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing - Main	314-8652
8P-6949	Plate - Retainer	260-0787
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785
9H-2256	Pump Gp	311-9443
9J-3346	Plate As - Trunnion	256-4839
9J-9543	Pin As	256-4791

Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-7079	Muffler As	247-2669
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
244-1090	Alarm - Backup	360-2345
3J-9133	Bearing - Sleeve	361-1691
4B-1455	Cap As - Filter	361-1719
7J-1309	Bearing - Aligning	360-2275
9J-9427	Bearing - Sleeve	361-1695

Sales Model 627B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
102-1561	Lifter As - Valve	311-9402
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202

Original Part Number	Part Name	Classic Part Number
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6749	Screw - Adjustable	256-4824
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460

Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1S-7114	Bolt	314-8500
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929

(Continued)

Sales Model 627B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1T-0256	Gear - Pump Drive	239-7930	2M-8762	Drum - Steering	239-7944	2V-5715	Bushing	299-1987
1T-0595	Carrier - Wheel	239-7939	2N-3220	Gear - Oil Pump Drive	311-9392	2V-5722	Carrier - Planet	297-7164
1T-0611	Converter As	235-1804 (Repair Kit)	2N-9297	Retainer - Spring	314-8535	2W-1086	Cover As - Cylinder Head	325-6049
1T-0665	Ring - Clamp	308-9918	2P-0483	Chamber As	256-4760	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
1T-1389	Carrier - Bearing	247-4124	2P-0484	Chamber As	247-3296	2W-6757	Trunnion As	295-5678
1T-1993	Wheel - Turbine	235-0920	2P-1170	Shaft As - Gear	296-1367	2W-7255	Shaft - Water Pump	325-6203
1T-2052	Stator As	295-5683	2P-1554	Gear - Ring	239-7931	2W-7458	Crankshaft As	242-3439
1W-1219	Trunnion As	314-8724	2P-1606	Piston - Steering	239-7948	2W-7678	Gear - Water Pump	325-6088
1W-1669	Piston	325-6158	2P-1607	Pilot - Piston	239-7975	2W-8494	Pulley - Alt	295-5692
1W-1695	Pump Gp	279-4980	2P-1738	Plate As - Oil Pan	325-6164	2W-9978	Core As - Oil Cooler	279-4983
1W-1698	Housing - Transfer Pump	296-1356	2P-1739	Tube As - Pump	325-6229	3F-4971	Pin	295-5693
1W-3062	Retainer As	311-9445	2P-1757	Hub - Fan Pulley	296-1357	3F-6185	Pin	295-5694
1W-4402	Gear - Camshaft	279-4981	2P-1781	Spacer - Oil Pump	325-6214	3F-6446	Pivot - Push Pole	256-4827
1W-4405	Gear - Crankshaft	279-4982	2P-2406	Pulley	264-5870	3F-6523	Pin - Clevis	256-4818
1W-5912	Tappet As - Guide	325-6223	2P-2519	Tube As - Inlet	325-6230	3F-6561	Arm As - Brace	256-4828
1W-6541	Plunger As	325-6173	2P-3586	Piston - Clutch	260-0777	3F-6611	Socket - Joint	256-4829
244-1090	Alarm - Back up	360-2345	2P-5680	Turbine - Converter	308-9942	3F-6612	Cap - Ball Joint	297-7155
2F-5721	Bearing - Ball	311-9354	2P-6128	Pulley	264-5872	3F-7445	Bearing - Sleeve	314-8508
2J-5394	Collar	256-4779	2P-6159	Pulley - Fan Drive	264-5873	3H-3378	Gear As - Pump	298-2795
2J-5468	Pin - Pivot	256-4781	2P-6245	Shaft As - Pump	325-6197	3J-6043	Trunnion	319-3477
2J-5531	Collar	256-4780	2S-2781	Plunger - Relief	311-9435	3J-9710	Bearing - Sleeve	256-4793
2J-5649	Pin - Cylinder	256-4782	2S-3966	Ring - Seal	297-7237	3K-5461	Wheel - Steering	308-9945
2J-5662	Shaft - Pivot	256-4775	2S-4015	Plunger As - Valve	311-9438	3L-1425	Bearing - Ball	311-9356
2J-8489	Bearing - Sleeve	295-5691	2S-6739	Pulley - Tightener	298-2794	3N-3368	Pipe - Exhaust	311-9434
2K-0535	Nut	299-2026	2S-7264	Pump As - Fuel Injector	311-9442	3P-2811	Flange	239-7976
2L-4731	Adapter - Housing	311-9343	2S-7873	Pump Gp	226-0162	3P-3208	Flange - Joint	301-4647
2M-1129	Cap - Support	239-7974	2S-7917	Gear - Pump Drive	247-4119	3P-3259	Cage - Bearing	217-7728
2M-2150	Nut - Spanner	239-7965	2S-7920	Pump Gp - Scavenge	217-2594	3P-4002	Pump Gp - Gear	217-2595
2M-3339	Piston - Clutch	221-7944	2S-8961	Pulley - Tightener	264-5875	3P-4850	Gear As - Oil Pump	308-9848
2M-5588	Gear - Final Drive	239-7936	2V-5697	Cover As	299-1999	3P-4855	Pump Gp	217-2596
2M-5589	Pinion - Final Drive	239-7942	2V-5714	Gear - Ring	288-8716	3P-6269	Cage - Pinion Bearing	239-7972
2M-6920	Hub - Steering	239-7968				3P-9394	Shaft - Planet	215-1680
2M-6960	Cage - Gear Bearing	239-7971						
2M-6984	Drum	239-7946						

(Continued)

Sales Model 627B (Continued)

Scrapers

Original Part Number	Part Name	Classic Part Number
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-2710	Shaft - Planet	260-0779
3S-9466	Bearing - Sleeve	314-8509
3S-9919	Shaft As	239-7959
3S-9975	Piston - Clutch	260-0778
3V-8777	Gear - Spiral	297-7176
4B-1455	Cap As - Filter	361-1719
4E-0403	Gear - Planet	260-0781
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
4J-3583	Screw - Adjusting	297-7242
4K-6810	Retainer - Seal	300-2586
4K-8225	Pin - Cylinder	297-7215
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8845	Shaft - Planet	215-1685
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260

Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-5833	Spacer	239-7961
4S-8472	Hood As	296-1355
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4V-5213	Spindle	299-2060
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-9989	Gear As - Idler	302-2677
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5F-7993	Pin	319-3454
5H-5553	Screw - Tapet Adjustable	311-9451
5J-4321	Trunnion	302-2700
5J-4798	Bearing As	256-4840
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-6417	Bearing	256-4798
5J-6418	Bearing - Sleeve	256-4799
5J-6419	Bearing - Sleeve	256-4800
5J-6421	Bearing	256-4801
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5J-8052	Trunnion	256-4843
5L-8856	Coupling - Exhaust	311-9379
5L-9738	Coupling - Exhaust	311-9380
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318

Original Part Number	Part Name	Classic Part Number
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7841	Gear - Ring	214-0525
5M-7900	Bolt - Hex Head	311-9349
5M-7953	Carrier As	239-7977
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-1480	Gear - Sun	288-8721
5V-4075	Gear - Planet	288-8722
5V-5917	Pinion - Diff Bevel	297-7224
6F-3183	Cap - Bearing	325-6038
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6I-0341	Line As - Fuel Injector	325-6117
6I-0342	Line As - Fuel Injector	325-6118
6I-0343	Line As - Fuel Injector	325-6119
6I-0344	Line As - Fuel Injector	325-6120
6I-0345	Line As - Fuel Injector	325-6121
6I-0346	Line As - Fuel Injector	325-6122
6I-1346	Pump Gp - Oil	295-5674
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526

(Continued)

Sales Model 627B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
6L-8968	Coupling - Exhaust	311-9381	7M-4603	Body - Fuel Valve	311-9348	7W-0450	Gear - Water Pump	279-4997
6N-1036	Gear - Oil Pump	279-4991	7M-4926	Retainer - Pin	314-8538	7W-0507	Gear - Oil Pump Drive	279-4998
6N-1965	Line As - Fuel Injector	250-7535	7M-5756	Gear - Ring	214-0531	7W-0508	Gear - Fuel Pump Drive	296-1351
6N-1966	Line As - Fuel Injector	250-7536	7M-7431	Service Gp - Valve	314-8550	7W-1902	Adapter - Fuel Nozzle	299-1955
6N-2789	Pulley	264-5886	7M-7817	Valve - Inlet	311-9474	7W-2164	Core As - Oil Cooler	299-1996
6N-6969	Chamber As	247-3299	7M-8395	Piston - Clutch	223-6322	7W-5687	Hub - Cam-shaft	314-8684
6N-7295	Manifold - Exhaust	261-0903	7M-8397	Housing As	239-7956	7W-5698	Pulley - Cam-shaft	295-5679
6N-8413	Housing - Pump	325-6110	7N-0110	Core As - Oil Cooler	319-3435	8D-2628	Nut	299-2027
6N-8847	Guide - Valve	314-8523	7N-1164	Mount As	295-5451	8D-8829	Bearing - Sleeve	361-1692
6N-9743	Support - Muffler	308-9940	7N-2871	Line As - Fuel Injector	319-8172	8E-7455	Gear - Planet	221-7947
6P-6739	Shaft - Planet	308-9929	7N-2872	Line As - Fuel Injector	319-8173	8E-7456	Gear - Planet	221-7948
6P-7704	Carrier - Ring	314-8658	7N-2874	Line As - Fuel Injector	298-2779	8E-9795	Connector As	256-4851
6T-4481	Shaft - Planet	221-7946	7N-2875	Line As - Fuel Injector	298-2780	8F-5104	Screen As - Oil Pan	314-8539
6W-1629	Shaft - Bevel Pinion	297-7250	7N-2876	Line As - Fuel Injector	298-2781	8F-8858	Button Valve	314-8511
7B-0503	Ballstud	308-9801	7N-2949	Pulley	264-5887	8F-9365	Pin	319-3463
7B-2420	Ferrule - Director	314-8517	7N-3515	Gear - Cam-shaft	314-8669	8H-1993	Valve - Inlet	256-4765
7C-0942	Adapter As	302-2636	7N-3536	Gear - Fuel	279-4993	8H-1994	Valve - Exhaust	256-4765
7C-4297	Seal As - Camshaft	325-6192	7N-5910	Impeller - Pump	314-8686	8H-2810	Case As - Filter	314-8512
7G-2476	Gear - Planet	223-4816	7N-9145	Gear - Fly-wheel	279-4994	8H-9806	Gear - Shaft Drive	325-6091
7G-2492	Gear - Planet	239-7933	7N-9146	Gear - Fly-wheel Starter	279-4995	8J-2652	Shaft	299-2054
7G-2500	Gear - Planet	296-1350	7N-9312	Damper As - Camshaft	299-2005	8J-2653	Lever As	299-2015
7G-2511	Gear - Planet	260-0782	7N-9805	Pin - Piston	295-6438	8J-2654	Lever As	299-2016
7G-2516	Gear - Planet	283-5203	7N-9810	Pin - Piston	311-9432	8J-7596	Bearing - Sleeve	361-1693
7G-2830	Ring - Seal	295-6441	7S-1579	Nut - Spanner	239-7964	8M-0874	Plunger As - Valve	311-9439
7G-5618	Manifold As	283-5204	7S-3161	Lifter - Valve	279-4996	8M-2549	Rod As - Connector	314-8537
7G-7724	Piston - Clutch	283-5206	7S-5787	Chamber As	247-3300	8M-4014	Insert - Seat Exhaust	311-9398
7G-9555	Bearing - Spider	314-8721	7S-6104	Gear - Sun	239-7934	8M-7166	Housing - Screen	297-7192
7H-0602	Dog - Clutch	314-8515	7S-6723	Bracket - Alternator	299-1978	8M-8161	Flange - Shaft	215-1781
7H-7630	Spacer	239-7962	7S-7400	Pump Gp	226-0173	8M-8652	Shaft	297-7252
7J-3390	Pin - Hitch	256-4786	7S-7809	Cap As - Radiator	295-6417	8N-0002	Trunnion As	314-8728
7M-1184	Housing As	219-9704	7S-7975	Guard - Final Drive Wear	239-7966	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
7M-1185	Housing As	219-9705	7S-8631	Shaft As	275-5296			
7M-1186	Housing As	219-9706	7S-9749	Pulley - Gen Drive	264-5888			
7M-1195	Housing - Clutch	219-9707	7T-2036	Cap As - Filter	361-1721			
7M-1249	Piston - Clutch	215-1748						
7M-2167	Ring - Governor Control	308-9919						

(Continued)

Sales Model 627B (Continued)

Scrapers

Original Part Number	Part Name	Classic Part Number
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2275	Bearing - Sleeve	311-9365
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-3723	Valve - Exhaust	311-9472
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6004	Head As - Cylinder	247-3369
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9174	Liner - Cylinder	314-8531
8N-9489	Chamber As	247-3301
8N-9733	Line As - Fuel Injector	319-8174
8P-0953	Turbine - Converter	297-7269
8P-1919	Gear - Planet	300-2579
8P-5849	Plate As	223-6323

Original Part Number	Part Name	Classic Part Number
8P-6949	Plate - Retainer	260-0787
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8P-8677	Hub - Impeller	297-7205
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
8S-3617	Chamber As	247-3302
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-5852	Hub As	297-7208
9C-8205	Gear - Bevel	319-8175
9C-9773	Gear - Differential Bevel	302-2672
9G-0280	Piston - Clutch	283-5213

Original Part Number	Part Name	Classic Part Number
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-2256	Pump Gp	311-9443
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9J-2988	--	--
9J-3346	Plate As - Trunnion	256-4839
9J-8323	Trunnion	361-1713
9J-9543	Pin As	256-4791
9M-1328	Bearing - Aligning	325-6018
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-6129	Pulley - Alternator Drive	264-5891
9S-6743	Chamber As	247-3303
9S-7079	Muffler As	247-2669
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9W-1677	Bearing	297-7145
9W-3605	Carrier - Ring	314-8662
9W-4702	Stator - Converter	308-9939
9W-9930	Mount As	295-6437

Sales Model 627E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193

Original Part Number	Part Name	Classic Part Number
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201

(Continued)

Sales Model 627E (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
172-5188	Shaft - Water Pump	325-6202	2P-2519	Tube As - Inlet	325-6230	6H-3957	Bearing - Ball	311-9358
172-5189	Impeller - Pump	295-5687	2P-5680	Turbine - Converter	308-9942	6I-0341	Line As - Fuel Injector	325-6117
172-5190	Impeller - Pump	325-6111	2P-6128	Pulley	264-5872	6I-0342	Line As - Fuel Injector	325-6118
172-6712	Impeller - Pump	325-6112	2P-6245	Shaft As - Pump	325-6197	6I-0343	Line As - Fuel Injector	325-6119
172-7767	Pump Gp - Water	296-1365	2W-1086	Cover As - Cylinder Head	325-6049	6I-0344	Line As - Fuel Injector	325-6120
177-9024	Adapter - Damper	299-1956	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	6I-0345	Line As - Fuel Injector	325-6121
180-3767	Adapter - Damper	299-1957	2W-6757	Trunnion As	295-5678	6I-0346	Line As - Fuel Injector	325-6122
1N-3576	Block Gp - Cylinder	279-4978	2W-7255	Shaft - Water Pump	325-6203	6I-1346	Pump Gp - Oil	295-5674
1N-3958	Elbow	325-6087	2W-7458	Crankshaft As	242-3439	6N-1036	Gear - Oil Pump	279-4991
1P-9945	Bracket As - Fan	296-1344	2W-7678	Gear - Water Pump	325-6088	6N-2789	Pulley	264-5886
1P-9946	Shaft - Fan	325-6194	2W-8494	Pulley - Alt	295-5692	6N-8413	Housing - Pump	325-6110
1S-4701	Pulley - Alt	264-5866	3F-6185	Pin	295-5694	6P-6739	Shaft - Planet	308-9929
1T-0665	Ring - Clamp	308-9918	3L-1425	Bearing - Ball	311-9356	7C-0942	Adapter As	302-2636
1T-1993	Wheel - Turbine	235-0920	3P-2768	Piston - Clutch	308-9909	7C-4297	Seal As - Camshaft	325-6192
1T-2052	Stator As	295-5683	3S-1262	Retainer	308-9915	7E-0853	Muffler As	360-7887
1W-1669	Piston	325-6158	3S-2710	Shaft - Planet	260-0779	7G-2500	Gear - Planet	296-1350
1W-1695	Pump Gp	279-4980	4E-0403	Gear - Planet	260-0781	7G-2516	Gear - Planet	283-5203
1W-1698	Housing - Transfer Pump	296-1356	4N-7693	Crankshaft As	242-3439	7N-0110	Core As - Oil Cooler	319-3435
1W-2491	Muffler As	360-7871	4P-3546	Valve As - Relief	325-6236	7N-1164	Mount As	295-5451
1W-4402	Gear - Camshaft	279-4981	4P-9381	Line As - Fuel Injector	279-4984	7N-5910	Impeller - Pump	314-8686
1W-4405	Gear - Crankshaft	279-4982	4P-9382	Line As - Fuel Injector	279-4985	7N-9145	Gear - Flywheel	279-4994
1W-5912	Tappet As - Guide	325-6223	4P-9385	Line As - Fuel Injector	279-4986	7N-9146	Gear - Flywheel Starter	279-4995
1W-6541	Plunger As	325-6173	4P-9386	Line As - Fuel Injector	279-4987	7N-9805	Pin - Piston	295-6438
244-1090	Alarm - Back up	360-2345	4P-9961	Line As - Fuel Injector	325-6115	7S-3161	Lifter - Valve	279-4996
2F-5721	Bearing - Ball	311-9354	4S-8472	Hood As	296-1355	7S-6723	Bracket - Alternator	299-1978
2P-1170	Shaft As - Gear	296-1367	4W-0452	Seal As - Camshaft	325-6191	7S-7809	Cap As - Radiator	295-6417
2P-1738	Plate As - Oil Pan	325-6164	4W-2042	Spacer	325-6217	7T-2036	Cap As - Filter	361-1721
2P-1739	Tube As - Pump	325-6229	4W-2446	Damper As	279-4990	7W-0450	Gear - Water Pump	279-4997
2P-1757	Hub - Fan Pulley	296-1357	5D-0470	Valve Gp	314-8549	7W-0507	Gear - Oil Pump Drive	279-4998
2P-1781	Spacer - Oil Pump	325-6214	5P-7807	Bearing - Ball	314-8502	7W-0508	Gear - Fuel Pump Drive	296-1351
2P-2406	Pulley	264-5870	5S-1211	Cover - Valve	314-8665	7W-1902	Adapter - Fuel Nozzle	299-1955
			5S-4557	Bearing	311-9360	7W-2164	Core As - Oil Cooler	299-1996
			5S-6795	Chamber As	242-3437			
			5S-9080	Pulley - Alt Drive	264-5883			

(Continued)

Sales Model 627E (Continued)

Scrapers

Original Part Number	Part Name	Classic Part Number
7W-5687	Hub - Cam-shaft	314-8684
7W-5698	Pulley - Cam-shaft	295-5679
8D-8829	Bearing - Sleeve	361-1692
8H-2810	Case As - Filter	314-8512
8J-7596	Bearing - Sleeve	361-1693
8M-7166	Housing - Screen	297-7192
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208

Original Part Number	Part Name	Classic Part Number
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-6949	Plate - Retainer	260-0787
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-9184	Gear As	260-0785
9J-8323	Trunnion	361-1713
9J-9427	Bearing - Sleeve	361-1695
9M-1328	Bearing - Aligning	325-6018
9N-5769	Cover - Housing	325-6050
9S-8679	Chamber As	325-6042
9W-4702	Stator - Converter	308-9939
9W-9930	Mount As	295-6437
9Y-2988	Breather As	361-1716

Sales Model 631A

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
2J-5394	Collar	256-4779
2J-5468	Pin - Pivot	256-4781
2J-5531	Collar	256-4780
2J-5649	Pin - Cylinder	256-4782
2J-5662	Shaft - Pivot	256-4775
2P-3586	Piston - Clutch	260-0777
2S-3966	Ring - Seal	297-7237

Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing - Sleeve	361-1691
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4M-8845	Shaft - Planet	215-1685
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928

Original Part Number	Part Name	Classic Part Number
5J-4929	Bearing	256-4796
5S-1211	Cover - Valve	314-8665
7B-0503	Ballstud	308-9801
7G-2511	Gear - Planet	260-0782
7G-2830	Ring - Seal	295-6441
7H-0602	Dog - Clutch	314-8515
7M-1249	Piston - Clutch	215-1748
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539

Sales Model 631B

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1S-4701	Pulley - Alt	264-5866
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5468	Pin - Pivot	256-4781
2J-5531	Collar	256-4780

Original Part Number	Part Name	Classic Part Number
2J-5649	Pin - Cylinder	256-4782
2J-5662	Shaft - Pivot	256-4775
2P-3586	Piston - Clutch	260-0777
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438

Original Part Number	Part Name	Classic Part Number
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4M-8845	Shaft - Planet	215-1685
4M-9215	Gear - Pump Idler	311-9391

(Continued)

Sales Model 631B (Continued)

Original Part Number	Part Name	Classic Part Number
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-6417	Bearing	256-4798
5J-6418	Bearing - Sleeve	256-4799
5J-6419	Bearing - Sleeve	256-4800
5J-6421	Bearing	256-4801

Original Part Number	Part Name	Classic Part Number
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
5V-4075	Gear - Planet	288-8722
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
7B-0503	Ballstud	308-9801
7G-2511	Gear - Planet	260-0782
7G-2830	Ring - Seal	295-6441
7H-0602	Dog - Clutch	314-8515

Original Part Number	Part Name	Classic Part Number
7M-1249	Piston - Clutch	215-1748
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
9J-9543	Pin As	256-4791

Sales Model 631C

Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2J-5394	Collar	256-4779
2J-5531	Collar	256-4780
2J-5662	Shaft - Pivot	256-4775
2P-1757	Hub - Fan Pulley	296-1357
2S-2781	Plunger - Relief	311-9435
2S-3966	Ring - Seal	297-7237
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3L-1425	Bearing - Ball	311-9356
3S-9975	Piston - Clutch	260-0778

Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As - Filter	361-1719
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5J-4924	Shaft - Pivot	256-4777
5J-4929	Bearing	256-4796
5J-6417	Bearing	256-4798
5J-6418	Bearing - Sleeve	256-4799
5J-6419	Bearing - Sleeve	256-4800
5J-6421	Bearing	256-4801
5J-7980	Pin	256-4783
5J-7981	Pin	256-4784
5J-7983	Pin	256-4785
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
5V-1480	Gear - Sun	288-8721
5V-4075	Gear - Planet	288-8722
6H-3957	Bearing - Ball	311-9358
7B-0503	Ballstud	308-9801
7C-3567	Mount As	314-8689

Original Part Number	Part Name	Classic Part Number
7G-2516	Gear - Planet	283-5203
7J-3390	Pin - Hitch	256-4786
7N-1164	Mount As	295-5451
7S-7809	Cap As - Radiator	295-6417
7S-8631	Shaft As	275-5296
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-8652	Shaft	297-7252
8P-6949	Plate - Retainer	260-0787
8S-9184	Gear As	260-0785
9D-0120	Gear - Planet	288-8737
9D-0127	Gear - Sun	288-8738
9J-0940	Pin	319-3467
9J-9427	Bearing - Sleeve	361-1695
9J-9543	Pin As	256-4791
9S-8789	Plate - Clutch	302-2712
9W-9930	Mount As	295-6437

Sales Model 631D

Scrapers

Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2P-1757	Hub - Fan Pulley	296-1357
307-1303	Muffler As	361-6574
3G-0034	Trunnion	361-1712
3J-9133	Bearing - Sleeve	361-1691
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3S-9975	Piston - Clutch	260-0778
4B-1455	Cap As - Filter	361-1719
4N-6302	Belt Set - Vee	314-8495
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5J-7983	Pin	256-4785
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
5V-1480	Gear - Sun	288-8721
5V-4075	Gear - Planet	288-8722
6H-3957	Bearing - Ball	311-9358
7C-3567	Mount As	314-8689
7G-2516	Gear - Planet	283-5203
7N-1164	Mount As	295-5451

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7S-8631	Shaft As	275-5296
7T-2036	Cap As - Filter	361-1721
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-8652	Shaft	297-7252
8P-6949	Plate - Retainer	260-0787
8S-9184	Gear As	260-0785
9D-0120	Gear - Planet	288-8737
9D-0127	Gear - Sun	288-8738
9J-0940	Pin	319-3467
9J-1105	Pin As	256-4790
9Y-2988	Breather As	361-1716

Cat® Classic™ Parts for Track Loaders

Track Loaders have long, productive lives. Their usage changes as the machine ages, so maintenance costs need to be re-evaluated. Caterpillar offers Classic parts for several models of track loaders to ensure a value priced repair option is available.

Cat® Classic™ parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for track loaders includes:

- Engine
- Final Drive
- Linkage Pins
- Moving Undercarriage
- Non-Moving Undercarriage
- Steering
- Torque Converter
- Transmission
- Trunnion/Blade Support
- ...and many more.



Sales Model 931, 931B, 931C, 933, 933C, 935B, 935C

Original Part Number	Part Name	Classic Part Number
164-1047	Idler Gp	275-3581
185-4037	Idler Gp	275-3581
190-8609	Valve - Fill	360-2288
244-1090	Alarm - Back up	360-2345
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579

Original Part Number	Part Name	Classic Part Number
2K-6413	Pin	360-2270
323-8756	Link As.	257-1992
323-8757	Link As.	257-1990
323-8758	Link As.	257-1994
323-8759	Link As.	257-1991
4B-1455	Cap As - Filter	361-1719
4N-6638	Muffler As	360-7875

Original Part Number	Part Name	Classic Part Number
5A-3187	Bolt Master	257-7773
6S-3609	Roller - Carrier	275-3578
6Y-1711	Link As.	261-8008
6Y-1713	Link As.	257-1993
7T-2036	Cap As - Filter	361-1721
9Y-9431	Precleaner As	361-1718

Sales Model 941

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201

Original Part Number	Part Name	Classic Part Number
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1930	Cage - Pinion Bearing	217-7727

Original Part Number	Part Name	Classic Part Number
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

(Continued)

Sales Model 941 (Continued)

Original Part Number	Part Name	Classic Part Number
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367

Original Part Number	Part Name	Classic Part Number
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3S-8800	Gear - Driven	325-6090
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-0300	Bearing - Sleeve	308-9817
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684

Original Part Number	Part Name	Classic Part Number
4K-5109	Gear - Reverse	219-9659
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Flywheel	302-2704

(Continued)

Sales Model 941 (Continued)

Original Part Number	Part Name	Classic Part Number
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6K-3447	Pin	241-2576
6K-3937	Pin	241-2557
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6Y-0710	Gear	226-6104
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565

Original Part Number	Part Name	Classic Part Number
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512

Original Part Number	Part Name	Classic Part Number
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988

(Continued)

Sales Model 941 (Continued)

Original Part Number	Part Name	Classic Part Number
9H-2256	Pump Gp	311-9443
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730

Original Part Number	Part Name	Classic Part Number
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050

Original Part Number	Part Name	Classic Part Number
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 941B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087

Original Part Number	Part Name	Classic Part Number
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817

Original Part Number	Part Name	Classic Part Number
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

(Continued)

Sales Model 941B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2W-7678	Gear - Water Pump	325-6088	4P-9963	Line As - Fuel Injector	298-2777	7H-2742	Nut	229-8220
3F-1537	Nut - Spanner	226-6098	4P-9964	Line As - Fuel Injector	298-2778	7J-9682	Bearing - Sleeve	360-2335
3K-3124	Muffler - Trap	247-2673	4S-8660	Pump Gp - Transmission	226-0167	7K-3582	Nut - Adjusting	226-6099
3L-1425	Bearing - Ball	311-9356	4S-8670	Shaft - Planet	300-2590	7K-4458	Gear - Final Drive	226-6093
3S-7987	Shaft - Planet	226-6074	4S-8687	Piston - Clutch	226-8008	7K-4512	Pinion - Final Drive	226-6081
3S-7996	Gear - Ring	226-6087	4S-8707	Shaft & Sun Gear	226-6089	7K-4770	Pinion	226-6082
3S-8007	Coupling	226-6088	4S-8713	Gear - Ring	226-6090	7K-4771	Gear	229-8221
3V-5916	Plate As - Press	226-8025	4V-2744	Gear	224-1303	7K-8237	Drum	226-6100
4F-4974	Clamp	311-9373	4V-3396	Hub - Gear	222-1763	7K-8238	Flange	213-8166
4K-0255	Retainer As	226-6102	4V-3397	Hub - Gear	219-2979	7K-9360	Pin	319-3461
4K-0300	Bearing - Sleeve	308-9817	4W-0452	Seal As - Camshaft	325-6191	7K-9361	Pin	241-2565
4K-1328	Drum - Steering (Drum), 230-7112 (Steering Clutch Kit)	216-7840	5G-3612	Cap Gp	295-6419	7M-2167	Ring - Governor Control	308-9919
4K-4632	Gear - Bevel	216-7842	5K-6090	Flange	216-7844	7M-4603	Body - Fuel Valve	311-9348
4K-4780	Strip As - Wear	299-2063	5K-8606	Cage - Gear Bearing	223-6310	7N-0128	Core As - Oil Cooler	299-1994
4N-2954	Sleeve - Camshaft	299-2059	5P-7807	Bearing - Ball	314-8502	7N-0165	Core As - Oil Cooler	295-5670
4N-3281	Line As - Fuel Injector	247-3362	5S-0884	Gear - Ring	226-7982	7N-2871	Line As - Fuel Injector	319-8172
4N-3282	Line As - Fuel Injector	247-3363	5S-0885	Plate - Front	229-8234	7N-2872	Line As - Fuel Injector	319-8173
4N-3283	Line As - Fuel Injector	247-3364	5S-0894	Shaft - Center	226-6075	7N-2874	Line As - Fuel Injector	298-2779
4N-3284	Line As - Fuel Injector	247-3365	5S-6795	Chamber As	242-3437	7N-2949	Pulley	264-5887
4N-4539	Sleeve	314-8720	5S-7609	Pulley - Alt Drive	264-5881	7N-3515	Gear - Camshaft	314-8669
4N-4864	Pump Gp - Fuel Transfer	242-3442	5S-8038	Pulley - Crankshaft	264-5882	7N-3536	Gear - Fuel	279-4993
4N-7692	Crankshaft As	242-3440	5S-9080	Pulley - Alt Drive	264-5883	7N-5910	Impeller - Pump	314-8686
4N-7693	Crankshaft As	242-3439	6H-3957	Bearing - Ball	311-9358	7N-8117	Muffler As	247-2668
4N-7977	Shaft As - Balance	314-8709	6I-1346	Pump Gp - Oil	295-5674	7N-9146	Gear - Fly-wheel Starter	279-4995
4N-7978	Shaft As - Balance	314-8710	6I-8132	Pinion	226-6080	7N-9805	Pin - Piston	295-6438
4N-9587	Shield - Heat	297-7260	6K-3447	Pin	241-2576	7S-3161	Lifter - Valve	279-4996
4P-3546	Valve As - Relief	325-6236	6K-3937	Pin	241-2557	7S-6723	Bracket - Alternator	299-1978
4P-9381	Line As - Fuel Injector	279-4984	6N-1036	Gear - Oil Pump	279-4991	7S-7070	Head As - Cylinder	325-6107
4P-9382	Line As - Fuel Injector	279-4985	6N-1553	Coupling - Exhaust	295-6422	7S-7809	Cap As - Radiator	295-6417
4P-9961	Line As - Fuel Injector	325-6115	6N-2789	Pulley	264-5886	7S-8443	Muffler	247-2675
4P-9962	Line As - Fuel Injector	325-6116	6N-8413	Housing - Pump	325-6110	7S-9749	Pulley - Gen Drive	264-5888
			6P-7704	Carrier - Ring	314-8658	7T-2036	Cap As - Filter	361-1721
			7C-4297	Seal As - Camshaft	325-6192	7V-5249	Shaft - Steering	215-1761
			7G-2480	Gear - Planet	226-6091			
			7G-2481	Gear - Planet	226-6092			
			7G-2485	Gear - Planet	226-7983			
			7G-2830	Ring - Seal	295-6441			

(Continued)

Sales Model 941B (Continued)

Original Part Number	Part Name	Classic Part Number
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Cam-shaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435

Original Part Number	Part Name	Classic Part Number
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232

Original Part Number	Part Name	Classic Part Number
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9H-2256	Pump Gp	311-9443
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 951

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984

Original Part Number	Part Name	Classic Part Number
1M-1663	Collar As - Retain	226-8030
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1S-1888	Bracket - Lamp	297-7147
1S-6422	Pilot As - Spring	226-4849

Original Part Number	Part Name	Classic Part Number
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1V-3242	Cage - Release Bearing	216-7475
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-4502	Bearing - Sleeve	299-1986

(Continued)

Sales Model 951 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2K-4512	Bearing - Sleeve	308-9813	4N-7692	Crankshaft As	242-3440	7M-7358	Valve - Inlet	298-2774
2K-4513	Bearing - Sleeve	308-9814	4N-7977	Shaft As - Balance	314-8709	7M-9398	Plate - Guide	297-7230
2K-6413	Pin	360-2270	4N-7978	Shaft As - Balance	314-8710	7N-9805	Pin - Piston	295-6438
2K-7418	Pin	241-2572	4P-3546	Valve As - Relief	325-6236	7S-3161	Lifter - Valve	279-4996
2M-1086	Plate As - Press	226-8023	4V-3396	Hub - Gear	222-1763	7S-7070	Head As - Cylinder	325-6107
2M-2290	Bracket - Ring	299-1979	5F-1401	Pin - Pivot	297-7216	7S-7602	Pump Gp	226-0174
2P-1170	Shaft As - Gear	296-1367	5H-5500	Collar - Fly-wheel	302-2704	7S-7809	Cap As - Radiator	295-6417
2P-1781	Spacer - Oil Pump	325-6214	5K-6090	Flange	216-7844	7S-9749	Pulley - Gen Drive	264-5888
2P-6245	Shaft As - Pump	325-6197	5K-7995	Bearing - Sleeve	308-9820	7T-2036	Cap As - Filter	361-1721
2P-7622	Bolt - Spring	226-4850	5K-8606	Cage - Gear Bearing	223-6310	7V-5249	Shaft - Steering	215-1761
2P-7828	Pan - Oil	314-8691	5S-1211	Cover - Valve	314-8665	7W-0507	Gear - Oil Pump Drive	279-4998
2S-4015	Plunger As - Valve	311-9438	5S-1822	Chamber As	248-5406	7W-0508	Gear - Fuel Pump Drive	296-1351
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	5S-1833	Chamber As	247-3298	8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
3F-1537	Nut - Spanner	226-6098	5S-6795	Chamber As	242-3437	8H-9806	Gear - Shaft Drive	325-6091
3H-3378	Gear As - Pump	298-2795	5S-8038	Pulley - Crankshaft	264-5882	8K-5587	Rod Gp - Recoil	226-4954
3K-3124	Muffler - Trap	247-2673	6F-3183	Cap - Bearing	325-6038	8M-0874	Plunger As - Valve	311-9439
3L-1425	Bearing - Ball	311-9356	6J-0800	Bearing	297-7140	8M-6676	Cylinder - Adjustable	226-4960
3S-8800	Gear - Driven	325-6090	6N-1036	Gear - Oil Pump	279-4991	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
3V-5916	Plate As - Press	226-8025	6P-0169	Hub - Fly-wheel Clutch	297-7204	8N-1188	Head Gp - Cylinder	242-3436
4H-4021	Plate As - Loading	229-8219	6Y-0710	Gear	226-6104	8N-1984	Rod As - Conn	242-3441
4J-2414	Trunnion	296-1370	7B-2420	Ferrule - Director	314-8517	8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
4K-0255	Retainer As	226-6102	7C-4297	Seal As - Camshaft	325-6192	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)	7H-2424	Sleeve - Spring	226-4852	8N-3251	Shaft As - Rocker Arm	314-8711
4K-4632	Gear - Bevel	216-7842	7H-2742	Nut	229-8220	8N-3311	Shaft As - Rocker Arm	325-6199
4K-4780	Strip As - Wear	299-2063	7J-9682	Bearing - Sleeve	360-2335	8N-3312	Shaft As - Rocker Arm	325-6200
4K-5074	Pinion	215-1683	7K-3582	Nut - Adjusting	226-6099	8N-3325	Arm Gp - Rocker	314-8623
4K-5086	Yoke	215-1684	7K-4458	Gear - Final Drive	226-6093	8N-3327	Arm Gp - Rocker	314-8624
4K-5109	Gear - Reverse	219-9659	7K-4512	Pinion - Final Drive	226-6081			
4K-6702	Pin	241-2573	7K-4770	Pinion	226-6082			
4K-7386	Plate - Guide	226-4851	7K-4771	Gear	229-8221			
4K-9559	Hub - Gear	219-2978	7K-8237	Drum	226-6100			
4N-4864	Pump Gp - Fuel Transfer	242-3442	7K-8238	Flange	213-8166			
			7M-2167	Ring - Governor Control	308-9919			
			7M-4603	Body - Fuel Valve	311-9348			

(Continued)

Sales Model 951 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)
8S-3970	Chamber As	242-3438

Original Part Number	Part Name	Classic Part Number
9F-7101	Bushing - Collar	299-1988
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998

Original Part Number	Part Name	Classic Part Number
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9S-2356	Manifold - Exhaust	261-0905
9W-1677	Bearing	297-7145
9Y-2992	Bearing - Sleeve	325-6032
9Y-9431	Precleaner As	361-1718

Sales Model 951B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103

Original Part Number	Part Name	Classic Part Number
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475

Original Part Number	Part Name	Classic Part Number
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023

(Continued)

Sales Model 951B (Continued)

Original Part Number	Part Name	Classic Part Number
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-5081	Muffler As	360-7872
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7622	Bolt - Spring	226-4850
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3F-1537	Nut - Spanner	226-6098
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3S-8800	Gear - Driven	325-6090
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-0300	Bearing - Sleeve	308-9817

Original Part Number	Part Name	Classic Part Number
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089

Original Part Number	Part Name	Classic Part Number
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-1822	Chamber As	248-5406
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6K-3447	Pin	241-2576
6K-3937	Pin	241-2557
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220

(Continued)

Sales Model 951B (Continued)

Original Part Number	Part Name	Classic Part Number
7J-9682	Bearing - Sleeve	360-2335
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Flywheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675

Original Part Number	Part Name	Classic Part Number
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199

Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9Y-2992	Bearing - Sleeve	325-6032
9Y-9431	Precleaner As	361-1718

Sales Model 951C

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769

Original Part Number	Part Name	Classic Part Number
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1V-3242	Cage - Release Bearing	216-7475
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812

Original Part Number	Part Name	Classic Part Number
2K-4502	Bearing - Sleeve	299-1986
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7622	Bolt - Spring	226-4850
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3S-8800	Gear - Driven	325-6090
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-0300	Bearing - Sleeve	308-9817

(Continued)

Sales Model 951C (Continued)

Original Part Number	Part Name	Classic Part Number
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-7386	Plate - Guide	226-4851
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089

Original Part Number	Part Name	Classic Part Number
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6K-3447	Pin	241-2576
6K-3937	Pin	241-2557
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6Y-0710	Gear	226-6104
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093

Original Part Number	Part Name	Classic Part Number
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684

(Continued)

Sales Model 951C (Continued)

Original Part Number	Part Name	Classic Part Number
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441

Original Part Number	Part Name	Classic Part Number
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 955C, 955E

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
1H-8382	Gear - Oil Pump Drive	226-6103
1M-9177	Flywheel	226-6112
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237

Original Part Number	Part Name	Classic Part Number
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4177	Pin - Lock	308-9893
2K-4502	Bearing - Sleeve	299-1986
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2K-7418	Pin	241-2572
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2P-7622	Bolt - Spring	226-4850
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
3B-6218	Muffler As	247-2672

Original Part Number	Part Name	Classic Part Number
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4K-0255	Retainer As	226-6102
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-1401	Pin - Pivot	297-7216
5H-5500	Collar - Flywheel	302-2704
5K-7995	Bearing - Sleeve	308-9820
5S-1211	Cover - Valve	314-8665
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358

(Continued)

Sales Model 955C, 955E (Continued)

Original Part Number	Part Name	Classic Part Number
6J-0800	Bearing	297-7140
6P-0169	Hub - Fly-wheel Clutch	297-7204
6W-0240	Bearing - Brace	297-7143
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7M-4603	Body - Fuel Valve	311-9348
7M-5050	Collar - Front Idler	226-4958

Original Part Number	Part Name	Classic Part Number
7M-9398	Plate - Guide	297-7230
7S-7809	Cap As - Radiator	295-6417
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-3428	Bearing - Sleeve	314-8647
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
8B-5972	Bearing - Ball	314-8503

Original Part Number	Part Name	Classic Part Number
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2300	Pinion - Final Drive	226-6083
8M-6676	Cylinder - Adjustable	226-4960
9F-5224	Gear - Final Drive	226-6094
9F-7101	Bushing - Collar	299-1988
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model 955H

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1M-7250	Bowl - Precleaner	360-2296
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1T-0020	Wheel - Turbine	297-4862
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-0940	Holder - Bearing Cage	216-7472
1V-3242	Cage - Release Bearing	216-7475
1V-3676	Case - Drive Gear	216-7799

Original Part Number	Part Name	Classic Part Number
1V-3677	Case - Final Drive Gear	216-7802
1W-4405	Gear - Crankshaft	279-4982
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-4502	Bearing - Sleeve	299-1986
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2K-6413	Pin	360-2270
2K-7418	Pin	241-2572
2M-4668	Retainer - Guard	297-4867
2P-7622	Bolt - Spring	226-4850
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
3F-1972	Retainer As	226-7988
3H-3378	Gear As - Pump	298-2795
3K-2230	Gear - Planet	219-9658

Original Part Number	Part Name	Classic Part Number
3K-2280	Carrier - Transmission	223-6317
3K-2498	Shaft - Planet	216-7824
3K-3774	Gear - Final Drive	217-7716
3K-3814	Gear & Pinion - Final Drive	216-7825
3P-3623	Lock - Adjustable Nut	226-7989
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-6702	Pin	241-2573
4K-7386	Plate - Guide	226-4851
5F-1401	Pin - Pivot	297-7216
5K-2888	Hub - Gear	219-2967
5K-2893	Shaft - Sprocket	221-7953

(Continued)

Sales Model 955H (Continued)

Original Part Number	Part Name	Classic Part Number
5K-6090	Flange	216-7844
5K-7995	Bearing - Sleeve	308-9820
5K-8606	Cage - Gear Bearing	223-6310
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6F-3183	Cap - Bearing	325-6038
6J-0800	Bearing	297-7140
7B-2420	Ferrule - Director	314-8517
7G-2522	Gear - Planet	216-7855
7G-6044	Cage As	216-7857

Original Part Number	Part Name	Classic Part Number
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7J-9682	Bearing - Sleeve	360-2335
7K-1311	Hub As - Sprocket	224-1313
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7S-7809	Cap As - Radiator	295-6417

Original Part Number	Part Name	Classic Part Number
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8H-9806	Gear - Shaft Drive	325-6091
8K-5587	Rod Gp - Recoil	226-4954
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-8225	Bearing - Main	314-8652
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-6841	Cage As	216-7871
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9W-1677	Bearing	297-7145

Sales Model 955K

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368

Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-7250	Bowl - Precleaner	360-2296
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-6160	Gear - Pump Driven	231-8760
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866

Original Part Number	Part Name	Classic Part Number
1S-5331	Cylinder - Adjustable	226-0214
1S-6422	Pilot As - Spring	226-4849
1T-0724	Impeller - Converter	216-7469
1T-0727	Hub - Impeller	229-8236
1T-0947	Flange As - Input	229-8224
1T-0949	Housing - Rotating	217-7732
1T-0972	Carrier As	216-7470
1T-1255	Torque Converter	235-1806 (Repair Kit)
1T-1285	Gear As - Drive	217-7734
1T-1331	Stator - Converter	229-8237
1T-1480	Turbine As - Converter	235-1818
1V-0940	Holder - Bearing Cage	216-7472
1V-3242	Cage - Release Bearing	216-7475

(Continued)

Sales Model 955K (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1V-3676	Case - Drive Gear	216-7799	3K-3774	Gear - Final Drive	217-7716	4N-7692	Crankshaft As	242-3440
1V-3677	Case - Final Drive Gear	216-7802	3K-3814	Gear & Pinion - Final Drive	216-7825	4N-7977	Shaft As - Balance	314-8709
1V-7556	Support	216-7804	3L-1425	Bearing - Ball	311-9356	4N-7978	Shaft As - Balance	314-8710
1W-1219	Trunnion As	314-8724	3P-3623	Lock - Adjustable Nut	226-7989	4N-9587	Shield - Heat	297-7260
1W-4402	Gear - Camshaft	279-4981	3S-1167	Gear - Planet	221-9101	4P-3546	Valve As - Relief	325-6236
1W-4405	Gear - Crankshaft	279-4982	3S-4386	Pump Gp - Steering	217-2599	4S-5943	Piston - Clutch	221-9112
2B-8824	Drum	216-7817	3V-1133	Strip	226-0203	4S-5944	Gear - Sun	221-9078
2F-5721	Bearing - Ball	311-9354	3V-2042	Hub - Gear	217-7735	4S-5945	Gear - Sun	221-9079
2J-8489	Bearing - Sleeve	295-5691	3V-2771	Retainer	216-7830	4S-5946	Shaft - Center	229-8238
2K-4502	Bearing - Sleeve	299-1986	3V-5604	Pinion - Final Drive	216-7832	4S-5947	Gear - Ring	221-9080
2K-4507	Bearing - Sleeve	325-6021	3V-5605	Gear - Final Drive & Pinion	216-7833	4S-5948	Gear - Ring	221-9082
2K-6413	Pin	360-2270	3V-5778	Shaft - Sprocket	216-7834	4S-5979	Carrier As	216-7843
2M-4668	Retainer - Guard	297-4867	3V-5916	Plate As - Press	226-8025	4S-5981	Gear - Ring	221-9084
2P-1170	Shaft As - Gear	296-1367	3V-5918	Gear - Final Drive	217-7717	4S-8530	Shaft - Planet	221-9111
2P-1757	Hub - Fan Pulley	296-1357	3V-5920	Hub - Gear	222-1762	4S-8534	Shaft As - Planet	221-9116
2P-1781	Spacer - Oil Pump	325-6214	3V-7365	Hub - Gear	219-2965	4V-7344	Pin	241-2574
2P-2406	Pulley	264-5870	4F-4974	Clamp	311-9373	4W-0452	Seal As - Camshaft	325-6191
2P-2519	Tube As - Inlet	325-6230	4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)	5F-7993	Pin	319-3454
2P-2744	Muffler As	247-2664	4K-3004	Bearing - Trunnion Support	314-8632	5G-3612	Cap Gp	295-6419
2P-5081	Muffler As	360-7872	4K-3128	Bearing - Sleeve	314-8633	5J-4798	Bearing As	256-4840
2P-6128	Pulley	264-5872	4K-4632	Gear - Bevel	216-7842	5J-8052	Trunnion	256-4843
2P-6245	Shaft As - Pump	325-6197	4K-4780	Strip As - Wear	299-2063	5K-2893	Shaft - Sprocket	221-7953
2P-7828	Pan - Oil	314-8691	4K-7386	Plate - Guide	226-4851	5K-6090	Flange	216-7844
2S-4015	Plunger As - Valve	311-9438	4N-2954	Sleeve - Camshaft	299-2059	5K-6142	Cage - Final Drive Gear Bearing	223-4811
2V-5551	Pinion - Final Drive	216-7822	4N-3281	Line As - Fuel Injector	247-3362	5K-7027	Pin	241-2575
2V-5552	Gear & Pinion - Final Drive	216-7823	4N-3282	Line As - Fuel Injector	247-3363	5K-8330	Holder - Tooth	299-2013
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4N-3283	Line As - Fuel Injector	247-3364	5K-8606	Cage - Gear Bearing	223-6310
2W-7255	Shaft - Water Pump	325-6203	4N-3284	Line As - Fuel Injector	247-3365	5K-8628	Cage	216-7845
2W-9978	Core As - Oil Cooler	279-4983	4N-4539	Sleeve	314-8720	5P-7807	Bearing - Ball	314-8502
3F-6185	Pin	295-5694	4N-4864	Pump Gp - Fuel Transfer	242-3442	5S-1822	Chamber As	248-5406
3H-3378	Gear As - Pump	298-2795				5S-4493	Carrier - Planet	223-6321
						5S-4557	Bearing	311-9360
						5S-6795	Chamber As	242-3437
						5S-6972	Gear - Sun	221-9087
						5S-6978	Shaft - Planet	221-9103
						5S-7009	Plate As - End	226-4957
						5S-7010	Shaft - Planet	221-9104
						5S-7013	Gear - Ring	221-9088
						5S-7023	Carrier - Planet	226-5986

(Continued)

Sales Model 955K (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5S-7609	Pulley - Alt Drive	264-5881	7M-1859	Pilot As - Spring	226-0207	7W-0450	Gear - Water Pump	279-4997
5S-7894	Flange As	216-7854	7M-1861	Stop - Spring Rh	226-0228	7W-0507	Gear - Oil Pump Drive	279-4998
5S-8038	Pulley - Crankshaft	264-5882	7M-1862	Stop - Spring Lh	226-0229	7W-0508	Gear - Fuel Pump Drive	296-1351
5S-9080	Pulley - Alt Drive	264-5883	7M-2167	Ring - Governor Control	308-9919	7W-5687	Hub - Camshaft	314-8684
6H-3957	Bearing - Ball	311-9358	7M-2531	Rod - Tie	297-7239	8B-5972	Bearing - Ball	314-8503
6I-1346	Pump Gp - Oil	295-5674	7M-4358	Manifold - Exhaust	261-0907	8E-9795	Connector As	256-4851
6J-2326	Pin	319-3458	7M-4603	Body - Fuel Valve	311-9348	8G-1682	Pin	241-2585
6J-7563	Pin	319-3459	7M-7358	Valve - Inlet	298-2774	8H-7980	Piston	226-0249
6J-8805	Bearing As	256-4841	7N-0128	Core As - Oil Cooler	299-1994	8H-9806	Gear - Shaft Drive	325-6091
6J-9793	Bearing	256-4835	7N-0165	Core As - Oil Cooler	295-5670	8K-6357	Pin	241-2586
6K-3447	Pin	241-2576	7N-1164	Mount As	295-5451	8K-6358	Pin	241-2587
6N-1036	Gear - Oil Pump	279-4991	7N-2871	Line As - Fuel Injector	319-8172	8K-6359	Pin	241-2588
6N-1553	Coupling - Exhaust	295-6422	7N-2872	Line As - Fuel Injector	319-8173	8K-9661	Gear - Bevel	213-8218
6N-2789	Pulley	264-5886	7N-2874	Line As - Fuel Injector	298-2779	8M-0874	Plunger As - Valve	311-9439
6N-8413	Housing - Pump	325-6110	7N-2949	Pulley	264-5887	8M-3224	Muffler	247-2676
7B-2420	Ferrule - Director	314-8517	7N-3515	Gear - Camshaft	314-8669	8M-6676	Cylinder - Adjustable	226-4960
7C-4297	Seal As - Camshaft	325-6192	7N-3536	Gear - Fuel	279-4993	8N-0002	Trunnion As	314-8728
7G-2477	Gear - Planet	221-9090	7N-5910	Impeller - Pump	314-8686	8N-0875	Valve - Exhaust (Valve), 241-3381 (Valve Kit)	247-6893 (Valve), 241-3381 (Valve Kit)
7G-2487	Gear - Planet	221-9092	7N-8117	Muffler As	247-2668	8N-1188	Head Gp - Cylinder	242-3436
7G-2520	Gear - Planet	221-9094	7N-9146	Gear - Fly-wheel Starter	279-4995	8N-1984	Rod As - Conn	242-3441
7H-2742	Nut	229-8220	7N-9805	Pin - Piston	295-6438	8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
7J-9708	Bearing - Sleeve	299-1964	7S-3161	Lifter - Valve	279-4996	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
7K-1311	Hub As - Sprocket	224-1313	7S-6723	Bracket - Alternator	299-1978	8N-3251	Shaft As - Rocker Arm	314-8711
7K-8237	Drum	226-6100	7S-6875	Pump Gp - Transmission	217-2601	8N-3311	Shaft As - Rocker Arm	325-6199
7K-8238	Flange	213-8166	7S-7070	Head As - Cylinder	325-6107	8N-3312	Shaft As - Rocker Arm	325-6200
7K-9372	Pin	241-2577	7S-7809	Cap As - Radiator	295-6417	8N-3325	Arm Gp - Rocker	314-8623
7K-9488	Pin	241-2578	7S-8443	Muffler	247-2675	8N-3327	Arm Gp - Rocker	314-8624
7K-9499	Pin	241-2579	7S-8572	Gear - Ring	221-9095	8N-5929	Cover - Water Pump	296-1349
7K-9502	Pin	241-2580	7S-9749	Pulley - Gen Drive	264-5888	8N-7315	Tube As - Outlet	325-6232
7K-9503	Pin	241-2581	7T-2036	Cap As - Filter	361-1721	8N-8225	Bearing - Main	314-8652
7K-9504	Pin	241-2582	7V-5249	Shaft - Steering	215-1761			
7K-9505	Pin	241-2583						
7K-9506	Pin	241-2584						
7K-9515	Pin	241-2589						
7K-9642	Bearing - Sleeve	360-2340						
7M-1776	Plate - Idler Guide	226-0222						
7M-1856	Pilot - Recoil Spring	226-0225						

(Continued)

Sales Model 955K (Continued)

Original Part Number	Part Name	Classic Part Number
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-2809	Muffler	247-2677
8S-3970	Chamber As	242-3438

Original Part Number	Part Name	Classic Part Number
9G-3526	Gear - Pump Drive	231-8763
9G-8302	Guide	226-4853
9G-8303	Collar - Idler End	226-0242
9H-2256	Pump Gp	311-9443
9H-7670	Piston	226-4961
9K-0447	Shaft - Bevel Pinion	216-7870
9K-6841	Cage As	216-7871

Original Part Number	Part Name	Classic Part Number
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8253	Guard As - Roller	226-0182
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 955L

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
117-1616	Segment Gp - Sprocket	260-5851 (sprocket group)
118-1617	Roller Gp - SF	188-5272
118-1618	Roller Gp - DF	188-5271
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1J-6746	Pin	256-4817

Original Part Number	Part Name	Classic Part Number
1J-6749	Screw - Adjustable	256-4824
1M-7250	Bowl - Precleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-6160	Gear - Pump Driven	231-8760
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1859	Bolt - Track	188-5633
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1S-6422	Pilot As - Spring	226-4849

Original Part Number	Part Name	Classic Part Number
1T-0724	Impeller - Converter	216-7469
1T-0727	Hub - Impeller	229-8236
1T-0947	Flange As - Input	229-8224
1T-0949	Housing - Rotating	217-7732
1T-0972	Carrier As	216-7470
1T-1255	Torque Converter	235-1806 (Repair Kit)
1T-1285	Gear As - Drive	217-7734
1T-1331	Stator - Converter	229-8237
1T-1480	Turbine As - Converter	235-1818
1V-0940	Holder - Bearing Cage	216-7472
1V-3242	Cage - Release Bearing	216-7475
1V-3676	Case - Drive Gear	216-7799
1V-3677	Case - Final Drive Gear	216-7802
1V-7556	Support	216-7804
1W-1219	Trunnion As	314-8724
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982

(Continued)

Sales Model 955L (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
236-9861	Link As.	175-8555	3K-3814	Gear & Pinion - Final Drive	216-7825	4N-4864	Pump Gp - Fuel Transfer	242-3442
236-9864	Link As.	188-5527	3L-1425	Bearing - Ball	311-9356	4N-7692	Crankshaft As	242-3440
236-9866	Link As.	188-5588	3P-3623	Lock - Adjustable Nut	226-7989	4N-7693	Crankshaft As	242-3439
238-9951	Link As.	290-6589	3S-1167	Gear - Planet	221-9101	4N-7977	Shaft As - Balance	314-8709
244-1090	Alarm - Back up	360-2345	3S-4386	Pump Gp - Steering	217-2599	4N-7978	Shaft As - Balance	314-8710
2B-8824	Drum	216-7817	3T-3206	Roller Gp - Carrier	188-5590	4N-9587	Shield - Heat	297-7260
2F-5721	Bearing - Ball	311-9354	3V-1133	Strip	226-0203	4P-3546	Valve As - Relief	325-6236
2J-8489	Bearing - Sleeve	295-5691	3V-2042	Hub - Gear	217-7735	4S-5943	Piston - Clutch	221-9112
2K-4502	Bearing - Sleeve	299-1986	3V-2771	Retainer	216-7830	4S-5944	Gear - Sun	221-9078
2K-4507	Bearing - Sleeve	325-6021	3V-5604	Pinion - Final Drive	216-7832	4S-5945	Gear - Sun	221-9079
2K-6413	Pin	360-2270	3V-5605	Gear - Final Drive & Pinion	216-7833	4S-5946	Shaft - Center	229-8238
2M-4668	Retainer - Guard	297-4867	3V-5778	Shaft - Sprocket	216-7834	4S-5947	Gear - Ring	221-9080
2P-1170	Shaft As - Gear	296-1367	3V-5916	Plate As - Press	226-8025	4S-5948	Gear - Ring	221-9082
2P-1757	Hub - Fan Pulley	296-1357	3V-5918	Gear - Final Drive	217-7717	4S-5979	Carrier As	216-7843
2P-1781	Spacer - Oil Pump	325-6214	3V-5920	Hub - Gear	222-1762	4S-5981	Gear - Ring	221-9084
2P-2406	Pulley	264-5870	3V-7365	Hub - Gear	219-2965	4S-8530	Shaft - Planet	221-9111
2P-2519	Tube As - Inlet	325-6230	4F-4974	Clamp	311-9373	4S-8534	Shaft As - Planet	221-9116
2P-2744	Muffler As	247-2664	4J-2414	Trunnion	296-1370	4V-7344	Pin	241-2574
2P-5081	Muffler As	360-7872	4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)	4W-0452	Seal As - Camshaft	325-6191
2P-6128	Pulley	264-5872	4K-3004	Bearing - Trunnion Support	314-8632	5F-0736	Pin - Pivot	256-4823
2P-6245	Shaft As - Pump	325-6197	4K-3128	Bearing - Sleeve	314-8633	5F-7993	Pin	319-3454
2P-7828	Pan - Oil	314-8691	4K-4632	Gear - Bevel	216-7842	5G-3612	Cap Gp	295-6419
2V-5551	Pinion - Final Drive	216-7822	4K-4780	Strip As - Wear	299-2063	5J-4798	Bearing As	256-4840
2V-5552	Gear & Pinion - Final Drive	216-7823	4K-7386	Plate - Guide	226-4851	5J-8052	Trunnion	256-4843
2W-1086	Cover As - Cylinder Head	325-6049	4N-2954	Sleeve - Camshaft	299-2059	5K-2893	Shaft - Sprocket	221-7953
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4N-3281	Line As - Fuel Injector	247-3362	5K-6090	Flange	216-7844
2W-7255	Shaft - Water Pump	325-6203	4N-3282	Line As - Fuel Injector	247-3363	5K-6142	Cage - Final Drive Gear Bearing	223-4811
2W-7458	Crankshaft As	242-3439	4N-3283	Line As - Fuel Injector	247-3364	5K-7027	Pin	241-2575
2W-7678	Gear - Water Pump	325-6088	4N-3284	Line As - Fuel Injector	247-3365	5K-8330	Holder - Tooth	299-2013
2W-9978	Core As - Oil Cooler	279-4983	4N-4539	Sleeve	314-8720	5K-8606	Cage - Gear Bearing	223-6310
3F-6185	Pin	295-5694				5K-8628	Cage	216-7845
3K-3774	Gear - Final Drive	217-7716				5P-7807	Bearing - Ball	314-8502
						5S-4493	Carrier - Planet	223-6321
						5S-4557	Bearing	311-9360
						5S-6795	Chamber As	242-3437
						5S-6972	Gear - Sun	221-9087
						5S-6978	Shaft - Planet	221-9103
						5S-7009	Plate As - End	226-4957
						5S-7010	Shaft - Planet	221-9104

(Continued)

Sales Model 955L (Continued)

Original Part Number	Part Name	Classic Part Number
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-7894	Flange As	216-7854
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6K-3447	Pin	241-2576
6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6Y-6289	Shoe -Track	188-5270
6Y-6290	Shoe -Track Master	175-8728
6Y-6291	Shoe -Track	175-8031
6Y-6292	Shoe -Track Master	175-8032
6Y-6293	Shoe -Track	175-8369
6Y-6294	Shoe -Track Master	175-8370
6Y-6295	Shoe -Track	175-8371
6Y-6296	Shoe -Track Master	175-8372
6Y-6394	Shoe -Track Master	188-5591
6Y-6395	Shoe -Track	188-5396
6Y-6397	Shoe -Track Master	188-5594
6Y-6398	Shoe -Track	188-5593
6Y-6411	Shoe -Track	188-5397
6Y-6412	Shoe -Track Master	188-5592
7C-4297	Seal As - Camshaft	325-6192
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092

Original Part Number	Part Name	Classic Part Number
7G-2520	Gear - Planet	221-9094
7H-2742	Nut	229-8220
7J-9708	Bearing - Sleeve	299-1964
7K-1311	Hub As - Sprocket	224-1313
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9372	Pin	241-2577
7K-9488	Pin	241-2578
7K-9499	Pin	241-2579
7K-9502	Pin	241-2580
7K-9503	Pin	241-2581
7K-9504	Pin	241-2582
7K-9505	Pin	241-2583
7K-9506	Pin	241-2584
7K-9515	Pin	241-2589
7K-9642	Bearing - Sleeve	360-2340
7M-1776	Plate - Idler Guide	226-0222
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-2167	Ring - Governor Control	308-9919
7M-2531	Rod - Tie	297-7239
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668

Original Part Number	Part Name	Classic Part Number
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6875	Pump Gp - Transmission	217-2601
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7T-4562	Idler As.	175-8263
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8B-5972	Bearing - Ball	314-8503
8E-4365	Segment Gp - Sprocket	188-5635 (sprocket group), 188-5589 (segment)
8E-4499	Shoe -Track	188-5383
8E-4500	Shoe -Track Master	188-5387
8E-4501	Shoe -Track	188-5381
8E-4502	Shoe -Track Master	188-5385
8E-9795	Connector As	256-4851
8G-1682	Pin	241-2585
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8K-6357	Pin	241-2586
8K-6358	Pin	241-2587
8K-6359	Pin	241-2588
8K-9661	Gear - Bevel	213-8218

(Continued)

Sales Model 955L (Continued)

Original Part Number	Part Name	Classic Part Number
8M-0874	Plunger As - Valve	311-9439
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711

Original Part Number	Part Name	Classic Part Number
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-5197	Bearing As	295-6413
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-2809	Muffler	247-2677

Original Part Number	Part Name	Classic Part Number
8S-3970	Chamber As	242-3438
9G-3526	Gear - Pump Drive	231-8763
9G-8302	Guide	226-4853
9G-8303	Collar - Idler End	226-0242
9H-2256	Pump Gp	311-9443
9H-7670	Piston	226-4961
9K-0447	Shaft - Bevel Pinion	216-7870
9K-6841	Cage As	216-7871
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9S-1838	Bolt Master	188-5634
9S-6129	Pulley - Alternator Drive	264-5891
9S-8253	Guard As - Roller	226-0182
9S-8679	Chamber As	325-6042
9W-1677	Bearing	297-7145
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 977D, 977E

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
121-7746	Precleaner As	360-2311
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1M-0176	Flange - Drum	223-4810
1M-5165	Pinion - Final Drive	231-8766
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-1931	Shaft - Steer	227-4772
1P-7044	Cage	226-7975

Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-5331	Cylinder - Adjustable	226-0214
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501

Original Part Number	Part Name	Classic Part Number
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2M-2290	Bracket - Ring	299-1979
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2P-0483	Chamber As	256-4760
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2S-1273	Chamber As	319-3434
2S-1477	Holder As - Cage	226-7985
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3B-6218	Muffler As	247-2672

(Continued)

Sales Model 977D, 977E (Continued)

Original Part Number	Part Name	Classic Part Number
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3P-3623	Lock - Adjustable Nut	226-7989
3P-5754	Hub - Gear	219-2976
3S-7153	Gear - Sliding	227-0024
3S-8800	Gear - Driven	325-6090
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4K-4460	Pin	241-2609
4M-9215	Gear - Pump Idler	311-9391
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8005	Pinion - Final Drive	226-6076
5A-9551	Gear - Final Drive	226-7979
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5F-2256	Cage - Bearing	226-7973

Original Part Number	Part Name	Classic Part Number
5H-5500	Collar - Fly-wheel	302-2704
5M-5244	Hub - Gear	219-2982
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6P-0169	Hub - Fly-wheel Clutch	297-7204
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9547	Pin As - Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7J-9682	Bearing - Sleeve	360-2335
7M-0820	Gear - Sliding	226-6086
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942

Original Part Number	Part Name	Classic Part Number
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7T-0206	Bearing - Brace	297-7144
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-6676	Cylinder - Adjustable	226-4960
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9M-8117	Shaft - Fly-wheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9S-3321	Cage - Pinion Bearing	226-7974
9S-8493	Bolt - Connecting Rod	311-9351
9W-1677	Bearing	297-7145

Sales Model 977H

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1M-0176	Flange - Drum	223-4810
1M-6128	Manifold - Exhaust	261-0906
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848

Original Part Number	Part Name	Classic Part Number
1S-5331	Cylinder - Adjustable	226-0214
1T-0699	Impeller - Converter	235-1808
1T-1993	Wheel - Turbine	235-0920
1W-4405	Gear - Crankshaft	279-4982
2F-5721	Bearing - Ball	311-9354
2K-4442	Bearing - Sleeve	308-9812

Original Part Number	Part Name	Classic Part Number
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2M-4668	Retainer - Guard	297-4867
2M-8296	Hub - Gear	219-2961
2M-8297	Pinion - Final Drive	218-4429
2M-8304	Shaft - Sprocket	221-1038

(Continued)

Sales Model 977H (Continued)

Original Part Number	Part Name	Classic Part Number
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3H-3378	Gear As - Pump	298-2795
3K-2230	Gear - Planet	219-9658
3K-2280	Carrier - Transmission	223-6317
3K-2498	Shaft - Planet	216-7824
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
4F-1252	Pin	295-5704
4K-4460	Pin	241-2609
4K-4780	Strip As - Wear	299-2063
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298

Original Part Number	Part Name	Classic Part Number
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9547	Pin As - Drawbar	295-0414
7G-2522	Gear - Planet	216-7855
7H-1318	Coupling - Steering	226-8002
7J-9682	Bearing - Sleeve	360-2335
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417

Original Part Number	Part Name	Classic Part Number
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
8H-1383	Rod - Tie	299-2051
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0493	Cage - Outer Bearing	216-7866
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-4112	Guard As	226-4946
8S-1832	Guard As - Sprocket	226-4948
8S-5722	Plate - Pressure	226-8009
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9J-9598	Pin	296-1362
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9W-1677	Bearing	297-7145

Sales Model 977K

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip - Guard	226-0245
1P-1897	Gear - Final Drive	215-1670
1P-4303	Head As - Cylinder	242-3434
1P-6160	Gear - Pump Driven	231-8760
1P-8554	Coupling - Exhaust	325-6052
1P-9663	Carrier - Bearing	217-7731

Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981

(Continued)

Sales Model 977K (Continued)

Original Part Number	Part Name	Classic Part Number
1W-4405	Gear - Crankshaft	279-4982
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2M-0369	Pilot - Spring Recoil	226-0226
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2744	Muffler As	247-2664
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-6245	Shaft As - Pump	325-6197
2S-3443	Drum - Steer (Drum), 230-7113 (Steering Clutch Kit)	219-9689
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-6344	Gear - Final Drive	297-7173
2S-7603	Drum	213-6951
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet (Valve), 241-3381 (Valve Kit)	247-6892
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3H-3378	Gear As - Pump	298-2795

Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
3P-6318	Flange - Drum	213-8165
3S-0777	Bearing - Roller Frame	229-8226
3S-1691	Disc - Steering	302-2705
3S-2337	Shaft - Output	231-8765
3S-6907	Gear - Transfer	217-9774
3S-6908	Gear - Transfer	217-9775
3S-9199	Hub - Sprocket	224-1310
3T-4482	Guide - Front Idler	226-0248
4F-4974	Clamp	311-9373
4K-0300	Bearing - Sleeve	308-9817
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7526	Seal As - Pump	311-9454
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5J-4542	Bearing - Sleeve	308-9818
5K-6377	Pin	241-2610
5K-6382	Pin	241-2611

Original Part Number	Part Name	Classic Part Number
5K-6383	Pin	241-2612
5K-7995	Bearing - Sleeve	308-9820
5K-9367	Pin	241-2613
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-6670	Shaft - Sprocket	216-7847
5M-6690	Hub - Steering	215-1695
5M-7290	Cage - Bearing	216-7848
5M-7740	Gear - Bevel	213-8216
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5M-7923	Shaft - Output	215-1697
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-0192	Pinion - Final Drive	215-1698
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-1983	Pin	241-2614
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-1382	Pin	241-2615
6P-1383	Pin	241-2616

(Continued)

Sales Model 977K (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
6T-1980	Collar - Idler End	226-0210	7N-2949	Pulley	264-5887	8M-8650	Piston - Clutch	217-9778
7B-2420	Ferrule - Director	314-8517	7N-3486	Manifold - Exhaust	261-0899	8M-8652	Shaft	297-7252
7C-4297	Seal As - Camshaft	325-6192	7N-3515	Gear - Camshaft	314-8669	8M-8677	Carrier - Planet	213-4449
7F-9547	Pin As - Drawbar	295-0414	7N-3536	Gear - Fuel	279-4993	8N-0002	Trunnion As	314-8728
7G-2475	Gear - Planet	223-4815	7N-5910	Impeller - Pump	314-8686	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
7G-2476	Gear - Planet	223-4816	7N-9145	Gear - Flywheel	279-4994	8N-1187	Head Gp - Cylinder	242-3435
7G-2513	Gear - Planet	215-1734	7N-9312	Damper As - Camshaft	299-2005	8N-1721	Rod As - Conn	269-5291
7G-5301	Pump Gp	217-2600	7N-9805	Pin - Piston	295-6438	8N-1984	Rod As - Conn	242-3441
7G-5323	Pinion - Final Drive	231-8767	7S-3161	Lifter - Valve	279-4996	8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
7G-6681	Cage As	216-7860	7S-6723	Bracket - Alternator	299-1978	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
7J-9344	Bearing - Sleeve	360-2334	7S-7809	Cap As - Radiator	295-6417	8N-3325	Arm Gp - Rocker	314-8623
7J-9731	Bearing - Sleeve	308-9822	7S-8443	Muffler	247-2675	8N-3327	Arm Gp - Rocker	314-8624
7J-9732	Bearing - Sleeve	308-9823	7S-9749	Pulley - Gen Drive	264-5888	8N-5929	Cover - Water Pump	296-1349
7K-9366	Pin	241-2617	7T-2036	Cap As - Filter	361-1721	8N-7315	Tube As - Outlet	325-6232
7K-9370	Pin	241-2618	7T-9963	Case As - Transfer Gear	219-9665	8N-8225	Bearing - Main	314-8652
7K-9371	Pin	241-2619	7W-0450	Gear - Water Pump	279-4997	8N-9733	Line As - Fuel Injector	319-8174
7K-9373	Pin	241-2620	7W-0507	Gear - Oil Pump Drive	279-4998	8P-0025	Gear - Idler	217-7721
7K-9375	Pin	241-2621	7W-5687	Hub - Camshaft	314-8684	8P-0605	Gear - First Reduction	213-8453
7K-9528	Bearing - Sleeve	308-9828	8H-1383	Rod - Tie	299-2051	8P-0606	Pinion - Sec Reduction	215-1783
7K-9530	Bearing - Sleeve	299-1967	8H-7980	Piston	226-0249	8P-0622	Hub - Sprocket	288-8731
7M-2167	Ring - Governor Control	308-9919	8H-9806	Gear - Shaft Drive	325-6091	8P-4537	Pinion - Reduction	216-7867
7M-4204	Manifold - Exhaust	261-0901	8M-0874	Plunger As - Valve	311-9439	8P-4538	Gear - First Reduction	216-7868
7M-4603	Body - Fuel Valve	311-9348	8M-3224	Muffler	247-2676	8P-4539	Pinion - Final Drive	217-7711
7M-7358	Valve - Inlet	298-2774	8M-6191	Sleeve - Bolt	226-0234	8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)
7N-0128	Core As - Oil Cooler	299-1994	8M-7166	Housing - Screen	297-7192	8P-6803	Shaft As	215-1842
7N-0165	Core As - Oil Cooler	295-5670	8M-8619	Cage - Bearing	217-7725	8P-7790	Valve Gp - Press	247-4437
7N-1164	Mount As	295-5451	8M-8623	Gear - Sun	213-8755	8S-0248	Breather As	325-6033
7N-2871	Line As - Fuel Injector	319-8172	8M-8628	Flange - Joint	217-9776			
7N-2872	Line As - Fuel Injector	319-8173	8M-8642	Housing - Clutch	219-9669			
7N-2874	Line As - Fuel Injector	298-2779	8M-8644	Housing - Clutch	215-1782			
7N-2875	Line As - Fuel Injector	298-2780	8M-8646	Plate As - Center	216-3583			
7N-2876	Line As - Fuel Injector	298-2781	8M-8649	Piston - Clutch	217-9777			

(Continued)

Sales Model 977K (Continued)

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9G-0383	Hub - Gear	221-1064
9G-3526	Gear - Pump Drive	231-8763
9H-2256	Pump Gp	311-9443
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533

Original Part Number	Part Name	Classic Part Number
9M-3025	Cover As	299-2001
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-3436	Holder As - Cage	216-7875
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904

Original Part Number	Part Name	Classic Part Number
9P-9000	Shaft - Steering	217-7738
9P-9575	Cage - Bevel Gr Bearing	216-7876
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 977L

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
117-1024	Link As.	188-5595
118-1619	Roller Gp - Track	188-5257
118-1620	Roller Gp - DF	188-5258
118-1623	Roller Gp - Track	188-5596
118-1625	Roller Gp - Track	188-5597
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112

Original Part Number	Part Name	Classic Part Number
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1006	Strip - Guard	226-0245
1P-1897	Gear - Final Drive	215-1670
1P-4303	Head As - Cylinder	242-3434
1P-6160	Gear - Pump Driven	231-8760
1P-8554	Coupling - Exhaust	325-6052
1P-8717	Roller Gp - Carrier	188-5600
1P-9663	Carrier - Bearing	217-7731
1P-9807	Shoe - Track	188-5333
1P-9808	Shoe - Track	175-8802
1P-9809	Shoe - Track	175-8882
1P-9810	Shoe - Track	188-5334
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685

Original Part Number	Part Name	Classic Part Number
1S-1860	Nut (3/4-16)	188-5856
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214
1S-8186	Idler As.	188-5268
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
1W-1219	Trunnion As	314-8724
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Back up	360-2345
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2M-0369	Pilot - Spring Recoil	226-0226
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164

(Continued)

Sales Model 977L (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As - Pump	325-6229	3P-6318	Flange - Drum	213-8165	5M-5822	Gear - Pump Drive	247-4120
2P-1757	Hub - Fan Pulley	296-1357	3S-0777	Bearing - Roller Frame	229-8226	5M-6120	Gear - Sun	213-8740
2P-1781	Spacer - Oil Pump	325-6214	3S-1691	Disc - Steering	302-2705	5M-6210	Shaft - Planet	219-9683
2P-2406	Pulley	264-5870	3S-2337	Shaft - Output	231-8765	5M-6211	Shaft - Planet	219-9684
2P-2519	Tube As - Inlet	325-6230	3S-6907	Gear - Transfer	217-9774	5M-6670	Shaft - Sprocket	216-7847
2P-2744	Muffler As	247-2664	3S-6908	Gear - Transfer	217-9775	5M-6690	Hub - Steering	215-1695
2P-3422	Gear - First Reduction	213-8451	3S-9199	Hub - Sprocket	224-1310	5M-7290	Cage - Bearing	216-7848
2P-3423	Pinion - Sec Reduction	216-3553	3T-4482	Guide - Front Idler	226-0248	5M-7740	Gear - Bevel	213-8216
2P-6245	Shaft As - Pump	325-6197	4F-4974	Clamp	311-9373	5M-7841	Gear - Ring	214-0525
2P-9669	Shoe -Track Master	188-5604	4K-0300	Bearing - Sleeve	308-9817	5M-7864	Pump Gp - Scavenge	226-0169
2P-9670	Bolt Master	188-5637	4N-2954	Sleeve - Camshaft	299-2059	5M-7869	Gear - Ring	214-0530
2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)	4N-3281	Line As - Fuel Injector	247-3362	5M-7875	Carrier - Front	213-4495
2S-6344	Gear - Final Drive	297-7173	4N-3282	Line As - Fuel Injector	247-3363	5M-7900	Bolt - Hex Head	311-9349
2S-7603	Drum	213-6951	4N-3283	Line As - Fuel Injector	247-3364	5M-7923	Shaft - Output	215-1697
2W-1086	Cover As - Cylinder Head	325-6049	4N-4864	Pump Gp - Fuel Transfer	242-3442	5P-7807	Bearing - Ball	314-8502
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4N-7693	Crankshaft As	242-3439	5S-0073	Plate - Steering	302-2692
2W-7255	Shaft - Water Pump	325-6203	4N-8591	Coupling - Exhaust	325-6053	5S-0192	Pinion - Final Drive	215-1698
2W-7458	Crankshaft As	242-3439	4N-8814	Line As - Fuel Injector	247-3366	5S-1211	Cover - Valve	314-8665
2W-7678	Gear - Water Pump	325-6088	4N-9587	Shield - Heat	297-7260	5S-4557	Bearing	311-9360
2W-9978	Core As - Oil Cooler	279-4983	4P-3546	Valve As - Relief	325-6236	5S-6795	Chamber As	242-3437
3L-1425	Bearing - Ball	311-9356	4S-8708	Housing - Clutch	216-3557	5S-6910	Shoe -Track	188-5603
3P-0615	Shoe - Track Master	188-5601	4S-8718	Cage - Carrier Bearing	217-7724	5S-6911	Shoe -Track	188-5605
3P-0616	Shoe - Track Master	175-8881	4S-9062	Cap - Final Drive Bearing	226-0204	5S-9080	Pulley - Alt Drive	264-5883
3P-0617	Shoe - Track Master	188-5246	4W-0452	Seal As - Camshaft	325-6191	6H-3957	Bearing - Ball	311-9358
3P-0618	Shoe - Track Master	188-5602	5G-3612	Cap Gp	295-6419	6I-1346	Pump Gp - Oil	295-5674
3P-0620	Shoe - Track Master	188-5606	5J-4542	Bearing - Sleeve	308-9818	6K-1983	Pin	241-2614
3P-0628	Link As.	175-8759	5K-6377	Pin	241-2610	6L-9211	Idler Gp	200-9237
3P-3623	Lock - Adjustable Nut	226-7989	5K-6382	Pin	241-2611	6N-1036	Gear - Oil Pump	279-4991
			5K-6383	Pin	241-2612	6N-1965	Line As - Fuel Injector	250-7535
			5K-7995	Bearing - Sleeve	308-9820	6N-1966	Line As - Fuel Injector	250-7536
			5K-9367	Pin	241-2613	6N-2789	Pulley	264-5886
						6N-8413	Housing - Pump	325-6110
						6P-1382	Pin	241-2615
						6P-1383	Pin	241-2616
						6T-1980	Collar - Idler End	226-0210
						7C-4297	Seal As - Camshaft	325-6192

(Continued)

Sales Model 977L (Continued)

Original Part Number	Part Name	Classic Part Number
7F-9547	Pin As - Drawbar	295-0414
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-5301	Pump Gp	217-2600
7G-5323	Pinion - Final Drive	231-8767
7G-6681	Cage As	216-7860
7H-3598	Bolt - Track	188-5636
7J-9344	Bearing - Sleeve	360-2334
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7K-9366	Pin	241-2617
7K-9370	Pin	241-2618
7K-9371	Pin	241-2619
7K-9373	Pin	241-2620
7K-9375	Pin	241-2621
7K-9528	Bearing - Sleeve	308-9828
7K-9530	Bearing - Sleeve	299-1967
7M-2167	Ring - Governor Control	308-9919
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994

Original Part Number	Part Name	Classic Part Number
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7T-9963	Case As - Transfer Gear	219-9665
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8E-4434	Shoe -Track	188-5263
8E-4435	Shoe -Track Master	188-5264
8E-4436	Shoe -Track	188-5261
8E-4437	Shoe -Track Master	188-5262
8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-6191	Sleeve - Bolt	226-0234
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782

Original Part Number	Part Name	Classic Part Number
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-0622	Hub - Sprocket	288-8731
8P-4537	Pinion - Reduction	216-7867
8P-4538	Gear - First Reduction	216-7868
8P-4539	Pinion - Final Drive	217-7711

(Continued)

Sales Model 977L (Continued)

Original Part Number	Part Name	Classic Part Number
8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)
8P-6803	Shaft As	215-1842
8P-7790	Valve Gp - Press	247-4437
8P-9657	Pin	241-2622
8P-9658	Pin	241-2623
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9G-0383	Hub - Gear	221-1064
9G-3526	Gear - Pump Drive	231-8763
9H-2256	Pump Gp	311-9443
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756

Original Part Number	Part Name	Classic Part Number
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-3436	Holder As - Cage	216-7875
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-9000	Shaft - Steering	217-7738
9P-9360	Gear - First Reduction	213-8454
9P-9361	Gear - Final Drive	223-4809

Original Part Number	Part Name	Classic Part Number
9P-9362	Pinion - Final Drive	215-1944
9P-9363	Pinion - Reduction	219-9677
9P-9575	Cage - Bevel Gr Bearing	216-7876
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model 983

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-6160	Gear - Pump Driven	231-8760
1P-7590	Support As	213-4400

Original Part Number	Part Name	Classic Part Number
1P-9663	Carrier - Bearing	217-7731
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
244-1090	Alarm - Backup	360-2345
2F-5721	Bearing - Ball	311-9354
2K-4507	Bearing - Sleeve	325-6021
2S-2781	Plunger - Relief	311-9435
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356

Original Part Number	Part Name	Classic Part Number
3P-1757	Yoke As - Idler	226-2729
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
4J-1612	Pin	308-9896
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5G-3612	Cap Gp	295-6419
5J-3492	Bearing - Sleeve	308-9879
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-3470	Gear - Transmission	224-1305

(Continued)

Original Part Number	Part Name	Classic Part Number
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5822	Gear - Pump Drive	247-4120
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4470	Gear - Transfer	224-1304
5S-4863	Holder As - Cage	215-1732

5S-5746	Retainer - Guard	319-3472
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
7F-9547	Pin As - Drawbar	295-0414
7G-2517	Gear - Planet	213-8747
7G-2521	Gear - Planet	213-8749
7G-6576	Cage As	216-7859
7J-9344	Bearing - Sleeve	360-2334
7M-2167	Ring - Governor Control	308-9919
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-2036	Cap As - Filter	361-1721

8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8P-0025	Gear - Idler	217-7721
8P-0187	Nut - Adjusting	219-9676
8P-8221	Plate - Guide	226-2748
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
9G-3526	Gear - Pump Drive	231-8763
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966

Sales Model 983B

Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp - Basic	325-6193
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1M-9444	Retainer - Spring	299-2046
1P-9663	Carrier - Bearing	217-7731
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1T-0665	Ring - Clamp	308-9918
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2P-1757	Hub - Fan Pulley	296-1357

Original Part Number	Part Name	Classic Part Number
2S-7064	Cap - Shaft Bearing	299-1991
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
3L-1425	Bearing - Ball	311-9356
3P-1757	Yoke As - Idler	226-2729
3P-2685	Piston - Clutch	308-9908
3P-2768	Piston - Clutch	308-9909
3P-3059	Gear - Sun	308-9861
3P-3096	Gear - Sun	308-9863
3P-3245	Shaft - Planet	308-9924
3P-3246	Shaft - Planet	308-9925
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
4J-1612	Pin	308-9896
4M-0503	Gear As - Oil Pump	297-7184
4S-8472	Hood As	296-1355
5J-3492	Bearing - Sleeve	308-9879

5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-5822	Gear - Pump Drive	247-4120
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-5746	Retainer - Guard	319-3472
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-9080	Pulley - Alt Drive	264-5883

(Continued)

Sales Model 983B (Continued)

Original Part Number	Part Name	Classic Part Number
5V-5866	Pin As	361-1707
6H-3957	Bearing - Ball	311-9358
6L-8968	Coupling - Exhaust	311-9381
6N-1572	Mount As	308-9876
6P-6739	Shaft - Planet	308-9929
7F-9547	Pin As - Drawbar	295-0414
7G-2476	Gear - Planet	223-4816
7G-3457	Gear - Planet	308-9857
7G-6576	Cage As	216-7859

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7W-2164	Core As - Oil Cooler	299-1996
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192

Original Part Number	Part Name	Classic Part Number
8P-0187	Nut - Adjusting	219-9676
8P-8221	Plate - Guide	226-2748
9M-3025	Cover As	299-2001
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-3955	Cage - Gear Bearing	216-7874
9S-6875	Pinion - Final Drive	217-7705
9Y-2988	Breather As	361-1716

Cat® Classic™ Parts for Track-Type Tractors

Cat® track-type tractors have always been built to provide maximum productivity and profitability in any application. Caterpillar has been setting industry standards with this product line since its introduction. As the machine ages, maintenance costs need to be re-evaluated to continue to ensure that maximum profitability. Cat® Classic™ parts are offered for several models of track-type tractors as a competitively priced alternative to aftermarket parts. This parts product line is intended to help you manage these maintenance costs.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for track-type tractors includes:

- Engine
- Final Drive
- Moving U/C
- Non-moving U/C
- Steering
- Transmission
- Trunnion Assembly
- Winch
- ...and many more.

Sales Model D3

Original Part Number	Part Name	Classic Part Number
190-7396	Segment Gp	275-3576 (sprocket group), 275-4087 segment
190-8609	Valve - Fill	360-2288
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2K-6413	Pin	360-2270
2M-1086	Plate As - Press	226-8023
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155

Original Part Number	Part Name	Classic Part Number
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
4J-0121	Cap - Bearing	360-2344
4J-3015	Shaft	325-6204
4N-2954	Sleeve - Cam-shaft	299-2059
4N-4539	Sleeve	314-8720
4N-6638	Muffler As	360-7875
4N-8809	Chamber As	247-3297
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
6F-3183	Cap - Bearing	325-6038
6Y-1381	Shoe - Track	275-3564
6Y-1382	Shoe - Track	275-3565
6Y-1385	Shoe - Track	275-3570
6Y-1386	Shoe - Track	275-3571
6Y-5344	Shoe - Track	275-3566



Original Part Number	Part Name	Classic Part Number
6Y-5345	Shoe - Track	275-3567
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-8238	Flange	213-8166
7N-3536	Gear - Fuel	279-4993
7T-2036	Cap As - Filter	361-1721
8J-2880	Cap - Bearing	295-6420
8S-0248	Breather As	325-6033
9K-8757	Rod End - Bearing	311-9361
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D3B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1S-1888	Bracket - Lamp	297-7147
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4737	Gear - Camshaft	295-5688

Original Part Number	Part Name	Classic Part Number
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
2D-5658	Bearing - Ball	301-4628
2M-1086	Plate As - Press	226-8023
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2S-3803	Gear	226-6106
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-8494	Pulley - Alt	295-5692
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155
3J-6559	Cap - Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
3T-4516	Trunnion As	325-6226
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4F-4974	Clamp	311-9373
4J-2414	Trunnion	296-1370

Original Part Number	Part Name	Classic Part Number
4J-3015	Shaft	325-6204
4N-4539	Sleeve	314-8720
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
5P-7807	Bearing - Ball	314-8502
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6N-1036	Gear - Oil Pump	279-4991
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7W-0450	Gear - Water Pump	279-4997

Sales Model D3B (Continued)

Original Part Number	Part Name	Classic Part Number
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5685	Pulley - Cam-shaft	298-2772
7W-5698	Pulley - Cam-shaft	295-5679
8H-2810	Case As - Filter	314-8512
8J-2880	Cap - Bearing	295-6420
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210

Original Part Number	Part Name	Classic Part Number
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416

Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End - Bearing	311-9361
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-3242	Plate - Clutch	325-6172
9S-8679	Chamber As	325-6042
9T-0066	Trunnion	325-6228
9W-1677	Bearing	297-7145
121-7746	Precleaner As	360-2311
190-8609	Valve - Fill	360-2288
244-1090	Alarm - Backup	360-2345
1M-7250	Bowl - Precleaner	360-2296
4J-0121	Cap - Bearing	360-2344
7K-9642	Bearing - Sleeve	360-2340
9Y-9431	Precleaner As	361-1718

Sales Model D3C

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
164-1047	Idler Gp	275-3581
185-4037	Idler Gp	275-3581
190-8609	Valve - Fill	360-2288
1M-7250	Bowl - Precleaner	360-2296
1S-1888	Bracket - Lamp	297-7147
1U-0612	Pin	325-6135
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Backup	360-2345
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579
2D-5658	Bearing - Ball	301-4628
2M-1086	Plate As - Press	226-8023
323-8756	Link As.	257-1992

Original Part Number	Part Name	Classic Part Number
323-8757	Link As.	257-1990
323-8758	Link As.	257-1994
323-8759	Link As.	257-1991
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-6559	Cap - Bearing	296-1346
3J-6575	Trunnion	297-7265
3L-1425	Bearing - Ball	311-9356
3P-0324	Coupling	301-0234
4F-4974	Clamp	311-9373
4J-0121	Cap - Bearing	360-2344
4J-2414	Trunnion	296-1370
4J-3015	Shaft	325-6204
4J-6374	Bearing - Sleeve	295-6407
4N-4539	Sleeve	314-8720
4T-0998	Lever	314-8687
4W-2042	Spacer	325-6217
5A-3187	Bolt Master	257-7773

Original Part Number	Part Name	Classic Part Number
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6P-2233	Gear - Planet	281-1690
6S-3609	Roller - Carrier	275-3578
6Y-1711	Link As.	261-8008
6Y-1713	Link As.	257-1993
7G-2480	Gear - Planet	226-6091
7G-4758	Gear - Planet	288-8723
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9639	Bearing - Sleeve	314-8643
7T-2036	Cap As - Filter	361-1721
7W-0508	Gear - Fuel Pump Drive	296-1351

(Continued)

Sales Model D3C (Continued)

Original Part Number	Part Name	Classic Part Number
8H-2810	Case As - Filter	314-8512
8J-2880	Cap - Bearing	295-6420
8N-2510	Shaft	325-6208
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
9J-7964	Bearing - Spherical	325-6017
9K-8757	Rod End - Bearing	311-9361

Original Part Number	Part Name	Classic Part Number
9M-1328	Bearing - Aligning	325-6018
9P-3242	Plate - Clutch	325-6172
9T-4762	Head	325-6109
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D4

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
190-7396	Segment Gp	275-3576 (sprocket group), 275-4087 segment
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1M-1618	Collar As - Shift	226-8029
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9177	Flywheel	226-6112
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pressure	226-8011
2H-6777	Plate - Fly-wheel	226-8012
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979

Original Part Number	Part Name	Classic Part Number
2S-1273	Chamber As	319-3434
2S-4015	Plunger As - Valve	311-9438
2V-7198	Pilot As - Recoil Spring	302-2709
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3F-1537	Nut - Spanner	226-6098
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3N-3368	Pipe - Exhaust	311-9434
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4K-0255	Retainer As	226-6102
4K-9559	Hub - Gear	219-2978
4N-2954	Sleeve - Camshaft	299-2059
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5H-5500	Collar - Fly-wheel	302-2704
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6L-8968	Coupling - Exhaust	311-9381

Original Part Number	Part Name	Classic Part Number
6P-0169	Hub - Fly-wheel Clutch	297-7204
6W-0240	Bearing - Brace	297-7143
6Y-1381	Shoe - Track	275-3564
6Y-1382	Shoe - Track	275-3565
6Y-1385	Shoe - Track	275-3570
6Y-1386	Shoe - Track	275-3571
6Y-5344	Shoe - Track	275-3566
6Y-5345	Shoe - Track	275-3567
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7H-2742	Nut	229-8220
7M-4603	Body - Fuel Valve	311-9348
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2300	Pinion - Final Drive	226-6083
8M-6676	Cylinder - Adjustable	226-4960
9F-5224	Gear - Final Drive	226-6094
9F-7101	Bushing - Collar	299-1988
9H-7670	Piston	226-4961
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D4B

Original Part Number	Part Name	Classic Part Number
190-8609	Valve - Fill	360-2288
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2M-1086	Plate As - Press	226-8023

Original Part Number	Part Name	Classic Part Number
3L-1425	Bearing - Ball	311-9356
4J-3015	Shaft	325-6204
4N-4539	Sleeve	314-8720
5P-7807	Bearing - Ball	314-8502
6H-3957	Bearing - Ball	311-9358
6P-2233	Gear - Planet	281-1690
7G-2480	Gear - Planet	226-6091
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-8237	Drum	226-6100

Original Part Number	Part Name	Classic Part Number
7K-8238	Flange	213-8166
7W-0508	Gear - Fuel Pump Drive	296-1351
8N-2510	Shaft	325-6208
9K-8757	Rod End - Bearing	311-9361
9M-1328	Bearing - Aligning	325-6018
9P-3242	Plate - Clutch	325-6172
9Y-9431	Precleaner As	361-1718

Sales Model D4C

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
164-1047	Idler Gp	275-3581
185-4037	Idler Gp	275-3581
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1K-7974	Gear - Transmission Shaft	226-7984
1M-1618	Collar As - Shift	226-8029
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1809	Shaft - Tr Sprocket	231-3314
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9177	Flywheel	226-6112
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1S-1888	Bracket - Lamp	297-7147
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1U-0105	Brace As	295-5684
1U-0612	Pin	325-6135
1W-4402	Gear - Cam-shaft	279-4981

Original Part Number	Part Name	Classic Part Number
1W-4405	Gear - Crank-shaft	279-4982
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579
2B-8824	Drum	216-7817
2D-5658	Bearing - Ball	301-4628
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pressure	226-8011
2H-6777	Plate - Fly-wheel	226-8012
2K-3592	Boss	314-8501
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2S-4015	Plunger As - Valve	311-9438
2V-7198	Pilot As - Recoil Spring	302-2709
3B-6218	Muffler As	247-2672
3F-1537	Nut - Spanner	226-6098
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155

Original Part Number	Part Name	Classic Part Number
3G-8932	Pin	325-6143
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-0324	Coupling	301-0234
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3015	Shaft	325-6204
4K-0255	Retainer As	226-6102
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-9559	Hub - Gear	219-2978
4N-4539	Sleeve	314-8720
4T-0998	Lever	314-8687
5F-0689	Pin	256-4821
5F-1401	Pin - Pivot	297-7216
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5K-6090	Flange	216-7844
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6J-0800	Bearing	297-7140
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-2233	Gear - Planet	281-1690
6S-3609	Roller - Carrier	275-3578

(Continued)

Sales Model D4C (Continued)

Original Part Number	Part Name	Classic Part Number
6W-0240	Bearing - Brace	297-7143
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7G-2480	Gear - Planet	226-6091
7G-4758	Gear - Planet	288-8723
7H-2742	Nut	229-8220
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9639	Bearing - Sleeve	314-8643
7M-2167	Ring - Governor Control	308-9919

Original Part Number	Part Name	Classic Part Number
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-2510	Shaft	325-6208
8N-8225	Bearing - Main	314-8652

Original Part Number	Part Name	Classic Part Number
9F-7101	Bushing - Collar	299-1988
9H-2256	Pump Gp	311-9443
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9J-7964	Bearing - Spherical	325-6017
9K-6842	Cage As	216-7872
9K-8757	Rod End - Bearing	311-9361
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-1328	Bearing - Aligning	325-6018
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9P-3242	Plate - Clutch	325-6172
9W-1677	Bearing	297-7145
9Y-9431	Precleaner As	361-1718

Sales Model D4D

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687

Original Part Number	Part Name	Classic Part Number
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1809	Shaft - Tr Sprocket	231-3314
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296

Original Part Number	Part Name	Classic Part Number
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862

(Continued)

Sales Model D4D (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1V-3242	Cage - Release Bearing	216-7475	2P-6245	Shaft As - Pump	325-6197	4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
1W-1219	Trunnion As	314-8724	2P-6255	Muffler As	247-2666	4K-4632	Gear - Bevel	216-7842
1W-1669	Piston	325-6158	2P-7828	Pan - Oil	314-8691	4K-4780	Strip As - Wear	299-2063
1W-1695	Pump Gp	279-4980	2S-4015	Plunger As - Valve	311-9438	4K-5074	Pinion	215-1683
1W-1698	Housing - Transfer Pump	296-1356	2V-7198	Pilot As - Recoil Spring	302-2709	4K-5086	Yoke	215-1684
1W-2870	Shaft As - Balance	314-8715	2W-1086	Cover As - Cylinder Head	325-6049	4K-5109	Gear - Reverse	219-9659
1W-2871	Shaft As - Balance	314-8716	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	4K-9559	Hub - Gear	219-2978
1W-4402	Gear - Camshaft	279-4981	2W-7255	Shaft - Water Pump	325-6203	4N-2954	Sleeve - Camshaft	299-2059
1W-4405	Gear - Crankshaft	279-4982	2W-7458	Crankshaft As	242-3439	4N-3281	Line As - Fuel Injector	247-3362
1W-5912	Tappet As - Guide	325-6223	2W-7678	Gear - Water Pump	325-6088	4N-3282	Line As - Fuel Injector	247-3363
1W-6541	Plunger As	325-6173	2Y-4213	Pulley	314-8703	4N-3283	Line As - Fuel Injector	247-3364
2B-8824	Drum	216-7817	3B-6218	Muffler As	247-2672	4N-3284	Line As - Fuel Injector	247-3365
2D-5658	Bearing - Ball	301-4628	3F-1537	Nut - Spanner	226-6098	4N-4782	Pulley	325-6176
2F-5721	Bearing - Ball	311-9354	3F-6185	Pin	295-5694	4N-4864	Pump Gp - Fuel Transfer	242-3442
2H-4338	Plate - Pressure	226-8010	3F-6523	Pin - Clevis	256-4818	4N-7692	Crankshaft As	242-3440
2H-4450	Washer - Thrust	325-6237	3F-6611	Socket - Joint	256-4829	4N-7693	Crankshaft As	242-3439
2H-4482	Collar	229-8218	3F-6612	Cap - Ball Joint	297-7155	4N-7977	Shaft As - Balance	314-8709
2H-5046	Link - Flycam	299-2024	3H-3378	Gear As - Pump	298-2795	4N-7978	Shaft As - Balance	314-8710
2H-6776	Plate - Pressure	226-8011	3J-6559	Cap - Bearing	296-1346	4N-9587	Shield - Heat	297-7260
2H-6777	Plate - Flywheel	226-8012	3K-3124	Muffler - Trap	247-2673	4P-3546	Valve As - Relief	325-6236
2K-6413	Pin	360-2270	3L-1425	Bearing - Ball	311-9356	4P-9381	Line As - Fuel Injector	279-4984
2M-1086	Plate As - Press	226-8023	3S-7987	Shaft - Planet	226-6074	4P-9382	Line As - Fuel Injector	279-4985
2M-2290	Bracket - Ring	299-1979	3S-7996	Gear - Ring	226-6087	4P-9961	Line As - Fuel Injector	325-6115
2M-4668	Retainer - Guard	297-4867	3S-8007	Coupling	226-6088	4P-9962	Line As - Fuel Injector	325-6116
2P-1170	Shaft As - Gear	296-1367	3S-8800	Gear - Driven	325-6090	4P-9963	Line As - Fuel Injector	298-2777
2P-1757	Hub - Fan Pulley	296-1357	3S-9466	Bearing - Sleeve	314-8509	4P-9964	Line As - Fuel Injector	298-2778
2P-1781	Spacer - Oil Pump	325-6214	3V-1025	Shaft - Pinion	226-6109	4S-8660	Pump Gp - Transmission	226-0167
2P-2406	Pulley	264-5870	3V-5916	Plate As - Press	226-8025	4S-8670	Shaft - Planet	300-2590
2P-2519	Tube As - Inlet	325-6230	4F-4974	Clamp	311-9373	4S-8687	Piston - Clutch	226-8008
2P-4404	Housing As	226-8027	4H-4021	Plate As - Loading	229-8219	4S-8707	Shaft & Sun Gear	226-6089
2P-4409	Gear - Ring	226-7981	4J-2414	Trunnion	296-1370			
2P-6128	Pulley	264-5872	4J-3583	Screw - Adjusting	297-7242			
			4J-6374	Bearing - Sleeve	295-6407			
			4K-0255	Retainer As	226-6102			

Sales Model D4D (Continued)

Original Part Number	Part Name	Classic Part Number
4S-8713	Gear - Ring	226-6090
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4V-6156	Saddle As	299-2052
4W-0452	Seal As - Camshaft	325-6191
5F-1401	Pin - Pivot	297-7216
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5K-6090	Flange	216-7844
5K-8606	Cage - Gear Bearing	223-6310
5L-8856	Coupling - Exhaust	311-9379
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-0885	Plate - Front	229-8234
5S-0894	Shaft - Center	226-6075
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6J-0800	Bearing	297-7140
6K-4617	Shaft - Sprocket	221-7951
6L-8968	Coupling - Exhaust	311-9381
6N-1036	Gear - Oil Pump	279-4991
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6P-7704	Carrier - Ring	314-8658
6W-0240	Bearing - Brace	297-7143
6Y-0710	Gear	226-6104

Original Part Number	Part Name	Classic Part Number
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7H-2742	Nut	229-8220
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7602	Pump Gp	226-0174

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7V-5249	Shaft - Steering	215-1761
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-9661	Gear - Bevel	213-8218
8M-0874	Plunger As - Valve	311-9439
8M-3224	Muffler	247-2676
8M-6676	Cylinder - Adjustable	226-4960
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199

(Continued)

Sales Model D4D (Continued)

Original Part Number	Part Name	Classic Part Number
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9K-0424	Shaft - Pinion	215-1874
9K-6842	Cage As	216-7872
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256

Original Part Number	Part Name	Classic Part Number
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-4333	Gear - Oil Pump Input	226-6105
9W-1677	Bearing	297-7145
9W-6358	Drum - Steering	226-7995
9Y-2992	Bearing - Sleeve	325-6032
9Y-9431	Precleaner As	361-1718

Sales Model D4E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111

Original Part Number	Part Name	Classic Part Number
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1K-7974	Gear - Transmission Shaft	226-7984
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902

Original Part Number	Part Name	Classic Part Number
1P-1636	Lever As	226-8013
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-6422	Pilot As - Spring	226-4849
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0020	Wheel - Turbine	297-4862
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715

(Continued)

Sales Model D4E (Continued)

Original Part Number	Part Name	Classic Part Number
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-6413	Pin	360-2270
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-7198	Pilot As - Recoil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)

Original Part Number	Part Name	Classic Part Number
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-1537	Nut - Spanner	226-6098
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3J-6559	Cap - Bearing	296-1346
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Exhaust	314-8516
3P-3935	Shaft	299-2053
3S-5396	Shaft - Fly-wheel	226-8015
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3S-8800	Gear - Driven	325-6090
3V-1025	Shaft - Pinion	226-6109
3V-5916	Plate As - Press	226-8025
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362

Original Part Number	Part Name	Classic Part Number
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8591	Coupling - Exhaust	325-6053
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8713	Gear - Ring	226-6090
4V-0381	Bearing - Sleeve	299-1963
4V-2744	Gear	224-1303
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4V-6156	Saddle As	299-2052
4W-0452	Seal As - Camshaft	325-6191
5F-1401	Pin - Pivot	297-7216
5H-5500	Collar - Fly-wheel	302-2704

(Continued)

Sales Model D4E (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5K-8606	Cage - Gear Bearing	223-6310	7K-8238	Flange	213-8166	8H-2810	Case As - Filter	314-8512
5P-7807	Bearing - Ball	314-8502	7M-2167	Ring - Governor Control	308-9919	8H-9806	Gear - Shaft Drive	325-6091
5S-0884	Gear - Ring	226-7982	7N-0128	Core As - Oil Cooler	299-1994	8K-9661	Gear - Bevel	213-8218
5S-0885	Plate - Front	229-8234	7N-0165	Core As - Oil Cooler	295-5670	8M-0874	Plunger As - Valve	311-9439
5S-0894	Shaft - Center	226-6075	7N-1164	Mount As	295-5451	8M-6676	Cylinder - Adjustable	226-4960
5S-6795	Chamber As	242-3437	7N-2871	Line As - Fuel Injector	319-8172	8M-7166	Housing - Screen	297-7192
5S-9080	Pulley - Alt Drive	264-5883	7N-2872	Line As - Fuel Injector	319-8173	8N-0002	Trunnion As	314-8728
5V-5661	Bearing - Sleeve	299-1965	7N-2874	Line As - Fuel Injector	298-2779	8N-0875	Valve - Exhaust (Valve), 241-3381 (Valve Kit)	
6F-3183	Cap - Bearing	325-6038	7N-2949	Pulley	264-5887	8N-1187	Head Gp - Cylinder	242-3435
6H-3957	Bearing - Ball	311-9358	7N-3515	Gear - Camshaft	314-8669	8N-1188	Head Gp - Cylinder	242-3436
6I-1346	Pump Gp - Oil	295-5674	7N-3536	Gear - Fuel	279-4993	8N-1721	Rod As - Conn	269-5291
6I-8132	Pinion	226-6080	7N-5910	Impeller - Pump	314-8686	8N-1984	Rod As - Conn	242-3441
6J-0800	Bearing	297-7140	7N-9146	Gear - Flywheel Starter	279-4995	8N-2510	Shaft	325-6208
6K-4617	Shaft - Sprocket	221-7951	7N-9805	Pin - Piston	295-6438	8N-2641	Sleeve	325-6210
6N-1036	Gear - Oil Pump	279-4991	7S-3161	Lifter - Valve	279-4996	8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
6N-1553	Coupling - Exhaust	295-6422	7S-6723	Bracket - Alternator	299-1978	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
6N-2789	Pulley	264-5886	7S-7070	Head As - Cylinder	325-6107	8N-3251	Shaft As - Rocker Arm	314-8711
6N-8413	Housing - Pump	325-6110	7S-7602	Pump Gp	226-0174	8N-3311	Shaft As - Rocker Arm	325-6199
6P-0169	Hub - Flywheel Clutch	297-7204	7S-7809	Cap As - Radiator	295-6417	8N-3312	Shaft As - Rocker Arm	325-6200
6P-7704	Carrier - Ring	314-8658	7S-8213	Guard As - Final Drive Wear	226-4943	8N-3325	Arm Gp - Rocker	314-8623
6W-0240	Bearing - Brace	297-7143	7S-8214	Guard As - Final Drive Wear	226-4944	8N-3327	Arm Gp - Rocker	314-8624
6Y-0710	Gear	226-6104	7S-8443	Muffler	247-2675	8N-5929	Cover - Water Pump	296-1349
7C-4297	Seal As - Camshaft	325-6192	7T-2036	Cap As - Filter	361-1721	8N-6796	Head Gp - Cylinder	269-5290
7G-2480	Gear - Planet	226-6091	7V-5249	Shaft - Steering	215-1761	8N-7315	Tube As - Outlet	325-6232
7G-2481	Gear - Planet	226-6092	7W-0450	Gear - Water Pump	279-4997	8N-7780	Shield - Oil	314-8544
7G-2485	Gear - Planet	226-7983	7W-0507	Gear - Oil Pump Drive	279-4998	8N-8225	Bearing - Main	314-8652
7G-2830	Ring - Seal	295-6441	7W-0508	Gear - Fuel Pump Drive	296-1351	8N-9733	Line As - Fuel Injector	319-8174
7G-7681	Shaft As	307-1530	7W-3042	Tube As - Drain	325-6231	8P-2430	Shaft As	297-7258
7H-2424	Sleeve - Spring	226-4852	7W-5687	Hub - Camshaft	314-8684	8S-0248	Breather As	325-6033
7H-2742	Nut	229-8220	7Y-1517	Pipe As - Tail	301-5246			
7J-6461	Crown	325-6054						
7J-9842	Bearing - Sleeve	299-1968						
7J-9884	Bearing - Sleeve	325-6016						
7K-3582	Nut - Adjusting	226-6099						
7K-4770	Pinion	226-6082						
7K-4771	Gear	229-8221						
7K-8237	Drum	226-6100						

(Continued)

Sales Model D4E (Continued)

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9K-6842	Cage As	216-7872

Original Part Number	Part Name	Classic Part Number
9K-8757	Rod End - Bearing	311-9361
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-4789	Shaft - Gov Control	297-7256
9M-8117	Shaft - Fly-wheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050

Original Part Number	Part Name	Classic Part Number
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9T-4761	Head	325-6108
9V-4333	Gear - Oil Pump Input	226-6105
9V-6775	Drum	226-7994
9W-1677	Bearing	297-7145
9W-6358	Drum - Steering	226-7995
9Y-2992	Bearing - Sleeve	325-6032

Sales Model D5

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
111-8015	Gasket As - Head	279-4977
121-7746	Precleaner As	360-2311
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-0176	Flange - Drum	223-4810
1M-1618	Collar As - Shift	226-8029
1M-6128	Manifold - Exhaust	261-0906
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112

Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1636	Lever As	226-8013
1P-1931	Shaft - Steer	227-4772
1P-4303	Head As - Cylinder	242-3434
1P-6273	Rod Gp - Recoil	226-4847
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-9024	Spring - Equalizer	231-3311
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-6422	Pilot As - Spring	226-4849
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1T-0521	Retainer - Bearing	325-6180

Original Part Number	Part Name	Classic Part Number
1T-0699	Impeller - Converter	235-1808
1T-1350	Torque Converter	235-0912 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
244-1090	Alarm - Backup	360-2345
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pressure	226-8011
2H-6777	Plate - Flywheel	226-8012
2K-4507	Bearing - Sleeve	325-6021
2M-1086	Plate As - Press	226-8023
2M-2290	Bracket - Ring	299-1979

(Continued)

Sales Model D5 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2M-2415	Guard-idler - Rh	226-4931	3B-6218	Muffler As	247-2672	4N-3281	Line As - Fuel Injector	247-3362
2M-2416	Guard-idler - Lh	226-4933	3F-1956	Cap - Frame Sup	226-7987	4N-3282	Line As - Fuel Injector	247-3363
2M-2417	Guard-spring - Rh	226-4934	3F-1972	Retainer As	226-7988	4N-3283	Line As - Fuel Injector	247-3364
2M-2418	Guard-spring - Lh	226-4935	3F-6185	Pin	295-5694	4N-3284	Line As - Fuel Injector	247-3365
2M-4668	Retainer - Guard	297-4867	3F-6446	Pivot - Push Pole	256-4827	4N-4864	Pump Gp - Fuel Transfer	242-3442
2P-1005	Bearing - Sleeve	296-1342	3F-6523	Pin - Clevis	256-4818	4N-7693	Crankshaft As	242-3439
2P-1170	Shaft As - Gear	296-1367	3F-6561	Arm As - Brace	256-4828	4N-7982	Pulley	264-5880
2P-1738	Plate As - Oil Pan	325-6164	3F-6611	Socket - Joint	256-4829	4N-8591	Coupling - Exhaust	325-6053
2P-1739	Tube As - Pump	325-6229	3F-6612	Cap - Ball Joint	297-7155	4N-8814	Line As - Fuel Injector	247-3366
2P-1757	Hub - Fan Pulley	296-1357	3H-3378	Gear As - Pump	298-2795	4N-9587	Shield - Heat	297-7260
2P-1781	Spacer - Oil Pump	325-6214	3J-6559	Cap - Bearing	296-1346	4P-0660	Muffler As	298-2787
2P-2519	Tube As - Inlet	325-6230	3K-3124	Muffler - Trap	247-2673	4P-3546	Valve As - Relief	325-6236
2P-4370	Plate - Clutch	325-6166	3L-1425	Bearing - Ball	311-9356	4S-5943	Piston - Clutch	221-9112
2P-6245	Shaft As - Pump	325-6197	3P-3623	Lock - Adjustable Nut	226-7989	4S-5944	Gear - Sun	221-9078
2P-7622	Bolt - Spring	226-4850	3P-5736	Hub - Gear	219-2975	4S-5945	Gear - Sun	221-9079
2P-9660	Gear - Final Drive	226-5995	3P-5754	Hub - Gear	219-2976	4S-5947	Gear - Ring	221-9080
2P-9667	Cage - Shaft Bearing	226-7971	3P-5755	Extension - Final Drive	226-7990	4S-5948	Gear - Ring	221-9082
2P-9672	Cage - Pinion Bearing	226-7972	3S-0311	Rod Gp	226-4953	4S-5979	Carrier As	216-7843
2S-1477	Holder As - Cage	226-7985	3S-1167	Gear - Planet	221-9101	4S-5981	Gear - Ring	221-9084
2S-4015	Plunger As - Valve	311-9438	3S-2712	Gear - Transfer	226-7977	4S-6189	Pinion - Reverse	226-6077
2S-8277	Guard Gp - Spring	226-4936	3S-5396	Shaft - Fly-wheel	226-8015	4S-6190	Pinion - Forward	226-6078
2S-8278	Guard Gp - Spring	226-4937	3S-7153	Gear - Sliding	227-0024	4S-6559	Tube	325-6234
2W-1086	Cover As - Cylinder Head	325-6049	3S-7504	Gear - Idler	226-6084	4S-8005	Pinion - Final Drive	226-6076
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	3S-8634	Hub - Gear	219-2977	4S-8530	Shaft - Planet	221-9111
2W-7255	Shaft - Water Pump	325-6203	3V-1133	Strip	226-0203	4S-8534	Shaft As - Planet	221-9116
2W-7458	Crankshaft As	242-3439	4B-1455	Cap As - Filter	361-1719	4S-8716	Gear - Transfer	226-7978
2W-9978	Core As - Oil Cooler	279-4983	4F-1252	Pin	295-5704	4W-0452	Seal As - Camshaft	325-6191
			4F-4974	Clamp	311-9373	5A-4003	Shaft - Sprocket	229-8228
			4H-4021	Plate As - Loading	229-8219	5A-5196	Hub - Gear	221-1066
			4H-9040	Nut	226-7996	5A-5740	Gear - Sliding	229-8229
			4J-2414	Trunnion	296-1370	5A-6897	Guard - Idler Rh	226-4951
			4J-3583	Screw - Adjusting	297-7242	5A-6898	Guard - Idler Lh	226-4952
			4J-6374	Bearing - Sleeve	295-6407	5A-9551	Gear - Final Drive	226-7979
			4K-4780	Strip As - Wear	299-2063			
			4K-7386	Plate - Guide	226-4851			
			4N-2954	Sleeve - Camshaft	299-2059			

(Continued)

Sales Model D5 (Continued)

Original Part Number	Part Name	Classic Part Number
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5F-2256	Cage - Bearing	226-7973
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5M-7342	Flange - Shaft	215-1696
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4023	Gear	229-8230
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-6513	Guard As - Roller	226-4938
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-8767	Gear - First	226-6085
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-0800	Bearing	297-7140
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204

Original Part Number	Part Name	Classic Part Number
6T-0443	Pinion - Shaft & Bevel	226-7999
6T-6053	Pinion - Shaft & Gear	226-6079
6W-0240	Bearing - Brace	297-7143
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-3815	Pump Gp	226-0171
7G-6044	Cage As	216-7857
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7H-4710	Bushing - Sleeve	299-1990
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994

Original Part Number	Part Name	Classic Part Number
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-8660	Pump Gp - Transmission	226-0175
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721

(Continued)

Sales Model D5 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7W-0450	Gear - Water Pump	279-4997	8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)	9H-4104	Pilot - Spring	226-4962
7W-0507	Gear - Oil Pump Drive	279-4998	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)	9H-7670	Piston	226-4961
8B-5972	Bearing - Ball	314-8503	8N-3325	Arm Gp - Rocker	314-8623	9J-9598	Pin	296-1362
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)	8N-3327	Arm Gp - Rocker	314-8624	9M-2049	Gear - Ring	214-0533
8H-9379	Nut - Brake Band Adjustable	299-2029	8N-5929	Cover - Water Pump	296-1349	9M-4163	Valve - Exhaust	298-2773
8H-9806	Gear - Shaft Drive	325-6091	8N-7315	Tube As - Outlet	325-6232	9M-4789	Shaft - Gov Control	297-7256
8J-2652	Shaft	299-2054	8N-8225	Bearing - Main	314-8652	9M-4955	Pump Gp - Fuel Transfer	242-3443
8J-2653	Lever As	299-2015	8N-9733	Line As - Fuel Injector	319-8174	9M-8117	Shaft - Fly-wheel Clutch	226-6073
8J-2654	Lever As	299-2016	8P-1182	Shaft	227-4771	9M-8119	Retainer - Inlet	226-8022
8K-5587	Rod Gp - Recoil	226-4954	8P-1183	Gear - Bevel	226-7980	9M-8281	Gear As - Oil Pump	325-6089
8M-0874	Plunger As - Valve	311-9439	8P-1853	Nut - Adjusting	226-7997	9N-5769	Cover - Housing	325-6050
8M-3224	Muffler	247-2676	8P-1855	Hub As - Sprocket	227-4770	9S-2354	Manifold - Exhaust	261-0888
8M-6219	Spring - Equalizer	293-7606	8P-4111	Guard As	226-4945	9S-2355	Manifold - Exhaust	261-0891
8M-6615	Leaf - Spring	293-7607	8P-4112	Guard As	226-4946	9S-3321	Cage - Pinion Bearing	226-7974
8M-6616	Leaf - Spring	293-7608	8S-0248	Breather As	325-6033	9S-6129	Pulley - Alternator Drive	264-5891
8M-6676	Cylinder - Adjustable	226-4960	8S-0493	Shaft As - Pump	325-6198	9S-8245	Strip - Track	226-0243
8M-7166	Housing - Screen	297-7192	8S-0556	Coupling	221-9114	9S-8246	Strip - Track	226-0244
8N-0002	Trunnion As	314-8728	8S-1831	Guard As - Sprocket	226-4947	9S-8257	Guard As - Guiding	226-0238
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8S-1832	Guard As - Sprocket	226-4948	9S-8258	Guard As - Guiding	226-0239
8N-1187	Head Gp - Cylinder	242-3435	8S-2140	Trunnion - Gear	226-8020	9S-8353	Strip - Track	226-4854
8N-1721	Rod As - Conn	269-5291	8S-3970	Chamber As	242-3438	9S-8354	Strip - Track	226-4855
8N-1984	Rod As - Conn	242-3441	8S-5722	Plate - Pressure	226-8009	9S-8358	Guard As - Guiding	226-4856
			9F-7101	Bushing - Collar	299-1988	9S-8359	Guard As - Guiding	226-4857
			9G-8246	Rod Gp - Idler Recoil	226-4955	9S-8679	Chamber As	325-6042
			9G-8302	Guide	226-4853	9T-4761	Head	325-6108
			9H-2256	Pump Gp	311-9443	9W-1677	Bearing	297-7145
						9Y-9431	Precleaner As	361-1718

Sales Model D5B

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
118-1611	Roller Gp - SF	175-8024
118-1612	Roller Gp - DF	175-8025
121-7576	--	--
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
154-3662	Link As.	257-8020
154-3667	Link As.	260-1509
154-3676	Link As.	257-8021
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
185-6151	Segment, Segment Gp	260-1510, 260-1511 (sprocket group)
190-8609	Valve - Fill	360-2288
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-1408	Nut (5/8-18)	200-9150
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087

Original Part Number	Part Name	Classic Part Number
1P-1636	Lever As	226-8013
1P-6273	Rod Gp - Recoil	226-4847
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-9024	Spring - Equalizer	231-3311
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-6422	Pilot As - Spring	226-4849
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1T-0521	Retainer - Bearing	325-6180
1T-1350	Torque Converter	235-0912 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072

Original Part Number	Part Name	Classic Part Number
2G-8872	Shaft - Bevel	275-5271
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-8489	Bearing - Sleeve	295-5691
2K-3592	Boss	314-8501
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2M-2290	Bracket - Ring	299-1979
2M-2415	Guard-idler - Rh	226-4931
2M-2416	Guard-idler - Lh	226-4933
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2M-4668	Retainer - Guard	297-4867
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-2744	Muffler As	247-2664
2P-4370	Plate - Clutch	325-6166
2P-6245	Shaft As - Pump	325-6197
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2P-9672	Cage - Pinion Bearing	226-7972
2S-1477	Holder As - Cage	226-7985
2S-8277	Guard Gp - Spring	226-4936

(Continued)

Sales Model D5B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2S-8278	Guard Gp - Spring	226-4937	3S-2712	Gear - Transfer	226-7977	4P-9385	Line As - Fuel Injector	279-4986
2W-1086	Cover As - Cylinder Head	325-6049	3S-5396	Shaft - Fly-wheel	226-8015	4P-9386	Line As - Fuel Injector	279-4987
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	3S-7153	Gear - Sliding	227-0024	4S-5943	Piston - Clutch	221-9112
2W-7255	Shaft - Water Pump	325-6203	3S-7504	Gear - Idler	226-6084	4S-5944	Gear - Sun	221-9078
2W-7458	Crankshaft As	242-3439	3S-8634	Hub - Gear	219-2977	4S-5945	Gear - Sun	221-9079
2W-7678	Gear - Water Pump	325-6088	3T-1900	Drum - Steering Clutch	226-7991 (Drum), 230-7111 (Steering Clutch Kit)	4S-5947	Gear - Ring	221-9080
2W-9978	Core As - Oil Cooler	279-4983	3T-3690	Shoe -Track	175-8553	4S-5948	Gear - Ring	221-9082
3F-1956	Cap - Frame Sup	226-7987	3V-1133	Strip	226-0203	4S-5979	Carrier As	216-7843
3F-1972	Retainer As	226-7988	4F-1252	Pin	295-5704	4S-5981	Gear - Ring	221-9084
3F-6185	Pin	295-5694	4F-4974	Clamp	311-9373	4S-6189	Pinion - Reverse	226-6077
3F-6446	Pivot - Push Pole	256-4827	4H-4021	Plate As - Loading	229-8219	4S-6190	Pinion - Forward	226-6078
3F-6523	Pin - Clevis	256-4818	4H-9040	Nut	226-7996	4S-6559	Tube	325-6234
3F-6561	Arm As - Brace	256-4828	4J-2414	Trunnion	296-1370	4S-8530	Shaft - Planet	221-9111
3F-6611	Socket - Joint	256-4829	4J-3583	Screw - Adjusting	297-7242	4S-8534	Shaft As - Planet	221-9116
3F-6612	Cap - Ball Joint	297-7155	4J-6374	Bearing - Sleeve	295-6407	4S-8716	Gear - Transfer	226-7978
3J-6559	Cap - Bearing	296-1346	4K-4780	Strip As - Wear	299-2063	4W-0452	Seal As - Camshaft	325-6191
3K-3124	Muffler - Trap	247-2673	4K-7386	Plate - Guide	226-4851	5A-4003	Shaft - Sprocket	229-8228
3L-1425	Bearing - Ball	311-9356	4N-2954	Sleeve - Camshaft	299-2059	5A-5740	Gear - Sliding	229-8229
3P-2274	Bolt Master	200-9133	4N-3281	Line As - Fuel Injector	247-3362	5A-6897	Guard - Idler Rh	226-4951
3P-3623	Lock - Adjustable Nut	226-7989	4N-3282	Line As - Fuel Injector	247-3363	5A-6898	Guard - Idler Lh	226-4952
3P-3889	Shoe - Track Master	175-8021	4N-3283	Line As - Fuel Injector	247-3364	5A-8374	Roller Gp - Carrier	200-9185
3P-3890	Shoe - Track Master	175-8366	4N-3284	Line As - Fuel Injector	247-3365	5A-9551	Gear - Final Drive	226-7979
3P-3891	Shoe - Track Master	175-8368	4N-4864	Pump Gp - Fuel Transfer	242-3442	5F-0689	Pin	256-4821
3P-3892	Shoe - Track Master	175-8674	4N-7693	Crankshaft As	242-3439	5F-0706	Pin	256-4822
3P-3896	Shoe - Track Master	175-8023	4N-7982	Pulley	264-5880	5F-0707	Collar	256-4831
3P-3935	Shaft	299-2053	4N-8591	Coupling - Exhaust	325-6053	5F-0736	Pin - Pivot	256-4823
3P-5736	Hub - Gear	219-2975	4N-8814	Line As - Fuel Injector	247-3366	5H-5500	Collar - Fly-wheel	302-2704
3P-5754	Hub - Gear	219-2976	4N-9587	Shield - Heat	297-7260	5M-7342	Flange - Shaft	215-1696
3P-5755	Extension - Final Drive	226-7990	4P-0660	Muffler As	298-2787	5P-7807	Bearing - Ball	314-8502
3P-5762	Link As.	257-8022	4P-3546	Valve As - Relief	325-6236	5S-0726	Hub As - Sprocket	227-4769
3S-0311	Rod Gp	226-4953	4P-9381	Line As - Fuel Injector	279-4984	5S-0821	Shoe -Track	175-8020
3S-1167	Gear - Planet	221-9101	4P-9382	Line As - Fuel Injector	279-4985	5S-0822	Shoe -Track	175-8365
						5S-0823	Shoe -Track	175-8367
						5S-1211	Cover - Valve	314-8665
						5S-4023	Gear	229-8230
						5S-4493	Carrier - Planet	223-6321

(Continued)

Sales Model D5B (Continued)

Original Part Number	Part Name	Classic Part Number
5S-6513	Guard As - Roller	226-4938
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-8767	Gear - First	226-6085
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6J-0800	Bearing	297-7140
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6T-0443	Pinion - Shaft & Bevel	226-7999
6T-6053	Pinion - Shaft & Gear	226-6079
7C-4297	Seal As - Camshaft	325-6192
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2477	Gear - Planet	221-9090
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-6044	Cage As	216-7857
7G-8459	Hub - Gear	221-1070

Original Part Number	Part Name	Classic Part Number
7H-2424	Sleeve - Spring	226-4852
7H-4710	Bushing - Sleeve	299-1990
7J-6461	Crown	325-6054
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7S-0706	Shoe -Track	175-8673
7S-3161	Lifter - Valve	279-4996
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7625	Support As	226-6095

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-8660	Pump Gp - Transmission	226-0175
7S-9567	Shoe -Track	175-8022
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
8H-2810	Case As - Filter	314-8512
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8K-5587	Rod Gp - Recoil	226-4954
8M-0874	Plunger As - Valve	311-9439
8M-6219	Spring - Equalizer	293-7606
8M-6615	Leaf - Spring	293-7607
8M-6616	Leaf - Spring	293-7608
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435

(Continued)

Sales Model D5B (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
8N-1721	Rod As - Conn	269-5291	8P-1328	Flange - Drive Drum	226-8006	9H-2256	Pump Gp	311-9443
8N-1984	Rod As - Conn	242-3441	8P-1353	Piston - Steering	226-8007	9H-4104	Pilot - Spring	226-4962
8N-2510	Shaft	325-6208	8P-1774	Pinion - Final Drive	226-8001	9H-7670	Piston	226-4961
8N-2641	Sleeve	325-6210	8P-1853	Nut - Adjusting	226-7997	9J-9598	Pin	296-1362
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)	8P-1855	Hub As - Sprocket	227-4770	9K-8757	Rod End - Bearing	311-9361
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)	8P-2430	Shaft As	297-7258	9M-2049	Gear - Ring	214-0533
8N-3251	Shaft As - Rocker Arm	314-8711	8P-4111	Guard As	226-4945	9M-4789	Shaft - Gov Control	297-7256
8N-3325	Arm Gp - Rocker	314-8623	8P-4112	Guard As	226-4946	9M-8117	Shaft - Fly-wheel Clutch	226-6073
8N-3327	Arm Gp - Rocker	314-8624	8P-8570	Pilot As - Piston	226-6097	9M-8119	Retainer - Inlet	226-8022
8N-5929	Cover - Water Pump	296-1349	8S-0248	Breather As	325-6033	9M-8281	Gear As - Oil Pump	325-6089
8N-6796	Head Gp - Cylinder	269-5290	8S-0493	Shaft As - Pump	325-6198	9N-5769	Cover - Housing	325-6050
8N-7315	Tube As - Outlet	325-6232	8S-0556	Coupling	221-9114	9S-2355	Manifold - Exhaust	261-0891
8N-7780	Shield - Oil	314-8544	8S-1831	Guard As - Sprocket	226-4947	9S-3321	Cage - Pinion Bearing	226-7974
8N-8225	Bearing - Main	314-8652	8S-1832	Guard As - Sprocket	226-4948	9S-6129	Pulley - Alternator Drive	264-5891
8N-9733	Line As - Fuel Injector	319-8174	8S-2140	Trunnion - Gear	226-8020	9S-8245	Strip - Track	226-0243
8P-0203	Drum	226-8004	8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)	9S-8246	Strip - Track	226-0244
8P-1182	Shaft	227-4771	8S-2809	Muffler	247-2677	9S-8257	Guard As - Guiding	226-0238
8P-1183	Gear - Bevel	226-7980	8S-3970	Chamber As	242-3438	9S-8258	Guard As - Guiding	226-0239
8P-1324	Cage - Gr Shft Bearing	229-8239	9F-7101	Bushing - Collar	299-1988	9S-8353	Strip - Track	226-4854
8P-1325	Hub - Steering	226-8005	9G-8246	Rod Gp - Idler Recoil	226-4955	9S-8354	Strip - Track	226-4855
8P-1326	Pilot - Piston	226-6097	9G-8302	Guide	226-4853	9S-8358	Guard As - Guiding	226-4856
8P-1327	Pinion - Final Drive	226-8000				9S-8359	Guard As - Guiding	226-4857
						9S-8679	Chamber As	325-6042
						9T-4761	Head	325-6108
						9W-1677	Bearing	297-7145

Sales Model D5H

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	115-7550	Gasket - Plate	314-8667	172-5188	Shaft - Water Pump	325-6202
104-4253	Line As - Fuel Injector	279-4988	131-3815	Seal Gp - Basic	325-6193	172-5189	Impeller - Pump	295-5687
104-4254	Line As - Fuel Injector	279-4989	148-7455	Valve - Exhaust	270-4361	172-5190	Impeller - Pump	325-6111
111-8015	Gasket As - Head	279-4977	165-4262	Body As - Piston	270-4353 (Liner Kit)	172-6712	Impeller - Pump	325-6112
			172-5185	Shaft - Water Pump	325-6201	172-7767	Pump Gp - Water	296-1365

(Continued)

Sales Model D5H (Continued)

Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-4701	Pulley - Alt	264-5866
1U-0105	Brace As	295-5684
1U-0159	Pin	325-6134
1U-0928	Screw - Adjusting	325-6187
1U-1267	Brace As	296-1343
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2F-5721	Bearing - Ball	311-9354
2J-8489	Bearing - Sleeve	295-5691
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1757	Hub - Fan Pulley	296-1357

Original Part Number	Part Name	Classic Part Number
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
3F-4971	Pin	295-5693
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6612	Cap - Ball Joint	297-7155
3G-6313	Bearing	325-6007
3G-6565	Bearing - Sleeve	325-6008
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3J-2452	Cap - Ball Joint	297-7156
3J-6167	Bearing - Sleeve	299-1960
3J-6173	Pin	325-6144
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6573	Screw - Adjusting	302-2714
3L-1425	Bearing - Ball	311-9356
3T-1162	Sleeve - Wear	325-6209
3T-2145	Carrier As	325-6041
3T-3447	Gear As - Sun	302-2676
3T-6795	Piston - Clutch	281-1693
3T-9496	Plate - Retainer	299-2042

Original Part Number	Part Name	Classic Part Number
3W-0640	Piston	325-6160
3W-0643	Cylinder	325-6061
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-2414	Trunnion	296-1370
4J-3015	Shaft	325-6204
4J-3583	Screw - Adjusting	297-7242
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4N-4782	Pulley	325-6176
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-6559	Tube	325-6234
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727
4T-5172	Seal As	325-6189
4T-5495	Ballstud	314-8626
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5T-1362	Bearing - Spider	325-6011
6D-0217	Bearing - Sleeve	325-6022
6F-3183	Cap - Bearing	325-6038

(Continued)

Sales Model D5H (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
6H-3957	Bearing - Ball	311-9358	7J-9842	Bearing - Sleeve	299-1968	8N-3312	Shaft As - Rocker Arm	325-6200
6I-1346	Pump Gp - Oil	295-5674	7J-9884	Bearing - Sleeve	325-6016	8N-3325	Arm Gp - Rocker	314-8623
6J-0800	Bearing	297-7140	7N-0128	Core As - Oil Cooler	299-1994	8N-3327	Arm Gp - Rocker	314-8624
6N-1036	Gear - Oil Pump	279-4991	7N-0165	Core As - Oil Cooler	295-5670	8N-5929	Cover - Water Pump	296-1349
6N-2789	Pulley	264-5886	7N-2949	Pulley	264-5887	8N-6796	Head Gp - Cylinder	269-5290
6N-8413	Housing - Pump	325-6110	7N-5910	Impeller - Pump	314-8686	8N-7315	Tube As - Outlet	325-6232
6P-2233	Gear - Planet	281-1690	7N-9145	Gear - Fly-wheel	279-4994	8N-8225	Bearing - Main	314-8652
6P-7742	Shaft - Planet	281-1695	7N-9805	Pin - Piston	295-6438	8N-9402	Coupling	325-6048
6P-7743	Shaft - Planet	281-1696	7P-6596	Bearing - Sleeve	295-6409	8P-8677	Hub - Impeller	297-7205
6P-8005	Gear - Planet	281-1691	7S-3161	Lifter - Valve	279-4996	8S-0248	Breather As	325-6033
6T-3009	Piston - Clutch	297-7226	7T-5038	Housing As	297-7202	8S-0493	Shaft As - Pump	325-6198
6T-3285	Shaft - Track Idler	325-6205	7W-0450	Gear - Water Pump	279-4997	8S-3970	Chamber As	242-3438
6Y-4027	Pin	325-6148	7W-0507	Gear - Oil Pump Drive	279-4998	8Y-1198	Strip	325-6220
6Y-6126	Plate - Wear	325-6174	7W-0508	Gear - Fuel Pump Drive	296-1351	8Y-1199	Strip	325-6221
6Y-6127	Plate - Wear	325-6175	7W-3042	Tube As - Drain	325-6231	9G-1231	Plate	297-7232
6Y-6134	Bearing - Sleeve	325-6013	8E-6221	Pin	325-6155	9G-1491	Carrier - Planet	281-1685
6Y-6234	Bearing - Sleeve	325-6014	8E-9214	Pin	325-6156	9G-9349	Retainer	295-0411
6Y-6236	Bearing - Sleeve	325-6024	8G-3102	Piston	325-6162	9J-2365	Retainer	325-6186
6Y-6775	Pin	325-6151	8G-4187	Pin As	295-5676	9J-5875	Bearing - Sleeve	308-9830
6Y-8248	Pin	325-6154	8G-4189	Bearing - Aligning	295-6411	9J-7964	Bearing - Spherical	325-6017
7C-4297	Seal As - Camshaft	325-6192	8G-4190	Seal - Ebar	296-1366	9J-9147	Nut	299-2028
7G-3707	Piston - Clutch	302-2691	8H-2810	Case As - Filter	314-8512	9J-9598	Pin	296-1362
7G-3708	Piston - Clutch	300-2585	8J-2880	Cap - Bearing	295-6420	9M-1328	Bearing - Aligning	325-6018
7G-4302	Housing - Clutch	302-2708	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	9N-4460	Housing As	297-7203
7G-4306	Plate - Center	297-7229	8N-1187	Head Gp - Cylinder	242-3435	9N-5769	Cover - Housing	325-6050
7G-5444	Carrier - Planet	297-7165	8N-1188	Head Gp - Cylinder	242-3436	9P-3242	Plate - Clutch	325-6172
7G-5593	Gear - Sun	300-2581	8N-1721	Rod As - Conn	269-5291	9S-8679	Chamber As	325-6042
7G-5614	Shaft - Planet	281-1697	8N-2510	Shaft	325-6208	9T-8424	Bearing - Sleeve	325-6030
7G-7681	Shaft As	307-1530	8N-2641	Sleeve	325-6210	9W-0099	Bearing - Sleeve	314-8639
7G-9555	Bearing - Spider	314-8721	8N-3251	Shaft As - Rocker Arm	314-8711	9W-0517	Carrier - Planet	281-1686
7J-1333	Bearing - Sleeve	295-6408				9W-1677	Bearing	297-7145
7J-5131	Trunnion	296-1371				9W-2579	Plate	314-8701
7J-6461	Crown	325-6054				9W-8384	Hub - Turbine	297-7207
7J-9732	Bearing - Sleeve	308-9823				9W-9930	Mount As	295-6437

(Continued)

Sales Model D5H (Continued)

Original Part Number	Part Name	Classic Part Number
9Y-2992	Bearing - Sleeve	325-6032

Sales Model D6

Original Part Number	Part Name	Classic Part Number
OT-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
102-1561	Lifter As - Valve	311-9402
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
118-1611	Roller Gp - SF	175-8024
118-1612	Roller Gp - DF	175-8025
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
154-3662	Link As.	257-8020
154-3667	Link As.	260-1509
154-3676	Link As.	257-8021
160-6305	Cap - Bearing	295-5686
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
185-6151	Segment, Segment Gp	260-1510, 260-1511 (sprocket group)

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1M-0176	Flange - Drum	223-4810
1M-1408	Nut (5/8-18)	200-9150
1M-5165	Pinion - Final Drive	231-8766
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1931	Shaft - Steer	227-4772
1P-4303	Head As - Cylinder	242-3434
1P-5480	Cover As - End	299-1998
1P-7044	Cage	226-7975
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-1967	Chamber As	247-3291
1S-1970	Chamber As	247-3292
1S-4701	Pulley - Alt	264-5866
1S-5315	Cap As - Brace Bearing	226-4848
1S-5738	Insert - Seat Exhaust	311-9396
1S-6422	Pilot As - Spring	226-4849

Original Part Number	Part Name	Classic Part Number
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-3062	Retainer As	311-9445
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2B-3708	Chamber As	247-3293
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2K-4177	Pin - Lock	308-9893
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2M-2290	Bracket - Ring	299-1979
2N-3227	Bracket - Lft Guide	311-9367
2N-9297	Retainer - Spring	314-8535
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164

(Continued)

Sales Model D6 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2P-1739	Tube As - Pump	325-6229	3F-6611	Socket - Joint	256-4829	4N-3284	Line As - Fuel Injector	247-3365
2P-1757	Hub - Fan Pulley	296-1357	3F-6612	Cap - Ball Joint	297-7155	4N-4356	Pulley - Camshaft	264-5878
2P-1781	Spacer - Oil Pump	325-6214	3F-7445	Bearing - Sleeve	314-8508	4N-4577	Muffler As	308-9877
2P-2406	Pulley	264-5870	3H-3378	Gear As - Pump	298-2795	4N-4864	Pump Gp - Fuel Transfer	242-3442
2P-2519	Tube As - Inlet	325-6230	3K-3124	Muffler - Trap	247-2673	4N-5503	Adapter - Exhaust	299-1954
2P-4701	Shaft As - Gear	297-7257	3L-1425	Bearing - Ball	311-9356	4N-7526	Seal As - Pump	311-9454
2P-6128	Pulley	264-5872	3N-3368	Pipe - Exhaust	311-9434	4N-7693	Crankshaft As	242-3439
2P-6245	Shaft As - Pump	325-6197	3P-2274	Bolt Master	200-9133	4N-7982	Pulley	264-5880
2P-7622	Bolt - Spring	226-4850	3P-3623	Lock - Adjustable Nut	226-7989	4N-8591	Coupling - Exhaust	325-6053
2P-7830	Pump Gp	314-8533	3P-3889	Shoe - Track Master	175-8021	4N-8814	Line As - Fuel Injector	247-3366
2P-9660	Gear - Final Drive	226-5995	3P-3890	Shoe - Track Master	175-8366	4N-9180	Seal As - Pump	311-9455
2S-1273	Chamber As	319-3434	3P-3891	Shoe - Track Master	175-8368	4N-9587	Shield - Heat	297-7260
2S-1477	Holder As - Cage	226-7985	3P-3892	Shoe - Track Master	175-8674	4P-3546	Valve As - Relief	325-6236
2S-4015	Plunger As - Valve	311-9438	3P-3896	Shoe - Track Master	175-8023	4P-9381	Line As - Fuel Injector	279-4984
2S-6739	Pulley - Tightener	298-2794	3P-5754	Hub - Gear	219-2976	4P-9382	Line As - Fuel Injector	279-4985
2W-1086	Cover As - Cylinder Head	325-6049	3P-5762	Link As.	257-8022	4P-9385	Line As - Fuel Injector	279-4986
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)	3S-7153	Gear - Sliding	227-0024	4P-9386	Line As - Fuel Injector	279-4987
2W-3211	Valve - Exhaust	311-9471	3S-8634	Hub - Gear	219-2977	4S-8005	Pinion - Final Drive	226-6076
2W-7255	Shaft - Water Pump	325-6203	3S-8800	Gear - Driven	325-6090	4S-8472	Hood As	296-1355
2W-7458	Crankshaft As	242-3439	3S-9466	Bearing - Sleeve	314-8509	4S-8908	Insert	311-9399
2W-7678	Gear - Water Pump	325-6088	3T-3690	Shoe - Track	175-8553	4S-8909	Insert - Valve Seat	311-9400
2W-9978	Core As - Oil Cooler	279-4983	3V-1133	Strip	226-0203	4W-0452	Seal As - Camshaft	325-6191
3B-1464	Cap - Bearing	226-0206	4B-1455	Cap As - Filter	361-1719	4W-2446	Damper As	279-4990
3B-6217	Muffler As	247-2671	4F-4974	Clamp	311-9373	4W-9989	Gear As - Idler	302-2677
3B-6218	Muffler As	247-2672	4H-4021	Plate As - Loading	229-8219	5A-8374	Roller Gp - Carrier	200-9185
3F-1956	Cap - Frame Sup	226-7987	4H-9040	Nut	226-7996	5A-9551	Gear - Final Drive	226-7979
3F-1972	Retainer As	226-7988	4J-1999	Ballstud	314-8625	5D-0470	Valve Gp	314-8549
3F-4971	Pin	295-5693	4L-7820	Rod Assembly	311-9449	5F-0689	Pin	256-4821
3F-6185	Pin	295-5694	4M-9215	Gear - Pump Idler	311-9391	5F-2256	Cage - Bearing	226-7973
3F-6446	Pivot - Push Pole	256-4827	4N-2954	Sleeve - Camshaft	299-2059	5F-7993	Pin	319-3454
3F-6561	Arm As - Brace	256-4828	4N-3281	Line As - Fuel Injector	247-3362	5H-5500	Collar - Flywheel	302-2704
			4N-3282	Line As - Fuel Injector	247-3363			
			4N-3283	Line As - Fuel Injector	247-3364			

Sales Model D6 (Continued)

Original Part Number	Part Name	Classic Part Number
5L-3980	V - Belt Set	314-8498
5L-8856	Coupling - Exhaust	311-9379
5L-9371	Connector - Inlet	311-9375
5M-5243	Hub - Gear	219-2981
5M-5244	Hub - Gear	219-2982
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-0821	Shoe -Track	175-8020
5S-0822	Shoe -Track	175-8365
5S-0823	Shoe -Track	175-8367
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-4557	Bearing	311-9360
5S-6513	Guard As - Roller	226-4938
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6B-7178	Fork - Band Adjustable	299-2009
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358
6L-1346	Pump Gp - Oil	295-5674
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6N-0714	Pulley - Alt	264-5884
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813

Original Part Number	Part Name	Classic Part Number
7C-4297	Seal As - Camshaft	325-6192
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7D-6841	Joint As - Univ	228-9566
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-6044	Cage As	216-7857
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-9398	Plate - Guide	297-7230
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5810	Gear As - Idler	233-2179

Original Part Number	Part Name	Classic Part Number
7N-5815	Gear - Camshaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-0706	Shoe -Track	175-8673
7S-3161	Lifter - Valve	279-4996
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-6723	Bracket - Alternator	299-1978
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-8443	Muffler	247-2675
7S-9567	Shoe -Track	175-8022
7T-0204	Bearing - Brace	247-4126
7T-0206	Bearing - Brace	297-7144
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8B-5972	Bearing - Ball	314-8503
8F-8858	Button Valve	314-8511
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862

(Continued)

Sales Model D6 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
8H-2810	Case As - Filter	314-8512	8N-3327	Arm Gp - Rocker	314-8624	9F-7101	Bushing - Collar	299-1988
8H-9379	Nut - Brake Band Adjustable	299-2029	8N-5929	Cover - Water Pump	296-1349	9G-8302	Guide	226-4853
8H-9806	Gear - Shaft Drive	325-6091	8N-6796	Head Gp - Cylinder	269-5290	9H-2256	Pump Gp	311-9443
8L-4529	Pulley - Alternator	264-5889	8N-7315	Tube As - Outlet	325-6232	9H-4104	Pilot - Spring	226-4962
8M-0874	Plunger As - Valve	311-9439	8N-7780	Shield - Oil	314-8544	9H-7670	Piston	226-4961
8M-6676	Cylinder - Adjustable	226-4960	8N-8225	Bearing - Main	314-8652	9J-9598	Pin	296-1362
8N-0002	Trunnion As	314-8728	8N-9733	Line As - Fuel Injector	319-8174	9M-3025	Cover As	299-2001
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8P-1182	Shaft	227-4771	9M-4789	Shaft - Gov Control	297-7256
8N-1187	Head Gp - Cylinder	242-3435	8P-1183	Gear - Bevel	226-7980	9M-8117	Shaft - Fly-wheel Clutch	226-6073
8N-1721	Rod As - Conn	269-5291	8S-0248	Breather As	325-6033	9M-8119	Retainer - Inlet	226-8022
8N-1984	Rod As - Conn	242-3441	8S-0493	Shaft As - Pump	325-6198	9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
8N-2510	Shaft	325-6208	8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)	9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
8N-2641	Sleeve	325-6210	8S-3970	Chamber As	242-3438	9N-5769	Cover - Housing	325-6050
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)	8S-5722	Plate - Pressure	226-8009	9S-2354	Manifold - Exhaust	261-0888
8N-3251	Shaft As - Rocker Arm	314-8711	8S-7716	Manifold - Exhaust	295-0415	9S-2355	Manifold - Exhaust	261-0891
8N-3325	Arm Gp - Rocker	314-8623	8S-7717	Manifold - Exhaust	261-0894	9S-3321	Cage - Pinion Bearing	226-7974
			8S-7718	Manifold - Exhaust	295-0416	9S-6129	Pulley - Alternator Drive	264-5891
						9S-8493	Bolt - Connecting Rod	311-9351
						9S-8679	Chamber As	325-6042
						9W-1677	Bearing	297-7145
						9Y-9431	Precleaner As	361-1718

Sales Model D6B

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311	1M-7250	Bowl - Precleaner	360-2296	1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
190-8609	Valve - Fill	360-2288	1M-9177	Flywheel	226-6112	1W-4405	Gear - Crankshaft	279-4982
1A-2846	Cap As - Filler	311-9368	1P-1931	Shaft - Steer	227-4772	2F-5721	Bearing - Ball	311-9354
1H-8262	Shaft	226-8016	1P-7044	Cage	226-7975	2F-7576	Shaft - Sprocket	226-6071
1H-8382	Gear - Oil Pump Drive	226-6103	1P-9024	Spring - Equalizer	231-3311	2F-7577	Shaft	226-6072
1H-8937	Drumbrake	226-7993	1S-1888	Bracket - Lamp	297-7147	2H-4338	Plate - Pressure	226-8010
1H-8938	Lever	226-8028	1S-5315	Cap As - Brace Bearing	226-4848	2H-4450	Washer - Thrust	325-6237
1M-0176	Flange - Drum	223-4810	1S-6422	Pilot As - Spring	226-4849	2H-4482	Collar	229-8218
1M-5165	Pinion - Final Drive	231-8766						
1M-6128	Manifold - Exhaust	261-0906						

(Continued)

Sales Model D6B (Continued)

Original Part Number	Part Name	Classic Part Number
2H-5046	Link - Flycam	299-2024
2J-8489	Bearing - Sleeve	295-5691
2K-4507	Bearing - Sleeve	325-6021
2M-2290	Bracket - Ring	299-1979
2M-2415	Guard-idler - Rh	226-4931
2M-2416	Guard-idler - Lh	226-4933
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2M-4668	Retainer - Guard	297-4867
2P-7622	Bolt - Spring	226-4850
2P-9660	Gear - Final Drive	226-5995
2S-1477	Holder As - Cage	226-7985
2S-4015	Plunger As - Valve	311-9438
2S-8277	Guard Gp - Spring	226-4936
2S-8278	Guard Gp - Spring	226-4937
3B-6218	Muffler As	247-2672
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-6185	Pin	295-5694
3F-6446	Pivot - Push Pole	256-4827
3F-6523	Pin - Clevis	256-4818
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3H-3378	Gear As - Pump	298-2795
3J-6559	Cap - Bearing	296-1346
3K-3124	Muffler - Trap	247-2673
3P-3623	Lock - Adjustable Nut	226-7989
3P-5754	Hub - Gear	219-2976
3S-0311	Rod Gp	226-4953
3S-7153	Gear - Sliding	227-0024
3S-8634	Hub - Gear	219-2977
3S-8800	Gear - Driven	325-6090

Original Part Number	Part Name	Classic Part Number
3V-1133	Strip	226-0203
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4H-9040	Nut	226-7996
4J-2414	Trunnion	296-1370
4J-3583	Screw - Adjusting	297-7242
4J-6374	Bearing - Sleeve	295-6407
4K-4780	Strip As - Wear	299-2063
4K-7386	Plate - Guide	226-4851
4S-6559	Tube	325-6234
4S-8005	Pinion - Final Drive	226-6076
5A-4003	Shaft - Sprocket	229-8228
5A-9551	Gear - Final Drive	226-7979
5F-0689	Pin	256-4821
5F-0706	Pin	256-4822
5F-0707	Collar	256-4831
5F-0736	Pin - Pivot	256-4823
5F-2256	Cage - Bearing	226-7973
5H-5500	Collar - Fly-wheel	302-2704
5M-5243	Hub - Gear	219-2981
5M-5244	Hub - Gear	219-2982
5P-7807	Bearing - Ball	314-8502
5S-0726	Hub As - Sprocket	227-4769
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-6513	Guard As - Roller	226-4938
6B-7178	Fork - Band Adjustable	299-2009
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6J-0800	Bearing	297-7140
6P-0169	Hub - Fly-wheel Clutch	297-7204
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9547	Pin As - Drawbar	295-0414

Original Part Number	Part Name	Classic Part Number
7G-6044	Cage As	216-7857
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7H-4710	Bushing - Sleeve	299-1990
7M-0820	Gear - Sliding	226-6086
7M-2167	Ring - Governor Control	308-9919
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-5002	Drum - Steering	226-7992
7M-5050	Collar - Front Idler	226-4958
7M-7358	Valve - Inlet	298-2774
7M-9398	Plate - Guide	297-7230
7N-0128	Core As - Oil Cooler	299-1994
7N-9146	Gear - Fly-wheel Starter	279-4995
7S-6531	Guard As - Rh	226-4939
7S-6532	Guard As - Lh	226-4940
7S-6537	Guard As - Rh Basic	226-4941
7S-6538	Guard As - Lh Basic	226-4942
7S-7602	Pump Gp	226-0174
7S-7625	Support As	226-6095
7S-7809	Cap As - Radiator	295-6417
7S-8213	Guard As - Final Drive Wear	226-4943
7S-8214	Guard As - Final Drive Wear	226-4944
7S-9749	Pulley - Gen Drive	264-5888
7T-0203	Guide	226-4959
7T-0206	Bearing - Brace	297-7144
7T-2036	Cap As - Filter	361-1721
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8M-3224	Muffler	247-2676

(Continued)

Sales Model D6B (Continued)

Original Part Number	Part Name	Classic Part Number
8M-6219	Spring - Equalizer	293-7606
8M-6615	Leaf - Spring	293-7607
8M-6616	Leaf - Spring	293-7608
8M-6676	Cylinder - Adjustable	226-4960
8N-8225	Bearing - Main	314-8652
8P-1182	Shaft	227-4771
8P-1183	Gear - Bevel	226-7980
8P-4111	Guard As	226-4945
8P-4112	Guard As	226-4946
8S-1831	Guard As - Sprocket	226-4947
8S-1832	Guard As - Sprocket	226-4948

Original Part Number	Part Name	Classic Part Number
8S-5722	Plate - Pressure	226-8009
9F-7101	Bushing - Collar	299-1988
9G-8302	Guide	226-4853
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-7670	Piston	226-4961
9J-9598	Pin	296-1362
9M-4163	Valve - Exhaust	298-2773
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-8117	Shaft - Flywheel Clutch	226-6073

Original Part Number	Part Name	Classic Part Number
9M-8119	Retainer - Inlet	226-8022
9S-3321	Cage - Pinion Bearing	226-7974
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8353	Strip - Track	226-4854
9S-8354	Strip - Track	226-4855
9S-8358	Guard As - Guiding	226-4856
9S-8359	Guard As - Guiding	226-4857
9W-1677	Bearing	297-7145

Sales Model D6C

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
115-7550	Gasket - Plate	314-8667
118-1614	Roller Gp - SF	175-8035
118-1615	Roller Gp - DF	175-8036
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687

Original Part Number	Part Name	Classic Part Number
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1H-8938	Lever	226-8028
1M-1663	Collar As - Retain	226-8030
1M-1698	Gear - Sliding	215-1659
1M-1930	Cage - Pinion Bearing	217-7727
1M-1947	Support As	226-6096
1M-7250	Bowl - Precleaner	360-2296
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-0963	Guard As - Roller	226-0179

Original Part Number	Part Name	Classic Part Number
1P-1605	Gear - Forward	215-1663
1P-1608	Gear - Forward	302-2707
1P-1636	Lever As	226-8013
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-1897	Gear - Final Drive	215-1670
1P-3759	Rod Gp - Recoil	302-2713
1P-4303	Head As - Cylinder	242-3434
1P-6265	Gear - Bevel	221-9177
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-5331	Cylinder - Adjustable	226-0214

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
1S-8734	Bracket - Roller	226-0212
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1T-0300	Converter As	235-1803 (Repair Kit)
1T-0421	Flange As - Output	295-5442
1T-0436	Gear - Pump Drive	247-3367
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0443	Carrier As - Guide	247-3368
1T-0447	Carrier - Ring	295-0409
1T-0930	Torque Converter	235-0913 (Repair Kit)
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2B-8824	Drum	216-7817
2F-5721	Bearing - Ball	311-9354
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2J-5462	Trunnion	297-7264
2J-8489	Bearing - Sleeve	295-5691
2K-4507	Bearing - Sleeve	325-6021
2M-1086	Plate As - Press	226-8023

Original Part Number	Part Name	Classic Part Number
2M-2290	Bracket - Ring	299-1979
2M-4668	Retainer - Guard	297-4867
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1502	Gear - Shaft	214-0956
2P-1503	Gear - First	213-8637
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-4370	Plate - Clutch	325-6166
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2P-7984	Yoke As - Idler	226-0220
2S-3188	Plate	299-2041
2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)
2S-3803	Gear	226-6106
2S-3804	Gear - Sliding	226-6107
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-4365	Retainer As	216-3554
2S-6263	Guard Gp - Spring	226-0192
2S-6264	Guard Gp - Spring	226-0193
2S-6265	Rod Gp - Recoil	226-0197
2S-6344	Gear - Final Drive	297-7173
2S-6739	Pulley - Tightener	298-2794

Original Part Number	Part Name	Classic Part Number
2S-7603	Drum	213-6951
2V-7198	Pilot As - Re-coil Spring	302-2709
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-1537	Nut - Spanner	226-6098
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3H-3378	Gear As - Pump	298-2795
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-5432	Pin - Pivot	297-7213
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3241	Plate - Pressure	325-6167
3P-3623	Lock - Adjustable Nut	226-7989
3P-3935	Shaft	299-2053
3P-6318	Flange - Drum	213-8165
3P-6814	Pump Gp	226-0163

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
3P-6816	Pump Gp	226-0164	4N-3282	Line As - Fuel Injector	247-3363	4W-0452	Seal As - Camshaft	325-6191
3P-7640	Gear - Ctrshft	325-6093	4N-3283	Line As - Fuel Injector	247-3364	4W-9771	Gear - Crankshaft	302-2674
3P-7641	Gear - Ctrshft	325-6094	4N-3284	Line As - Fuel Injector	247-3365	4W-9989	Gear As - Idler	302-2677
3P-7642	Gear - Ctrshft	302-2668	4N-4539	Sleeve	314-8720	5A-7840	Shaft - Track Sprocket	215-1687
3P-7643	Gear - Pinion Shift	302-2669	4N-4782	Pulley	325-6176	5A-7841	Hub - Gear	219-2966
3P-7644	Gear - Pinion Shift	302-2706	4N-4864	Pump Gp - Fuel Transfer	242-3442	5G-3612	Cap Gp	295-6419
3S-1691	Disc - Steering	302-2705	4N-7526	Seal As - Pump	311-9454	5H-5500	Collar - Flywheel	302-2704
3S-8800	Gear - Driven	325-6090	4N-7692	Crankshaft As	242-3440	5K-6090	Flange	216-7844
3T-1898	Drum	219-9674	4N-7693	Crankshaft As	242-3439	5M-5073	Joint Gp - Univ	325-6113
3T-1899	Drum	219-9690 (Drum), 230-7114 (Steering Clutch Kit)	4N-7977	Shaft As - Balance	314-8709	5M-5822	Gear - Pump Drive	247-4120
3V-1133	Strip	226-0203	4N-7978	Shaft As - Balance	314-8710	5M-6120	Gear - Sun	213-8740
4F-1121	Bracket	299-1981	4N-8591	Coupling - Exhaust	325-6053	5M-6198	Shaft - Planet	297-7245
4F-1252	Pin	295-5704	4N-8814	Line As - Fuel Injector	247-3366	5M-6199	Shaft As - Planet	215-1694
4F-4974	Clamp	311-9373	4N-9180	Seal As - Pump	311-9455	5M-6208	Gear - Ring	247-4121
4H-4021	Plate As - Loading	229-8219	4N-9587	Shield - Heat	297-7260	5M-6210	Shaft - Planet	219-9683
4J-1612	Pin	308-9896	4P-0660	Muffler As	298-2787	5M-6211	Shaft - Planet	219-9684
4J-1614	Pin - Pivot	297-7214	4P-3546	Valve As - Relief	325-6236	5M-6636	Support - Frame	235-8007
4J-1616	Bracket	299-1982	4P-9381	Line As - Fuel Injector	279-4984	5M-6651	Hub - Gear	211-2135
4J-1999	Ballstud	314-8625	4P-9382	Line As - Fuel Injector	279-4985	5M-6670	Shaft - Sprocket	216-7847
4J-2414	Trunnion	296-1370	4P-9385	Line As - Fuel Injector	279-4986	5M-6690	Hub - Steering	215-1695
4J-2585	Pin	299-2034	4P-9386	Line As - Fuel Injector	279-4987	5M-7290	Cage - Bearing	216-7848
4J-2590	Bearing	299-1958	4S-5049	Guard As - Rh	226-0183	5M-7336	Retainer - Washer	325-6181
4J-2847	Trunnion As	297-7267	4S-5050	Guard As - Lh	226-0184	5M-7340	Cage - Bearing	325-6034
4J-3583	Screw - Adjusting	297-7242	4S-6256	Nut - Bearing Adjustable	235-8008	5M-7342	Flange - Shaft	215-1696
4J-3589	Cap - Ball Joint	297-7157	4S-8472	Hood As	296-1355	5M-7344	Gear - Bevel	213-8741
4J-3590	Bearing	297-7139	4S-8708	Housing - Clutch	216-3557	5M-7345	Gear - Bevel	214-0957
4J-3591	Bracket - Rh	299-1983	4S-8718	Cage - Carrier Bearing	217-7724	5M-7346	Gear - Bevel	214-0958
4J-6374	Bearing - Sleeve	295-6407	4S-9062	Cap - Final Drive Bearing	226-0204	5M-7348	Gear - Bevel	215-1699
4K-0255	Retainer As	226-6102	4T-6151	Trunnion	295-5671	5M-7349	Gear - Bevel	213-8742
4K-4780	Strip As - Wear	299-2063	4V-2744	Gear	224-1303	5M-7352	Gear - Bevel	217-7713
4K-5074	Pinion	215-1683	4V-3396	Hub - Gear	222-1763	5M-7353	Gear - Bevel	217-7714
4K-5086	Yoke	215-1684	4V-6156	Saddle As	299-2052	5M-7355	Gear - Reverse	216-3581
4K-5109	Gear - Reverse	219-9659				5M-7740	Gear - Bevel	213-8216
4M-0503	Gear As - Oil Pump	297-7184				5M-7841	Gear - Ring	214-0525
4N-2954	Sleeve - Camshaft	299-2059				5M-7864	Pump Gp - Scavenge	226-0169
4N-3281	Line As - Fuel Injector	247-3362				5M-7869	Gear - Ring	214-0530

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
5M-7875	Carrier - Front	213-4495
5M-7882	Joint Gp - Univ	297-7210
5M-7900	Bolt - Hex Head	311-9349
5M-7923	Shaft - Output	215-1697
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-0192	Pinion - Final Drive	215-1698
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5S-6531	Holder As - Cage	214-2078
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-8132	Pinion	226-6080
6J-0774	Trunnion	256-4844
6K-4617	Shaft - Sprocket	221-7951
6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236
6N-1036	Gear - Oil Pump	279-4991
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-3256	Mount As	314-8688
6N-8413	Housing - Pump	325-6110
6P-0169	Hub - Fly-wheel Clutch	297-7204
6W-0240	Bearing - Brace	297-7143
6Y-0710	Gear	226-6104
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192

Original Part Number	Part Name	Classic Part Number
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2513	Gear - Planet	215-1734
7G-5323	Pinion - Final Drive	231-8767
7G-6042	Cage As	216-7856
7G-8513	Guard As	361-1714
7G-8517	Guard As	361-1715
7H-2742	Nut	229-8220
7J-6461	Crown	325-6054
7J-9344	Bearing - Sleeve	360-2334
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7M-0457	Guard - Frame	226-0217
7M-0665	Bar As - Equalizer	231-3312
7M-0699	Cap - Brace Bearing	247-4123
7M-0859	Fork As - Shift	297-7172
7M-1776	Plate - Idler Guide	226-0222
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-2167	Ring - Governor Control	308-9919

Original Part Number	Part Name	Classic Part Number
7M-2531	Rod - Tie	297-7239
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5503	Gear - Camshaft Rr	233-2182
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-6677	Core As - Oil Cooler	299-1995
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7602	Pump Gp	226-0174
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-0205	Bearing - Brace	247-4127
7T-2036	Cap As - Filter	361-1721
7T-4562	Idler As.	175-8263

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7T-9931	Countershaft	215-1760	8M-8652	Shaft	297-7252	8P-6803	Shaft As	215-1842
7T-9963	Case As - Transfer Gear	219-9665	8M-8677	Carrier - Planet	213-4449	8P-7790	Valve Gp - Press	247-4437
7V-5249	Shaft - Steering	215-1761	8N-0002	Trunnion As	314-8728	8S-0248	Breather As	325-6033
7W-0450	Gear - Water Pump	279-4997	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8S-0493	Shaft As - Pump	325-6198
7W-0507	Gear - Oil Pump Drive	279-4998	8N-1187	Head Gp - Cylinder	242-3435	8S-0569	Gear - Transfer	213-8754
7W-0508	Gear - Fuel Pump Drive	296-1351	8N-1188	Head Gp - Cylinder	242-3436	8S-0573	Gear - Transfer	215-1844
7W-5687	Hub - Camshaft	314-8684	8N-1721	Rod As - Conn	269-5291	8S-3970	Chamber As	242-3438
8E-5993	Gear As - Idler	215-1903	8N-1984	Rod As - Conn	242-3441	9F-7101	Bushing - Collar	299-1988
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)	8N-2510	Shaft	325-6208	9G-8303	Collar - Idler End	226-0242
8H-2810	Case As - Filter	314-8512	8N-2641	Sleeve	325-6210	9H-2256	Pump Gp	311-9443
8H-7980	Piston	226-0249	8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)	9H-6980	Shaft - Pinion	226-6110
8H-9806	Gear - Shaft Drive	325-6091	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)	9H-7670	Piston	226-4961
8J-2652	Shaft	299-2054	8N-3251	Shaft As - Rocker Arm	314-8711	9J-2332	Bearing - Pivot	299-1969
8J-2653	Lever As	299-2015	8N-3311	Shaft As - Rocker Arm	325-6199	9J-8427	Bracket	299-1984
8J-2654	Lever As	299-2016	8N-3312	Shaft As - Rocker Arm	325-6200	9J-9147	Nut	299-2028
8K-9661	Gear - Bevel	213-8218	8N-3325	Arm Gp - Rocker	314-8623	9J-9598	Pin	296-1362
8M-0874	Plunger As - Valve	311-9439	8N-3327	Arm Gp - Rocker	314-8624	9K-0424	Shaft - Pinion	215-1874
8M-3224	Muffler	247-2676	8N-5929	Cover - Water Pump	296-1349	9K-6842	Cage As	216-7872
8M-6191	Sleeve - Bolt	226-0234	8N-6796	Head Gp - Cylinder	269-5290	9K-9271	Holder As - Cage	217-7730
8M-6676	Cylinder - Adjustable	226-4960	8N-7315	Tube As - Outlet	325-6232	9K-9273	Nut - Adjusting	226-7998
8M-7166	Housing - Screen	297-7192	8N-8225	Bearing - Main	314-8652	9M-0701	Piston - Steer	219-9692
8M-7207	Guard As - Rh	226-0236	8N-9733	Line As - Fuel Injector	319-8174	9M-0702	Pilot - Piston	229-8232
8M-7208	Guard As - Frame	226-0237	8P-0605	Gear - First Reduction	213-8453	9M-1500	Shaft - Planet	219-9685
8M-8619	Cage - Bearing	217-7725	8P-0606	Pinion - Sec Reduction	215-1783	9M-1502	Cage - Bearing	219-9686
8M-8623	Gear - Sun	213-8755	8P-1851	Hub As - Sprocket	224-1314	9M-1995	Gear - Sun	213-8756
8M-8628	Flange - Joint	217-9776	8P-5197	Bearing As	295-6413	9M-1996	Shaft - Planet	215-1875
8M-8642	Housing - Clutch	219-9669	8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)	9M-2013	Housing As	216-3585
8M-8644	Housing - Clutch	215-1782				9M-2028	Gear - Sun	214-0959
8M-8646	Plate As - Center	216-3583				9M-2038	Gear - Transfer Driven	215-1876
8M-8649	Piston - Clutch	217-9777				9M-2039	Gear - Transfer Driving	219-9672
8M-8650	Piston - Clutch	217-9778				9M-2045	Pinion - Bevel	215-1878
						9M-2049	Gear - Ring	214-0533
						9M-3025	Cover As	299-2001
						9M-4163	Valve - Exhaust	298-2773
						9M-4789	Shaft - Gov Control	297-7256
						9M-4955	Pump Gp - Fuel Transfer	242-3443

(Continued)

Sales Model D6C (Continued)

Original Part Number	Part Name	Classic Part Number
9M-5045	Guard As - Wear	213-9111
9M-8117	Shaft - Fly-wheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-9000	Shaft - Steering	217-7738
9P-9360	Gear - First Reduction	213-8454
9P-9361	Gear - Final Drive	223-4809

Original Part Number	Part Name	Classic Part Number
9P-9362	Pinion - Final Drive	215-1944
9P-9363	Pinion - Reduction	219-9677
9P-9575	Cage - Bevel Gr Bearing	216-7876
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-2356	Manifold - Exhaust	261-0905
9S-5265	Shaft As	215-1945
9S-6129	Pulley - Alternator Drive	264-5891
9S-6590	Pump Gp - Oil	226-0176
9S-8245	Strip - Track	226-0243
9S-8246	Strip - Track	226-0244
9S-8251	Guard As - Roller	226-0180

Original Part Number	Part Name	Classic Part Number
9S-8252	Guard As - Roller	226-0181
9S-8253	Guard As - Roller	226-0182
9S-8257	Guard As - Guiding	226-0238
9S-8258	Guard As - Guiding	226-0239
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-9385	Gear As - Oil Pump	297-7185
9T-4761	Head	325-6108
9W-0318	Spacer	325-6218
9W-0550	Shaft - Transmission Upper	226-6000
9W-0552	Shaft - Pinion	226-6001
9W-1677	Bearing	297-7145
9Y-2992	Bearing - Sleeve	325-6032

Sales Model D6D

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3249	Muffler As	247-2661
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
115-7550	Gasket - Plate	314-8667
117-1616	Segment Gp - Sprocket	260-5851 (sprocket group)
118-1617	Roller Gp - SF	188-5272
118-1618	Roller Gp - DF	188-5271
122-9405	Bracket As	325-6005
129-2339	Spider	308-9936
131-3815	Seal Gp - Basic	325-6193

Original Part Number	Part Name	Classic Part Number
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1H-8262	Shaft	226-8016

Original Part Number	Part Name	Classic Part Number
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0963	Guard As - Roller	226-0179
1P-1605	Gear - Forward	215-1663
1P-1608	Gear - Forward	302-2707
1P-1636	Lever As	226-8013
1P-1897	Gear - Final Drive	215-1670
1P-3759	Rod Gp - Recoil	302-2713
1P-6265	Gear - Bevel	221-9177
1P-6752	Pump Gp	226-0161
1P-7044	Cage	226-7975
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1P-9946	Shaft - Fan	325-6194	244-1090	Alarm - Back up	360-2345	2P-4370	Plate - Clutch	325-6166
1P-9952	Impeller - Pump	314-8685	2D-5658	Bearing - Ball	301-4628	2P-5680	Turbine - Converter	308-9942
1S-1859	Bolt - Track	188-5633	2D-9130	Washer - Thrust	308-9943	2P-5693	Housing - Rotating	308-9866
1S-1888	Bracket - Lamp	297-7147	2F-5721	Bearing - Ball	311-9354	2P-6128	Pulley	264-5872
1S-4701	Pulley - Alt	264-5866	2G-8872	Shaft - Bevel	275-5271	2P-6245	Shaft As - Pump	325-6197
1S-5331	Cylinder - Adjustable	226-0214	2H-4338	Plate - Pressure	226-8010	2P-7984	Yoke As - Idler	226-0220
1S-8734	Bracket - Roller	226-0212	2H-4450	Washer - Thrust	325-6237	2S-3188	Plate	299-2041
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014	2H-4482	Collar	229-8218	2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)
1T-0300	Converter As	235-1803 (Repair Kit)	2H-5046	Link - Flycam	299-2024	2S-3803	Gear	226-6106
1T-0421	Flange As - Output	295-5442	2J-5462	Trunnion	297-7264	2S-3804	Gear - Sliding	226-6107
1T-0436	Gear - Pump Drive	247-3367	2J-5596	Pin - Pivot	297-7211	2S-4365	Retainer As	216-3554
1T-0437	Housing - Rotating	295-5685	2J-8489	Bearing - Sleeve	295-5691	2S-6263	Guard Gp - Spring	226-0192
1T-0438	Retainer - Bearing	295-0410	2K-3592	Boss	314-8501	2S-6264	Guard Gp - Spring	226-0193
1T-0443	Carrier As - Guide	247-3368	2K-4507	Bearing - Sleeve	325-6021	2S-6265	Rod Gp - Recoil	226-0197
1T-0447	Carrier - Ring	295-0409	2M-2290	Bracket - Ring	299-1979	2S-6344	Gear - Final Drive	297-7173
1T-0930	Torque Converter	235-0913 (Repair Kit)	2M-4668	Retainer - Guard	297-4867	2S-6739	Pulley - Tightener	298-2794
1T-1993	Wheel - Turbine	235-0920	2P-1005	Bearing - Sleeve	296-1342	2S-7596	Retainer	215-1679
1T-2052	Stator As	295-5683	2P-1170	Shaft As - Gear	296-1367	2S-7603	Drum	213-6951
1V-8604	Gear - Ring	308-9853	2P-1438	Pipe - Exhaust Ext	325-6157	2V-7170	Yoke	308-9948
1W-1219	Trunnion As	314-8724	2P-1502	Gear - Shaft	214-0956	2V-7393	Retainer	308-9914
1W-1669	Piston	325-6158	2P-1503	Gear - First	213-8637	2W-1086	Cover As - Cylinder Head	325-6049
1W-1695	Pump Gp	279-4980	2P-1738	Plate As - Oil Pan	325-6164	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
1W-1698	Housing - Transfer Pump	296-1356	2P-1739	Tube As - Pump	325-6229	2W-6757	Trunnion As	295-5678
1W-1766	Muffler As	298-2783	2P-1757	Hub - Fan Pulley	296-1357	2W-7255	Shaft - Water Pump	325-6203
1W-4402	Gear - Camshaft	279-4981	2P-1781	Spacer - Oil Pump	325-6214	2W-7458	Crankshaft As	242-3439
1W-4405	Gear - Crankshaft	279-4982	2P-2406	Pulley	264-5870	2W-7678	Gear - Water Pump	325-6088
1W-5912	Tappet As - Guide	325-6223	2P-2519	Tube As - Inlet	325-6230	2W-9978	Core As - Oil Cooler	279-4983
1W-6541	Plunger As	325-6173	2P-2744	Muffler As	247-2664	2Y-4213	Pulley	314-8703
236-9861	Link As.	175-8555	2P-3422	Gear - First Reduction	213-8451	3F-4971	Pin	295-5693
236-9864	Link As.	188-5527	2P-3423	Pinion - Sec Reduction	216-3553	3F-6149	Pin	299-2033
236-9866	Link As.	188-5588	2P-3424	Gear - First Reduction	215-1675	3F-6185	Pin	295-5694
238-9951	Link As.	290-6589	2P-3425	Pinion - Sec Reduction	217-7697	3F-6612	Cap - Ball Joint	297-7155

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
3F-7445	Bearing - Sleeve	314-8508
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-5432	Pin - Pivot	297-7213
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-2685	Piston - Clutch	308-9908
3P-2768	Piston - Clutch	308-9909
3P-3059	Gear - Sun	308-9861
3P-3060	Gear - Sun	308-9862
3P-3096	Gear - Sun	308-9863
3P-3241	Plate - Pressure	325-6167
3P-3242	Shaft - Planet	308-9923
3P-3245	Shaft - Planet	308-9924
3P-3246	Shaft - Planet	308-9925
3P-3623	Lock - Adjustable Nut	226-7989
3P-3935	Shaft	299-2053
3P-6318	Flange - Drum	213-8165
3P-6814	Pump Gp	226-0163
3P-6816	Pump Gp	226-0164
3P-7640	Gear - Ctrshft	325-6093
3P-7641	Gear - Ctrshft	325-6094
3P-7642	Gear - Ctrshft	302-2668
3P-7643	Gear - Pinion Shft	302-2669
3P-7644	Gear - Pinion Shft	302-2706
3S-1691	Disc - Steering	302-2705
3S-8800	Gear - Driven	325-6090
3T-1898	Drum	219-9674

Original Part Number	Part Name	Classic Part Number
3T-1899	Drum	219-9690 (Drum), 230-7114 (Steering Clutch Kit)
3T-3206	Roller Gp - Carrier	188-5590
3V-1133	Strip	226-0203
4E-5882	Shaft - Axle	308-9921
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2590	Bearing	299-1958
4J-2847	Trunnion As	297-7267
4J-3583	Screw - Adjusting	297-7242
4J-3589	Cap - Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-3591	Bracket - Rh	299-1983
4J-6374	Bearing - Sleeve	295-6407
4M-0503	Gear As - Oil Pump	297-7184
4M-8845	Shaft - Planet	215-1685
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787

Original Part Number	Part Name	Classic Part Number
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-5049	Guard As - Rh	226-0183
4S-5050	Guard As - Lh	226-0184
4S-6256	Nut - Bearing Adjustable	235-8008
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4S-8718	Cage - Carrier Bearing	217-7724
4S-9062	Cap - Final Drive Bearing	226-0204
4T-6151	Trunnion	295-5671
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
4W-9771	Gear - Crankshaft	302-2674
4W-9989	Gear As - Idler	302-2677
5A-7840	Shaft - Track Sprocket	215-1687
5A-7841	Hub - Gear	219-2966
5H-5500	Collar - Flywheel	302-2704
5M-5073	Joint Gp - Univ	325-6113
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-6636	Support - Frame	235-8007
5M-6651	Hub - Gear	211-2135
5M-6670	Shaft - Sprocket	216-7847
5M-6690	Hub - Steering	215-1695

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5M-7290	Cage - Bearing	216-7848	6N-1966	Line As - Fuel Injector	250-7536	7G-2474	Gear - Planet	300-2577
5M-7336	Retainer - Washer	325-6181	6N-2789	Pulley	264-5886	7G-2475	Gear - Planet	223-4815
5M-7340	Cage - Bearing	325-6034	6N-3256	Mount As	314-8688	7G-2476	Gear - Planet	223-4816
5M-7342	Flange - Shaft	215-1696	6N-8413	Housing - Pump	325-6110	7G-2513	Gear - Planet	215-1734
5M-7344	Gear - Bevel	213-8741	6P-0169	Hub - Fly-wheel Clutch	297-7204	7G-2516	Gear - Planet	283-5203
5M-7345	Gear - Bevel	214-0957	6P-6556	Carrier As	308-9836	7G-2830	Ring - Seal	295-6441
5M-7346	Gear - Bevel	214-0958	6P-6739	Shaft - Planet	308-9929	7G-3457	Gear - Planet	308-9857
5M-7348	Gear - Bevel	215-1699	6P-7704	Carrier - Ring	314-8658	7G-5323	Pinion - Final Drive	231-8767
5M-7349	Gear - Bevel	213-8742	6S-3457	Pin	325-6147	7G-6042	Cage As	216-7856
5M-7352	Gear - Bevel	217-7713	6S-3759	Pin As	241-2543	7G-7218	Carrier - Planet	283-5205
5M-7353	Gear - Bevel	217-7714	6T-1702	Support As	299-2065	7G-7724	Piston - Clutch	283-5206
5M-7355	Gear - Reverse	216-3581	6T-1724	Bar As - Equalizer	283-5223	7G-8389	Guard	226-0202
5M-7740	Gear - Bevel	213-8216	6W-7290	Shaft - Planet	308-9930	7G-8513	Guard As	361-1714
5M-7841	Gear - Ring	214-0525	6W-7331	Cover As	308-9845	7G-8517	Guard As	361-1715
5M-7864	Pump Gp - Scavenge	226-0169	6Y-2054	Plate As	302-2695	7H-0602	Dog - Clutch	314-8515
5M-7869	Gear - Ring	214-0530	6Y-6289	Shoe -Track	188-5270	7J-6461	Crown	325-6054
5M-7875	Carrier - Front	213-4495	6Y-6290	Shoe -Track Master	175-8728	7J-9344	Bearing - Sleeve	360-2334
5M-7882	Joint Gp - Univ	297-7210	6Y-6291	Shoe -Track	175-8031	7J-9842	Bearing - Sleeve	299-1968
5M-7900	Bolt - Hex Head	311-9349	6Y-6292	Shoe -Track Master	175-8032	7J-9884	Bearing - Sleeve	325-6016
5M-7923	Shaft - Output	215-1697	6Y-6293	Shoe -Track	175-8369	7K-9360	Pin	319-3461
5P-7807	Bearing - Ball	314-8502	6Y-6294	Shoe -Track Master	175-8370	7M-0457	Guard - Frame	226-0217
5P-8194	Ring - Retaining	308-9920	6Y-6295	Shoe -Track	175-8371	7M-0665	Bar As - Equalizer	231-3312
5S-0073	Plate - Steering	302-2692	6Y-6296	Shoe -Track Master	175-8372	7M-0699	Cap - Brace Bearing	247-4123
5S-0192	Pinion - Final Drive	215-1698	6Y-6394	Shoe -Track Master	188-5591	7M-0859	Fork As - Shift	297-7172
5S-1211	Cover - Valve	314-8665	6Y-6395	Shoe -Track	188-5396	7M-1249	Piston - Clutch	215-1748
5S-4557	Bearing	311-9360	6Y-6397	Shoe -Track Master	188-5594	7M-1776	Plate - Idler Guide	226-0222
5S-6531	Holder As - Cage	214-2078	6Y-6398	Shoe -Track	188-5593	7M-1851	Bolt - Spring	226-0223
5S-6795	Chamber As	242-3437	6Y-6411	Shoe -Track	188-5397	7M-1856	Pilot - Recoil Spring	226-0225
5S-9080	Pulley - Alt Drive	264-5883	6Y-6412	Shoe -Track Master	188-5592	7M-1859	Pilot As - Spring	226-0207
6F-2904	Bearing	295-5673	7C-3567	Mount As	314-8689	7M-1861	Stop - Spring Rh	226-0228
6H-3957	Bearing - Ball	311-9358	7C-4297	Seal As - Camshaft	325-6192	7M-1862	Stop - Spring Lh	226-0229
6I-1346	Pump Gp - Oil	295-5674	7F-9541	Pin As - Drawbar	296-1361	7M-2167	Ring - Governor Control	308-9919
6J-0774	Trunnion	256-4844	7F-9547	Pin As - Drawbar	295-0414	7M-2531	Rod - Tie	297-7239
6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236	7G-1013	Pump Gp	226-0170	7M-4603	Body - Fuel Valve	311-9348
6N-1036	Gear - Oil Pump	279-4991	7G-2037	Joint Gp - Univ	226-8017	7M-4926	Retainer - Pin	314-8538
6N-1965	Line As - Fuel Injector	250-7535	7G-2038	Tube - Univ Joint	297-7268			

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5503	Gear - Camshaft Rr	233-2182
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9146	Gear - Flywheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7T-0205	Bearing - Brace	247-4127
7T-2036	Cap As - Filter	361-1721
7T-4562	Idler As.	175-8263
7T-9370	Gear - Sun	283-5207
7T-9931	Countershaft	215-1760
7T-9963	Case As - Transfer Gear	219-9665
7W-0450	Gear - Water Pump	279-4997

Original Part Number	Part Name	Classic Part Number
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
8B-5972	Bearing - Ball	314-8503
8E-4365	Segment Gp - Sprocket	188-5635 (sprocket group), 188-5589 (segment)
8E-4499	Shoe -Track	188-5383
8E-4500	Shoe -Track Master	188-5387
8E-4501	Shoe -Track	188-5381
8E-4502	Shoe -Track Master	188-5385
8E-5993	Gear As - Idler	215-1903
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8M-0874	Plunger As - Valve	311-9439
8M-6191	Sleeve - Bolt	226-0234
8M-7166	Housing - Screen	297-7192
8M-7207	Guard As - Rh	226-0236
8M-7208	Guard As - Frame	226-0237
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777

Original Part Number	Part Name	Classic Part Number
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0514	Yoke As	308-9947
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-0769	Hub - Turbine	308-9870
8P-1851	Hub As - Sprocket	224-1314
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-1918	Gear - Planet	283-5210
8P-1919	Gear - Planet	300-2579
8P-2042	Shaft - Planet	283-5211
8P-2430	Shaft As	297-7258

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
8P-5197	Bearing As	295-6413	9J-8427	Bracket	299-1984	9P-9361	Gear - Final Drive	223-4809
8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)	9J-9147	Nut	299-2028	9P-9362	Pinion - Final Drive	215-1944
8P-6803	Shaft As	215-1842	9J-9598	Pin	296-1362	9P-9363	Pinion - Reduction	219-9677
8P-7790	Valve Gp - Press	247-4437	9K-8757	Rod End - Bearing	311-9361	9P-9575	Cage - Bevel Gr Bearing	216-7876
8P-9507	Piston - Clutch	283-5212	9M-0701	Piston - Steer	219-9692	9S-1838	Bolt Master	188-5634
8R-4821	Carrier - Planet	308-9837	9M-0702	Pilot - Piston	229-8232	9S-2354	Manifold - Exhaust	261-0888
8R-7425	Retainer	308-9917	9M-1328	Bearing - Aligning	325-6018	9S-2355	Manifold - Exhaust	261-0891
8S-0248	Breather As	325-6033	9M-1500	Shaft - Planet	219-9685	9S-5265	Shaft As	215-1945
8S-0493	Shaft As - Pump	325-6198	9M-1502	Cage - Bearing	219-9686	9S-6129	Pulley - Alternator Drive	264-5891
8S-0569	Gear - Transfer	213-8754	9M-1995	Gear - Sun	213-8756	9S-6590	Pump Gp - Oil	226-0176
8S-0573	Gear - Transfer	215-1844	9M-1996	Shaft - Planet	215-1875	9S-6875	Pinion - Final Drive	217-7705
8S-2809	Muffler	247-2677	9M-2013	Housing As	216-3585	9S-7079	Muffler As	247-2669
8S-3970	Chamber As	242-3438	9M-2028	Gear - Sun	214-0959	9S-8245	Strip - Track	226-0243
8S-7716	Manifold - Exhaust	295-0415	9M-2038	Gear - Transfer Driven	215-1876	9S-8246	Strip - Track	226-0244
8S-7717	Manifold - Exhaust	261-0894	9M-2039	Gear - Transfer Driving	219-9672	9S-8251	Guard As - Roller	226-0180
8S-7718	Manifold - Exhaust	295-0416	9M-2045	Pinion - Bevel	215-1878	9S-8252	Guard As - Roller	226-0181
8V-6382	Hub As	308-9868	9M-2049	Gear - Ring	214-0533	9S-8253	Guard As - Roller	226-0182
8V-6384	Spacer As	308-9935	9M-4789	Shaft - Gov Control	297-7256	9S-8257	Guard As - Guiding	226-0238
9C-8074	Gear - Planet	308-9858	9M-5045	Guard As - Wear	213-9111	9S-8258	Guard As - Guiding	226-0239
9C-8075	Gear - Sun	308-9864	9M-8117	Shaft - Fly-wheel Clutch	226-6073	9S-8493	Bolt - Connecting Rod	311-9351
9C-8277	Gear - Bevel	308-9851	9M-8119	Retainer - Inlet	226-8022	9S-8679	Chamber As	325-6042
9F-7101	Bushing - Collar	299-1988	9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)	9S-8789	Plate - Clutch	302-2712
9G-0280	Piston - Clutch	283-5213	9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)	9S-9385	Gear As - Oil Pump	297-7185
9G-0284	Housing - Clutch	283-5214	9N-5769	Cover - Housing	325-6050	9T-4761	Head	325-6108
9G-0285	Piston - Clutch	283-5215	9P-0418	Cage	223-6311	9W-0318	Spacer	325-6218
9G-0289	Shaft - Planet	283-5216	9P-0620	Cage - Pinion Bearing	221-1052	9W-0550	Shaft - Transmission Upper	226-6000
9G-0290	Hub - Clutch	283-5217	9P-5363	Piston - Clutch	219-9687	9W-0552	Shaft - Pinion	226-6001
9G-6476	Rod Gp - Idler Recoil	226-0198	9P-5379	Housing - Clutch	215-1904	9W-4702	Stator - Converter	308-9939
9G-7412	Gear As - Oil Pump	297-7183	9P-7757	Gear - Sun	283-5218	9W-6433	Impeller - Converter	308-9871
9G-8303	Collar - Idler End	226-0242	9P-8623	Shaft - Planet	314-8719	9W-6435	Flange - Drive	308-9846
9H-2256	Pump Gp	311-9443	9P-8624	Shaft - Planet	295-5446	9W-8270	Gear - Ring	308-9859
9J-2332	Bearing - Pivot	299-1969	9P-8626	Gear - Sun	283-5219	9W-8433	Shaft As - Output	302-4249
			9P-9000	Shaft - Steering	217-7738			
			9P-9031	Gear - Sun	283-5220			
			9P-9360	Gear - First Reduction	213-8454			

(Continued)

Sales Model D6D (Continued)

Original Part Number	Part Name	Classic Part Number
9W-8437	Gear - Sun	283-5222

Sales Model D6H

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
128-0307	Plate	325-6165
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686
160-6308	Cap - Bearing	325-6036
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
179-6152	Bearing	361-1704
190-8609	Valve - Fill	360-2288
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

Original Part Number	Part Name	Classic Part Number
1S-4701	Pulley - Alt	264-5866
1T-0421	Flange As - Output	295-5442
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0447	Carrier - Ring	295-0409
1T-0521	Retainer - Bearing	325-6180
1T-0699	Impeller - Converter	235-1808
1T-1790	Carrier As	296-1347
1T-1880	Carrier - Ring	295-0408
1T-1993	Wheel - Turbine	235-0920
1T-2052	Stator As	295-5683
1U-0105	Brace As	295-5684
1U-0159	Pin	325-6134
1U-0612	Pin	325-6135
1U-0725	Retainer	314-8707
1U-0899	Pin	296-1363
1U-0928	Screw - Adjusting	325-6187
1U-1267	Brace As	296-1343
1U-4103	Trunnion	295-5680
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690

Original Part Number	Part Name	Classic Part Number
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-7940	Spider As - Fan	295-5443
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2J-8489	Bearing - Sleeve	295-5691
2K-4507	Bearing - Sleeve	325-6021
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4370	Plate - Clutch	325-6166
2P-6245	Shaft As - Pump	325-6197
2R-0179	Pin As	325-6127
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692

(Continued)

Sales Model D6H (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2W-9978	Core As - Oil Cooler	279-4983	4F-1252	Pin	295-5704	6F-3183	Cap - Bearing	325-6038
3F-4971	Pin	295-5693	4F-4974	Clamp	311-9373	6H-3957	Bearing - Ball	311-9358
3F-6185	Pin	295-5694	4J-0121	Cap - Bearing	360-2344	6I-0341	Line As - Fuel Injector	325-6117
3G-8917	Pin	325-6141	4J-1616	Bracket	299-1982	6I-0342	Line As - Fuel Injector	325-6118
3J-2452	Cap - Ball Joint	297-7156	4J-1641	Trunnion	314-8725	6I-0343	Line As - Fuel Injector	325-6119
3J-2682	Bracket	296-1345	4J-1999	Ballstud	314-8625	6I-0344	Line As - Fuel Injector	325-6120
3J-4284	Cap - Bearing	314-8656	4J-2414	Trunnion	296-1370	6I-0345	Line As - Fuel Injector	325-6121
3J-6559	Cap - Bearing	296-1346	4J-3583	Screw - Adjusting	297-7242	6I-0346	Line As - Fuel Injector	325-6122
3J-6560	Screw - Adjustable	297-7240	4J-6374	Bearing - Sleeve	295-6407	6I-1346	Pump Gp - Oil	295-5674
3J-6561	Screw - Adjustable	297-7241	4K-1102	Bearing - Sleeve	325-6010	6I-8736	Guard As	295-6434
3J-6573	Screw - Adjusting	302-2714	4K-3004	Bearing - Trunnion Support	314-8632	6I-9034	Guard As	295-6435
3L-1425	Bearing - Ball	311-9356	4K-3128	Bearing - Sleeve	314-8633	6N-1036	Gear - Oil Pump	279-4991
3T-0996	Bearing - Sleeve	295-5695	4N-7693	Crankshaft As	242-3439	6N-1553	Coupling - Exhaust	295-6422
3T-0997	Bearing - Sleeve	307-1524	4P-3546	Valve As - Relief	325-6236	6N-2789	Pulley	264-5886
3T-1162	Sleeve - Wear	325-6209	4P-9381	Line As - Fuel Injector	279-4984	6N-8413	Housing - Pump	325-6110
3T-1446	Pump Gp	325-6178	4P-9382	Line As - Fuel Injector	279-4985	6P-5404	Plate & Brake	325-6168
3T-1554	Guard As	295-5696	4P-9385	Line As - Fuel Injector	279-4986	6P-7704	Carrier - Ring	314-8658
3T-2481	Strip	295-5448	4P-9386	Line As - Fuel Injector	279-4987	6T-0064	Shaft - Planet	295-6442
3T-2849	Strip	295-5697	4S-8472	Hood As	296-1355	6T-0234	Retainer	325-6183
3T-4008	Gear - Planet	295-5444	4T-0732	Bracket	314-8627	6T-0240	Retainer	325-6184
3T-4011	Shaft As - Planet	295-5698	4T-0998	Lever	314-8687	6T-0241	Piston	325-6161
3T-4308	Bearing - Sleeve	296-1341	4T-1504	Trunnion	314-8727	6T-0243	Plate - Thrust	325-6169
3T-4568	Shaft - Planet	314-8712	4T-5495	Ballstud	314-8626	6T-0248	Ring - Seal	295-6440
3T-4824	Gear - Planet	295-5699	4T-6151	Trunnion	295-5671	6T-3080	Plate & Brake	325-6170
3T-5021	Carrier - Planet	295-5700	4W-0452	Seal As - Camshaft	325-6191	6T-7882	Gear - Planet	296-1352
3T-5200	Carrier - Planet	295-5701	4W-2042	Spacer	325-6217	6Y-0926	Gear - Planet	295-6427
3T-5672	Gear As - Oil Pump	295-5447	4W-2446	Damper As	279-4990	6Y-0984	Gear - Ring	295-6428
3T-5674	Gear As - Oil Pump	295-5449	4Y-2817	Ejector As	295-6423	6Y-3896	Pin As	325-6132
3T-6247	Shaft	314-8713	5G-3612	Cap Gp	295-6419	6Y-4819	Carrier - Planet	296-1348
3W-0630	Pin	307-1525	5G-9075	Strip	295-0412	6Y-6751	Pin	325-6149
3W-0640	Piston	325-6160	5G-9076	Strip	295-0413	6Y-7471	Pin - Pivot	325-6152
3W-0643	Cylinder	325-6061	5P-7807	Bearing - Ball	314-8502	6Y-9468	Retainer As	325-6185
3W-3284	Strip	296-1368	5P-8194	Ring - Retaining	308-9920	7C-3567	Mount As	314-8689
3W-3285	Strip	296-1369	5S-1211	Cover - Valve	314-8665	7C-4297	Seal As - Camshaft	325-6192
3W-3628	Guard As	295-5677	5S-6795	Chamber As	242-3437	7F-9541	Pin As - Drawbar	296-1361
3W-6551	Shaft	295-5702	5S-9080	Pulley - Alt Drive	264-5883	7F-9547	Pin As - Drawbar	295-0414
3W-6555	Shaft	295-5703	6F-2904	Bearing	295-5673	7G-2500	Gear - Planet	296-1350
						7G-2516	Gear - Planet	283-5203

(Continued)

Sales Model D6H (Continued)

Original Part Number	Part Name	Classic Part Number
7G-2824	Piston	295-6439
7G-2828	Plate - Clutch	325-6171
7G-2830	Ring - Seal	295-6441
7G-6489	Spring - Recoil	314-8722
7G-7013	Coupling - Pump Drive	295-5450
7G-7218	Carrier - Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston - Clutch	283-5206
7G-9555	Bearing - Spider	314-8721
7J-1333	Bearing - Sleeve	295-6408
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-7195	Bearing - Sleeve	325-6025
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-3486	Manifold - Exhaust	261-0899
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9805	Pin - Piston	295-6438
7P-6596	Bearing - Sleeve	295-6409
7P-8370	Bearing	295-6410
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
7T-3952	Gear - Transfer	295-6429
7T-8136	Shaft - Planet	314-8714
7T-9272	Gear - Sun	296-1354
7T-9370	Gear - Sun	283-5207
7T-9586	Bearing	314-8645
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351

Original Part Number	Part Name	Classic Part Number
7W-5684	Pulley - Cam-shaft	298-2771
7W-5698	Pulley - Cam-shaft	295-5679
8G-4187	Pin As	295-5676
8G-4189	Bearing - Aligning	295-6411
8G-4190	Seal - Ebar	296-1366
8G-8311	Bearing - Sleeve	295-6412
8H-2810	Case As - Filter	314-8512
8J-2880	Cap - Bearing	295-6420
8M-8628	Flange - Joint	217-9776
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-5197	Bearing As	295-6413
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7718	Manifold - Exhaust	295-0416
8S-7818	Bracket	226-0211

Original Part Number	Part Name	Classic Part Number
8Y-1624	Guard As	295-6432
8Y-1625	Guard As	295-6433
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-1499	Gear - Oil Pump	295-6424
9G-8638	Gear - Planet	295-6425
9G-9174	Gear - Sun	295-6430
9G-9178	Spindle	295-6443
9G-9180	Hub - Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9349	Retainer	295-0411
9G-9543	Gear - Oil Pump	295-6426
9J-7964	Bearing - Spherical	325-6017
9J-9147	Nut	299-2028
9J-9598	Pin	296-1362
9M-8281	Gear As - Oil Pump	325-6089
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042
9T-0066	Trunnion	325-6228
9T-4762	Head	325-6109
9U-8481	Pin As	295-5675
9W-0099	Bearing - Sleeve	314-8639
9W-0876	Bearing - Sleeve	325-6031
9W-2344	Coupling - Pump Drive	314-8666
9W-2579	Plate	314-8701
9W-3605	Carrier - Ring	314-8662
9W-4897	Bracket As	295-6414

(Continued)

Sales Model D6H (Continued)

Original Part Number	Part Name	Classic Part Number
9W-7481	Gear - Planet	295-6431
9W-7839	Carrier - Planet	295-6421
9W-8270	Gear - Ring	308-9859

Original Part Number	Part Name	Classic Part Number
9W-9930	Mount As	295-6437

Sales Model D7

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
121-7746	Precleaner As	360-2311
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Pre-cleaner	360-2296
1P-1931	Shaft - Steer	227-4772
1S-1888	Bracket - Lamp	297-7147
1S-5331	Cylinder - Adjustable	226-0214
2B-3708	Chamber As	247-3293
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3B-6218	Muffler As	247-2672
3F-4971	Pin	295-5693
3F-7445	Bearing - Sleeve	314-8508

Original Part Number	Part Name	Classic Part Number
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
3P-3623	Lock - Adjustable Nut	226-7989
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5F-2256	Cage - Bearing	226-7973
5F-7993	Pin	319-3454
5L-9371	Connector - Inlet	311-9375
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6F-2904	Bearing	295-5673
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
7B-5088	Drum - Steering	223-4813

Original Part Number	Part Name	Classic Part Number
7D-6841	Joint As - Univ	228-9566
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8B-5972	Bearing - Ball	314-8503
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862
8H-7980	Piston	226-0249
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-0493	Cage - Outer Bearing	216-7866
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D7C, D7D

Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl - Pre-cleaner	360-2296
121-7746	Precleaner As	360-2311
4B-1455	Cap As - Filter	361-1719
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1P-0005	Pump Gp - Fuel Transfer	256-4756

Original Part Number	Part Name	Classic Part Number
1S-1888	Bracket - Lamp	297-7147
1S-5331	Cylinder - Adjustable	226-0214
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3F-6149	Pin	299-2033

Original Part Number	Part Name	Classic Part Number
3F-6185	Pin	295-5694
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3P-3623	Lock - Adjustable Nut	226-7989
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4M-9215	Gear - Pump Idler	311-9391

(Continued)

Sales Model D7C, D7D (Continued)

Original Part Number	Part Name	Classic Part Number
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-2256	Cage - Bearing	226-7973
5S-1211	Cover - Valve	314-8665
6B-7178	Fork - Band Adjustable	299-2009
6F-2904	Bearing	295-5673
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6T-1980	Collar - Idler End	226-0210

Original Part Number	Part Name	Classic Part Number
7B-2420	Ferrule - Director	314-8517
7B-5088	Drum - Steering	223-4813
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417

Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2810	Case As - Filter	314-8512
8H-7980	Piston	226-0249
8H-9379	Nut - Brake Band Adjustable	299-2029
8M-0493	Cage - Outer Bearing	216-7866
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D7E

Original Part Number	Part Name	Classic Part Number
112-3249	Muffler As	247-2661
160-6305	Cap - Bearing	295-5686
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1P-0965	Gear - Bevel	213-8215
1P-4145	Valve Gp - Press	247-4436
1P-7590	Support As	213-4400
1S-0876	Bolt - Spring	226-0224
1S-1532	Flange - Shaft	215-1673

Original Part Number	Part Name	Classic Part Number
1S-1801	Shaft As - Transmission	215-1674
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0256	Gear - Pump Drive	239-7930
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2J-3271	Pin	319-3452
2J-5462	Trunnion	297-7264
2J-5596	Pin - Pivot	297-7211
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2M-4668	Retainer - Guard	297-4867
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3992	Gear - Bevel	219-9666

Original Part Number	Part Name	Classic Part Number
2S-3946	Gear - Final Drive	215-1678
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
2S-7062	Shaft - Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8356	Rod Gp - Track Adjustable	226-0199
3B-1464	Cap - Bearing	226-0206
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345

(Continued)

Sales Model D7E (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
3J-6167	Bearing - Sleeve	299-1960	4N-7000	Head As - Cylinder	325-6105	5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
3J-6173	Pin	325-6144	4N-7526	Seal As - Pump	311-9454	5S-9080	Pulley - Alt Drive	264-5883
3J-6182	Pin As	325-6128	4N-9180	Seal As - Pump	311-9455	6F-2904	Bearing	295-5673
3J-6204	Pin As	325-6129	5F-7993	Pin	319-3454	6F-7523	Cap - Bearing	325-6039
3J-6442	Bearing - Sleeve	299-1961	5J-2602	Plate As - Trunnion	256-4838	6H-3957	Bearing - Ball	311-9358
3J-6502	Pin	319-3453	5J-4321	Trunnion	302-2700	6J-5342	Retainer	325-6182
3J-6559	Cap - Bearing	296-1346	5J-5643	Connector	325-6043	6J-5354	Bearing	297-7142
3J-6560	Screw - Adjustable	297-7240	5M-1127	Countershaft	216-3558	6J-6229	Pin	299-2030
3J-6561	Screw - Adjustable	297-7241	5M-1133	Gear - Idler	214-0524	6J-9258	Trunnion As	256-4846
3J-6570	Support - Bearing	299-2069	5M-1137	Gear As - Ctrshft	214-0960	6L-7816	Seal - o-Ring	314-8542
3J-6573	Screw - Adjusting	302-2714	5M-1139	Gear As - Ctrshft	214-0961	6P-4948	Cap - Final Drive Bearing	226-0205
3J-6575	Trunnion	297-7265	5M-1141	Gear As - Ctrshft	214-0962	6P-6653	Plate - Guide	226-0208
3J-6576	Bearing	256-4833	5M-1143	Gear As	214-0963	6T-1980	Collar - Idler End	226-0210
3K-2230	Gear - Planet	219-9658	5M-1145	Gear As - Forward	214-0964	7B-2420	Ferrule - Director	314-8517
3P-3623	Lock - Adjustable Nut	226-7989	5M-1147	Gear As - Reverse	214-0965	7F-9541	Pin As - Drawbar	296-1361
3P-6293	Pump Gp	217-2597	5M-1988	Piston - Steer	219-9691	7G-2517	Gear - Planet	213-8747
3P-6560	Stop - Recoil Spring	226-0232	5M-1990	Pilot - Piston	229-8233	7G-2521	Gear - Planet	213-8749
3P-6561	Stop - Recoil Spring	226-0233	5M-1998	Drum Steering	213-6952	7G-6576	Cage As	216-7859
3S-3917	Guard As - Sprocket	226-0188	5M-2026	Hubdriving	216-4471	7H-0602	Dog - Clutch	314-8515
3S-3918	Guard As - Sprocket	226-4950	5M-2971	Guard As - Front Idler	226-0190	7J-1185	Bearing As	297-7146
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)	5M-3470	Gear - Transmission	224-1305	7J-1333	Bearing - Sleeve	295-6408
3T-4482	Guide - Front Idler	226-0248	5M-3474	Shaft - Output	215-1690	7J-1334	Bearing - Sleeve	325-6015
4F-1121	Bracket	299-1981	5M-3499	Shaft - Planet	319-3475	7J-5131	Trunnion	296-1371
4F-1252	Pin	295-5704	5M-3906	Gear - Ring	214-0526	7J-7488	Bearing	256-4836
4F-4974	Clamp	311-9373	5M-3907	Carrier - Planet	210-8475	7M-1840	Gear As - Ctrshft	214-0966
4J-1612	Pin	308-9896	5M-3941	Shaft - Planet	215-1691	7M-1842	Gear As-ctr - Shft	214-0967
4J-1614	Pin - Pivot	297-7214	5M-3942	Shaft - Planet	215-1692	7M-1889	Guard As	213-9108
4J-1616	Bracket	299-1982	5M-5037	Hub - Gear	219-2980	7M-1890	Guard As - Final Drive Wear	213-9109
4J-1641	Trunnion	314-8725	5M-7900	Bolt - Hex Head	311-9349	7M-4603	Body - Fuel Valve	311-9348
4J-1999	Ballstud	314-8625	5P-7807	Bearing - Ball	314-8502	7M-4926	Retainer - Pin	314-8538
4J-6167	Bearing - Sleeve	325-6009	5S-0073	Plate - Steering	302-2692	7M-8453	Piston - Clutch	215-1755
4M-7099	Gear - Ring	214-0521	5S-1211	Cover - Valve	314-8665	7N-0128	Core As - Oil Cooler	299-1994
4M-7100	Gear - Ring	214-0522	5S-4863	Holder As - Cage	215-1732	7S-7809	Cap As - Radiator	295-6417
4M-7102	Gear - Ring	214-0523						
4M-9215	Gear - Pump Idler	311-9391						

(Continued)

Sales Model D7E (Continued)

Original Part Number	Part Name	Classic Part Number
7S-7973	Guard - Final Drive Wear	213-9110
7S-9749	Pulley - Gen Drive	264-5888
7T-0119	Support As	299-2066
7T-0204	Bearing - Brace	247-4126
7T-2036	Cap As - Filter	361-1721
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8F-5104	Screen As - Oil Pan	314-8539
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765

Original Part Number	Part Name	Classic Part Number
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8J-2880	Cap - Bearing	295-6420
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8P-0187	Nut - Adjusting	219-9676
8P-1865	Bar As - Equalizer	231-3313
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8S-0905	Muffler As	302-2690
8S-1061	Pilot As - Spring	226-0227
8S-7818	Bracket	226-0211

Original Part Number	Part Name	Classic Part Number
8S-9071	Cage - Bearing	216-7869
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-3955	Cage - Gear Bearing	216-7874
9S-4732	Guard Gp - Spring	226-0195
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8493	Bolt - Connecting Rod	311-9351
9Y-2988	Breather As	361-1716

Sales Model D7F

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-0637	Pump Gp	226-0160
115-7550	Gasket - Plate	314-8667
117-1024	Link As.	188-5595
118-1619	Roller Gp - Track	188-5257
118-1620	Roller Gp - DF	188-5258
118-1623	Roller Gp - Track	188-5596
118-1625	Roller Gp - Track	188-5597
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-6305	Cap - Bearing	295-5686

Original Part Number	Part Name	Classic Part Number
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
1H-8382	Gear - Oil Pump Drive	226-6103
1M-0598	Gear - Transmission	213-8636
1M-2607	Cage - Bearing	239-7970
1M-2626	Cage - Carrier Bearing	216-7458
1M-2635	Housing - Clutch	216-3549
1M-2637	Housing - Clutch	216-3550

Original Part Number	Part Name	Classic Part Number
1M-4486	Piston - Clutch	215-1660
1M-5151	Pinion - Bevel	215-1661
1M-8647	Housing As	215-1662
1M-9029	Guard	226-0219
1M-9177	Flywheel	226-6112
1M-9444	Retainer - Spring	299-2046
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-0579	Housing As	219-9678
1P-0965	Gear - Bevel	213-8215
1P-1006	Strip - Guard	226-0245
1P-1636	Lever As	226-8013
1P-2187	Pump Gp	299-2044
1P-4303	Head As - Cylinder	242-3434
1P-7044	Cage	226-7975
1P-7590	Support As	213-4400
1P-8554	Coupling - Exhaust	325-6052
1P-8717	Roller Gp - Carrier	188-5600
1P-8835	Shaft As	215-1672
1P-9807	Shoe - Track	188-5333

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1P-9808	Shoe -Track	175-8802	2H-4450	Washer - Thrust	325-6237	2S-3946	Gear - Final Drive	215-1678
1P-9809	Shoe -Track	175-8882	2H-4482	Collar	229-8218	2S-4015	Plunger As - Valve	311-9438
1P-9810	Shoe -Track	188-5334	2H-5046	Link - Flycam	299-2024	2S-6739	Pulley - Tightener	298-2794
1P-9945	Bracket As - Fan	296-1344	2J-3271	Pin	319-3452	2S-7062	Shaft - Sprocket	219-9673
1P-9946	Shaft - Fan	325-6194	2J-5462	Trunnion	297-7264	2S-7063	Nut	300-2584
1P-9952	Impeller - Pump	314-8685	2J-5596	Pin - Pivot	297-7211	2S-7064	Cap - Shaft Bearing	299-1991
1S-0876	Bolt - Spring	226-0224	2M-0125	Cylinder - Adjustable	226-0215	2S-7099	Hub - Gear	219-2962
1S-1532	Flange - Shaft	215-1673	2M-0365	Stop - Spring Rh	226-0230	2S-7527	Flange - Drum	213-8163
1S-1801	Shaft As - Transmission	215-1674	2M-0366	Stop - Spring Lh	226-0231	2S-7596	Retainer	215-1679
1S-1860	Nut (3/4-16)	188-5856	2M-0369	Pilot - Spring Recoil	226-0226	2S-8356	Rod Gp - Track Adjustable	226-0199
1S-1888	Bracket - Lamp	297-7147	2M-0398	Sleeve - Bolt	226-0235	2W-1086	Cover As - Cylinder Head	325-6049
1S-4701	Pulley - Alt	264-5866	2M-2290	Bracket - Ring	299-1979	2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
1S-8186	Idler As.	188-5268	2M-4668	Retainer - Guard	297-4867	2W-7255	Shaft - Water Pump	325-6203
1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014	2P-1005	Bearing - Sleeve	296-1342	2W-7458	Crankshaft As	242-3439
1T-0421	Flange As - Output	295-5442	2P-1170	Shaft As - Gear	296-1367	2W-7678	Gear - Water Pump	325-6088
1T-0436	Gear - Pump Drive	247-3367	2P-1738	Plate As - Oil Pan	325-6164	3B-1464	Cap - Bearing	226-0206
1T-0437	Housing - Rotating	295-5685	2P-1739	Tube As - Pump	325-6229	3F-4971	Pin	295-5693
1T-0438	Retainer - Bearing	295-0410	2P-1757	Hub - Fan Pulley	296-1357	3F-6149	Pin	299-2033
1T-0443	Carrier As - Guide	247-3368	2P-1781	Spacer - Oil Pump	325-6214	3J-2452	Cap - Ball Joint	297-7156
1T-0447	Carrier - Ring	295-0409	2P-2519	Tube As - Inlet	325-6230	3J-2682	Bracket	296-1345
1T-0930	Torque Converter	235-0913 (Repair Kit)	2P-2922	Gear - Transfer	219-9679	3J-6167	Bearing - Sleeve	299-1960
1T-1993	Wheel - Turbine	235-0920	2P-2923	Gear - Transfer	219-9680	3J-6173	Pin	325-6144
1T-2052	Stator As	295-5683	2P-3424	Gear - First Reduction	215-1675	3J-6182	Pin As	325-6128
1W-1219	Trunnion As	314-8724	2P-3425	Pinion - Sec Reduction	217-7697	3J-6204	Pin As	325-6129
1W-1669	Piston	325-6158	2P-3598	Shaft - Output	215-1676	3J-6442	Bearing - Sleeve	299-1961
1W-1695	Pump Gp	279-4980	2P-3669	Pinion - Bevel	215-1677	3J-6502	Pin	319-3453
1W-1698	Housing - Transfer Pump	296-1356	2P-3992	Gear - Bevel	219-9666	3J-6559	Cap - Bearing	296-1346
1W-4402	Gear - Camshaft	279-4981	2P-4370	Plate - Clutch	325-6166	3J-6560	Screw - Adjustable	297-7240
1W-4405	Gear - Crankshaft	279-4982	2P-4701	Shaft As - Gear	297-7257	3J-6561	Screw - Adjustable	297-7241
1W-5912	Tappet As - Guide	325-6223	2P-6245	Shaft As - Pump	325-6197	3J-6570	Support - Bearing	299-2069
1W-6541	Plunger As	325-6173	2P-9669	Shoe -Track Master	188-5604	3J-6573	Screw - Adjusting	302-2714
2F-0025	Tube	325-6233				3J-6575	Trunnion	297-7265
2F-5721	Bearing - Ball	311-9354						

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number
3J-6576	Bearing	256-4833
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-0214	Gear - Transfer	219-9681
3P-0215	Gear - Transfer	219-9682
3P-0395	Cage - Carrier Bearing	217-7723
3P-0615	Shoe - Track Master	188-5601
3P-0616	Shoe - Track Master	175-8881
3P-0617	Shoe - Track Master	188-5246
3P-0618	Shoe - Track Master	188-5602
3P-0620	Shoe - Track Master	188-5606
3P-0628	Link As.	175-8759
3P-3241	Plate - Pressure	325-6167
3P-4142	Plate As	299-2039
3P-4157	Yoke As - Idler	226-0221
3P-4197	Guard As - Idler	226-0189
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3P-6814	Pump Gp	226-0163
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3S-5396	Shaft - Fly-wheel	226-8015
3S-8800	Gear - Driven	325-6090
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4H-4021	Plate As - Loading	229-8219
4J-1616	Bracket	299-1982
4J-1999	Ballstud	314-8625

Original Part Number	Part Name	Classic Part Number
4J-6167	Bearing - Sleeve	325-6009
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5191	Muffler As	298-2785
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4S-6707	Piston - Clutch	215-1686
4S-8472	Hood As	296-1355
4S-8708	Housing - Clutch	216-3557
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5H-5500	Collar - Fly-wheel	302-2704
5J-4321	Trunnion	302-2700
5J-5643	Connector	325-6043
5M-1127	Countershaft	216-3558
5M-1133	Gear - Idler	214-0524
5M-1137	Gear As - Ctrshft	214-0960
5M-1139	Gear As - Ctrshft	214-0961

Original Part Number	Part Name	Classic Part Number
5M-1141	Gear As - Ctrshft	214-0962
5M-1143	Gear As	214-0963
5M-1145	Gear As - Forward	214-0964
5M-1147	Gear As - Reverse	214-0965
5M-1988	Piston - Steer	219-9691
5M-1990	Pilot - Piston	229-8233
5M-1998	Drum Steering	213-6952
5M-2026	Hubdriving	216-4471
5M-2971	Guard As - Front Idler	226-0190
5M-3470	Gear - Transmission	224-1305
5M-3474	Shaft - Output	215-1690
5M-3499	Shaft - Planet	319-3475
5M-3906	Gear - Ring	214-0526
5M-3907	Carrier - Planet	210-8475
5M-3941	Shaft - Planet	215-1691
5M-3942	Shaft - Planet	215-1692
5M-5822	Gear - Pump Drive	247-4120
5M-6120	Gear - Sun	213-8740
5M-6198	Shaft - Planet	297-7245
5M-6199	Shaft As - Planet	215-1694
5M-6208	Gear - Ring	247-4121
5M-6210	Shaft - Planet	219-9683
5M-6211	Shaft - Planet	219-9684
5M-7841	Gear - Ring	214-0525
5M-7864	Pump Gp - Scavenge	226-0169
5M-7869	Gear - Ring	214-0530
5M-7875	Carrier - Front	213-4495
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-0073	Plate - Steering	302-2692
5S-1211	Cover - Valve	314-8665
5S-4470	Gear - Transfer	224-1304
5S-4557	Bearing	311-9360
5S-4863	Holder As - Cage	215-1732
5S-6795	Chamber As	242-3437

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)	7G-2038	Tube - Univ Joint	297-7268	7N-3536	Gear - Fuel	279-4993
5S-6910	Shoe -Track	188-5603	7G-2474	Gear - Planet	300-2577	7N-5810	Gear As - Idler	233-2179
5S-6911	Shoe -Track	188-5605	7G-2475	Gear - Planet	223-4815	7N-5815	Gear - Camshaft Rr	233-2181
5S-9080	Pulley - Alt Drive	264-5883	7G-2476	Gear - Planet	223-4816	7N-5819	Gear - Hyd Pump Drive	215-1758
6F-2904	Bearing	295-5673	7G-2500	Gear - Planet	296-1350	7N-5825	Gear - Drive	215-1759
6F-7523	Cap - Bearing	325-6039	7G-2513	Gear - Planet	215-1734	7N-5910	Impeller - Pump	314-8686
6H-3957	Bearing - Ball	311-9358	7G-2517	Gear - Planet	213-8747	7N-9146	Gear - Fly-wheel Starter	279-4995
6I-1346	Pump Gp - Oil	295-5674	7G-2521	Gear - Planet	213-8749	7N-9312	Damper As - Camshaft	299-2005
6J-5342	Retainer	325-6182	7G-6576	Cage As	216-7859	7N-9805	Pin - Piston	295-6438
6J-5354	Bearing	297-7142	7H-3598	Bolt - Track	188-5636	7S-3161	Lifter - Valve	279-4996
6J-6229	Pin	299-2030	7J-1185	Bearing As	297-7146	7S-6723	Bracket - Alternator	299-1978
6J-9258	Trunnion As	256-4846	7J-1333	Bearing - Sleeve	295-6408	7S-6964	Gear - Ring	214-0532
6N-0714	Pulley - Alt	264-5884	7J-1334	Bearing - Sleeve	325-6015	7S-7809	Cap As - Radiator	295-6417
6N-1036	Gear - Oil Pump	279-4991	7J-4827	Yoke	299-2070	7S-7973	Guard - Final Drive Wear	213-9110
6N-1965	Line As - Fuel Injector	250-7535	7J-5131	Trunnion	296-1371	7T-0119	Support As	299-2066
6N-1966	Line As - Fuel Injector	250-7536	7J-7488	Bearing	256-4836	7T-0204	Bearing - Brace	247-4126
6N-8413	Housing - Pump	325-6110	7J-9884	Bearing - Sleeve	325-6016	7W-0450	Gear - Water Pump	279-4997
6P-0169	Hub - Fly-wheel Clutch	297-7204	7M-1840	Gear As - Ctrshft	214-0966	7W-0507	Gear - Oil Pump Drive	279-4998
6P-4948	Cap - Final Drive Bearing	226-0205	7M-1842	Gear As-ctr - Shft	214-0967	7W-0508	Gear - Fuel Pump Drive	296-1351
6P-5172	Guard Gp - Recoil	226-0196	7M-1889	Guard As	213-9108	7W-5687	Hub - Camshaft	314-8684
6P-5173	Guard Gp - Recoil	229-8617	7M-1890	Guard As - Final Drive Wear	213-9109	8E-4434	Shoe -Track	188-5263
6P-5343	Rod Gp - Track Adjustable	226-0200	7M-2167	Ring - Governor Control	308-9919	8E-4435	Shoe -Track Master	188-5264
6P-6653	Plate - Guide	226-0208	7M-8453	Piston - Clutch	215-1755	8E-4436	Shoe -Track	188-5261
6P-7625	Guard As - Track Roller	226-0185	7N-0110	Core As - Oil Cooler	319-3435	8E-4437	Shoe -Track Master	188-5262
6P-7626	Guard As - Track Roller	226-0186	7N-0128	Core As - Oil Cooler	299-1994	8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
6P-7627	Guard As - Track Roller	226-0187	7N-0165	Core As - Oil Cooler	295-5670	8E-6754	Connector As	325-6044
6T-1980	Collar - Idler End	226-0210	7N-2871	Line As - Fuel Injector	319-8172	8E-6755	Bearing - Sleeve	325-6026
7C-4297	Seal As - Camshaft	325-6192	7N-2872	Line As - Fuel Injector	319-8173	8E-6756	Bearing - Sleeve	325-6027
7F-9541	Pin As - Drawbar	296-1361	7N-2874	Line As - Fuel Injector	298-2779	8H-1383	Rod - Tie	299-2051
7F-9547	Pin As - Drawbar	295-0414	7N-2875	Line As - Fuel Injector	298-2780	8H-2810	Case As - Filter	314-8512
7G-2037	Joint Gp - Univ	226-8017	7N-2876	Line As - Fuel Injector	298-2781			
			7N-2949	Pulley	264-5887			
			7N-3515	Gear - Camshaft	314-8669			

(Continued)

Sales Model D7F (Continued)

Original Part Number	Part Name	Classic Part Number
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711

Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-1865	Bar As - Equalizer	231-3313
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7818	Bracket	226-0211
8S-9070	Carrier - Front	213-4464
8S-9071	Cage - Bearing	216-7869
9F-7101	Bushing - Collar	299-1988
9H-2256	Pump Gp	311-9443
9K-8757	Rod End - Bearing	311-9361
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959

Original Part Number	Part Name	Classic Part Number
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256
9M-8119	Retainer - Inlet	226-8022
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-4732	Guard Gp - Spring	226-0195
9S-5265	Shaft As	215-1945
9S-5277	Gear - Transfer	213-8758
9S-6129	Pulley - Alternator Drive	264-5891
9S-6590	Pump Gp - Oil	226-0176
9S-6788	Pump Gp - Oil	217-2602
9S-6875	Pinion - Final Drive	217-7705
9S-6948	Shaft - Center	213-9966
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712
9S-8802	Gear - Ring	214-0952

Sales Model D7G

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	1N-3958	Elbow	325-6087	1W-1669	Piston	325-6158
104-4253	Line As - Fuel Injector	279-4988	1P-0579	Housing As	219-9678	1W-1695	Pump Gp	279-4980
104-4254	Line As - Fuel Injector	279-4989	1P-0965	Gear - Bevel	213-8215	1W-1698	Housing - Transfer Pump	296-1356
111-8015	Gasket As - Head	279-4977	1P-1006	Strip - Guard	226-0245	1W-4402	Gear - Cam-shaft	279-4981
115-0637	Pump Gp	226-0160	1P-1636	Lever As	226-8013	1W-4405	Gear - Crank-shaft	279-4982
115-7550	Gasket - Plate	314-8667	1P-2187	Pump Gp	299-2044	1W-4407	Hub - Fan Pulley	296-1358
117-1024	Link As.	188-5595	1P-7044	Cage	226-7975	1W-5912	Tappet As - Guide	325-6223
118-1619	Roller Gp - Track	188-5257	1P-7590	Support As	213-4400	1W-6541	Plunger As	325-6173
118-1620	Roller Gp - DF	188-5258	1P-8554	Coupling - Exhaust	325-6052	1W-9229	Muffler As	302-4282
118-1623	Roller Gp - Track	188-5596	1P-8717	Roller Gp - Carrier	188-5600	236-7724	Retainer	299-2048
118-1625	Roller Gp - Track	188-5597	1P-8835	Shaft As	215-1672	244-1090	Alarm - Back up	360-2345
122-9405	Bracket As	325-6005	1P-9807	Shoe -Track	188-5333	2F-0025	Tube	325-6233
127-5537	Core As	325-6045	1P-9808	Shoe -Track	175-8802	2F-5721	Bearing - Ball	311-9354
129-2381	Gear - Planet	275-5274	1P-9809	Shoe -Track	175-8882	2H-4450	Washer - Thrust	325-6237
131-3815	Seal Gp - Basic	325-6193	1P-9810	Shoe -Track	188-5334	2H-4482	Collar	229-8218
148-7455	Valve - Ex-haust	270-4361	1P-9945	Bracket As - Fan	296-1344	2H-5046	Link - Flycam	299-2024
160-6305	Cap - Bearing	295-5686	1P-9946	Shaft - Fan	325-6194	2J-5462	Trunnion	297-7264
165-4262	Body As - Piston	270-4353 (Liner Kit)	1P-9952	Impeller - Pump	314-8685	2J-5596	Pin - Pivot	297-7211
167-8123	Damper As	299-2006	1S-0876	Bolt - Spring	226-0224	2J-8489	Bearing - Sleeve	295-5691
172-5185	Shaft - Water Pump	325-6201	1S-1532	Flange - Shaft	215-1673	2M-0125	Cylinder - Adjustable	226-0215
172-5188	Shaft - Water Pump	325-6202	1S-1801	Shaft As - Transmission	215-1674	2M-0369	Pilot - Spring Recoil	226-0226
172-5189	Impeller - Pump	295-5687	1S-1860	Nut (3/4-16)	188-5856	2M-0398	Sleeve - Bolt	226-0235
172-5190	Impeller - Pump	325-6111	1S-1888	Bracket - Lamp	297-7147	2M-2290	Bracket - Ring	299-1979
172-6712	Impeller - Pump	325-6112	1S-4701	Pulley - Alt	264-5866	2M-4668	Retainer - Guard	297-4867
172-7767	Pump Gp - Water	296-1365	1S-8186	Idler As.	188-5268	2P-1005	Bearing - Sleeve	296-1342
190-8609	Valve - Fill	360-2288	1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014	2P-1170	Shaft As - Gear	296-1367
1H-8382	Gear - Oil Pump Drive	226-6103	1T-0421	Flange As - Output	295-5442	2P-1738	Plate As - Oil Pan	325-6164
1M-9029	Guard	226-0219	1T-0436	Gear - Pump Drive	247-3367	2P-1739	Tube As - Pump	325-6229
1M-9177	Flywheel	226-6112	1T-0437	Housing - Rotating	295-5685	2P-1757	Hub - Fan Pulley	296-1357
1M-9444	Retainer - Spring	299-2046	1T-0438	Retainer - Bearing	295-0410	2P-1781	Spacer - Oil Pump	325-6214
1N-3576	Block Gp - Cylinder	279-4978	1T-0443	Carrier As - Guide	247-3368	2P-2519	Tube As - Inlet	325-6230
			1T-0447	Carrier - Ring	295-0409			
			1T-0930	Torque Converter	235-0913 (Repair Kit)			
			1T-1993	Wheel - Turbine	235-0920			
			1T-2052	Stator As	295-5683			
			1W-1219	Trunnion As	314-8724			

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number
2P-2922	Gear - Transfer	219-9679
2P-2923	Gear - Transfer	219-9680
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697
2P-3598	Shaft - Output	215-1676
2P-3669	Pinion - Bevel	215-1677
2P-3992	Gear - Bevel	219-9666
2P-4370	Plate - Clutch	325-6166
2P-4701	Shaft As - Gear	297-7257
2P-6245	Shaft As - Pump	325-6197
2P-9669	Shoe -Track Master	188-5604
2P-9670	Bolt Master	188-5637
2R-0179	Pin As	325-6127
2S-3946	Gear - Final Drive	215-1678
2S-6739	Pulley - Tightener	298-2794
2S-7062	Shaft - Sprocket	219-9673
2S-7063	Nut	300-2584
2S-7064	Cap - Shaft Bearing	299-1991
2S-7099	Hub - Gear	219-2962
2S-7527	Flange - Drum	213-8163
2S-7596	Retainer	215-1679
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3B-1464	Cap - Bearing	226-0206
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6612	Cap - Ball Joint	297-7155

Original Part Number	Part Name	Classic Part Number
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-6167	Bearing - Sleeve	299-1960
3J-6173	Pin	325-6144
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6502	Pin	319-3453
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6576	Bearing	256-4833
3L-1425	Bearing - Ball	311-9356
3P-0395	Cage - Carrier Bearing	217-7723
3P-0615	Shoe - Track Master	188-5601
3P-0616	Shoe - Track Master	175-8881
3P-0617	Shoe - Track Master	188-5246
3P-0618	Shoe - Track Master	188-5602
3P-0620	Shoe - Track Master	188-5606
3P-0628	Link As.	175-8759
3P-3241	Plate - Pressure	325-6167
3P-3935	Shaft	299-2053
3P-4142	Plate As	299-2039
3P-4157	Yoke As - Idler	226-0221
3P-4197	Guard As - Idler	226-0189
3P-6560	Stop - Recoil Spring	226-0232
3P-6561	Stop - Recoil Spring	226-0233
3P-7623	Pump Gp	217-2598

Original Part Number	Part Name	Classic Part Number
3P-8283	Spacer	325-6215
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3S-5396	Shaft - Fly-wheel	226-8015
3S-8800	Gear - Driven	325-6090
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-4482	Guide - Front Idler	226-0248
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-4021	Plate As - Loading	229-8219
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-2414	Trunnion	296-1370
4J-2847	Trunnion As	297-7267
4J-3583	Screw - Adjusting	297-7242
4J-3589	Cap - Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-3591	Bracket - Rh	299-1983
4J-6167	Bearing - Sleeve	325-6009
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4356	Pulley - Camshaft	264-5878
4N-4539	Sleeve	314-8720
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-5191	Muffler As	298-2785
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4N-8814	Line As - Fuel Injector	247-3366

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
4N-9587	Shield - Heat	297-7260	5M-7841	Gear - Ring	214-0525	6P-5343	Rod Gp - Track Adjust-able	226-0200
4P-3546	Valve As - Relief	325-6236	5M-7864	Pump Gp - Scavenge	226-0169	6P-6653	Plate - Guide	226-0208
4P-9381	Line As - Fuel Injector	279-4984	5M-7869	Gear - Ring	214-0530	6P-7625	Guard As - Track Roller	226-0185
4P-9382	Line As - Fuel Injector	279-4985	5M-7875	Carrier - Front	213-4495	6P-7626	Guard As - Track Roller	226-0186
4P-9385	Line As - Fuel Injector	279-4986	5M-7900	Bolt - Hex Head	311-9349	6P-7627	Guard As - Track Roller	226-0187
4P-9386	Line As - Fuel Injector	279-4987	5P-7807	Bearing - Ball	314-8502	6T-1980	Collar - Idler End	226-0210
4S-6707	Piston - Clutch	215-1686	5S-0073	Plate - Steering	302-2692	7C-4297	Seal As - Camshaft	325-6192
4S-8472	Hood As	296-1355	5S-1211	Cover - Valve	314-8665	7D-7889	Gear - Ring	275-5276
4S-8708	Housing - Clutch	216-3557	5S-4557	Bearing	311-9360	7F-9541	Pin As - Drawbar	296-1361
4V-3603	Pin As	319-3441	5S-4863	Holder As - Cage	215-1732	7F-9547	Pin As - Drawbar	295-0414
4W-0452	Seal As - Camshaft	325-6191	5S-6795	Chamber As	242-3437	7G-2037	Joint Gp - Univ	226-8017
4W-2446	Damper As	279-4990	5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)	7G-2038	Tube - Univ Joint	297-7268
5G-3612	Cap Gp	295-6419	5S-6910	Shoe -Track	188-5603	7G-2474	Gear - Planet	300-2577
5H-5500	Collar - Fly-wheel	302-2704	5S-6911	Shoe -Track	188-5605	7G-2475	Gear - Planet	223-4815
5J-4321	Trunnion	302-2700	5S-7609	Pulley - Alt Drive	264-5881	7G-2476	Gear - Planet	223-4816
5J-5643	Connector	325-6043	5S-9080	Pulley - Alt Drive	264-5883	7G-2500	Gear - Planet	296-1350
5M-1127	Countershaft	216-3558	6F-7523	Cap - Bearing	325-6039	7G-2513	Gear - Planet	215-1734
5M-1133	Gear - Idler	214-0524	6H-3957	Bearing - Ball	311-9358	7G-6576	Cage As	216-7859
5M-1137	Gear As - Ctrshft	214-0960	6I-1346	Pump Gp - Oil	295-5674	7G-7681	Shaft As	307-1530
5M-1139	Gear As - Ctrshft	214-0961	6J-0774	Trunnion	256-4844	7H-3598	Bolt - Track	188-5636
5M-1141	Gear As - Ctrshft	214-0962	6J-5342	Retainer	325-6182	7J-1185	Bearing As	297-7146
5M-1143	Gear As	214-0963	6J-5354	Bearing	297-7142	7J-1333	Bearing - Sleeve	295-6408
5M-1145	Gear As - Forward	214-0964	6J-6229	Pin	299-2030	7J-1334	Bearing - Sleeve	325-6015
5M-1147	Gear As - Reverse	214-0965	6J-9258	Trunnion As	256-4846	7J-4827	Yoke	299-2070
5M-1988	Piston - Steer	219-9691	6L-9211	Idler Gp	200-9237	7J-5131	Trunnion	296-1371
5M-1990	Pilot - Piston	229-8233	6N-0714	Pulley - Alt	264-5884	7J-7488	Bearing	256-4836
5M-1998	Drum Steering	213-6952	6N-1036	Gear - Oil Pump	279-4991	7J-9344	Bearing - Sleeve	360-2334
5M-2026	Hubdriving	216-4471	6N-1965	Line As - Fuel Injector	250-7535	7J-9884	Bearing - Sleeve	325-6016
5M-5822	Gear - Pump Drive	247-4120	6N-1966	Line As - Fuel Injector	250-7536	7M-1840	Gear As - Ctrshft	214-0966
5M-6120	Gear - Sun	213-8740	6N-8413	Housing - Pump	325-6110	7M-1842	Gear As-ctr - Shft	214-0967
5M-6198	Shaft - Planet	297-7245	6P-0169	Hub - Fly-wheel Clutch	297-7204	7M-1889	Guard As	213-9108
5M-6199	Shaft As - Planet	215-1694	6P-4948	Cap - Final Drive Bearing	226-0205	7M-1890	Guard As - Final Drive Wear	213-9109
5M-6208	Gear - Ring	247-4121	6P-5172	Guard Gp - Recoil	226-0196			
5M-6210	Shaft - Planet	219-9683	6P-5173	Guard Gp - Recoil	229-8617			
5M-6211	Shaft - Planet	219-9684						

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number
7N-0110	Core As - Oil Cooler	319-3435
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5810	Gear As - Idler	233-2179
7N-5815	Gear - Cam-shaft Rr	233-2181
7N-5819	Gear - Hyd Pump Drive	215-1758
7N-5825	Gear - Drive	215-1759
7N-5910	Impeller - Pump	314-8686
7N-9146	Gear - Fly-wheel Starter	279-4995
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-6964	Gear - Ring	214-0532
7S-7809	Cap As - Radiator	295-6417
7S-7973	Guard - Final Drive Wear	213-9110
7T-0119	Support As	299-2066
7T-0204	Bearing - Brace	247-4126
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351

Original Part Number	Part Name	Classic Part Number
7W-5687	Hub - Cam-shaft	314-8684
8D-3591	Carrier - Planet	301-4769
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8E-4434	Shoe -Track	188-5263
8E-4435	Shoe -Track Master	188-5264
8E-4436	Shoe -Track	188-5261
8E-4437	Shoe -Track Master	188-5262
8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8M-0874	Plunger As - Valve	311-9439
8M-7166	Housing - Screen	297-7192
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728

Original Part Number	Part Name	Classic Part Number
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8P-0187	Nut - Adjusting	219-9676
8P-1865	Bar As - Equalizer	231-3313
8P-6274	Guard As - Lh	226-4949
8P-6275	Guard As - Rh	226-0191
8P-7790	Valve Gp - Press	247-4437
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-1061	Pilot As - Spring	226-0227
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
8S-7818	Bracket	226-0211
8W-2308	Shaft - Planet	275-5285
8W-8317	Sprocket	275-5287

(Continued)

Sales Model D7G (Continued)

Original Part Number	Part Name	Classic Part Number
9F-7101	Bushing - Collar	299-1988
9K-8757	Rod End - Bearing	311-9361
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2028	Gear - Sun	214-0959
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256

Original Part Number	Part Name	Classic Part Number
9M-8119	Retainer - Inlet	226-8022
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-3242	Plate - Clutch	325-6172
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904

Original Part Number	Part Name	Classic Part Number
9S-1043	Guard As - Guiding	226-0240
9S-1044	Guard As - Guiding	226-0241
9S-1045	Strip - Guard	226-0246
9S-1046	Strip - Guard	226-0247
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-3955	Cage - Gear Bearing	216-7874
9S-5265	Shaft As	215-1945
9S-6590	Pump Gp - Oil	226-0176
9S-6875	Pinion - Final Drive	217-7705
9S-8679	Chamber As	325-6042
9S-8789	Plate - Clutch	302-2712

Sales Model D7H

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-0416	Guard As (rh)	325-6096
111-0419	Guard As (lh)	325-6097
111-0431	Guard As	325-6098
111-8015	Gasket As - Head	279-4977
112-5585	Shaft - Planet	308-9932
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
128-0307	Plate	325-6165
131-3815	Seal Gp - Basic	325-6193
131-7736	Support As - Engine	325-6222
148-7455	Valve - Exhaust	270-4361
155-2819	Ejector As - Exhaust	325-6078
160-6305	Cap - Bearing	295-5686
160-6308	Cap - Bearing	325-6036
165-4262	Body As - Piston	270-4353 (Liner Kit)

Original Part Number	Part Name	Classic Part Number
165-7211	Strip	325-6219
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
190-8609	Valve - Fill	360-2288
1H-4106	Pin As - Drawbar	325-6126
1H-8262	Shaft	226-8016
1H-8382	Gear - Oil Pump Drive	226-6103
1H-8937	Drumbrake	226-7993
1M-9177	Flywheel	226-6112
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-1636	Lever As	226-8013
1P-7044	Cage	226-7975
1P-8554	Coupling - Exhaust	325-6052
1S-4701	Pulley - Alt	264-5866

Original Part Number	Part Name	Classic Part Number
1S-8764	Ring - Flywheel Clutch Adjustable	226-8014
1T-0421	Flange As - Output	295-5442
1T-0437	Housing - Rotating	295-5685
1T-0438	Retainer - Bearing	295-0410
1T-0447	Carrier - Ring	295-0409
1T-0521	Retainer - Bearing	325-6180
1T-0699	Impeller - Converter	235-1808
1T-1386	Yoke - Univ Joint	325-6239
1T-1880	Carrier - Ring	295-0408
1T-1993	Wheel - Turbine	235-0920
1T-2050	Carrier As - Stat	325-6040
1T-2052	Stator As	295-5683
1U-0612	Pin	325-6135
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980

(Continued)

Sales Model D7H (Continued)

Original Part Number	Part Name	Classic Part Number
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4737	Gear - Cam-shaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-9229	Muffler As	302-4282
208-5026	Pin	325-6133
244-1090	Alarm - Back up	360-2345
258-2308	Bearing - Sleeve	325-6019
2D-5658	Bearing - Ball	301-4628
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2K-3592	Boss	314-8501
2M-2290	Bracket - Ring	299-1979
2P-1005	Bearing - Sleeve	296-1342
2P-1170	Shaft As - Gear	296-1367
2P-1502	Gear - Shaft	214-0956
2P-1503	Gear - First	213-8637
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214

Original Part Number	Part Name	Classic Part Number
2P-2519	Tube As - Inlet	325-6230
2P-4370	Plate - Clutch	325-6166
2P-6245	Shaft As - Pump	325-6197
2R-0179	Pin As	325-6127
2S-3803	Gear	226-6106
2S-3804	Gear - Sliding	226-6107
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
2W-9978	Core As - Oil Cooler	279-4983
3F-4971	Pin	295-5693
3G-0910	Cap - Bearing	325-6037
3G-1525	Bearing - Sleeve	325-6006
3G-4929	Pin	325-6139
3J-2682	Bracket	296-1345
3J-6167	Bearing - Sleeve	299-1960
3J-6173	Pin	325-6144
3J-6182	Pin As	325-6128
3J-6442	Bearing - Sleeve	299-1961
3P-3241	Plate - Pressure	325-6167
3P-7640	Gear - Ctrshft	325-6093
3P-7641	Gear - Ctrshft	325-6094
3P-7642	Gear - Ctrshft	302-2668
3P-7643	Gear - Pinion Shft	302-2669
3P-7644	Gear - Pinion Shft	302-2706
3P-8283	Spacer	325-6215
3S-8800	Gear - Driven	325-6090
3T-0997	Bearing - Sleeve	307-1524
3T-1446	Pump Gp	325-6178
3T-4008	Gear - Planet	295-5444
3T-4011	Shaft As - Planet	295-5698

Original Part Number	Part Name	Classic Part Number
3T-4299	Joint Gp - Univ	325-6114
3T-4516	Trunnion As	325-6226
3T-4568	Shaft - Planet	314-8712
3T-4824	Gear - Planet	295-5699
3T-5021	Carrier - Planet	295-5700
3T-5200	Carrier - Planet	295-5701
3T-5294	Spacer	325-6216
3T-5297	Pin	325-6145
3T-5672	Gear As - Oil Pump	295-5447
3T-5674	Gear As - Oil Pump	295-5449
3T-5929	Gear	288-8718
3T-6247	Shaft	314-8713
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7399	Piston	325-6159
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3W-0640	Piston	325-6160
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124
4F-1252	Pin	295-5704
4H-4021	Plate As - Loading	229-8219
4J-2414	Trunnion	296-1370
4J-6167	Bearing - Sleeve	325-6009
4J-6374	Bearing - Sleeve	295-6407
4K-1102	Bearing - Sleeve	325-6010
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7693	Crankshaft As	242-3439
4N-8591	Coupling - Exhaust	325-6053
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986

(Continued)

Sales Model D7H (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
4P-9386	Line As - Fuel Injector	279-4987	6I-0343	Line As - Fuel Injector	325-6119	7G-5783	Gear - Planet	288-8724
4S-8472	Hood As	296-1355	6I-0344	Line As - Fuel Injector	325-6120	7G-5784	Gear - Planet	288-8725
4T-0202	Pin As	325-6130	6I-0345	Line As - Fuel Injector	325-6121	7G-7013	Coupling - Pump Drive	295-5450
4T-0998	Lever	314-8687	6I-0346	Line As - Fuel Injector	325-6122	7G-7218	Carrier - Planet	283-5205
4T-5405	Trunnion As	319-3476	6I-1346	Pump Gp - Oil	295-5674	7G-7681	Shaft As	307-1530
4T-5495	Ballstud	314-8626	6J-5342	Retainer	325-6182	7G-7724	Piston - Clutch	283-5206
4T-8088	Screw	325-6188	6N-1036	Gear - Oil Pump	279-4991	7J-1333	Bearing - Sleeve	295-6408
4T-9444	Pin	325-6146	6N-8413	Housing - Pump	325-6110	7J-1334	Bearing - Sleeve	325-6015
4W-0452	Seal As - Camshaft	325-6191	6P-0169	Hub - Fly-wheel Clutch	297-7204	7J-5131	Trunnion	296-1371
4W-2042	Spacer	325-6217	6P-5404	Plate & Brake	325-6168	7J-6461	Crown	325-6054
4W-2446	Damper As	279-4990	6P-7704	Carrier - Ring	314-8658	7J-9884	Bearing - Sleeve	325-6016
5H-5500	Collar - Fly-wheel	302-2704	6S-3457	Pin	325-6147	7K-7195	Bearing - Sleeve	325-6025
5J-1204	Pin As	325-6131	6T-0064	Shaft - Planet	295-6442	7N-0110	Core As - Oil Cooler	319-3435
5J-4321	Trunnion	302-2700	6T-0234	Retainer	325-6183	7N-0128	Core As - Oil Cooler	299-1994
5J-5643	Connector	325-6043	6T-0240	Retainer	325-6184	7N-0165	Core As - Oil Cooler	295-5670
5M-5073	Joint Gp - Univ	325-6113	6T-0241	Piston	325-6161	7N-1164	Mount As	295-5451
5M-7336	Retainer - Washer	325-6181	6T-0243	Plate - Thrust	325-6169	7N-3536	Gear - Fuel	279-4993
5M-7340	Cage - Bearing	325-6034	6T-0248	Ring - Seal	295-6440	7N-5910	Impeller - Pump	314-8686
5M-7342	Flange - Shaft	215-1696	6T-3080	Plate & Brake	325-6170	7N-9146	Gear - Fly-wheel Starter	279-4995
5M-7344	Gear - Bevel	213-8741	6T-7882	Gear - Planet	296-1352	7N-9805	Pin - Piston	295-6438
5M-7345	Gear - Bevel	214-0957	6T-8250	Retainer	319-3473	7S-3161	Lifter - Valve	279-4996
5M-7349	Gear - Bevel	213-8742	6Y-0926	Gear - Planet	295-6427	7S-7809	Cap As - Radiator	295-6417
5M-7352	Gear - Bevel	217-7713	6Y-0984	Gear - Ring	295-6428	7T-2036	Cap As - Filter	361-1721
5M-7353	Gear - Bevel	217-7714	6Y-4819	Carrier - Planet	296-1348	7T-2092	Washer - Thrust	325-6238
5M-7355	Gear - Reverse	216-3581	6Y-5812	Bearing - Sleeve	325-6012	7T-3952	Gear - Transfer	295-6429
5P-7807	Bearing - Ball	314-8502	6Y-6752	Pin	325-6150	7T-6427	Pin	319-3462
5P-8194	Ring - Retaining	308-9920	6Y-6931	Shaft As	325-6206	7T-8136	Shaft - Planet	314-8714
5S-1211	Cover - Valve	314-8665	6Y-7471	Pin - Pivot	325-6152	7T-9272	Gear - Sun	296-1354
5S-4557	Bearing	311-9360	6Y-7474	Pin - Pivot	325-6153	7T-9370	Gear - Sun	283-5207
5S-6795	Chamber As	242-3437	6Y-9468	Retainer As	325-6185	7T-9586	Bearing	314-8645
5S-9080	Pulley - Alt Drive	264-5883	7C-3567	Mount As	314-8689	7T-9931	Countershaft	215-1760
6E-1108	Bearing - Sleeve	325-6023	7C-4297	Seal As - Camshaft	325-6192	7W-0450	Gear - Water Pump	279-4997
6F-2904	Bearing	295-5673	7F-9541	Pin As - Drawbar	296-1361	7W-0507	Gear - Oil Pump Drive	279-4998
6F-3183	Cap - Bearing	325-6038	7G-2500	Gear - Planet	296-1350	7W-0508	Gear - Fuel Pump Drive	296-1351
6F-7523	Cap - Bearing	325-6039	7G-2516	Gear - Planet	283-5203			
6H-3957	Bearing - Ball	311-9358	7G-2824	Piston	295-6439			
6I-0341	Line As - Fuel Injector	325-6117	7G-2828	Plate - Clutch	325-6171			
6I-0342	Line As - Fuel Injector	325-6118	7G-2830	Ring - Seal	295-6441			
			7G-5776	Shaft - Planet	325-6195			
			7G-5780	Shaft - Planet	325-6196			

(Continued)

Sales Model D7H (Continued)

Original Part Number	Part Name	Classic Part Number
7W-5685	Pulley - Cam-shaft	298-2772
7W-5698	Pulley - Cam-shaft	295-5679
8E-5450	Seal - Ebar	325-6190
8E-5993	Gear As - Idler	215-1903
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8G-4187	Pin As	295-5676
8G-4189	Bearing - Aligning	295-6411
8H-1383	Rod - Tie	299-2051
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8J-5654	Bearing - Sleeve	325-6028
8M-0874	Plunger As - Valve	311-9439
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711

Original Part Number	Part Name	Classic Part Number
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8P-1892	Piston - Clutch	283-5208
8P-1916	Gear - Planet	283-5209
8P-9507	Piston - Clutch	283-5212
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
9F-7101	Bushing - Collar	299-1988
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-9543	Gear - Oil Pump	295-6426
9J-0123	Trunnion	325-6227

Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing - Sleeve	308-9830
9M-4789	Shaft - Gov Control	297-7256
9M-8117	Shaft - Fly-wheel Clutch	226-6073
9M-8119	Retainer - Inlet	226-8022
9M-8281	Gear As - Oil Pump	325-6089
9N-4622	Pin	319-3468
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-1779	Bearing - Sleeve	325-6029
9P-3242	Plate - Clutch	325-6172
9P-7757	Gear - Sun	283-5218
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9S-6590	Pump Gp - Oil	226-0176
9S-8679	Chamber As	325-6042
9T-0066	Trunnion	325-6228
9T-4761	Head	325-6108
9T-4762	Head	325-6109
9W-0318	Spacer	325-6218
9W-0550	Shaft - Transmission Upper	226-6000
9W-0552	Shaft - Pinion	226-6001
9W-1677	Bearing	297-7145
9W-2344	Coupling - Pump Drive	314-8666
9W-3605	Carrier - Ring	314-8662
9W-4897	Bracket As	295-6414
9W-7481	Gear - Planet	295-6431
9W-7839	Carrier - Planet	295-6421
9W-8270	Gear - Ring	308-9859
9W-9930	Mount As	295-6437

Sales Model D8

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1D-3996	Fork - Knuckle	228-9428

Original Part Number	Part Name	Classic Part Number
1F-2254	Bushing - Stem	314-8510
1M-7250	Bowl - Pre-cleaner	360-2296
1S-1888	Bracket - Lamp	297-7147

Original Part Number	Part Name	Classic Part Number
2B-3708	Chamber As	247-3293
2D-5658	Bearing - Ball	301-4628
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3B-6218	Muffler As	247-2672

(Continued)

Sales Model D8 (Continued)

Original Part Number	Part Name	Classic Part Number
3F-4971	Pin	295-5693
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
3K-3124	Muffler - Trap	247-2673
3L-1425	Bearing - Ball	311-9356
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
5F-0689	Pin	256-4821
5F-7993	Pin	319-3454

Original Part Number	Part Name	Classic Part Number
5L-9371	Connector - Inlet	311-9375
5S-1211	Cover - Valve	314-8665
6F-2904	Bearing	295-5673
6H-3957	Bearing - Ball	311-9358
7D-6841	Joint As - Univ	228-9566
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7M-4926	Retainer - Pin	314-8538

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8B-5972	Bearing - Ball	314-8503
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D8D

Original Part Number	Part Name	Classic Part Number
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6744	Bearing	361-1705
1M-9444	Retainer - Spring	299-2046
2F-5721	Bearing - Ball	311-9354
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694

Original Part Number	Part Name	Classic Part Number
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-7993	Pin	319-3454
5J-4321	Trunnion	302-2700
5S-1211	Cover - Valve	314-8665
6F-2904	Bearing	295-5673
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542

Original Part Number	Part Name	Classic Part Number
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D8E, D8F

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824

Original Part Number	Part Name	Classic Part Number
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9444	Retainer - Spring	299-2046
1P-0005	Pump Gp - Fuel Transfer	256-4756
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354

Original Part Number	Part Name	Classic Part Number
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3F-4971	Pin	295-5693
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795

(Continued)

Sales Model D8E, D8F (Continued)

Original Part Number	Part Name	Classic Part Number
3S-2420	Pilot As - Spring	226-2733
4B-1455	Cap As - Filter	361-1719
4F-4974	Clamp	311-9373
4J-1999	Ballstud	314-8625
4M-9215	Gear - Pump Idler	311-9391
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-0689	Pin	256-4821
5F-7993	Pin	319-3454
5J-4321	Trunnion	302-2700
5P-7807	Bearing - Ball	314-8502

Original Part Number	Part Name	Classic Part Number
5S-1211	Cover - Valve	314-8665
5S-9080	Pulley - Alt Drive	264-5883
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538

Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Connecting Rod	311-9351
9W-1677	Bearing	297-7145

Sales Model D8G

Original Part Number	Part Name	Classic Part Number
160-6305	Cap - Bearing	295-5686
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1M-7250	Bowl - Pre-cleaner	360-2296
1M-9444	Retainer - Spring	299-2046
2F-5721	Bearing - Ball	311-9354
2P-0483	Chamber As	256-4760
2S-3966	Ring - Seal	297-7237
2S-4015	Plunger As - Valve	311-9438
3B-1464	Cap - Bearing	226-0206
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694

Original Part Number	Part Name	Classic Part Number
3F-7445	Bearing - Sleeve	314-8508
3H-3378	Gear As - Pump	298-2795
4B-1455	Cap As - Filter	361-1719
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
5F-7993	Pin	319-3454
5J-4321	Trunnion	302-2700
5S-1211	Cover - Valve	314-8665
6F-2904	Bearing	295-5673
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358

Original Part Number	Part Name	Classic Part Number
6L-7816	Seal - o-Ring	314-8542
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7S-7809	Cap As - Radiator	295-6417
7T-0204	Bearing - Brace	247-4126
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D8H

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368

Original Part Number	Part Name	Classic Part Number
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-1738	Pin	319-3448
1J-6744	Bearing	361-1705

Original Part Number	Part Name	Classic Part Number
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-3925	Gear - Shaft Idler	216-7459

(Continued)

Sales Model D8H (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1M-4153	Carrier - Planet	213-1114	2M-3339	Piston - Clutch	221-7944	3P-4002	Pump Gp - Gear	217-2595
1M-4155	Gear - Ring	214-0519	2N-9297	Retainer - Spring	314-8535	3P-4850	Gear As - Oil Pump	308-9848
1M-4156	Gear - Ring	214-0520	2P-0483	Chamber As	256-4760	3P-4855	Pump Gp	217-2596
1M-4167	Shaft - Planet	219-9700	2P-0484	Chamber As	247-3296	3P-6293	Pump Gp	217-2597
1M-4171	Cage - Bearing	216-7460	2P-1005	Bearing - Sleeve	296-1342	3P-7482	Cap - Drive Bearing	226-2731
1M-4344	Cage As	216-7466	2P-1604	Piston - Steering	219-9694	3P-9394	Shaft - Planet	215-1680
1M-6603	Gear - Transfer	217-7720	2P-1605	Pilot - Piston	219-9695	3S-1262	Retainer	308-9915
1M-6604	Gear - Transfer	217-7715	2P-4370	Plate - Clutch	325-6166	3S-1274	Shaft - Center	215-1681
1M-9444	Retainer - Spring	299-2046	2S-2140	Nut (7/8-14)	188-5857	3S-2252	Manifold - Exhaust	261-0887
1P-0005	Pump Gp - Fuel Transfer	256-4756	2S-3913	Cage - Gear Bearing	217-7722	3S-2420	Pilot As - Spring	226-2733
1P-2187	Pump Gp	299-2044	2S-3966	Ring - Seal	297-7237	3S-6989	Nut - Spanner	219-9701
1P-4145	Valve Gp - Press	247-4436	2S-4015	Plunger As - Valve	311-9438	3S-7306	Flange - Drum	216-7827
1S-1888	Bracket - Lamp	297-7147	2S-4357	Pinion - Final Drive	217-7706	3S-7308	Cage - Pinion Bearing	219-9702
1S-2268	Piston	226-2726	2S-6346	Shoe -Track	188-5311	3S-7517	Pulley - Belt Adjustable	264-5876
1S-2269	Sleeve	226-2720	2S-6347	Shoe -Track	188-5613	3S-7519	Pulley - Damper As	264-5877
1S-4701	Pulley - Alt	264-5866	2S-6357	Shoe -Track	281-6373	3S-8735	Guard As	226-2723
1S-8753	Plate - Coupling	308-9910	2S-6364	Shoe -Track	188-5615	3S-8736	Guard As	226-9992
1S-8754	Joint Gp - Univ	308-9873	2S-7873	Pump Gp	226-0162	3S-9919	Shaft As	239-7959
1T-0224	Carrier - Ring	239-7928	2S-7917	Gear - Pump Drive	247-4119	4M-0503	Gear As - Oil Pump	297-7184
1T-0228	Housing - Rotating	216-7467	2S-7920	Pump Gp - Scavenge	217-2594	4M-8967	Gear - Sun	219-9661
1T-0231	Retainer - Bearing	319-3471	2S-8892	Pulley - Fan Drive	264-5874	4M-9215	Gear - Pump Idler	311-9391
1T-0237	Flange As - Output	239-7929	3F-6185	Pin	295-5694	4N-4577	Muffler As	308-9877
1T-0256	Gear - Pump Drive	239-7930	3F-6523	Pin - Clevis	256-4818	4N-4880	Pump Gp - Fuel Transfer	256-4758
1T-0595	Carrier - Wheel	239-7939	3F-7445	Bearing - Sleeve	314-8508	4N-7526	Seal As - Pump	311-9454
1T-0611	Converter As	235-1804 (Repair Kit)	3H-3378	Gear As - Pump	298-2795	4N-9180	Seal As - Pump	311-9455
1T-0670	Converter As	235-1805 (Repair Kit)	3H-7161	Pin	256-4819	4S-5833	Spacer	239-7961
1T-1389	Carrier - Bearing	247-4124	3H-7162	Collar	256-4830	4S-8472	Hood As	296-1355
2F-5721	Bearing - Ball	311-9354	3H-7164	Pin - Pivot	256-4820	5F-7993	Pin	319-3454
2J-1506	Pin	319-3451	3J-3493	Ballstud	256-4832	5G-3612	Cap Gp	295-6419
2J-2622	Bracket	256-4826	3J-5190	Cap - Bearing	256-4837	5H-1719	Pump Gp - Final Drive Oil	226-0168
2J-3271	Pin	319-3452	3J-6497	Screw - Adjusting	256-4825	5J-0698	Pin	319-3456
2K-4507	Bearing - Sleeve	325-6021	3L-1425	Bearing - Ball	311-9356	5J-1204	Pin As	325-6131
			3P-1757	Yoke As - Idler	226-2729	5J-2602	Plate As - Trunnion	256-4838
			3P-3259	Cage - Bearing	217-7728	5J-4321	Trunnion	302-2700
			3P-3755	Guard As	226-2721	5L-8856	Coupling - Exhaust	311-9379
			3P-3757	Guard As	226-2722			

(Continued)

Sales Model D8H (Continued)

Original Part Number	Part Name	Classic Part Number
5M-0549	Gear - Transmission	215-1689
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3998	Gear - Ring	214-0528
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-6673	Guard - F Idler Rh	226-2735
5M-6674	Guard - F Idler Lh	226-2736
5M-7306	Cylinder	226-2737
5M-7953	Carrier As	239-7977
5M-8007	Gear - Ring	239-7932
5N-8501	Head As - Cylinder	256-4762
5N-8657	Manifold - Exhaust	261-0886
5P-7807	Bearing - Ball	314-8502
5S-0135	Cage - Pinion Bearing	222-1766
5S-0160	Strip - Guard	226-2738
5S-0161	Strip - Guard	226-2739
5S-0162	Guard As - Guiding	226-2740
5S-0163	Guard As - Guiding	226-2741
5S-0464	Gear - First Reduction	216-7852
5S-0465	Pinion - Reduction	216-7853
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6J-2326	Pin	319-3458
6J-9258	Trunnion As	256-4846
6J-9474	Pin As	319-3444
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8968	Coupling - Exhaust	311-9381
6L-9212	Idler Gp	200-9238
6N-8847	Guide - Valve	314-8523
6P-0549	Guard - Final Drive Wear	223-4812

Original Part Number	Part Name	Classic Part Number
6P-2776	Gear - Final Drive	217-7718
6P-3593	Support	229-8231
6P-3596	Hub	222-1764
6P-3597	Retainer	222-1770
6P-8884	Guard As - Idler	226-2742
6P-8904	Guard Gp - Track Adjustable	226-2744
6T-1933	Collar - Idler End	226-2746
6T-4481	Shaft - Planet	221-7946
6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7H-0602	Dog - Clutch	314-8515
7H-3599	Bolt - Track	188-5639
7H-7630	Spacer	239-7962
7J-0086	Bearing As	256-4842
7J-9884	Bearing - Sleeve	325-6016
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5289	Hub - Steering	217-7736
7M-5756	Gear - Ring	214-0531
7M-6621	Pump Gp - Oil	226-0172
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-9093	Shoe -Track	188-5617
7S-9094	Shoe -Track	188-5313
7S-9096	Shoe -Track	281-6370
7S-9101	Shoe -Track	281-6372
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7Y-1517	Pipe As - Tail	301-5246
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948

Original Part Number	Part Name	Classic Part Number
8F-5104	Screen As - Oil Pan	314-8539
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-9806	Gear - Shaft Drive	325-6091
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-6004	Head As - Cylinder	247-3369
8P-3252	Pin	319-3464
8P-5117	Rod Gp - Track Adjustable	226-2747
8P-5849	Plate As	223-6323
8P-6256	Roller Gp - Carrier	188-5612
8P-8221	Plate - Guide	226-2748
8S-0386	Shoe -Track Master	188-5312
8S-0387	Shoe -Track Master	188-5614
8S-0388	Shoe -Track Master	188-5616
8S-0390	Shoe -Track Master	281-6371
8S-0391	Shoe -Track Master	188-5618
8S-0392	Shoe -Track Master	188-5314
8S-0394	Shoe -Track Master	315-6693
8S-0395	Bolt Master	188-5640
8S-0915	Shoe -Track Master	281-6374
8S-1194	Shaft - Sprocket	217-7733
8S-1198	Hub - Gear	219-2969
8S-2123	Cage - Final Drive Bearing	217-7726

(Continued)

Sales Model D8H (Continued)

Original Part Number	Part Name	Classic Part Number
8S-2126	Spacer - Hub Bearing	222-1767
9F-7101	Bushing - Collar	299-1988
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-5233	Piston - Clutch	219-9708

Original Part Number	Part Name	Classic Part Number
9H-5433	Spacer	239-7963
9J-5273	Trunnion As	256-4848
9M-1328	Bearing - Aligning	325-6018
9M-3025	Cover As	299-2001
9M-4789	Shaft - Gov Control	297-7256

Original Part Number	Part Name	Classic Part Number
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-1026	Cage - Gear Bearing	216-7873
9S-7221	Idler As.	188-5610
9S-8493	Bolt - Connecting Rod	311-9351
9W-8937	Link As.	188-5310

Sales Model D8K

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
115-0637	Pump Gp	226-0160
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5189	Impeller - Pump	295-5687
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
190-8609	Valve - Fill	360-2288
1H-4106	Pin As - Drawbar	325-6126
1J-1738	Pin	319-3448
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-3925	Gear - Shaft Idler	216-7459
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1M-4344	Cage As	216-7466
1M-6603	Gear - Transfer	217-7720
1M-6604	Gear - Transfer	217-7715
1M-9444	Retainer - Spring	299-2046
1P-2187	Pump Gp	299-2044

Original Part Number	Part Name	Classic Part Number
1P-4145	Valve Gp - Press	247-4436
1S-1888	Bracket - Lamp	297-7147
1S-2268	Piston	226-2726
1S-2269	Sleeve	226-2720
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-0670	Converter As	235-1805 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-1669	Piston	325-6158
1W-1698	Housing - Transfer Pump	296-1356
1W-4738	Bearing - Sleeve	325-6020
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2J-1506	Pin	319-3451

Original Part Number	Part Name	Classic Part Number
2J-2622	Bracket	256-4826
2M-3339	Piston - Clutch	221-7944
2N-9297	Retainer - Spring	314-8535
2P-0484	Chamber As	247-3296
2P-1005	Bearing - Sleeve	296-1342
2P-1126	Pulley - Camshaft	264-5868
2P-1129	Pulley - Tightener	264-5869
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-4370	Plate - Clutch	325-6166
2P-9037	Drum - Steering Clutch	219-9696
2P-9038	Drum - Steering	216-7821
2P-9039	Hub - Steering	219-9697
2S-2140	Nut (7/8-14)	188-5857
2S-3913	Cage - Gear Bearing	217-7722
2S-3966	Ring - Seal	297-7237
2S-4357	Pinion - Final Drive	217-7706
2S-6346	Shoe - Track	188-5311
2S-6347	Shoe - Track	188-5613
2S-6357	Shoe - Track	281-6373
2S-6364	Shoe - Track	188-5615
2S-7917	Gear - Pump Drive	247-4119
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3G-0910	Cap - Bearing	325-6037

(Continued)

Sales Model D8K (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
3H-3378	Gear As - Pump	298-2795	5F-7993	Pin	319-3454	6L-8968	Coupling - Exhaust	311-9381
3H-7161	Pin	256-4819	5G-3612	Cap Gp	295-6419	6L-9212	Idler Gp	200-9238
3H-7162	Collar	256-4830	5H-1719	Pump Gp - Final Drive Oil	226-0168	6N-0762	Pulley - Fan	264-5885
3H-7164	Pin - Pivot	256-4820	5J-1204	Pin As	325-6131	6N-5437	Muffler As	247-2674
3J-3493	Ballstud	256-4832	5J-4321	Trunnion	302-2700	6P-0549	Guard - Final Drive Wear	223-4812
3J-5190	Cap - Bearing	256-4837	5L-9738	Coupling - Exhaust	311-9380	6P-2776	Gear - Final Drive	217-7718
3J-6497	Screw - Adjusting	256-4825	5M-0549	Gear - Transmission	215-1689	6P-3593	Support	229-8231
3L-1425	Bearing - Ball	311-9356	5M-3947	Shaft - Planet	223-6318	6P-3596	Hub	222-1764
3P-1757	Yoke As - Idler	226-2729	5M-3996	Gear - Ring	214-0527	6P-3597	Retainer	222-1770
3P-3259	Cage - Bearing	217-7728	5M-3999	Shaft - Transmission	215-1693	6P-8884	Guard As - Idler	226-2742
3P-3755	Guard As	226-2721	5M-4427	Gear - Sun	214-0529	6P-8904	Guard Gp - Track Adjustable	226-2744
3P-3757	Guard As	226-2722	5M-6673	Guard - F Idler Rh	226-2735	6T-1933	Collar - Idler End	226-2746
3P-3935	Shaft	299-2053	5M-6674	Guard - F Idler Lh	226-2736	6T-4481	Shaft - Planet	221-7946
3P-4850	Gear As - Oil Pump	308-9848	5M-7306	Cylinder	226-2737	6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
3P-4855	Pump Gp	217-2596	5M-7953	Carrier As	239-7977	7B-2420	Ferrule - Director	314-8517
3P-6293	Pump Gp	217-2597	5M-8007	Gear - Ring	239-7932	7C-0942	Adapter As	302-2636
3P-7482	Cap - Drive Bearing	226-2731	5N-8501	Head As - Cylinder	256-4762	7G-2492	Gear - Planet	239-7933
3P-9394	Shaft - Planet	215-1680	5N-8657	Manifold - Exhaust	261-0886	7G-2500	Gear - Planet	296-1350
3S-1262	Retainer	308-9915	5P-7807	Bearing - Ball	314-8502	7H-3599	Bolt - Track	188-5639
3S-1274	Shaft - Center	215-1681	5S-0135	Cage - Pinion Bearing	222-1766	7H-7630	Spacer	239-7962
3S-2252	Manifold - Exhaust	261-0887	5S-0160	Strip - Guard	226-2738	7J-0086	Bearing As	256-4842
3S-2420	Pilot As - Spring	226-2733	5S-0161	Strip - Guard	226-2739	7J-9884	Bearing - Sleeve	325-6016
3S-6989	Nut - Spanner	219-9701	5S-0162	Guard As - Guiding	226-2740	7M-1184	Housing As	219-9704
3S-7306	Flange - Drum	216-7827	5S-0163	Guard As - Guiding	226-2741	7M-1185	Housing As	219-9705
3S-7308	Cage - Pinion Bearing	219-9702	5S-0464	Gear - First Reduction	216-7852	7M-1186	Housing As	219-9706
3S-8735	Guard As	226-2723	5S-0465	Pinion - Reduction	216-7853	7M-1195	Housing - Clutch	219-9707
3S-8736	Guard As	226-9992	5S-1211	Cover - Valve	314-8665	7M-4603	Body - Fuel Valve	311-9348
3S-9919	Shaft As	239-7959	5S-4557	Bearing	311-9360	7M-4926	Retainer - Pin	314-8538
4M-8967	Gear - Sun	219-9661	5S-5746	Retainer - Guard	319-3472	7M-5756	Gear - Ring	214-0531
4N-4577	Muffler As	308-9877	5S-9080	Pulley - Alt Drive	264-5883	7M-8395	Piston - Clutch	223-6322
4N-4880	Pump Gp - Fuel Transfer	256-4758	6F-7523	Cap - Bearing	325-6039	7N-3350	Gear As - Pump Drive	319-3437
4N-5390	Pulley - Alt Drive	264-5879	6H-3957	Bearing - Ball	311-9358	7S-7400	Pump Gp	226-0173
4N-7526	Seal As - Pump	311-9454	6J-2326	Pin	319-3458	7S-7809	Cap As - Radiator	295-6417
4N-9180	Seal As - Pump	311-9455	6J-9474	Pin As	319-3444	7S-9093	Shoe -Track	188-5617
4P-9961	Line As - Fuel Injector	325-6115	6J-9793	Bearing	256-4835	7S-9094	Shoe -Track	188-5313
4S-5833	Spacer	239-7961	6L-7816	Seal - o-Ring	314-8542	7S-9096	Shoe -Track	281-6370
4S-8472	Hood As	296-1355						

(Continued)

Sales Model D8K (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7S-9101	Shoe -Track	281-6372	8P-5117	Rod Gp - Track Adjust-able	226-2747	8S-3487	Gear As - Ring	221-7949
7T-2036	Cap As - Filter	361-1721	8P-5849	Plate As	223-6323	8S-3491	Housing As	221-7950
7W-1902	Adapter - Fuel Nozzle	299-1955	8P-6256	Roller Gp - Carrier	188-5612	9F-7101	Bushing - Collar	299-1988
7W-2164	Core As - Oil Cooler	299-1996	8P-8221	Plate - Guide	226-2748	9H-1918	Gear - Bevel	219-9698
8E-7455	Gear - Planet	221-7947	8S-0386	Shoe -Track Master	188-5312	9H-1980	Pinion - Bevel	219-9699
8E-7456	Gear - Planet	221-7948	8S-0388	Shoe -Track Master	188-5616	9H-5233	Piston - Clutch	219-9708
8H-1993	Valve - Inlet	256-4765	8S-0390	Shoe -Track Master	281-6371	9H-5433	Spacer	239-7963
8H-1994	Valve - Ex-haust	256-4765	8S-0391	Shoe -Track Master	188-5618	9J-0123	Trunnion	325-6227
8H-2810	Case As - Filter	314-8512	8S-0392	Shoe -Track Master	188-5314	9J-5273	Trunnion As	256-4848
8H-7810	Gear	213-8753	8S-0394	Shoe -Track Master	315-6693	9K-8757	Rod End - Bearing	311-9361
8H-7813	Collar	215-1780	8S-0395	Bolt Master	188-5640	9M-3025	Cover As	299-2001
8H-9806	Gear - Shaft Drive	325-6091	8S-0915	Shoe -Track Master	281-6374	9M-4789	Shaft - Gov Control	297-7256
8M-0874	Plunger As - Valve	311-9439	8S-1194	Shaft - Sprocket	217-7733	9P-3663	Carrier - Planet	213-6939
8M-7166	Housing - Screen	297-7192	8S-2123	Cage - Final Drive Bearing	217-7726	9P-6592	Gear - Planet	215-1915
8M-8161	Flange - Shaft	215-1781	8S-2126	Spacer - Hub Bearing	222-1767	9P-6594	Gear - Planet	215-1921
8N-2510	Shaft	325-6208				9S-1026	Cage - Gear Bearing	216-7873
8N-2641	Sleeve	325-6210				9S-7221	Idler As.	188-5610
8N-6004	Head As - Cylinder	247-3369				9S-8493	Bolt - Connecting Rod	311-9351
8P-3252	Pin	319-3464				9W-8937	Link As.	188-5310

Sales Model D9D

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431	2F-5721	Bearing - Ball	311-9354	4M-9216	Gear - Pump Drive	311-9390
102-1561	Lifter As - Valve	311-9402	2N-9297	Retainer - Spring	314-8535	4N-3664	Guide - Valve	314-8524
1A-2846	Cap As - Filler	311-9368	2S-3966	Ring - Seal	297-7237	4N-7526	Seal As - Pump	311-9454
1F-2254	Bushing - Stem	314-8510	3F-7445	Bearing - Sleeve	314-8508	4N-9180	Seal As - Pump	311-9455
1H-4106	Pin As - Drawbar	325-6126	3H-7161	Pin	256-4819	4S-8906	Insert	311-9397
1J-1738	Pin	319-3448	3H-7162	Collar	256-4830	4S-8908	Insert	311-9399
1J-6746	Pin	256-4817	3H-7164	Pin - Pivot	256-4820	4S-8909	Insert - Valve Seat	311-9400
1M-7250	Bowl - Pre-cleaner	360-2296	3J-5190	Cap - Bearing	256-4837	5H-1719	Pump Gp - Final Drive Oil	226-0168
1M-9444	Retainer - Spring	299-2046	3J-6497	Screw - Adjusting	256-4825	5H-5553	Screw -Tap-pet Adjust-able	311-9451
1P-8005	Gasket - Chamber	314-8527	3L-1425	Bearing - Ball	311-9356	5J-4321	Trunnion	302-2700
1W-3062	Retainer As	311-9445	4B-1455	Cap As - Filter	361-1719	5N-9055	Manifold - Exhaust	261-0890
1W-5105	Ring Gp - Piston	311-9446	4F-1252	Pin	295-5704	5S-1757	Insert - Seat	311-9401
			4M-9214	Shaft - Pump Drive	314-8543			
			4M-9215	Gear - Pump Idler	311-9391			

(Continued)

Sales Model D9D (Continued)

Original Part Number	Part Name	Classic Part Number
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6L-7816	Seal - o-Ring	314-8542
6N-6969	Chamber As	247-3299
6N-8847	Guide - Valve	314-8523
7B-2420	Ferrule - Director	314-8517
7H-0602	Dog - Clutch	314-8515
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538

Original Part Number	Part Name	Classic Part Number
7M-7817	Valve - Inlet	311-9474
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439

Original Part Number	Part Name	Classic Part Number
8M-4014	Insert - Seat Exhaust	311-9398
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8S-3617	Chamber As	247-3302
9F-7101	Bushing - Collar	299-1988
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D9E

Original Part Number	Part Name	Classic Part Number
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6744	Bearing	361-1705
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1W-5105	Ring Gp - Piston	311-9446
2S-3966	Ring - Seal	297-7237
3J-6043	Trunnion	319-3477
4N-3664	Guide - Valve	314-8524

Original Part Number	Part Name	Classic Part Number
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5J-4321	Trunnion	302-2700
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
6F-7523	Cap - Bearing	325-6039
6L-7816	Seal - o-Ring	314-8542
6N-8847	Guide - Valve	314-8523

Original Part Number	Part Name	Classic Part Number
7B-2420	Ferrule - Director	314-8517
7M-7817	Valve - Inlet	311-9474
7S-5787	Chamber As	247-3300
7S-7809	Cap As - Radiator	295-6417
7T-2036	Cap As - Filter	361-1721
8F-5104	Screen As - Oil Pan	314-8539
8M-4014	Insert - Seat Exhaust	311-9398
8N-3723	Valve - Exhaust	311-9472
8N-9174	Liner - Cylinder	314-8531

Sales Model D9G

Original Part Number	Part Name	Classic Part Number
102-1561	Lifter As - Valve	311-9402
190-8609	Valve - Fill	360-2288
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1H-4106	Pin As - Drawbar	325-6126
1J-6744	Bearing	361-1705
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700

Original Part Number	Part Name	Classic Part Number
1M-4171	Cage - Bearing	216-7460
1P-2187	Pump Gp	299-2044
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467

Original Part Number	Part Name	Classic Part Number
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
1W-5105	Ring Gp - Piston	311-9446
244-1090	Alarm - Backup	360-2345

(Continued)

Sales Model D9G (Continued)

Original Part Number	Part Name	Classic Part Number
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2K-4507	Bearing - Sleeve	325-6021
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-9297	Retainer - Spring	314-8535
2P-1005	Bearing - Sleeve	296-1342
2P-1554	Gear - Ring	239-7931
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-4370	Plate - Clutch	325-6166
2P-6159	Pulley - Fan Drive	264-5873
2S-3966	Ring - Seal	297-7237
2S-7264	Pump As - Fuel Injector	311-9442
2S-7873	Pump Gp	226-0162
2S-7917	Gear - Pump Drive	247-4119
2S-7920	Pump Gp - Scavenge	217-2594
2S-8961	Pulley - Tightener	264-5875
3F-6185	Pin	295-5694
3F-6523	Pin - Clevis	256-4818
3F-7445	Bearing - Sleeve	314-8508
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830
3J-5190	Cap - Bearing	256-4837
3J-6043	Trunnion	319-3477

Original Part Number	Part Name	Classic Part Number
3J-6497	Screw - Adjusting	256-4825
3L-1425	Bearing - Ball	311-9356
3P-1849	Ring - Sealing	360-2259
3P-2811	Flange	239-7976
3P-3259	Cage - Bearing	217-7728
3P-4002	Pump Gp - Gear	217-2595
3P-4850	Gear As - Oil Pump	308-9848
3P-4855	Pump Gp	217-2596
3P-6269	Cage - Pinion Bearing	239-7972
3P-9394	Shaft - Planet	215-1680
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-9919	Shaft As	239-7959
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-3664	Guide - Valve	314-8524
4N-7526	Seal As - Pump	311-9454
4N-9180	Seal As - Pump	311-9455
4S-5833	Spacer	239-7961
4S-8472	Hood As	296-1355
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
5D-0470	Valve Gp	314-8549
5F-7993	Pin	319-3454
5G-3612	Cap Gp	295-6419
5H-5553	Screw - Tap-pet Adjustable	311-9451
5J-4321	Trunnion	302-2700
5J-4798	Bearing As	256-4840
5J-8052	Trunnion	256-4843
5M-0549	Gear - Transmission	215-1689

Original Part Number	Part Name	Classic Part Number
5M-3947	Shaft - Planet	223-6318
5M-3996	Gear - Ring	214-0527
5M-3999	Shaft - Transmission	215-1693
5M-4427	Gear - Sun	214-0529
5M-7953	Carrier As	239-7977
5M-7990	Gear - Sun	239-7938
5M-8007	Gear - Ring	239-7932
5N-8879	Manifold - Exhaust	261-0898
5N-9055	Manifold - Exhaust	261-0890
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1757	Insert - Seat	311-9401
5S-5746	Retainer - Guard	319-3472
5S-9080	Pulley - Alt Drive	264-5883
6F-7523	Cap - Bearing	325-6039
6H-3957	Bearing - Ball	311-9358
6J-2326	Pin	319-3458
6J-7563	Pin	319-3459
6J-8805	Bearing As	256-4841
6J-9793	Bearing	256-4835
6L-7816	Seal - o-Ring	314-8542
6L-8585	Gear - Gov Drive	314-8526
6N-6969	Chamber As	247-3299
6N-7295	Manifold - Exhaust	261-0903
6N-8847	Guide - Valve	314-8523
6T-4481	Shaft - Planet	221-7946
7B-2420	Ferrule - Director	314-8517
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7H-0602	Dog - Clutch	314-8515
7H-7630	Spacer	239-7962
7J-9884	Bearing - Sleeve	325-6016
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-1249	Piston - Clutch	215-1748
7M-2167	Ring - Governor Control	308-9919

(Continued)

Sales Model D9G (Continued)

Original Part Number	Part Name	Classic Part Number
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7M-5756	Gear - Ring	214-0531
7M-6621	Pump Gp - Oil	226-0172
7M-7431	Service Gp - Valve	314-8550
7M-7817	Valve - Inlet	311-9474
7M-8395	Piston - Clutch	223-6322
7M-8397	Housing As	239-7956
7N-9810	Pin - Piston	311-9432
7S-1579	Nut - Spanner	239-7964
7S-5787	Chamber As	247-3300
7S-6104	Gear - Sun	239-7934
7S-7400	Pump Gp	226-0173
7S-7809	Cap As - Radiator	295-6417
7S-7975	Guard - Final Drive Wear	239-7966
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8B-5972	Bearing - Ball	314-8503

Original Part Number	Part Name	Classic Part Number
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8E-9795	Connector As	256-4851
8F-5104	Screen As - Oil Pan	314-8539
8F-8858	Button Valve	314-8511
8H-2810	Case As - Filter	314-8512
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-4014	Insert - Seat Exhaust	311-9398
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8P-5849	Plate As	223-6323

Original Part Number	Part Name	Classic Part Number
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8S-3487	Gear As - Ring	221-7949
8S-3491	Housing As	221-7950
8S-3617	Chamber As	247-3302
8S-5438	Muffler As	360-7896
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9J-3346	Plate As - Trunnion	256-4839
9M-1328	Bearing - Aligning	325-6018
9M-3025	Cover As	299-2001
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-8493	Bolt - Connecting Rod	311-9351

Sales Model D9H

Original Part Number	Part Name	Classic Part Number
095-2927	Valve - Fill	360-2292
095-9291	Valve - Fill	360-2293
102-1561	Lifter As - Valve	311-9402
115-0637	Pump Gp	226-0160
190-8609	Valve - Fill	360-2288
1H-4106	Pin As - Drawbar	325-6126
1J-6746	Pin	256-4817
1J-6749	Screw - Adjustable	256-4824
1M-4153	Carrier - Planet	213-1114
1M-4155	Gear - Ring	214-0519
1M-4156	Gear - Ring	214-0520
1M-4167	Shaft - Planet	219-9700
1M-4171	Cage - Bearing	216-7460
1P-2187	Pump Gp	299-2044

Original Part Number	Part Name	Classic Part Number
1P-4145	Valve Gp - Press	247-4436
1P-8005	Gasket - Chamber	314-8527
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0224	Carrier - Ring	239-7928
1T-0228	Housing - Rotating	216-7467
1T-0231	Retainer - Bearing	319-3471
1T-0237	Flange As - Output	239-7929
1T-0256	Gear - Pump Drive	239-7930

Original Part Number	Part Name	Classic Part Number
1T-0595	Carrier - Wheel	239-7939
1T-0611	Converter As	235-1804 (Repair Kit)
1T-1389	Carrier - Bearing	247-4124
1W-3062	Retainer As	311-9445
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-3339	Piston - Clutch	221-7944
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968

(Continued)

Sales Model D9H (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2M-6960	Cage - Gear Bearing	239-7971	3S-9919	Shaft As	239-7959	6H-3957	Bearing - Ball	311-9358
2M-6984	Drum	239-7946	4M-0433	Shaft - Steer	239-7960	6J-2326	Pin	319-3458
2M-8762	Drum - Steering	239-7944	4M-1001	Pump Gp - Final Drive Oil	226-0166	6J-7563	Pin	319-3459
2N-3220	Gear - Oil Pump Drive	311-9392	4M-8967	Gear - Sun	219-9661	6J-8805	Bearing As	256-4841
2N-9297	Retainer - Spring	314-8535	4M-9214	Shaft - Pump Drive	314-8543	6J-9793	Bearing	256-4835
2P-1005	Bearing - Sleeve	296-1342	4M-9215	Gear - Pump Idler	311-9391	6L-7816	Seal - o-Ring	314-8542
2P-1554	Gear - Ring	239-7931	4M-9216	Gear - Pump Drive	311-9390	6L-8585	Gear - Gov Drive	314-8526
2P-1606	Piston - Steering	239-7948	4N-3664	Guide - Valve	314-8524	6N-6969	Chamber As	247-3299
2P-1607	Pilot - Piston	239-7975	4N-5184	Muffler As	360-7874	6N-7295	Manifold - Exhaust	261-0903
2P-4370	Plate - Clutch	325-6166	4N-7526	Seal As - Pump	311-9454	6N-8847	Guide - Valve	314-8523
2P-6159	Pulley - Fan Drive	264-5873	4N-9180	Seal As - Pump	311-9455	6T-4481	Shaft - Planet	221-7946
2S-3966	Ring - Seal	297-7237	4S-5833	Spacer	239-7961	7B-2420	Ferrule - Director	314-8517
2S-7264	Pump As - Fuel Injector	311-9442	4S-8906	Insert	311-9397	7G-2492	Gear - Planet	239-7933
2S-7917	Gear - Pump Drive	247-4119	4S-8908	Insert	311-9399	7G-2500	Gear - Planet	296-1350
2S-8961	Pulley - Tightener	264-5875	4S-8909	Insert - Valve Seat	311-9400	7H-0602	Dog - Clutch	314-8515
2W-9978	Core As - Oil Cooler	279-4983	5D-0470	Valve Gp	314-8549	7J-9884	Bearing - Sleeve	325-6016
3F-6185	Pin	295-5694	5F-7993	Pin	319-3454	7M-1185	Housing As	219-9705
3F-6523	Pin - Clevis	256-4818	5G-3612	Cap Gp	295-6419	7M-1186	Housing As	219-9706
3F-7445	Bearing - Sleeve	314-8508	5H-5553	Screw - Tap-pet Adjustable	311-9451	7M-1195	Housing - Clutch	219-9707
3H-7161	Pin	256-4819	5J-4798	Bearing As	256-4840	7M-4603	Body - Fuel Valve	311-9348
3H-7162	Collar	256-4830	5J-8052	Trunnion	256-4843	7M-4926	Retainer - Pin	314-8538
3J-5190	Cap - Bearing	256-4837	5M-0549	Gear - Transmission	215-1689	7M-7817	Valve - Inlet	311-9474
3J-6043	Trunnion	319-3477	5M-3947	Shaft - Planet	223-6318	7N-9810	Pin - Piston	311-9432
3J-6497	Screw - Adjusting	256-4825	5M-3996	Gear - Ring	214-0527	7S-1579	Nut - Spanner	239-7964
3L-1425	Bearing - Ball	311-9356	5M-3999	Shaft - Transmission	215-1693	7S-5787	Chamber As	247-3300
3P-2811	Flange	239-7976	5M-4427	Gear - Sun	214-0529	7S-6104	Gear - Sun	239-7934
3P-3259	Cage - Bearing	217-7728	5M-7953	Carrier As	239-7977	7S-7400	Pump Gp	226-0173
3P-3935	Shaft	299-2053	5M-7990	Gear - Sun	239-7938	7S-7809	Cap As - Radiator	295-6417
3P-4089	Gear As - Ring	239-7952	5M-8007	Gear - Ring	239-7932	7S-7975	Guard - Final Drive Wear	239-7966
3P-4094	Housing As	239-7954	5N-8879	Manifold - Exhaust	261-0898	7T-2036	Cap As - Filter	361-1721
3P-4096	Gear As - Ring	239-7953	5N-9055	Manifold - Exhaust	261-0890	8E-7455	Gear - Planet	221-7947
3P-6269	Cage - Pinion Bearing	239-7972	5P-7807	Bearing - Ball	314-8502	8E-7456	Gear - Planet	221-7948
3P-9394	Shaft - Planet	215-1680	5S-1211	Cover - Valve	314-8665	8E-9795	Connector As	256-4851
3S-1261	Shaft - Center	239-7958	5S-1757	Insert - Seat	311-9401	8F-8858	Button Valve	314-8511
3S-1262	Retainer	308-9915	5S-5746	Retainer - Guard	319-3472	8H-2810	Case As - Filter	314-8512
			5S-9080	Pulley - Alt Drive	264-5883	8M-0874	Plunger As - Valve	311-9439
						8M-2549	Rod As - Connector	314-8537
						8M-4014	Insert - Seat Exhaust	311-9398

Sales Model D9H (Continued)

Original Part Number	Part Name	Classic Part Number
8M-7166	Housing - Screen	297-7192
8M-8161	Flange - Shaft	215-1781
8N-0597	Pulley	264-5890
8N-2275	Bearing - Sleeve	311-9365
8N-3723	Valve - Exhaust	311-9472
8N-7780	Shield - Oil	314-8544
8N-9174	Liner - Cylinder	314-8531
8P-4734	Housing As	239-7955

Original Part Number	Part Name	Classic Part Number
8P-4735	Piston - Clutch	239-7949
8P-7396	Hub - Planet Gear	239-7967
8P-7595	Washer - Thrust	239-7940
8P-7639	Gear - Planet	239-7935
8S-3617	Chamber As	247-3302
9G-7993	Cage - Gr Bearing Rh	239-7973
9H-5233	Piston - Clutch	219-9708

Original Part Number	Part Name	Classic Part Number
9H-5433	Spacer	239-7963
9J-3346	Plate As - Trunnion	256-4839
9K-8757	Rod End - Bearing	311-9361
9M-3025	Cover As	299-2001
9P-3663	Carrier - Planet	213-6939
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9S-8493	Bolt - Connecting Rod	311-9351

Cat® Classic™ Parts for Wheel Loaders

Cat® wheel loaders are designed to deliver exceptional performance, ease of serviceability, and to have long, productive lives. The residual value of a machine depreciates as it gets older, so maintenance costs often need to be re-evaluated. Caterpillar offers Cat® Classic™ parts for several models of wheel loaders (920, 930, 950/B/E, 966A/B/C/D/E, 980/B/C) to help you manage those maintenance costs.

Cat Classic parts provide owners of older Cat products with low cost repair alternatives that minimize the risk associated with non-genuine parts.

Cat Classic parts coverage for wheel loaders includes:

- Axle Final Drive
- Circle/Center Shift Linkage Pin
- Differential Torque Converter
- Engine
- Final Drive
- Transmission
- ...and many more.

Sales Model 920

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761

Original Part Number	Part Name	Classic Part Number
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-0851	Impeller - Converter	253-1418
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-1409	Carrier - Planet	253-1423
1V-1554	Spindle	219-2972
1V-4838	Link As - Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980

Original Part Number	Part Name	Classic Part Number
1W-1698	Housing - Transfer Pump	296-1356
1W-1766	Muffler As	298-2783
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
2F-5721	Bearing - Ball	311-9354
2K-4502	Bearing - Sleeve	299-1986
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691

(Continued)



Sales Model 920 (Continued)

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3K-3124	Muffler - Trap	247-2673
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3P-3208	Flange - Joint	301-4647
3S-2616	Pump Gp - Transmission	226-0165
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3V-7427	Housing As	297-7197
4F-4974	Clamp	311-9373
4J-3015	Shaft	325-6204
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115

Original Part Number	Part Name	Classic Part Number
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4V-9577	Shaft - Planet	231-0001
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419
5M-7882	Joint Gp - Univ	297-7210
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-2703	Pin - Lower	252-6853
6K-2704	Pin - Upper	252-6873
6K-2707	Plate - Lock	319-3470
6K-3447	Pin	241-2576
6K-3674	Shaft - Bevel Pinion	253-1427
6K-5448	Pin	252-6856
6K-5472	Pin	252-6857
6K-5619	Shaft	253-1429
6K-5621	Retainer - Oil Seal	253-1443
6K-5625	Gear - Bevel Ring	253-1438
6K-6175	Pin	241-2606
6K-6185	Pin - Cylinder	252-6859
6K-6349	Pin	252-6860
6K-7285	Pin	252-6861
6K-7288	Pin	252-6862
6K-8314	Pin	252-6863
6K-8316	Pin	252-6865

Original Part Number	Part Name	Classic Part Number
6K-8542	Pin	252-6867
6K-8544	Pin	252-6874
6K-8546	Pin	252-6868
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
6S-3759	Pin As	241-2543
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-6461	Crown	325-6054
7J-9842	Bearing - Sleeve	299-1968
7K-0252	Gear - Ring	231-0008
7K-5213	Pin	252-6869
7K-6497	Pin	252-6870
7K-7237	Gear - Planet	231-0009
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994

(Continued)

Sales Model 920 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7N-9805	Pin - Piston	295-6438	8N-1188	Head Gp - Cylinder	242-3436	8N-9733	Line As - Fuel Injector	319-8174
7S-3161	Lifter - Valve	279-4996	8N-1721	Rod As - Conn	269-5291	8S-0248	Breather As	325-6033
7S-6723	Bracket - Alternator	299-1978	8N-1965	Tube - Disposal	325-6235	8S-0493	Shaft As - Pump	325-6198
7S-7070	Head As - Cylinder	325-6107	8N-1984	Rod As - Conn	242-3441	8S-3970	Chamber As	242-3438
7S-7809	Cap As - Radiator	295-6417	8N-2510	Shaft	325-6208	8V-3134	Pinion - Bevel	260-0788
7S-9749	Pulley - Gen Drive	264-5888	8N-2641	Sleeve	325-6210	8V-3135	Gear - Differential Bevel	260-0783
7W-0450	Gear - Water Pump	279-4997	8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)	8V-3136	Gear - Differential Bevel	253-1442
7W-0507	Gear - Oil Pump Drive	279-4998	8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)	9H-2256	Pump Gp	311-9443
7W-0508	Gear - Fuel Pump Drive	296-1351	8N-3251	Shaft As - Rocker Arm	314-8711	9M-4789	Shaft - Gov Control	297-7256
7W-5687	Hub - Camshaft	314-8684	8N-3311	Shaft As - Rocker Arm	325-6199	9N-5769	Cover - Housing	325-6050
8H-2810	Case As - Filter	314-8512	8N-3312	Shaft As - Rocker Arm	325-6200	9S-2356	Manifold - Exhaust	261-0905
8H-9806	Gear - Shaft Drive	325-6091	8N-3325	Arm Gp - Rocker	314-8623	9S-6129	Pulley - Alternator Drive	264-5891
8K-6320	Shaft - Axle	253-1430	8N-3327	Arm Gp - Rocker	314-8624	9S-8679	Chamber As	325-6042
8K-6321	Gear - Sun	253-1441	8N-5929	Cover - Water Pump	296-1349	9Y-2992	Bearing - Sleeve	325-6032
8M-0874	Plunger As - Valve	311-9439	8N-6796	Head Gp - Cylinder	269-5290	244-1090	Alarm - Backup	360-2345
8N-0002	Trunnion As	314-8728	8N-7315	Tube As - Outlet	325-6232	1M-7250	Bowl - Precleaner	360-2296
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8N-7780	Shield - Oil	314-8544	7J-9682	Bearing - Sleeve	360-2335
8N-1187	Head Gp - Cylinder	242-3435	8N-8225	Bearing - Main	314-8652	7K-9593	Bearing - Sleeve	360-2337
						7T-2036	Cap As - Filter	361-1721
						121-7746	Precleaner As	360-2311
						7K-9592	Bearing - Sleeve	360-2336

Sales Model 930

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	121-7746	Precleaner As	360-2311	172-5189	Impeller - Pump	295-5687
104-4253	Line As - Fuel Injector	279-4988	131-3815	Seal Gp - Basic	325-6193	172-5190	Impeller - Pump	325-6111
104-4254	Line As - Fuel Injector	279-4989	148-7455	Valve - Exhaust	270-4361	172-6712	Impeller - Pump	325-6112
111-8015	Gasket As - Head	279-4977	165-4262	Body As - Piston	270-4353 (Liner Kit)	172-7767	Pump Gp - Water	296-1365
112-3249	Muffler As	247-2661	172-5185	Shaft - Water Pump	325-6201	1M-7250	Bowl - Precleaner	360-2296
115-7550	Gasket - Plate	314-8667	172-5188	Shaft - Water Pump	325-6202	1N-3576	Block Gp - Cylinder	279-4978
						1N-3958	Elbow	325-6087

(Continued)

Sales Model 930 (Continued)

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-0851	Impeller - Converter	253-1418
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-3335	Carrier - Planet	253-1424
1V-4718	Spindle	223-4817
1V-4838	Link As - Spring	308-9874
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-3592	Boss	314-8501

Original Part Number	Part Name	Classic Part Number
2K-4502	Bearing - Sleeve	299-1986
2K-4513	Bearing - Sleeve	308-9814
2K-8753	Gear - Diff	253-1432
2K-8754	Gear - Diff Bevel	253-1433
2P-1170	Shaft As - Gear	296-1367
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-4404	Housing As	226-8027
2P-4409	Gear - Ring	226-7981
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2P-6255	Muffler As	247-2666
2P-7828	Pan - Oil	314-8691
2V-5881	Gear - Bevel Ring	253-1434
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
2Y-4213	Pulley	314-8703
3J-6502	Pin	319-3453
3K-3124	Muffler - Trap	247-2673
3K-5461	Wheel - Steering	308-9945
3K-7110	Gear - Planet	253-1435
3K-7111	Gear - Sun	253-1436
3K-7112	Gear - Ring	253-1437
3L-1425	Bearing - Ball	311-9356
3P-0114	Elbow - Exhaust	314-8516
3P-3208	Flange - Joint	301-4647

Original Part Number	Part Name	Classic Part Number
3S-2616	Pump Gp - Transmission	226-0165
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3V-7427	Housing As	297-7197
4F-4974	Clamp	311-9373
4J-3015	Shaft	325-6204
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8591	Coupling - Exhaust	325-6053
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8713	Gear - Ring	226-6090
4W-0452	Seal As - Camshaft	325-6191
5G-3612	Cap Gp	295-6419

(Continued)

Sales Model 930 (Continued)

Original Part Number	Part Name	Classic Part Number
5K-7995	Bearing - Sleeve	308-9820
5M-7882	Joint Gp - Univ	297-7210
5P-7807	Bearing - Ball	314-8502
5S-0884	Gear - Ring	226-7982
5S-1211	Cover - Valve	314-8665
5S-6795	Chamber As	242-3437
5S-7609	Pulley - Alt Drive	264-5881
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-3447	Pin	241-2576
6K-4180	Pin - Upper	252-6854
6K-4190	Cap - Lower	297-7161
6K-4191	Cap - Upper	300-2576
6K-4192	Pin - Lower	252-6855
6K-4193	Plate - Lock	282-6566
6K-6046	Pin	241-2602
6K-6047	Pin	241-2603
6K-6051	Pin	252-6858
6K-6053	Pin	241-2604
6K-6054	Pin	241-2605
6K-6175	Pin	241-2606
6K-6185	Pin - Cylinder	252-6859
6K-6349	Pin	252-6860
6N-1036	Gear - Oil Pump	279-4991
6N-1553	Coupling - Exhaust	295-6422
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-7704	Carrier - Ring	314-8658
6S-3759	Pin As	241-2543
7C-4297	Seal As - Camshaft	325-6192
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2830	Ring - Seal	295-6441
7J-9682	Bearing - Sleeve	360-2335

Original Part Number	Part Name	Classic Part Number
7J-9842	Bearing - Sleeve	299-1968
7K-7176	Pin	241-2570
7K-7195	Bearing - Sleeve	325-6025
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9601	Bearing - Sleeve	360-2338
7K-9602	Bearing - Sleeve	360-2339
7K-9604	Bearing - Sleeve	308-9829
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997

Original Part Number	Part Name	Classic Part Number
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5991	Gear - Diff Bevel	253-1439
8K-5999	Gear - Sun	253-1440
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232

(Continued)

Sales Model 930 (Continued)

Original Part Number	Part Name	Classic Part Number
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033

Original Part Number	Part Name	Classic Part Number
8S-0493	Shaft As - Pump	325-6198
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
9H-2256	Pump Gp	311-9443
9M-4789	Shaft - Gov Control	297-7256

Original Part Number	Part Name	Classic Part Number
9N-5769	Cover - Housing	325-6050
9S-2356	Manifold - Exhaust	261-0905
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 950

Original Part Number	Part Name	Classic Part Number
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7010	Shaft - Planet	221-9104
5S-7609	Pulley - Alt Drive	264-5881
5S-7888	Retainer - Bearing	226-5988
5S-8038	Pulley - Crankshaft	264-5882
5S-9080	Pulley - Alt Drive	264-5883
5V-5661	Bearing - Sleeve	299-1965
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-2085	Shaft - Bevel Pinion	221-9102
6K-3937	Pin	241-2557
6K-4600	Yoke	226-5993
6K-5513	Pin	241-2558
6K-7161	Pin	241-2559
6K-7162	Pin	241-2560
6K-7164	Pin	241-2561
6K-7165	Pin	241-2562
6K-7166	Pin - Arm Pivot	241-2563
6K-7167	Pin	241-2569
6K-7287	Pin	241-2564
6K-9841	Cam & Lever As	226-5997
6L-8968	Coupling - Exhaust	311-9381
6N-1036	Gear - Oil Pump	279-4991

Original Part Number	Part Name	Classic Part Number
6N-1553	Coupling - Exhaust	295-6422
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6S-3759	Pin As	241-2543
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7C-4297	Seal As - Camshaft	325-6192
7G-2477	Gear - Planet	221-9090
7G-2485	Gear - Planet	226-7983
7G-2487	Gear - Planet	221-9092
7G-2520	Gear - Planet	221-9094
7G-3454	Gear - Planet	300-2578
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-0686	Trunnion - Rear	297-7266
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7176	Pin	241-2570
7K-7195	Bearing - Sleeve	325-6025
7K-9343	Pin	241-2571
7K-9361	Pin	241-2565
7M-2167	Ring - Governor Control	308-9919
7M-4358	Manifold - Exhaust	261-0907
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774

Original Part Number	Part Name	Classic Part Number
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-8117	Muffler As	247-2668
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-2980	Plate - Reaction	226-5998
7S-3033	Hub - Clutch	226-5985
7S-3161	Lifter - Valve	279-4996
7S-4494	Piston - Clutch	226-5999
7S-4629	Pump Gp - Transfer	226-0158
7S-6723	Bracket - Alternator	299-1978
7S-7070	Head As - Cylinder	325-6107

(Continued)

Sales Model 950 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7S-7809	Cap As - Radiator	295-6417	8N-6796	Head Gp - Cylinder	269-5290	165-4262	Body As - Piston	270-4353 (Liner Kit)
7S-8443	Muffler	247-2675	8N-7315	Tube As - Outlet	325-6232	172-5185	Shaft - Water Pump	325-6201
7S-8572	Gear - Ring	221-9095	8N-7780	Shield - Oil	314-8544	172-5188	Shaft - Water Pump	325-6202
7S-9749	Pulley - Gen Drive	264-5888	8N-8225	Bearing - Main	314-8652	172-5189	Impeller - Pump	295-5687
7W-0450	Gear - Water Pump	279-4997	8N-9733	Line As - Fuel Injector	319-8174	172-5190	Impeller - Pump	325-6111
7W-0507	Gear - Oil Pump Drive	279-4998	8P-1918	Gear - Planet	283-5210	172-6712	Impeller - Pump	325-6112
7W-0508	Gear - Fuel Pump Drive	296-1351	8S-0248	Breather As	325-6033	172-7767	Pump Gp - Water	296-1365
7W-5687	Hub - Camshaft	314-8684	8S-0493	Shaft As - Pump	325-6198	1A-2846	Cap As - Filler	311-9368
8H-2810	Case As - Filter	314-8512	8S-0556	Coupling	221-9114	1N-3576	Block Gp - Cylinder	279-4978
8H-9806	Gear - Shaft Drive	325-6091	8S-2809	Muffler	247-2677	1N-3958	Elbow	325-6087
8K-5283	Plate	299-2043	8S-3970	Chamber As	242-3438	1N-4304	Head Gp - Cylinder	269-8761
8K-5758	Pin	241-2566	8V-3134	Pinion - Bevel	260-0788	1P-0320	Retainer - Bearing	226-5987
8K-6015	Gear - Bevel Ring	221-9076	8V-3135	Gear - Differential Bevel	260-0783	1P-1216	Manifold - Exhaust	261-0902
8K-6283	Gear - Sun	221-9077	8V-3136	Gear - Differential Bevel	253-1442	1P-1721	Gear - Balance	298-2769
8M-3224	Muffler	247-2676	8V-7175	Pin	241-2567	1P-1722	Gear - Balance	298-2770
8N-0002	Trunnion As	314-8728	8V-7176	Pin	241-2568	1P-5262	Cage - Bearing	226-5989
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	9C-4811	Hub As	224-1300	1P-5480	Cover As - End	299-1998
8N-1187	Head Gp - Cylinder	242-3435	9H-2256	Pump Gp	311-9443	1P-9945	Bracket As - Fan	296-1344
8N-1188	Head Gp - Cylinder	242-3436	9K-3413	Gear - Bevel Ring	223-4807	1P-9946	Shaft - Fan	325-6194
8N-1721	Rod As - Conn	269-5291	9M-4163	Valve - Exhaust	298-2773	1P-9952	Impeller - Pump	314-8685
8N-1984	Rod As - Conn	242-3441	9M-4789	Shaft - Gov Control	297-7256	1S-1888	Bracket - Lamp	297-7147
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)	9N-5769	Cover - Housing	325-6050	1S-4701	Pulley - Alt	264-5866
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)	9P-6888	Shaft - Output	221-9105	1T-0020	Wheel - Turbine	297-4862
8N-3251	Shaft As - Rocker Arm	314-8711	9S-2355	Manifold - Exhaust	261-0891	1T-1428	Retainer - Bearing	300-2587
8N-3311	Shaft As - Rocker Arm	325-6199	9S-6129	Pulley - Alternator Drive	264-5891	1T-1987	Housing - Rotating	297-4864
8N-3312	Shaft As - Rocker Arm	325-6200	9S-8679	Chamber As	325-6042	1V-1080	Housing - Bearing Spt	260-0775
8N-3325	Arm Gp - Rocker	314-8623	9Y-2992	Bearing - Sleeve	325-6032	1V-1687	Wheel	226-5990
8N-3327	Arm Gp - Rocker	314-8624	100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)	1V-2281	Carrier - Planet	226-5984
8N-5929	Cover - Water Pump	296-1349	111-8015	Gasket As - Head	279-4977	1V-2992	Gear - Diff Bevel	224-1301
			115-7550	Gasket - Plate	314-8667			
			131-3815	Seal Gp - Basic	325-6193			
			148-7455	Valve - Exhaust	270-4361			

(Continued)

Sales Model 950 (Continued)

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
1V-3995	Pin	319-3449
1V-5724	Diff Gp	260-0776
1V-8655	Lever As	226-5991
1V-9208	Link As - Rear	299-2020
1W-1219	Trunnion As	314-8724
1W-1766	Muffler As	298-2783
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4402	Gear - Cam-shaft	279-4981
1W-4405	Gear - Crank-shaft	279-4982
2F-5721	Bearing - Ball	311-9354
2J-1506	Pin	319-3451
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2K-8753	Gear - Diff	253-1432
2K-8754	Gear - Diff Bevel	253-1433
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2744	Muffler As	247-2664
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-4015	Plunger As - Valve	311-9438

Original Part Number	Part Name	Classic Part Number
2V-5881	Gear - Bevel Ring	253-1434
2V-6220	Shaft - Planet	221-9073
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3H-3378	Gear As - Pump	298-2795
3K-0963	Pin - Lock	308-9895
3K-2498	Shaft - Planet	216-7824
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3K-7110	Gear - Planet	253-1435
3K-7111	Gear - Sun	253-1436
3K-7112	Gear - Ring	253-1437
3L-1425	Bearing - Ball	311-9356
3P-5672	Yoke	223-6313
3S-1167	Gear - Planet	221-9101
3S-2616	Pump Gp - Transmission	226-0165
3V-7427	Housing As	297-7197
4F-4974	Clamp	311-9373
4J-3015	Shaft	325-6204
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-5109	Gear - Reverse	219-9659
4K-6212	Shaft - Bevel Pinion	223-4806
4K-7251	Cover	299-2003
4K-7269	Support	299-2067
4K-7420	Retainer	297-7234
4K-8416	Shaft	308-9927
4K-9598	Retainer	297-7235
4N-2954	Sleeve - Cam-shaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362

Original Part Number	Part Name	Classic Part Number
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-3546	Valve As - Relief	325-6236
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5981	Gear - Ring	221-9084
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4V-0015	Plate - Lock	282-6563
4V-0381	Bearing - Sleeve	299-1963
4V-5454	Link	299-2025
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5G-3612	Cap Gp	295-6419
5K-0609	Cover	308-9843
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0990	Pin	299-2035
5K-0991	Cap - Lower	319-3433
5K-1068	Retainer - Seal	260-0786
5K-2570	Spacer	226-5996
5K-5933	Cover As	247-4125
5K-7995	Bearing - Sleeve	308-9820
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406

(Continued)

Sales Model 950 (Continued)

Original Part Number	Part Name	Classic Part Number
5S-1833	Chamber As	247-3298
5S-4493	Carrier - Planet	223-6321
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-6972	Gear - Sun	221-9087

Original Part Number	Part Name	Classic Part Number
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
244-1090	Alarm - Back up	360-2345
7J-9682	Bearing - Sleeve	360-2335

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
7J-9344	Bearing - Sleeve	360-2334
7T-2036	Cap As - Filter	361-1721
1M-7250	Bowl - Pre-cleaner	360-2296
2K-6413	Pin	360-2270

Sales Model 950B, 950E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
114-9036	Shaft - Input	297-4859
115-0637	Pump Gp	226-0160
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
176-9273	Piston	297-4860
1M-7250	Bowl - Pre-cleaner	360-2296
1N-2936	Muffler As	298-2782

Original Part Number	Part Name	Classic Part Number
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1N-4304	Head Gp - Cylinder	269-8761
1P-1216	Manifold - Exhaust	261-0902
1P-1721	Gear - Balance	298-2769
1P-1722	Gear - Balance	298-2770
1P-5480	Cover As - End	299-1998
1P-7590	Support As	213-4400
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-1331	Stator - Converter	229-8237
1T-1428	Retainer - Bearing	300-2587
1T-1480	Turbine As - Converter	235-1818
1T-1691	Impeller - Converter	297-4863
1T-1987	Housing - Rotating	297-4864
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356

Original Part Number	Part Name	Classic Part Number
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2P-7828	Pan - Oil	314-8691
2S-7064	Cap - Shaft Bearing	299-1991
2V-5697	Cover As	299-1999
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987

(Continued)

Sales Model 950B, 950E (Continued)

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
2V-5722	Carrier - Planet	297-7164
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3L-1425	Bearing - Ball	311-9356
3P-3935	Shaft	299-2053
3P-8283	Spacer	325-6215
3T-3447	Gear As - Sun	302-2676
3T-4223	Gear - Transfer	319-3438
3T-4224	Gear - Transfer	297-7175
3T-6795	Piston - Clutch	281-1693
3T-9496	Plate - Retainer	299-2042
3V-2337	Pin As	319-3440
3V-8777	Gear - Spiral	297-7176
4E-3196	Pin As	361-1697
4E-5213	Cover As	299-2000
4E-8534	Retainer - Seal	300-2588
4F-4974	Clamp	311-9373
4J-6167	Bearing - Sleeve	325-6009
4K-6810	Retainer - Seal	300-2586
4K-7269	Support	299-2067
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4P-3546	Valve As - Relief	325-6236

Original Part Number	Part Name	Classic Part Number
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4V-0015	Plate - Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-6430	Bracket As	299-1974
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8534	Shaft - Planet	281-1700
4V-8538	Gear - Ring	288-8720
4V-8674	Bearing - Bushing	307-1529
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4W-0452	Seal As - Camshaft	325-6191
4W-2446	Damper As	279-4990
5D-0470	Valve Gp	314-8549
5G-3612	Cap Gp	295-6419
5J-4321	Trunnion	302-2700
5K-0871	Pin - Lower	282-6630
5K-0989	Cap - Upper	297-7158
5K-0991	Cap - Lower	319-3433
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-1508	Pin As	361-1703
5V-1509	Pin As	319-3443
5V-1510	Pin As	252-6876
5V-1882	Pin As	361-1700

Original Part Number	Part Name	Classic Part Number
5V-5917	Pinion - Diff Bevel	297-7224
5V-8782	Lever As	299-2014
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6I-9034	Guard As	295-6435
6J-9258	Trunnion As	256-4846
6K-8897	Bracket As	299-1977
6N-1036	Gear - Oil Pump	279-4991
6N-8413	Housing - Pump	325-6110
6P-2233	Gear - Planet	281-1690
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8003	Gear - Planet	281-1689
6P-8005	Gear - Planet	281-1691
6T-0830	Housing As	297-7199
6T-3009	Piston - Clutch	297-7226
6T-6987	Piston - Clutch	297-7227
6W-1629	Shaft - Bevel Pinion	297-7250
6Y-7877	Housing As	297-7200
7C-5851	Muffler As	298-2790
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-4281	Housing As - Support	297-7201
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-5444	Carrier - Planet	297-7165
7G-5572	Gear - Sun	300-2580
7G-5589	Gear - Ring	281-1692
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-6060	Plate - Center	302-2694
7G-6062	Gear - Ring	302-2678
7G-9721	Gear As - Oil Pump	297-7178
7G-9722	Gear - Pump Drive	297-7179
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015

(Continued)

Sales Model 950B, 950E (Continued)

Original Part Number	Part Name	Classic Part Number
7J-4827	Yoke	299-2070
7J-6461	Crown	325-6054
7J-9884	Bearing - Sleeve	325-6016
7K-0686	Trunnion - Rear	297-7266
7K-9528	Bearing - Sleeve	308-9828
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-7809	Cap As - Radiator	295-6417
7T-0119	Support As	299-2066
7T-1285	Gear - Planet	297-7190
7T-2036	Cap As - Filter	361-1721
7T-3343	Plate - Clutch	297-7231
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5684	Pulley - Camshaft	298-2771
7W-5685	Pulley - Camshaft	298-2772
7W-5698	Pulley - Camshaft	295-5679
8D-2628	Nut	299-2027
8E-6221	Pin	325-6155
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8J-2880	Cap - Bearing	295-6420
8K-6282	Gear - Sun	281-1698

Original Part Number	Part Name	Classic Part Number
8K-6285	Shaft - Axle	299-2057
8M-0874	Plunger As - Valve	311-9439
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5388	Muffler As	360-7895
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9402	Coupling	325-6048
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-7659	Pin As	361-1702
9C-1528	Gear - Planet	223-4802
9C-5852	Hub As	297-7208

Original Part Number	Part Name	Classic Part Number
9C-8204	Shaft - Bevel Pinion	319-3474
9C-8205	Gear - Bevel	319-8175
9C-9191	Trunnion	302-2701
9C-9773	Gear - Differential Bevel	302-2672
9G-1231	Plate	297-7232
9G-1491	Carrier - Planet	281-1685
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9G-8117	Housing As	302-2686
9G-9764	Yoke As	319-3478
9J-7964	Bearing - Spherical	325-6017
9K-8757	Rod End - Bearing	311-9361
9M-1328	Bearing - Aligning	325-6018
9M-4789	Shaft - Gov Control	297-7256
9N-4460	Housing As	297-7203
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807
9V-2410	Housing - Bearing	302-2679
9V-2411	Housing - Bearing	302-2680
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-0517	Carrier - Planet	281-1686
9W-4949	Carrier - Planet	281-1687
9W-4950	Gear - Sun	281-1688
9Y-2992	Bearing - Sleeve	325-6032

Sales Model 966A

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1H-8262	Shaft	226-8016
1M-7250	Bowl - Pre-cleaner	360-2296
1S-1888	Bracket - Lamp	297-7147
1T-0020	Wheel - Turbine	297-4862
1T-0553	Gear As - Pump Drive	226-5983
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-2992	Gear - Diff Bevel	224-1301
1V-5724	Diff Gp	260-0776
1W-4405	Gear - Crankshaft	279-4982
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2S-4015	Plunger As - Valve	311-9438
3H-3378	Gear As - Pump	298-2795
3K-0963	Pin - Lock	308-9895

Original Part Number	Part Name	Classic Part Number
3K-2498	Shaft - Planet	216-7824
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3K-7021	Gear - Ring	221-9075
3L-1425	Bearing - Ball	311-9356
3S-2616	Pump Gp - Transmission	226-0165
3V-2281	Link As	299-2023
4K-9598	Retainer	297-7235
5K-1068	Retainer - Seal	260-0786
5K-5927	Boss	299-1973
5K-7995	Bearing - Sleeve	308-9820
5K-8265	Pin	241-2590
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5V-5279	Bearing - Sleeve	299-1966
6K-7284	Pin	241-2591
6K-7286	Pin	241-2592
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
7B-2420	Ferrule - Director	314-8517
7G-3454	Gear - Planet	300-2578
7J-9344	Bearing - Sleeve	360-2334
7J-9682	Bearing - Sleeve	360-2335
7K-0686	Trunnion - Rear	297-7266
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597

Original Part Number	Part Name	Classic Part Number
7K-9515	Pin	241-2589
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6015	Gear - Bevel Ring	221-9076
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
8P-1918	Gear - Planet	283-5210
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9H-2256	Pump Gp	311-9443
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9M-4163	Valve - Exhaust	298-2773

Sales Model 966B

Original Part Number	Part Name	Classic Part Number
1A-2846	Cap As - Filler	311-9368
1S-1888	Bracket - Lamp	297-7147
1T-0020	Wheel - Turbine	297-4862
1T-0553	Gear As - Pump Drive	226-5983

Original Part Number	Part Name	Classic Part Number
1T-1428	Retainer - Bearing	300-2587
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-2992	Gear - Diff Bevel	224-1301

Original Part Number	Part Name	Classic Part Number
1V-5724	Diff Gp	260-0776
1W-4405	Gear - Crankshaft	279-4982
2J-1506	Pin	319-3451
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501

(Continued)

Sales Model 966B (Continued)

Original Part Number	Part Name	Classic Part Number
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2K-6413	Pin	360-2270
2S-4015	Plunger As - Valve	311-9438
2S-6739	Pulley - Tight-ener	298-2794
2V-4332	Collar	299-1993
2V-6221	Shaft - Planet	221-9108
3H-3378	Gear As - Pump	298-2795
3K-0963	Pin - Lock	308-9895
3K-2498	Shaft - Planet	216-7824
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3L-1425	Bearing - Ball	311-9356
3V-2281	Link As	299-2023
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-6212	Shaft - Bevel Pinion	223-4806
4K-6558	Pin - Lower	302-2710
4K-6736	Drum - Brake	223-6320
4K-6737	Gear - Ring	221-9097
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-6835	Gear - Output	226-5994
4K-7251	Cover	299-2003
4K-7269	Support	299-2067
4K-7420	Retainer	297-7234
4K-8225	Pin - Cylinder	297-7215
4K-8416	Shaft	308-9927
4K-8561	Pin	299-2036

Original Part Number	Part Name	Classic Part Number
4K-8734	Bearing - Sleeve	299-1962
4K-9598	Retainer	297-7235
4V-0015	Plate - Lock	282-6563
5F-6393	Shaft	308-9928
5K-0609	Cover	308-9843
5K-2570	Spacer	226-5996
5K-5927	Boss	299-1973
5K-5933	Cover As	247-4125
5K-7995	Bearing - Sleeve	308-9820
5K-8265	Pin	241-2590
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-1822	Chamber As	248-5406
5S-1833	Chamber As	247-3298
5S-4557	Bearing	311-9360
5V-5279	Bearing - Sleeve	299-1966
6K-4498	Bracket As - Lh	299-1976
6K-4600	Yoke	226-5993
6K-7284	Pin	241-2591
6K-7286	Pin	241-2592
6K-8307	Pin	241-2593
6K-8308	Pin	241-2594
6K-8309	Pin	241-2595
6K-8311	Pin	241-2599
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7G-3454	Gear - Planet	300-2578
7J-9344	Bearing - Sleeve	360-2334
7J-9366	Bearing - Sleeve	299-1985
7J-9682	Bearing - Sleeve	360-2335
7J-9731	Bearing - Sleeve	308-9822
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion - Rear	297-7266
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7200	Pin	241-2600
7K-7613	Joint Gp - Slip	302-2689

Original Part Number	Part Name	Classic Part Number
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341
7M-4204	Manifold - Exhaust	261-0901
7M-4603	Body - Fuel Valve	311-9348
7M-7358	Valve - Inlet	298-2774
7N-5511	Gear As - Idler	233-2180
7S-7809	Cap As - Radiator	295-6417
7S-9749	Pulley - Gen Drive	264-5888
7T-2036	Cap As - Filter	361-1721
8F-9365	Pin	319-3463
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8M-3224	Muffler	247-2676
8N-8225	Bearing - Main	314-8652
8P-1918	Gear - Planet	283-5210
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-4811	Hub As	224-1300
9H-2256	Pump Gp	311-9443
9K-1193	Gear - Sun	221-9099
9K-3413	Gear - Bevel Ring	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9M-4163	Valve - Ex-haust	298-2773
9M-8281	Gear As - Oil Pump	325-6089
9M-8284	Pump Gp - Transmission	226-0159

Sales Model 966C

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
114-9036	Shaft - Input	297-4859
115-0637	Pump Gp	226-0160
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
176-9273	Piston	297-4860
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4231	Pump Gp - Gear	226-0156
1P-4303	Head As - Cylinder	242-3434
1P-5262	Cage - Bearing	226-5989
1P-8554	Coupling - Exhaust	325-6052
1P-9945	Bracket As - Fan	296-1344

Original Part Number	Part Name	Classic Part Number
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1T-0020	Wheel - Turbine	297-4862
1T-0553	Gear As - Pump Drive	226-5983
1T-1428	Retainer - Bearing	300-2587
1T-1691	Impeller - Converter	297-4863
1T-1987	Housing - Rotating	297-4864
1V-1080	Housing - Bearing Spt	260-0775
1V-2992	Gear - Diff Bevel	224-1301
1V-3995	Pin	319-3449
1V-5724	Diff Gp	260-0776
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2F-5721	Bearing - Ball	311-9354
2J-1506	Pin	319-3451
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989

Original Part Number	Part Name	Classic Part Number
2K-5977	Yoke	226-5992
2K-6413	Pin	360-2270
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-5609	Muffler As	247-2665
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2S-4015	Plunger As - Valve	311-9438
2V-4332	Collar	299-1993
2V-6221	Shaft - Planet	221-9108
2V-7083	Yoke	224-1302
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-9978	Core As - Oil Cooler	279-4983
3F-7445	Bearing - Sleeve	314-8508
3K-0963	Pin - Lock	308-9895
3K-5461	Wheel - Steering	308-9945
3K-7020	Gear - Planet	221-9074
3L-1425	Bearing - Ball	311-9356
3P-3450	Yoke	229-8225
3P-5672	Yoke	223-6313
3S-1167	Gear - Planet	221-9101
3T-3447	Gear As - Sun	302-2676
3T-4223	Gear - Transfer	319-3438
3T-4224	Gear - Transfer	297-7175

(Continued)

Sales Model 966C (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
3T-6795	Piston - Clutch	281-1693	4P-9385	Line As - Fuel Injector	279-4986	6K-0053	Housing	297-7191
3T-9496	Plate - Retainer	299-2042	4P-9386	Line As - Fuel Injector	279-4987	6K-2034	Shaft	297-7249
3V-2281	Link As	299-2023	4S-5943	Piston - Clutch	221-9112	6K-2036	Rack	299-2045
3V-7427	Housing As	297-7197	4S-5944	Gear - Sun	221-9078	6K-4498	Bracket As - Lh	299-1976
4F-4974	Clamp	311-9373	4S-5945	Gear - Sun	221-9079	6K-4600	Yoke	226-5993
4K-3004	Bearing - Trunnion Support	314-8632	4S-5947	Gear - Ring	221-9080	6K-6046	Pin	241-2602
4K-3128	Bearing - Sleeve	314-8633	4S-5948	Gear - Ring	221-9082	6K-6047	Pin	241-2603
4K-6212	Shaft - Bevel Pinion	223-4806	4S-5981	Gear - Ring	221-9084	6K-6053	Pin	241-2604
4K-6558	Pin - Lower	302-2710	4S-5981	Gear - Ring	221-9084	6K-6054	Pin	241-2605
4K-6736	Drum - Brake	223-6320	4S-8530	Shaft - Planet	221-9111	6K-6175	Pin	241-2606
4K-6737	Gear - Ring	221-9097	4S-8534	Shaft As - Planet	221-9116	6K-7284	Pin	241-2591
4K-6760	Cap - Lower	300-2574	4V-0015	Plate - Lock	282-6563	6K-7286	Pin	241-2592
4K-6761	Cap - Upper	300-2575	4W-0452	Seal As - Camshaft	325-6191	6K-8307	Pin	241-2593
4K-6810	Retainer - Seal	300-2586	5D-0470	Valve Gp	314-8549	6K-8308	Pin	241-2594
4K-7251	Cover	299-2003	5F-6393	Shaft	308-9928	6K-8309	Pin	241-2595
4K-7269	Support	299-2067	5G-3612	Cap Gp	295-6419	6K-8311	Pin	241-2599
4K-7420	Retainer	297-7234	5K-0609	Cover	308-9843	6K-8897	Bracket As	299-1977
4K-8225	Pin - Cylinder	297-7215	5K-5927	Boss	299-1973	6N-1036	Gear - Oil Pump	279-4991
4K-8416	Shaft	308-9927	5K-5933	Cover As	247-4125	6N-1965	Line As - Fuel Injector	250-7535
4K-8561	Pin	299-2036	5K-7995	Bearing - Sleeve	308-9820	6N-1966	Line As - Fuel Injector	250-7536
4K-8734	Bearing - Sleeve	299-1962	5K-8265	Pin	241-2590	6N-2789	Pulley	264-5886
4K-9598	Retainer	297-7235	5P-7807	Bearing - Ball	314-8502	6N-8413	Housing - Pump	325-6110
4N-2954	Sleeve - Camshaft	299-2059	5S-1211	Cover - Valve	314-8665	6P-2233	Gear - Planet	281-1690
4N-3281	Line As - Fuel Injector	247-3362	5S-4359	Pump Gp - Transmission	226-0157	6P-7742	Shaft - Planet	281-1695
4N-3282	Line As - Fuel Injector	247-3363	5S-4493	Carrier - Planet	223-6321	6P-7743	Shaft - Planet	281-1696
4N-3283	Line As - Fuel Injector	247-3364	5S-4557	Bearing	311-9360	6P-8003	Gear - Planet	281-1689
4N-7692	Crankshaft As	242-3440	5S-6795	Chamber As	242-3437	6P-8005	Gear - Planet	281-1691
4N-7693	Crankshaft As	242-3439	5S-6972	Gear - Sun	221-9087	6T-0830	Housing As	297-7199
4N-8591	Coupling - Exhaust	325-6053	5S-6978	Shaft - Planet	221-9103	6T-3009	Piston - Clutch	297-7226
4N-8814	Line As - Fuel Injector	247-3366	5S-7009	Plate As - End	226-4957	6T-6987	Piston - Clutch	297-7227
4N-9587	Shield - Heat	297-7260	5S-7010	Shaft - Planet	221-9104	6Y-7877	Housing As	297-7200
4P-3546	Valve As - Relief	325-6236	5S-7013	Gear - Ring	221-9088	7B-0503	Ballstud	308-9801
4P-9381	Line As - Fuel Injector	279-4984	5S-7023	Carrier - Planet	226-5986	7C-4297	Seal As - Camshaft	325-6192
4P-9382	Line As - Fuel Injector	279-4985	5S-7609	Pulley - Alt Drive	264-5881	7G-2477	Gear - Planet	221-9090
			5S-7888	Retainer - Bearing	226-5988	7G-2487	Gear - Planet	221-9092
			5S-9080	Pulley - Alt Drive	264-5883	7G-2520	Gear - Planet	221-9094
			5V-5279	Bearing - Sleeve	299-1966	7G-3707	Piston - Clutch	302-2691
			6H-3957	Bearing - Ball	311-9358	7G-3708	Piston - Clutch	300-2585
			6I-1346	Pump Gp - Oil	295-5674	7G-4281	Housing As - Support	297-7201

(Continued)

Sales Model 966C (Continued)

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-5444	Carrier - Planet	297-7165
7G-5572	Gear - Sun	300-2580
7G-5589	Gear - Ring	281-1692
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-6060	Plate - Center	302-2694
7G-6062	Gear - Ring	302-2678
7G-9721	Gear As - Oil Pump	297-7178
7G-9722	Gear - Pump Drive	297-7179
7H-0602	Dog - Clutch	314-8515
7J-9344	Bearing - Sleeve	360-2334
7J-9366	Bearing - Sleeve	299-1985
7J-9682	Bearing - Sleeve	360-2335
7J-9731	Bearing - Sleeve	308-9822
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion - Rear	297-7266
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7176	Pin	241-2570
7K-7200	Pin	241-2600
7K-7613	Joint Gp - Slip	302-2689
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9601	Bearing - Sleeve	360-2338
7K-9602	Bearing - Sleeve	360-2339
7K-9604	Bearing - Sleeve	308-9829
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341

Original Part Number	Part Name	Classic Part Number
7M-2167	Ring - Governor Control	308-9919
7M-4603	Body - Fuel Valve	311-9348
7M-4926	Retainer - Pin	314-8538
7N-0128	Core As - Oil Cooler	299-1994
7N-0165	Core As - Oil Cooler	295-5670
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-3486	Manifold - Exhaust	261-0899
7N-3515	Gear - Camshaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Flywheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-2980	Plate - Reaction	226-5998
7S-3033	Hub - Clutch	226-5985
7S-3161	Lifter - Valve	279-4996
7S-4494	Piston - Clutch	226-5999
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7S-8572	Gear - Ring	221-9095
7S-9749	Pulley - Gen Drive	264-5888
7T-1285	Gear - Planet	297-7190
7T-2036	Cap As - Filter	361-1721
7T-3343	Plate - Clutch	297-7231

Original Part Number	Part Name	Classic Part Number
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Camshaft	314-8684
7Y-1517	Pipe As - Tail	301-5246
8B-5972	Bearing - Ball	314-8503
8F-5104	Screen As - Oil Pan	314-8539
8F-9365	Pin	319-3463
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765
8H-2810	Case As - Filter	314-8512
8H-9806	Gear - Shaft Drive	325-6091
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-6015	Gear - Bevel Ring	221-9076
8K-6282	Gear - Sun	281-1698
8K-6285	Shaft - Axle	299-2057
8M-0874	Plunger As - Valve	311-9439
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-1984	Rod As - Conn	242-3441
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624

(Continued)

Sales Model 966C (Continued)

Original Part Number	Part Name	Classic Part Number
8N-5929	Cover - Water Pump	296-1349
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-0556	Coupling	221-9114
8S-0905	Muffler As	302-2690
8S-3970	Chamber As	242-3438
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
9C-1528	Gear - Planet	223-4802

Original Part Number	Part Name	Classic Part Number
9C-4811	Hub As	224-1300
9G-1231	Plate	297-7232
9G-1491	Carrier - Planet	281-1685
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9G-8117	Housing As	302-2686
9H-2256	Pump Gp	311-9443
9K-1193	Gear - Sun	221-9099
9K-1759	Carrier - Planet	221-9113
9K-1773	Gear - Ring	221-9100
9K-3413	Gear - Bevel Ring	223-4807
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9M-1328	Bearing - Aligning	325-6018

Original Part Number	Part Name	Classic Part Number
9M-4789	Shaft - Gov Control	297-7256
9M-8281	Gear As - Oil Pump	325-6089
9N-4460	Housing As	297-7203
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9P-6888	Shaft - Output	221-9105
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-6129	Pulley - Alternator Drive	264-5891
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9W-0517	Carrier - Planet	281-1686
9W-4949	Carrier - Planet	281-1687
9W-4950	Gear - Sun	281-1688

Wheel Loaders

Sales Model 966D, 966E

Original Part Number	Part Name	Classic Part Number
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
127-5537	Core As	325-6045
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
160-1400	Yoke	319-3479
165-4262	Body As - Piston	270-4353 (Liner Kit)

Original Part Number	Part Name	Classic Part Number
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1N-2936	Muffler As	298-2782
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194

Original Part Number	Part Name	Classic Part Number
1P-9952	Impeller - Pump	314-8685
1S-4701	Pulley - Alt	264-5866
1V-3995	Pin	319-3449
1V-6342	Gear As	308-9847
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
244-1090	Alarm - Back up	360-2345
2F-5721	Bearing - Ball	311-9354
2K-0535	Nut	299-2026

(Continued)

Sales Model 966D, 966E (Continued)

Original Part Number	Part Name	Classic Part Number
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-4442	Bearing - Sleeve	308-9812
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-6245	Shaft As - Pump	325-6197
2V-5697	Cover As	299-1999
2V-5709	Shaft - Axle	299-2056
2V-5714	Gear - Ring	288-8716
2V-5715	Bushing	299-1987
2V-5722	Carrier - Planet	297-7164
2V-6551	Pin	297-7212
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3G-2665	Cover	308-9842
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3P-3208	Flange - Joint	301-4647
3P-8283	Spacer	325-6215
3T-2145	Carrier As	325-6041
3T-3203	Gear - Transfer	302-2675
3V-8777	Gear - Spiral	297-7176
4E-3196	Pin As	361-1697
4E-5213	Cover As	299-2000
4E-8534	Retainer - Seal	300-2588

Original Part Number	Part Name	Classic Part Number
4E-8535	Retainer - Seal	300-2589
4J-6374	Bearing - Sleeve	295-6407
4K-6558	Pin - Lower	302-2710
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-7269	Support	299-2067
4N-2954	Sleeve - Camshaft	299-2059
4N-6302	Belt Set - Vee	314-8495
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
4V-0015	Plate - Lock	282-6563
4V-2518	Shaft	297-7243
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft - Bevel Pinion	297-7244
4V-5393	Gear - Bevel	297-7189
4V-5394	Gear - Diff Bevel	297-7177
4V-6040	Drum	297-7168
4V-6421	Pin As	319-3442
4V-6430	Bracket As	299-1974
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7543	Retainer	281-1699
4V-8519	Bearing - Sleeve	307-1526
4V-8520	Bearing - Sleeve	307-1527
4V-8673	Bearing - Sleeve	307-1528
4V-8674	Bearing - Bushing	307-1529

Original Part Number	Part Name	Classic Part Number
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-5053	Muffler As	360-7881
5C-9207	Drum	301-4623
5D-0470	Valve Gp	314-8549
5G-3612	Cap Gp	295-6419
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
5V-1271	Diff Gp	299-2008
5V-5917	Pinion - Diff Bevel	297-7224
5V-8782	Lever As	299-2014
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-6051	Pin	252-6858
6N-1036	Gear - Oil Pump	279-4991
6N-1572	Mount As	308-9876
6N-8413	Housing - Pump	325-6110
6N-9743	Support - Muffler	308-9940
6P-7704	Carrier - Ring	314-8658
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6W-1629	Shaft - Bevel Pinion	297-7250
6Y-2054	Plate As	302-2695
6Y-4819	Carrier - Planet	296-1348
6Y-4840	Plate As	297-7233
7C-0942	Adapter As	302-2636
7C-5851	Muffler As	298-2790
7G-2516	Gear - Planet	283-5203
7G-2830	Ring - Seal	295-6441
7G-5618	Manifold As	283-5204
7G-7218	Carrier - Planet	283-5205
7G-7724	Piston - Clutch	283-5206

(Continued)

Sales Model 966D, 966E (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7J-6461	Crown	325-6054	8D-2628	Nut	299-2027	8R-3252	Shaft - Planet	297-7259
7J-9344	Bearing - Sleeve	360-2334	8F-9365	Pin	319-3463	8R-3943	Collet	308-9840
7J-9682	Bearing - Sleeve	360-2335	8H-2810	Case As - Filter	314-8512	8S-0248	Breather As	325-6033
7K-0686	Trunnion - Rear	297-7266	8K-6285	Shaft - Axle	299-2057	8S-0493	Shaft As - Pump	325-6198
7K-6497	Pin	252-6870	8M-0874	Plunger As - Valve	311-9439	8S-3970	Chamber As	242-3438
7N-0110	Core As - Oil Cooler	319-3435	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8V-1613	Lever	299-2017
7N-0165	Core As - Oil Cooler	295-5670	8N-1187	Head Gp - Cylinder	242-3435	8V-1624	Lever	299-2019
7N-1164	Mount As	295-5451	8N-1214	Mount As	325-6125	8V-3134	Pinion - Bevel	260-0788
7N-2871	Line As - Fuel Injector	319-8172	8N-1721	Rod As - Conn	269-5291	8V-3135	Gear - Differential Bevel	260-0783
7N-2872	Line As - Fuel Injector	319-8173	8N-1965	Tube - Disposal	325-6235	8V-3136	Gear - Differential Bevel	253-1442
7N-2874	Line As - Fuel Injector	298-2779	8N-2510	Shaft	325-6208	8V-7659	Pin As	361-1702
7N-3515	Gear - Camshaft	314-8669	8N-2641	Sleeve	325-6210	8V-7884	Housing - Support	302-2681
7N-5910	Impeller - Pump	314-8686	8N-3251	Shaft As - Rocker Arm	314-8711	8V-7885	Housing - Support	297-7193
7N-9145	Gear - Fly-wheel	279-4994	8N-3325	Arm Gp - Rocker	314-8623	9C-1484	Pin As	319-3446
7N-9146	Gear - Fly-wheel Starter	279-4995	8N-3327	Arm Gp - Rocker	314-8624	9C-4080	Yoke - Brake	302-2703
7N-9312	Damper As - Camshaft	299-2005	8N-5929	Cover - Water Pump	296-1349	9C-5852	Hub As	297-7208
7N-9805	Pin - Piston	295-6438	8N-6796	Head Gp - Cylinder	269-5290	9C-6015	Pinion - Diff Bevel	297-7225
7S-3161	Lifter - Valve	279-4996	8N-7315	Tube As - Outlet	325-6232	9C-6017	Gear - Diff Bevel	297-7187
7S-4629	Pump Gp - Transfer	226-0158	8N-8225	Bearing - Main	314-8652	9C-6027	Carrier - Planet	297-7166
7T-2036	Cap As - Filter	361-1721	8N-9733	Line As - Fuel Injector	319-8174	9C-8218	Shaft - Bevel Pinion	302-2697
7T-3370	Yoke As	302-2702	8P-0953	Turbine - Converter	297-7269	9C-8219	Gear - Bevel	297-7186
7T-5038	Housing As	297-7202	8P-0957	Impeller - Converter	297-7209	9C-9191	Trunnion	302-2701
7T-9370	Gear - Sun	283-5207	8P-1121	Ring - Clamp	299-2049	9C-9748	Gear - Differential Bevel	302-2671
7W-0450	Gear - Water Pump	279-4997	8P-1892	Piston - Clutch	283-5208	9C-9773	Gear - Differential Bevel	302-2672
7W-0507	Gear - Oil Pump Drive	279-4998	8P-1916	Gear - Planet	283-5209	9G-0280	Piston - Clutch	283-5213
7W-0508	Gear - Fuel Pump Drive	296-1351	8P-1918	Gear - Planet	283-5210	9G-0284	Housing - Clutch	283-5214
7W-1902	Adapter - Fuel Nozzle	299-1955	8P-1919	Gear - Planet	300-2579	9G-0285	Piston - Clutch	283-5215
7W-2164	Core As - Oil Cooler	299-1996	8P-2042	Shaft - Planet	283-5211	9G-0289	Shaft - Planet	283-5216
7W-5684	Pulley - Camshaft	298-2771	8P-8677	Hub - Impeller	297-7205	9G-0290	Hub - Clutch	283-5217
7W-5685	Pulley - Camshaft	298-2772	8P-9507	Piston - Clutch	283-5212	9G-2413	Shaft - Output	297-7255
7W-5698	Pulley - Camshaft	295-5679	8R-0931	Housing - Pinion	302-4300	9G-7411	Gear - Oil Pump Drive	297-7182
						9G-7412	Gear As - Oil Pump	297-7183
						9K-8757	Rod End - Bearing	311-9361
						9N-5404	Piston Gp - Basic (Liner Kit)	250-6558

(Continued)

Sales Model 966D, 966E (Continued)

Original Part Number	Part Name	Classic Part Number
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-3731	Carrier - Planet	301-4767
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-8866	Gear - Transfer	299-2012

Original Part Number	Part Name	Classic Part Number
9P-9031	Gear - Sun	283-5220
9P-9517	Stator - Converter	297-7262
9P-9610	Pump Gp	283-5221
9P-9790	Shaft - Output	302-2696
9S-2354	Manifold - Exhaust	261-0888
9S-2355	Manifold - Exhaust	261-0891
9S-8679	Chamber As	325-6042
9U-3124	Gear - Planet	288-8806
9U-3125	Gear - Sun	288-8807

Original Part Number	Part Name	Classic Part Number
9V-2410	Housing - Bearing	302-2679
9V-2411	Housing - Bearing	302-2680
9V-3853	Pin	319-3469
9V-6523	Cap	297-7162
9V-6524	Cap	297-7163
9W-3605	Carrier - Ring	314-8662
9W-8270	Gear - Ring	308-9859
9W-8384	Hub - Turbine	297-7207
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2988	Breather As	361-1716

Sales Model 980

Original Part Number	Part Name	Classic Part Number
121-7746	Precleaner As	360-2311
1M-7250	Bowl - Pre-cleaner	360-2296
7J-9344	Bearing - Sleeve	360-2334
129-2339	Spider	308-9936
1A-2846	Cap As - Filler	311-9368
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0665	Ring - Clamp	308-9918
1T-1091	Hub - Turbine	308-9869
1V-4838	Link As - Spring	308-9874
1V-5410	Bearing	308-9806
1V-6978	Bolt - Shoulder	308-9803
2D-9130	Washer - Thrust	308-9943
2F-5721	Bearing - Ball	311-9354
2J-5649	Pin - Cylinder	256-4782
2K-3592	Boss	314-8501
2K-4177	Pin - Lock	308-9893
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021

Original Part Number	Part Name	Classic Part Number
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2S-2781	Plunger - Relief	311-9435
2V-4374	Joint Gp - Slip	308-9872
3D-5315	Pinion - Diff Bevel	308-9856
3F-4971	Pin	295-5693
3K-0963	Pin - Lock	308-9895
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3S-1262	Retainer	308-9915
3S-8034	Shaft - Planet	308-9926
3S-9466	Bearing - Sleeve	314-8509
4J-1612	Pin	308-9896
4J-3015	Shaft	325-6204
4J-6899	Bearing - Sleeve	308-9815
4K-0299	Bearing - Sleeve	308-9816
4K-0300	Bearing - Sleeve	308-9817
4K-1102	Bearing - Sleeve	325-6010
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633

Original Part Number	Part Name	Classic Part Number
4K-8416	Shaft	308-9927
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5G-3612	Cap Gp	295-6419
5J-3492	Bearing - Sleeve	308-9879
5J-4542	Bearing - Sleeve	308-9818
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3497	Pin	308-9897
5K-3499	Pin - Lower	308-9898
5K-3502	Cap - Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage - Bearing	308-9804
5K-4079	Cage - Bearing	308-9805
5K-4180	Gear - Planet	308-9854
5K-4268	Retainer - Bearing	308-9916
5K-4305	Support As	308-9937
5K-4426	Bushing	308-9831
5K-4787	Bearing - Sleeve	308-9819
5K-4801	Pin	308-9899
5K-4802	Pin	308-9900
5K-4819	Pin	308-9901
5K-7995	Bearing - Sleeve	308-9820

(Continued)

Sales Model 980 (Continued)

Original Part Number	Part Name	Classic Part Number
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-6001	Pin	308-9902
6P-6739	Shaft - Planet	308-9929
6W-7290	Shaft - Planet	308-9930
7B-0503	Ballstud	308-9801
7G-2513	Gear - Planet	215-1734
7J-9707	Bearing - Sleeve	308-9821

Original Part Number	Part Name	Classic Part Number
7J-9708	Bearing - Sleeve	299-1964
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7J-9814	Bearing - Sleeve	308-9824
7K-0078	Bearing - Sleeve	308-9825
7K-0373	Pin As	308-9885
7K-0374	Pin As	308-9886
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7102	Pin	308-9903
7K-9528	Bearing - Sleeve	308-9828

Original Part Number	Part Name	Classic Part Number
7K-9604	Bearing - Sleeve	308-9829
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7K-9992	Pin	308-9907
7N-9146	Gear - Fly-wheel Starter	279-4995
7S-7809	Cap As - Radiator	295-6417
8F-9365	Pin	319-3463
8K-0042	Gear - Differential Bevel	308-9850
8M-2549	Rod As - Connector	314-8537
9K-0198	Gear - Sun	308-9865
9V-7860	Support As - Front	308-9938
7T-2036	Cap As - Filter	361-1721

Wheel Loaders

Sales Model 980B

Original Part Number	Part Name	Classic Part Number
111-8015	Gasket As - Head	279-4977
115-7550	Gasket - Plate	314-8667
121-7746	Precleaner As	360-2311
129-2339	Spider	308-9936
131-3815	Seal Gp - Basic	325-6193
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365
1M-7250	Bowl - Pre-cleaner	360-2296
1N-3576	Block Gp - Cylinder	279-4978
1N-3958	Elbow	325-6087
1P-4303	Head As - Cylinder	242-3434

Original Part Number	Part Name	Classic Part Number
1P-9945	Bracket As - Fan	296-1344
1P-9946	Shaft - Fan	325-6194
1P-9952	Impeller - Pump	314-8685
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1S-8753	Plate - Coupling	308-9910
1S-8754	Joint Gp - Univ	308-9873
1T-0665	Ring - Clamp	308-9918
1T-1091	Hub - Turbine	308-9869
1V-4838	Link As - Spring	308-9874
1V-5410	Bearing	308-9806
1V-6978	Bolt - Shoulder	308-9803
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
2D-9130	Washer - Thrust	308-9943
2F-5721	Bearing - Ball	311-9354
2J-5649	Pin - Cylinder	256-4782
2K-3592	Boss	314-8501

Original Part Number	Part Name	Classic Part Number
2K-4177	Pin - Lock	308-9893
2K-4442	Bearing - Sleeve	308-9812
2K-4507	Bearing - Sleeve	325-6021
2K-4512	Bearing - Sleeve	308-9813
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-6128	Pulley	264-5872
2P-6245	Shaft As - Pump	325-6197
2S-4015	Plunger As - Valve	311-9438
2V-3687	Gear - Diff Bevel	308-9849
2V-4374	Joint Gp - Slip	308-9872

(Continued)

Sales Model 980B (Continued)

Original Part Number	Part Name	Classic Part Number
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
3D-5315	Pinion - Diff Bevel	308-9856
3F-4971	Pin	295-5693
3K-0963	Pin - Lock	308-9895
3K-5461	Wheel - Steering	308-9945
3L-1425	Bearing - Ball	311-9356
3S-1262	Retainer	308-9915
3S-8034	Shaft - Planet	308-9926
3V-7427	Housing As	297-7197
4J-1612	Pin	308-9896
4J-3015	Shaft	325-6204
4J-6899	Bearing - Sleeve	308-9815
4K-0299	Bearing - Sleeve	308-9816
4K-0300	Bearing - Sleeve	308-9817
4K-1102	Bearing - Sleeve	325-6010
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-8416	Shaft	308-9927
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-4577	Muffler As	308-9877
4N-7693	Crankshaft As	242-3439
4N-8814	Line As - Fuel Injector	247-3366
4N-9587	Shield - Heat	297-7260
4P-3546	Valve As - Relief	325-6236

Original Part Number	Part Name	Classic Part Number
4S-8472	Hood As	296-1355
4V-3044	Plate - Lock	308-9911
4W-0452	Seal As - Camshaft	325-6191
5D-0470	Valve Gp	314-8549
5F-6393	Shaft	308-9928
5F-7404	Nut - Bearing Lock	308-9878
5G-3612	Cap Gp	295-6419
5J-3492	Bearing - Sleeve	308-9879
5J-4542	Bearing - Sleeve	308-9818
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3497	Pin	308-9897
5K-3499	Pin - Lower	308-9898
5K-3502	Cap - Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage - Bearing	308-9804
5K-4079	Cage - Bearing	308-9805
5K-4180	Gear - Planet	308-9854
5K-4268	Retainer - Bearing	308-9916
5K-4305	Support As	308-9937
5K-4426	Bushing	308-9831
5K-4787	Bearing - Sleeve	308-9819
5K-4801	Pin	308-9899
5K-4802	Pin	308-9900
5K-4819	Pin	308-9901
5K-7995	Bearing - Sleeve	308-9820
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5S-1211	Cover - Valve	314-8665
5S-4557	Bearing	311-9360
5S-6795	Chamber As	242-3437
5S-9080	Pulley - Alt Drive	264-5883
6H-3957	Bearing - Ball	311-9358
6I-1346	Pump Gp - Oil	295-5674
6K-0053	Housing	297-7191
6K-2034	Shaft	297-7249
6K-2036	Rack	299-2045
6K-6001	Pin	308-9902
6N-1036	Gear - Oil Pump	279-4991

Original Part Number	Part Name	Classic Part Number
6N-1965	Line As - Fuel Injector	250-7535
6N-1966	Line As - Fuel Injector	250-7536
6N-2789	Pulley	264-5886
6N-8413	Housing - Pump	325-6110
6P-6739	Shaft - Planet	308-9929
6W-7290	Shaft - Planet	308-9930
7B-0503	Ballstud	308-9801
7C-4297	Seal As - Camshaft	325-6192
7G-2513	Gear - Planet	215-1734
7J-9344	Bearing - Sleeve	360-2334
7J-9707	Bearing - Sleeve	308-9821
7J-9708	Bearing - Sleeve	299-1964
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7J-9814	Bearing - Sleeve	308-9824
7K-0078	Bearing - Sleeve	308-9825
7K-0373	Pin As	308-9885
7K-0374	Pin As	308-9886
7K-1818	Cover	308-9844
7K-6260	Shaft - Sector	308-9931
7K-7102	Pin	308-9903
7K-9528	Bearing - Sleeve	308-9828
7K-9604	Bearing - Sleeve	308-9829
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7K-9992	Pin	308-9907
7M-2167	Ring - Governor Control	308-9919
7N-0110	Core As - Oil Cooler	319-3435
7N-1164	Mount As	295-5451
7N-2871	Line As - Fuel Injector	319-8172
7N-2872	Line As - Fuel Injector	319-8173
7N-2874	Line As - Fuel Injector	298-2779

(Continued)

Sales Model 980B (Continued)

Original Part Number	Part Name	Classic Part Number
7N-2875	Line As - Fuel Injector	298-2780
7N-2876	Line As - Fuel Injector	298-2781
7N-2949	Pulley	264-5887
7N-3515	Gear - Cam-shaft	314-8669
7N-3536	Gear - Fuel	279-4993
7N-5511	Gear As - Idler	233-2180
7N-5910	Impeller - Pump	314-8686
7N-9145	Gear - Fly-wheel	279-4994
7N-9312	Damper As - Camshaft	299-2005
7N-9805	Pin - Piston	295-6438
7S-3161	Lifter - Valve	279-4996
7S-6723	Bracket - Alternator	299-1978
7S-7809	Cap As - Radiator	295-6417
7S-8443	Muffler	247-2675
7T-2036	Cap As - Filter	361-1721
7W-0450	Gear - Water Pump	279-4997

Original Part Number	Part Name	Classic Part Number
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351
7W-5687	Hub - Cam-shaft	314-8684
8F-9365	Pin	319-3463
8H-9806	Gear - Shaft Drive	325-6091
8K-0042	Gear - Differential Bevel	308-9850
8N-0002	Trunnion As	314-8728
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1721	Rod As - Conn	269-5291
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-5929	Cover - Water Pump	296-1349

Original Part Number	Part Name	Classic Part Number
8N-7315	Tube As - Outlet	325-6232
8N-8225	Bearing - Main	314-8652
8N-9733	Line As - Fuel Injector	319-8174
8S-0248	Breather As	325-6033
8S-0493	Shaft As - Pump	325-6198
8S-3970	Chamber As	242-3438
8S-7716	Manifold - Exhaust	295-0415
8S-7717	Manifold - Exhaust	261-0894
8S-7718	Manifold - Exhaust	295-0416
9H-2256	Pump Gp	311-9443
9K-0198	Gear - Sun	308-9865
9M-4789	Shaft - Gov Control	297-7256
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9S-6129	Pulley - Alternator Drive	264-5891
9S-8679	Chamber As	325-6042
9V-7860	Support As - Front	308-9938

Wheel Loaders

Sales Model 980C

Original Part Number	Part Name	Classic Part Number
0T-0259	Nut - Bearing Sleeve	311-9431
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
111-8015	Gasket As - Head	279-4977
112-3818	Shaft - Input	302-2698
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
115-7550	Gasket - Plate	314-8667
122-9405	Bracket As	325-6005
129-2339	Spider	308-9936

Original Part Number	Part Name	Classic Part Number
131-3815	Seal Gp - Basic	325-6193
148-7455	Valve - Exhaust	270-4361
165-4262	Body As - Piston	270-4353 (Liner Kit)
167-8123	Damper As	299-2006
172-5185	Shaft - Water Pump	325-6201
172-5188	Shaft - Water Pump	325-6202
172-5189	Impeller - Pump	295-5687
172-5190	Impeller - Pump	325-6111
172-6712	Impeller - Pump	325-6112
172-7767	Pump Gp - Water	296-1365

Original Part Number	Part Name	Classic Part Number
177-9024	Adapter - Damper	299-1956
180-3767	Adapter - Damper	299-1957
1A-2846	Cap As - Filler	311-9368
1F-2254	Bushing - Stem	314-8510
1F-4419	Gasket - Cover	311-9393
1N-3576	Block Gp - Cylinder	279-4978
1P-9946	Shaft - Fan	325-6194
1S-1888	Bracket - Lamp	297-7147
1S-4701	Pulley - Alt	264-5866
1V-6342	Gear As	308-9847
1V-8240	Bearing - Sleeve	308-9807

(Continued)

Sales Model 980C (Continued)

Wheel Loaders

Original Part Number	Part Name	Classic Part Number
1V-8241	Bearing - Sleeve	308-9808
1V-8242	Bearing - Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8604	Gear - Ring	308-9853
1V-8606	Gear - Sun	308-9860
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing - Sleeve	308-9810
1V-9148	Bearing - Sleeve	308-9811
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980
1W-1698	Housing - Transfer Pump	296-1356
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-5912	Tappet As - Guide	325-6223
244-1090	Alarm - Back up	360-2345
2D-5658	Bearing - Ball	301-4628
2D-9130	Washer - Thrust	308-9943
2F-5721	Bearing - Ball	311-9354
2K-3592	Boss	314-8501
2P-1170	Shaft As - Gear	296-1367
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2519	Tube As - Inlet	325-6230
2P-5680	Turbine - Converter	308-9942

Original Part Number	Part Name	Classic Part Number
2P-5693	Housing - Rotating	308-9866
2P-6245	Shaft As - Pump	325-6197
2V-3687	Gear - Diff Bevel	308-9849
2V-4374	Joint Gp - Slip	308-9872
2V-4700	Pin	308-9894
2V-7170	Yoke	308-9948
2V-7198	Pilot As - Recoil Spring	302-2709
2V-7393	Retainer	308-9914
2W-1086	Cover As - Cylinder Head	325-6049
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
3D-5315	Pinion - Diff Bevel	308-9856
3F-7445	Bearing - Sleeve	314-8508
3G-2665	Cover	308-9842
3K-2230	Gear - Planet	219-9658
3L-1425	Bearing - Ball	311-9356
3P-2685	Piston - Clutch	308-9908
3P-2768	Piston - Clutch	308-9909
3P-3059	Gear - Sun	308-9861
3P-3060	Gear - Sun	308-9862
3P-3096	Gear - Sun	308-9863
3P-3242	Shaft - Planet	308-9923
3P-3245	Shaft - Planet	308-9924
3P-3246	Shaft - Planet	308-9925
3P-4850	Gear As - Oil Pump	308-9848
3P-8283	Spacer	325-6215
3S-1262	Retainer	308-9915
3T-3203	Gear - Transfer	302-2675
3V-6648	Pin As	308-9884
4E-5213	Cover As	299-2000
4E-5882	Shaft - Axle	308-9921

Original Part Number	Part Name	Classic Part Number
4K-4780	Strip As - Wear	299-2063
4N-2954	Sleeve - Camshaft	299-2059
4N-6302	Belt Set - Vee	314-8495
4N-7693	Crankshaft As	242-3439
4P-3546	Valve As - Relief	325-6236
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4S-8472	Hood As	296-1355
4V-2518	Shaft	297-7243
4V-3044	Plate - Lock	308-9911
4V-3680	Bellcrank	308-9802
4V-6156	Saddle As	299-2052
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-8674	Bearing - Bushing	307-1529
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
5D-0470	Valve Gp	314-8549
5F-7404	Nut - Bearing Lock	308-9878
5K-0609	Cover	308-9843
5K-3490	Spacer	308-9933
5K-3491	Spacer	308-9934
5K-3499	Pin - Lower	308-9898
5K-3502	Cap - Lower	308-9835
5K-3967	Yoke As	308-9946
5K-3968	Cage - Bearing	308-9804
5K-4079	Cage - Bearing	308-9805
5K-4268	Retainer - Bearing	308-9916
5K-4305	Support As	308-9937
5K-4426	Bushing	308-9831
5M-7900	Bolt - Hex Head	311-9349
5P-7807	Bearing - Ball	314-8502
5P-8194	Ring - Retaining	308-9920

(Continued)

Sales Model 980C (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5S-1211	Cover - Valve	314-8665	7N-5910	Impeller - Pump	314-8686	8N-3327	Arm Gp - Rocker	314-8624
5S-4557	Bearing	311-9360	7N-9146	Gear - Fly-wheel Starter	279-4995	8N-5779	Coupling - Exhaust	325-6047
5S-6795	Chamber As	242-3437	7N-9674	Muffler As	360-7892	8N-5929	Cover - Water Pump	296-1349
5S-9080	Pulley - Alt Drive	264-5883	7N-9805	Pin - Piston	295-6438	8N-6796	Head Gp - Cylinder	269-5290
5V-8782	Lever As	299-2014	7S-3161	Lifter - Valve	279-4996	8N-7315	Tube As - Outlet	325-6232
6H-3957	Bearing - Ball	311-9358	7S-7809	Cap As - Radiator	295-6417	8N-8225	Bearing - Main	314-8652
6L-1346	Pump Gp - Oil	295-5674	7T-2036	Cap As - Filter	361-1721	8P-0514	Yoke As	308-9947
6L-8968	Coupling - Exhaust	311-9381	7T-9370	Gear - Sun	283-5207	8P-0769	Hub - Turbine	308-9870
6N-1036	Gear - Oil Pump	279-4991	7V-6790	Shaft - Bevel Pinion	308-9922	8P-1892	Piston - Clutch	283-5208
6N-1572	Mount As	308-9876	7W-0450	Gear - Water Pump	279-4997	8P-1916	Gear - Planet	283-5209
6N-8413	Housing - Pump	325-6110	7W-0507	Gear - Oil Pump Drive	279-4998	8P-1918	Gear - Planet	283-5210
6N-9743	Support - Muffler	308-9940	7W-0508	Gear - Fuel Pump Drive	296-1351	8P-1919	Gear - Planet	300-2579
6P-6556	Carrier As	308-9836	7W-1902	Adapter - Fuel Nozzle	299-1955	8P-2042	Shaft - Planet	283-5211
6P-6739	Shaft - Planet	308-9929	7W-2164	Core As - Oil Cooler	299-1996	8P-9507	Piston - Clutch	283-5212
6P-7358	Pump Gp	308-9913	8B-5972	Bearing - Ball	314-8503	8R-3921	Collet	308-9839
6P-7704	Carrier - Ring	314-8658	8F-5104	Screen As - Oil Pan	314-8539	8R-3943	Collet	308-9840
6W-0240	Bearing - Brace	297-7143	8H-1993	Valve - Inlet	256-4765	8R-3946	Collet	308-9841
6W-4281	Yoke - Flange	308-9949	8H-1994	Valve - Exhaust	256-4765	8R-4821	Carrier - Planet	308-9837
6W-4284	Cage - Bearing	308-9832	8H-2810	Case As - Filter	314-8512	8R-7425	Retainer	308-9917
6W-7290	Shaft - Planet	308-9930	8K-0042	Gear - Differential Bevel	308-9850	8R-9798	Plate - Lock	308-9912
6W-7331	Cover As	308-9845	8M-0874	Plunger As - Valve	311-9439	8S-0248	Breather As	325-6033
6Y-2054	Plate As	302-2695	8M-6676	Cylinder - Adjustable	226-4960	8S-0493	Shaft As - Pump	325-6198
6Y-4819	Carrier - Planet	296-1348	8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)	8S-3970	Chamber As	242-3438
6Y-4840	Plate As	297-7233	8N-1187	Head Gp - Cylinder	242-3435	8V-1613	Lever	299-2017
7C-0942	Adapter As	302-2636	8N-1214	Mount As	325-6125	8V-1624	Lever	299-2019
7C-4297	Seal As - Camshaft	325-6192	8N-1721	Rod As - Conn	269-5291	8V-6382	Hub As	308-9868
7G-2476	Gear - Planet	223-4816	8N-2510	Shaft	325-6208	8V-6384	Spacer As	308-9935
7G-2516	Gear - Planet	283-5203	8N-2641	Sleeve	325-6210	9C-0624	Pin As	361-1709
7G-2830	Ring - Seal	295-6441	8N-3251	Shaft As - Rocker Arm	314-8711	9C-0625	Pin As	308-9888
7G-3457	Gear - Planet	308-9857	8N-3325	Arm Gp - Rocker	314-8623	9C-8074	Gear - Planet	308-9858
7G-5618	Manifold As	283-5204				9C-8075	Gear - Sun	308-9864
7G-7218	Carrier - Planet	283-5205				9C-8277	Gear - Bevel	308-9851
7G-7724	Piston - Clutch	283-5206				9G-0280	Piston - Clutch	283-5213
7H-0602	Dog - Clutch	314-8515				9G-0284	Housing - Clutch	283-5214
7M-4603	Body - Fuel Valve	311-9348				9G-0285	Piston - Clutch	283-5215
7M-4926	Retainer - Pin	314-8538				9G-0289	Shaft - Planet	283-5216
7N-0110	Core As - Oil Cooler	319-3435				9G-0290	Hub - Clutch	283-5217
						9H-7670	Piston	226-4961

(Continued)

Sales Model 980C (Continued)

Original Part Number	Part Name	Classic Part Number
9J-5875	Bearing - Sleeve	308-9830
9K-8428	Pin As	241-2533
9K-8757	Rod End - Bearing	311-9361
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-3731	Carrier - Planet	301-4767
9P-7757	Gear - Sun	283-5218

Original Part Number	Part Name	Classic Part Number
9P-8283	Plate - Clutch	296-1364
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-9031	Gear - Sun	283-5220
9S-8493	Bolt - Connecting Rod	311-9351
9S-8679	Chamber As	325-6042
9V-7860	Support As - Front	308-9938

Original Part Number	Part Name	Classic Part Number
9W-3605	Carrier - Ring	314-8662
9W-4702	Stator - Converter	308-9939
9W-6433	Impeller - Converter	308-9871
9W-6435	Flange - Drive	308-9846
9W-8270	Gear - Ring	308-9859
9W-8433	Shaft As - Output	302-4249
9W-8437	Gear - Sun	283-5222
9W-9069	Shaft - Input	302-2715
9Y-2988	Breather As	361-1716

Cornerstone Brochure

Media Number	Description	Languages Available
PEDP9129	Cat® Classic™ Parts - Another Option for Older Cat Machines	English
PFDP9129	Cat Classic Parts - Another Option for Older Cat Machines	French
PPDP9129	Cat Classic Parts - Another Option for Older Cat Machines	Portuguese
PSDP9129	Cat Classic Parts - Another Option for Older Cat Machines	Spanish

Datasheets

Media Number	Description	Languages Available
PEHJ0160	Cat Classic Parts for Track-Type Tractors	English
PEHP9565	Cat Classic Parts	English
PEHJ0178	Cat Classic Parts for Wheel Loaders	English
PEHJ0176	Cat Classic Parts for Hydraulic Excavators	English
PEHJ0132	Cat Classic Parts for 3300 DI Engines	English
PEHJ0144	Cat Classic Parts for Motor Graders	English
PEHJ0188	Cat Classic Parts for Commercial Engines	English
PFHJ0188	Cat Classic Parts for Commercial Engines	French
PPHJ0188	Cat Classic Parts for Commercial Engines	Portuguese
PSHJ0188	Cat Classic Parts for Commercial Engines	Spanish

Tri-folds

Media Number	Description	Languages Available
PECJ0011	D300/3300 PC Engine Quick Reference Card	English
PECJ0034	Customer Quick Reference Guide	English
PECJ0015	3300 DI Engine Quick Reference Guide	English
PECJ0037	Commercial Engines Quick Reference Guide	English
PFCJ0037	Commercial Engines Quick Reference Guide	French
PPCJ0037	Commercial Engines Quick Reference Guide	Portuguese
PSCJ0037	Commercial Engines Quick Reference Guide	Spanish

Counter Cards

Media Number	Description	Languages Available
PEKJ0008	Cat Classic Parts 3300 DI Engine Parts	English
PEKJ0013	Cat Classic Parts for High-Hour Commercial Engines	English
PFKJ0013	Cat Classic Parts for High-Hour Commercial Engines	French
PPKJ0013	Cat Classic Parts for High-Hour Commercial Engines	Portuguese
PSKJ0013	Cat Classic Parts for High-Hour Commercial Engines	Spanish

Posters/Banners

Media Number	Description	Languages Available
PEPJ0086	Cat Classic 3300 DI Engine Parts	English
PEPJ0094	Dealer Services Campaign - Cat Classic Parts	English
PEPJ0141	It's Time for Cat Classic Parts	English
PEPJ0142	Power Up Cost Down	English

CDs

Media Number	Description	Languages Available
PEWJ0124	Cat Classic Parts 3300 DI Engine Parts Promo Kit	English
PERJ0074	Cat Classic Parts for Commercial Engines Promo Kit	English

Sales Aid - DEALER USE ONLY

Media Number	Description	Languages Available
PEWJ0050	What Are Cat Classic Parts?	English
PEWJ0143	Cat Classic Parts Cutaway Engine	English

DLMS Course - DEALER USE ONLY

Course Number	Description	Languages Available
20269	Parts Pro - Cat® Classic™ Parts	English

Part Numbers Beginning with 0

Original Part Number	Part Name	Classic Part Number
054-2213	Spider and Bearing As	347-0464
054-6549	Pinion - Planetary	347-0478
055-1260	Housing Bk - Outer	347-0479
055-1986	Seal - Lip type	347-0465
086-0523	Pin	314-8696
087-5499	Bearing - Sleeve	314-8640

Original Part Number	Part Name	Classic Part Number
087-5533	Bearing - Sleeve	314-8628
087-5802	Link - Rh	301-7964
087-5803	Link As	301-7966
087-5805	Pin	301-7967
087-5806	Pin	301-7968
087-5845	Pin	301-7969
087-5847	Bearing - Sleeve	314-8629
094-1509	Shaft - Planet	360-2273
095-2927	Valve - Fill	360-2292

Original Part Number	Part Name	Classic Part Number
095-9291	Valve - Fill	360-2293
096-7911	Bearing - Sleeve	314-8653
096-7912	Bearing - Sleeve	314-8654
096-7913	Bearing - Sleeve	314-8655
099-0718	Bearing - Sleeve	360-2313
099-0721	Bearing - Sleeve	314-8641
0T-0259	Nut - Bearing Sleeve	311-9431

Part Numbers Beginning with 1

Original Part Number	Part Name	Classic Part Number
100-3431	Stop	314-8723
100-7860	Valve - Inlet	270-4360 (Valve), 270-4362 (Valve Kit)
102-1561	Lifter As - Valve	311-9402
102-4560	Bearing - Sleeve	347-0469
102-8112	Cylinder - Adjustable	360-2276
104-4253	Line As - Fuel Injector	279-4988
104-4254	Line As - Fuel Injector	279-4989
105-3196	Motor Gp - Gerotor	282-6547
106-7131	Shaft	288-8714
107-2139	Pin As	360-2352
108-0980	Pin As	314-8692
109-5562	Shaft	275-5272
109-9463	Muffler As	360-7864
110-4652	Housing	302-2683
110-7058	Carrier - Planet	301-4630
110-7059	Carrier - Planet	301-4636
110-7209	Carrier As	301-5237
111-0416	Guard As (rh)	325-6096
111-0419	Guard As (lh)	325-6097
111-0431	Guard As	325-6098
111-8015	Gasket As - Head	279-4977
112-1773	Piston	347-0462
112-3249	Muffler As	247-2661

Original Part Number	Part Name	Classic Part Number
112-3818	Shaft - Input	302-2698
112-5495	Joint Gp - Univ	297-4858
112-5585	Shaft - Planet	308-9932
112-8041	Carrier - Planet	295-5681
112-9629	Pin	347-0470
114-9036	Shaft - Input	297-4859
115-0637	Pump Gp	226-0160
115-4204	Pulley As - Idler	301-5219
115-6427	Spring	301-4776
115-6429	Cylinder	301-4679
115-7550	Gasket - Plate	314-8667
117-1024	Link As.	188-5595
117-1616	Segment Gp - Sprocket	260-5851 (sprocket group)
118-1611	Roller Gp - SF	175-8024
118-1612	Roller Gp - DF	175-8025
118-1614	Roller Gp - SF	175-8035
118-1615	Roller Gp - DF	175-8036
118-1617	Roller Gp - SF	188-5272
118-1618	Roller Gp - DF	188-5271
118-1619	Roller Gp - Track	188-5257
118-1620	Roller Gp - DF	188-5258
118-1623	Roller Gp - Track	188-5596
118-1625	Roller Gp - Track	188-5597
118-9906	Muffler As	360-7865
119-2863	Pin	314-8698
119-7042	Shaft	347-0480

Original Part Number	Part Name	Classic Part Number
119-7047	Seal	347-0481
121-7746	Precleaner As	360-2311
122-1881	Plate - Clutch	347-0475
122-5076	Rod	301-4569
122-5077	Cylinder	301-4673
122-5178	Piston As	301-5252
122-9405	Bracket As	325-6005
124-3240	Pin	282-6548
125-2950	Gear As	301-4762
126-5061	Shoe -Track	335-5478
126-5062	Shoe -Track	286-9827
126-7130	Shaft As	275-5300
127-5537	Core As	325-6045
127-5969	Gear - Sun	301-4761
127-5970	Gear - Planet	301-3398
127-8592	Muffler As	347-0463
128-0307	Plate	325-6165
128-9863	Bearing - Sleeve	314-8630
128-9882	Bearing - Sleeve	314-8642
128-9883	Bearing - Sleeve	360-2314
128-9884	Bearing - Sleeve	360-2315
129-2339	Spider	308-9936
129-2381	Gear - Planet	275-5274
129-7768	Bearing - Sleeve	360-2316
130-1637	Shaft	347-0471
130-6856	Precleaner As	361-1717
130-6879	Seal	347-0482

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
130-9293	Rod	314-8708	172-6712	Impeller - Pump	325-6112	1M-1618	Collar As - Shift	226-8029
131-3736	Socket Gp - Basic	325-6211	172-7767	Pump Gp - Water	296-1365	1M-1663	Collar As - Retain	226-8030
131-3737	Socket As	282-6626	175-4070	Bushing - Sleeve	347-0484	1M-1698	Gear - Sliding	215-1659
131-3738	Socket As	282-6627	176-9273	Piston	297-4860	1M-1809	Shaft - Tr Sprocket	231-3314
131-3815	Seal Gp - Basic	325-6193	177-9024	Adapter - Damper	299-1956	1M-1930	Cage - Pinion Bearing	217-7727
131-7736	Support As - Engine	325-6222	179-6152	Bearing	361-1704	1M-1947	Support As	226-6096
137-2819	Bearing - Sleeve	360-2317	180-3767	Adapter - Damper	299-1957	1M-2607	Cage - Bearing	239-7970
137-2820	Bearing - Sleeve	360-2318	185-4037	Idler Gp	275-3581	1M-2626	Cage - Carrier Bearing	216-7458
137-2919	Bearing - Sleeve	360-2319	185-6151	Segment, Segment Gp	260-1510, 260-1511 (sprocket group)	1M-2635	Housing - Clutch	216-3549
137-3060	Bearing - Sleeve	360-2320	186-4118	Gear - Planet	347-0483	1M-2637	Housing - Clutch	216-3550
141-6137	Socket Gp	325-6212	190-7396	Segment Gp	275-3576 (sprocket group), 275-4087 segment	1M-3925	Gear - Shaft Idler	216-7459
141-6138	Socket Gp	325-6213	190-8609	Valve - Fill	360-2288	1M-4153	Carrier - Planet	213-1114
145-3030	Cylinder	360-2260	194-1608	Link As.	308-6230	1M-4155	Gear - Ring	214-0519
147-3309	Spindle	282-6628	194-1609	Link As.	308-6229	1M-4156	Gear - Ring	214-0520
147-3400	Spindle	282-6549	1A-2846	Cap As - Filler	311-9368	1M-4167	Shaft - Planet	219-9700
148-4634	Shaft - Planet	360-2274	1D-3996	Fork - Knuckle	228-9428	1M-4171	Cage - Bearing	216-7460
148-7455	Valve - Exhaust	270-4361	1F-2254	Bushing - Stem	314-8510	1M-4344	Cage As	216-7466
153-3580	Shaft	299-2055	1F-4419	Gasket - Cover	311-9393	1M-4486	Piston - Clutch	215-1660
154-3662	Link As.	257-8020	1H-4106	Pin As - Drawbar	325-6126	1M-5151	Pinion - Bevel	215-1661
154-3667	Link As.	260-1509	1H-8037	Yoke - Fitting	228-9415	1M-5165	Pinion - Final Drive	231-8766
154-3676	Link As.	257-8021	1H-8262	Shaft	226-8016	1M-6128	Manifold - Exhaust	261-0906
155-2819	Ejector As - Exhaust	325-6078	1H-8382	Gear - Oil Pump Drive	226-6103	1M-6603	Gear - Transfer	217-7720
160-1014	Pin As	347-0473	1H-8937	Drumbrake	226-7993	1M-6604	Gear - Transfer	217-7715
160-1400	Yoke	319-3479	1H-8938	Lever	226-8028	1M-7250	Bowl - Pre-cleaner	360-2296
160-6305	Cap - Bearing	295-5686	1J-1738	Pin	319-3448	1M-8647	Housing As	215-1662
160-6308	Cap - Bearing	325-6036	1J-6744	Bearing	361-1705	1M-9029	Guard	226-0219
163-4143	Roller Gp - SF	286-9823	1J-6746	Pin	256-4817	1M-9177	Flywheel	226-6112
164-1047	Idler Gp	275-3581	1J-6749	Screw - Adjustable	256-4824	1M-9444	Retainer - Spring	299-2046
165-4262	Body As - Piston	270-4353 (Liner Kit)	1K-7974	Gear - Transmission Shaft	226-7984	1N-2936	Muffler As	298-2782
165-7211	Strip	325-6219	1M-0176	Flange - Drum	223-4810	1N-3576	Block Gp - Cylinder	279-4978
167-2329	Seal - U-cup	347-0466	1M-0598	Gear - Transmission	213-8636	1N-3958	Elbow	325-6087
167-8123	Damper As	299-2006	1M-1408	Nut (5/8-18)	200-9150	1N-4304	Head Gp - Cylinder	269-8761
172-5185	Shaft - Water Pump	325-6201						
172-5188	Shaft - Water Pump	325-6202						
172-5189	Impeller - Pump	295-5687						
172-5190	Impeller - Pump	325-6111						

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
1N-5943	Manifold - Upper	311-9429	1P-8005	Gasket - Chamber	314-8527	1S-8764	Ring - Fly-wheel Clutch Adjustable	226-8014
1N-7478	Manifold - Front	311-9428	1P-8554	Coupling - Exhaust	325-6052	1T-0020	Wheel - Turbine	297-4862
1P-0005	Pump Gp - Fuel Transfer	256-4756	1P-8717	Roller Gp - Carrier	188-5600	1T-0224	Carrier - Ring	239-7928
1P-0009	Rod As - Conn	311-9450	1P-8835	Shaft As	215-1672	1T-0228	Housing - Rotating	216-7467
1P-0320	Retainer - Bearing	226-5987	1P-9024	Spring - Equalizer	231-3311	1T-0231	Retainer - Bearing	319-3471
1P-0579	Housing As	219-9678	1P-9663	Carrier - Bearing	217-7731	1T-0237	Flange As - Output	239-7929
1P-0963	Guard As - Roller	226-0179	1P-9807	Shoe -Track	188-5333	1T-0256	Gear - Pump Drive	239-7930
1P-0965	Gear - Bevel	213-8215	1P-9808	Shoe -Track	175-8802	1T-0300	Converter As	235-1803 (Repair Kit)
1P-1006	Strip - Guard	226-0245	1P-9809	Shoe -Track	175-8882	1T-0421	Flange As - Output	295-5442
1P-1216	Manifold - Exhaust	261-0902	1P-9810	Shoe -Track	188-5334	1T-0436	Gear - Pump Drive	247-3367
1P-1605	Gear - Forward	215-1663	1P-9945	Bracket As - Fan	296-1344	1T-0437	Housing - Rotating	295-5685
1P-1608	Gear - Forward	302-2707	1P-9946	Shaft - Fan	325-6194	1T-0438	Retainer - Bearing	295-0410
1P-1636	Lever As	226-8013	1P-9952	Impeller - Pump	314-8685	1T-0443	Carrier As - Guide	247-3368
1P-1721	Gear - Balance	298-2769	1Q-4983	Shoe - Track	289-5117	1T-0447	Carrier - Ring	295-0409
1P-1722	Gear - Balance	298-2770	1S-0876	Bolt - Spring	226-0224	1T-0521	Retainer - Bearing	325-6180
1P-1758	Bushing - Stem	311-9350	1S-1532	Flange - Shaft	215-1673	1T-0553	Gear As - Pump Drive	226-5983
1P-1897	Gear - Final Drive	215-1670	1S-1801	Shaft As - Transmission	215-1674	1T-0595	Carrier - Wheel	239-7939
1P-1931	Shaft - Steer	227-4772	1S-1859	Bolt - Track	188-5633	1T-0611	Converter As	235-1804 (Repair Kit)
1P-2187	Pump Gp	299-2044	1S-1860	Nut (3/4-16)	188-5856	1T-0665	Ring - Clamp	308-9918
1P-3759	Rod Gp - Recoil	302-2713	1S-1888	Bracket - Lamp	297-7147	1T-0670	Converter As	235-1805 (Repair Kit)
1P-4145	Valve Gp - Press	247-4436	1S-1967	Chamber As	247-3291	1T-0699	Impeller - Converter	235-1808
1P-4231	Pump Gp - Gear	226-0156	1S-1970	Chamber As	247-3292	1T-0724	Impeller - Converter	216-7469
1P-4303	Head As - Cylinder	242-3434	1S-2268	Piston	226-2726	1T-0727	Hub - Impeller	229-8236
1P-5262	Cage - Bearing	226-5989	1S-2269	Sleeve	226-2720	1T-0851	Impeller - Converter	253-1418
1P-5480	Cover As - End	299-1998	1S-4701	Pulley - Alt	264-5866	1T-0930	Torque Converter	235-0913 (Repair Kit)
1P-6160	Gear - Pump Driven	231-8760	1S-5315	Cap As - Brace Bearing	226-4848	1T-0947	Flange As - Input	229-8224
1P-6265	Gear - Bevel	221-9177	1S-5331	Cylinder - Adjustable	226-0214	1T-0949	Housing - Rotating	217-7732
1P-6273	Rod Gp - Recoil	226-4847	1S-5738	Insert - Seat Exhaust	311-9396	1T-0972	Carrier As	216-7470
1P-6752	Pump Gp	226-0161	1S-6422	Pilot As - Spring	226-4849			
1P-7044	Cage	226-7975	1S-7114	Bolt	314-8500			
1P-7590	Support As	213-4400	1S-8186	Idler As.	188-5268			
			1S-8734	Bracket - Roller	226-0212			
			1S-8753	Plate - Coupling	308-9910			
			1S-8754	Joint Gp - Univ	308-9873			

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number
1T-0987	Hub - Impeller	247-4118
1T-1089	Hub - Turbine	216-7471
1T-1091	Hub - Turbine	308-9869
1T-1255	Torque Converter	235-1806 (Repair Kit)
1T-1285	Gear As - Drive	217-7734
1T-1331	Stator - Converter	229-8237
1T-1350	Torque Converter	235-0912 (Repair Kit)
1T-1386	Yoke - Univ Joint	325-6239
1T-1389	Carrier - Bearing	247-4124
1T-1428	Retainer - Bearing	300-2587
1T-1480	Turbine As - Converter	235-1818
1T-1691	Impeller - Converter	297-4863
1T-1790	Carrier As	296-1347
1T-1880	Carrier - Ring	295-0408
1T-1987	Housing - Rotating	297-4864
1T-1993	Wheel - Turbine	235-0920
1T-2050	Carrier As - Stat	325-6040
1T-2052	Stator As	295-5683
1U-0105	Brace As	295-5684
1U-0159	Pin	325-6134
1U-0612	Pin	325-6135
1U-0725	Retainer	314-8707
1U-0872	Pin	325-6136
1U-0873	Pin	325-6137
1U-0899	Pin	296-1363
1U-0928	Screw - Adjusting	325-6187
1U-0990	Pin	325-6138
1U-1204	Trunnion	325-6224
1U-1267	Brace As	296-1343
1U-4103	Trunnion	295-5680
1V-0557	Shoe - Track	288-6678
1V-0940	Holder - Bearing Cage	216-7472
1V-1080	Housing - Bearing Spt	260-0775
1V-1409	Carrier - Planet	253-1423
1V-1554	Spindle	219-2972

Original Part Number	Part Name	Classic Part Number
1V-1687	Wheel	226-5990
1V-2281	Carrier - Planet	226-5984
1V-2992	Gear - Diff Bevel	224-1301
1V-3242	Cage - Release Bearing	216-7475
1V-3335	Carrier - Planet	253-1424
1V-3676	Case - Drive Gear	216-7799
1V-3677	Case - Final Drive Gear	216-7802
1V-3995	Pin	319-3449
1V-4718	Spindle	223-4817
1V-4838	Link As - Spring	308-9874
1V-5410	Bearing	308-9806
1V-5724	Diff Gp	260-0776
1V-5744	Pin	241-2554
1V-6342	Gear As	308-9847
1V-6978	Bolt - Shoulder	308-9803
1V-7556	Support	216-7804
1V-8240	Bearing - Sleeve	308-9807
1V-8241	Bearing - Sleeve	308-9808
1V-8242	Bearing - Sleeve	308-9809
1V-8439	Pin As	308-9881
1V-8604	Gear - Ring	308-9853
1V-8606	Gear - Sun	308-9860
1V-8655	Lever As	226-5991
1V-8849	Collar	308-9838
1V-8850	Pin	308-9891
1V-8851	Cap	308-9833
1V-8852	Cap	308-9834
1V-8947	Pin As	308-9882
1V-8949	Pin As	308-9883
1V-8953	Pin	308-9892
1V-8954	Pin As	361-1696
1V-9143	Bearing - Sleeve	308-9810
1V-9148	Bearing - Sleeve	308-9811
1V-9208	Link As - Rear	299-2020
1W-0777	Muffler As	247-2662
1W-1219	Trunnion As	314-8724
1W-1669	Piston	325-6158
1W-1695	Pump Gp	279-4980

Original Part Number	Part Name	Classic Part Number
1W-1698	Housing - Transfer Pump	296-1356
1W-1766	Muffler As	298-2783
1W-2491	Muffler As	360-7871
1W-2572	Muffler As	247-2663
1W-2870	Shaft As - Balance	314-8715
1W-2871	Shaft As - Balance	314-8716
1W-3062	Retainer As	311-9445
1W-4369	Pulley - Alt	296-1340
1W-4402	Gear - Camshaft	279-4981
1W-4405	Gear - Crankshaft	279-4982
1W-4407	Hub - Fan Pulley	296-1358
1W-4623	Muffler As	360-9622
1W-4737	Gear - Camshaft	295-5688
1W-4738	Bearing - Sleeve	325-6020
1W-4740	Gear As - Drive	295-5689
1W-4746	Retainer - Gear	295-5690
1W-5105	Ring Gp - Piston	311-9446
1W-5912	Tappet As - Guide	325-6223
1W-6541	Plunger As	325-6173
1W-7940	Spider As - Fan	295-5443
1W-9191	Line As - Fuel Injector	311-9403
1W-9192	Line As - Fuel Injector	311-9404
1W-9193	Line As - Fuel Injector	311-9405
1W-9194	Line As - Fuel Injector	311-9406
1W-9195	Line As - Fuel Injector	311-9407
1W-9196	Line As - Fuel Injector	311-9408
1W-9197	Line As - Fuel Injector	311-9409
1W-9198	Line As - Fuel Injector	311-9410
1W-9201	Line As - Fuel Injector	311-9411

(Continued)

Part Numbers Beginning with 1 (Continued)

Original Part Number	Part Name	Classic Part Number
1W-9202	Line As - Fuel Injector	311-9412
1W-9203	Line As - Fuel Injector	311-9413
1W-9204	Line As - Fuel Injector	311-9414

Original Part Number	Part Name	Classic Part Number
1W-9205	Line As - Fuel Injector	311-9415
1W-9206	Line As - Fuel Injector	311-9416
1W-9207	Line As - Fuel Injector	311-9417
1W-9208	Line As - Fuel Injector	311-9418

Original Part Number	Part Name	Classic Part Number
1W-9209	Line As - Fuel Injector	311-9419
1W-9210	Line As - Fuel Injector	311-9420
1W-9211	Line As - Fuel Injector	311-9421
1W-9212	Line As - Fuel Injector	311-9422
1W-9229	Muffler As	302-4282

Part Numbers Beginning with 2

Original Part Number	Part Name	Classic Part Number
208-5026	Pin	325-6133
223-3095	Gauge As	360-2295
227-0620	Gauge As	360-2295
227-6228	Cage	360-2343
227-6789	Bearing - Sleeve	360-2322
228-5621	Bearing - Sleeve	360-2323
229-2949	Rod As - Track	347-0486
229-2950	Rod As - Track	347-0487
236-6271	Bearing - Sleeve	360-2324
236-7724	Retainer	299-2048
236-9861	Link As.	175-8555
236-9864	Link As.	188-5527
236-9866	Link As.	188-5588
237-2252	Bearing - Sleeve	347-0474
238-9951	Link As.	290-6589
239-9956	Brake Disc	347-0485
240-2913	Bearing - Sleeve	360-2325
244-1090	Alarm - Back up	360-2345
246-5228	Rim	289-2207
248-2041	Rim	289-2211
248-7143	Idler Gp	286-9830
250-2402	Pin As	360-2351
253-4393	Muffler - Converter	301-7975
253-4426	Muffler - Converter	301-7974
258-2308	Bearing - Sleeve	325-6019
281-8338	Roller - DF	275-3580
281-8339	Roller - SF	275-3579

Original Part Number	Part Name	Classic Part Number
2B-3708	Chamber As	247-3293
2B-8824	Drum	216-7817
2D-1345	Drum - Brake	228-9430
2D-1659	Rack - Shift	228-9431
2D-3467	Hub - Final Drive Gear	228-9396
2D-3609	Shaft - Final Drive Pinion	228-8919
2D-4010	Adjuster - Bearing	228-8916
2D-4205	Block - Pivot	228-9432
2D-4209	Pin - Pivot	228-9434
2D-4211	Arm - Steering	228-9435
2D-4215	Knuckle - Rh	228-9436
2D-4216	Knuckle - Lh	228-9437
2D-5658	Bearing - Ball	301-4628
2D-5795	Sleeve - Thrust	243-0360
2D-5799	Pinion - Reverse	243-0342
2D-5961	Pin - Axle Pivot	228-9438
2D-6381	Pinion	228-8915
2D-6382	Gear - Worm	228-9558
2D-7694	Shaft - Pivot	256-4774
2D-7933	Cover - Circle Rev	243-0340
2D-8212	Plate As - Press	229-1582
2D-9130	Washer - Thrust	308-9943
2F-0025	Tube	325-6233
2F-5721	Bearing - Ball	311-9354
2F-5894	Drum - Brake	228-9439
2F-5969	Collar - Coupling	228-9440
2F-5970	Collar - Coupling	228-9441

Original Part Number	Part Name	Classic Part Number
2F-6046	Pinion - Reduction	228-9442
2F-6050	Gear - Reduction	229-1584
2F-6051	Gear	229-1585
2F-6053	Gear - Reduction	228-9443
2F-6057	Gear - Reduction	228-9444
2F-7576	Shaft - Sprocket	226-6071
2F-7577	Shaft	226-6072
2F-8001	Shaft - Worm	228-9445
2F-9047	Block - Pivot	228-9446
2F-9074	Link - Tie Bar	228-9447
2G-2858	Cap - Pivot	243-0345
2G-4187	Shell - Bearing	245-5794
2G-5876	Housing - Drive	302-2684
2G-6157	Pin	282-6550
2G-6336	Hub - Brake	282-6551
2G-6375	Shaft - Drive	275-5282
2G-6377	Sprocket	275-5286
2G-7829	Housing As - Drive	297-7196
2G-8238	Yoke As	282-6631
2G-8239	Yoke As	282-6632
2G-8609	Pin	319-3450
2G-8612	Pin	282-6552
2G-8613	Pin	282-6553
2G-8616	Pin	282-6554
2G-8617	Pin	282-6555
2G-8618	Pin	299-2031
2G-8620	Pin	282-6556
2G-8621	Pin	282-6557
2G-8622	Pin	299-2032
2G-8625	Pin	282-6558

(Continued)

Part Numbers Beginning with 2 (Continued)

Original Part Number	Part Name	Classic Part Number
2G-8628	Pin	282-6559
2G-8629	Pin	282-6560
2G-8633	Pin	282-6561
2G-8736	Bearing - Sleeve	299-1959
2G-8769	Pin	282-6562
2G-8872	Shaft - Bevel	275-5271
2G-9098	Cap	300-2573
2H-4338	Plate - Pressure	226-8010
2H-4450	Washer - Thrust	325-6237
2H-4482	Collar	229-8218
2H-5046	Link - Flycam	299-2024
2H-6776	Plate - Pressure	226-8011
2H-6777	Plate - Flywheel	226-8012
2J-1506	Pin	319-3451
2J-2622	Bracket	256-4826
2J-3271	Pin	319-3452
2J-5394	Collar	256-4779
2J-5462	Trunnion	297-7264
2J-5468	Pin - Pivot	256-4781
2J-5531	Collar	256-4780
2J-5596	Pin - Pivot	297-7211
2J-5649	Pin - Cylinder	256-4782
2J-5662	Shaft - Pivot	256-4775
2J-8489	Bearing - Sleeve	295-5691
2K-0535	Nut	299-2026
2K-0714	Plate - Thrust	299-2040
2K-3592	Boss	314-8501
2K-3632	Yoke As	297-4866
2K-4177	Pin - Lock	308-9893
2K-4442	Bearing - Sleeve	308-9812
2K-4502	Bearing - Sleeve	299-1986
2K-4507	Bearing - Sleeve	325-6021
2K-4512	Bearing - Sleeve	308-9813
2K-4513	Bearing - Sleeve	308-9814
2K-5073	Bushing	299-1989
2K-5977	Yoke	226-5992
2K-6000	Shaft - Planet	221-9106
2K-6001	Shaft - Planet	221-9107
2K-6413	Pin	360-2270
2K-7418	Pin	241-2572

Original Part Number	Part Name	Classic Part Number
2K-8753	Gear - Diff	253-1432
2K-8754	Gear - Diff Bevel	253-1433
2L-4731	Adapter - Housing	311-9343
2M-0125	Cylinder - Adjustable	226-0215
2M-0365	Stop - Spring Rh	226-0230
2M-0366	Stop - Spring Lh	226-0231
2M-0369	Pilot - Spring Recoil	226-0226
2M-0398	Sleeve - Bolt	226-0235
2M-1086	Plate As - Press	226-8023
2M-1129	Cap - Support	239-7974
2M-2150	Nut - Spanner	239-7965
2M-2290	Bracket - Ring	299-1979
2M-2415	Guard-idler - Rh	226-4931
2M-2416	Guard-idler - Lh	226-4933
2M-2417	Guard-spring - Rh	226-4934
2M-2418	Guard-spring - Lh	226-4935
2M-3339	Piston - Clutch	221-7944
2M-4668	Retainer - Guard	297-4867
2M-5588	Gear - Final Drive	239-7936
2M-5589	Pinion - Final Drive	239-7942
2M-6920	Hub - Steering	239-7968
2M-6960	Cage - Gear Bearing	239-7971
2M-6984	Drum	239-7946
2M-8296	Hub - Gear	219-2961
2M-8297	Pinion - Final Drive	218-4429
2M-8304	Shaft - Sprocket	221-1038
2M-8762	Drum - Steering	239-7944
2N-3220	Gear - Oil Pump Drive	311-9392
2N-3227	Bracket - Lft Guide	311-9367

Original Part Number	Part Name	Classic Part Number
2N-7194	Cap - Main Bearing	311-9369
2N-7224	Cap As - Main Bearing	311-9370
2N-8519	Guide - Spring	314-8525
2N-9297	Retainer - Spring	314-8535
2P-0483	Chamber As	256-4760
2P-0484	Chamber As	247-3296
2P-1005	Bearing - Sleeve	296-1342
2P-1126	Pulley - Camshaft	264-5868
2P-1129	Pulley - Tightener	264-5869
2P-1170	Shaft As - Gear	296-1367
2P-1438	Pipe - Exhaust Ext	325-6157
2P-1502	Gear - Shaft	214-0956
2P-1503	Gear - First	213-8637
2P-1554	Gear - Ring	239-7931
2P-1604	Piston - Steering	219-9694
2P-1605	Pilot - Piston	219-9695
2P-1606	Piston - Steering	239-7948
2P-1607	Pilot - Piston	239-7975
2P-1738	Plate As - Oil Pan	325-6164
2P-1739	Tube As - Pump	325-6229
2P-1757	Hub - Fan Pulley	296-1357
2P-1781	Spacer - Oil Pump	325-6214
2P-2406	Pulley	264-5870
2P-2519	Tube As - Inlet	325-6230
2P-2744	Muffler As	247-2664
2P-2922	Gear - Transfer	219-9679
2P-2923	Gear - Transfer	219-9680
2P-3422	Gear - First Reduction	213-8451
2P-3423	Pinion - Sec Reduction	216-3553
2P-3424	Gear - First Reduction	215-1675
2P-3425	Pinion - Sec Reduction	217-7697

(Continued)

Part Numbers Beginning with 2 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
2P-3586	Piston - Clutch	260-0777	2S-2140	Nut (7/8-14)	188-5857	2S-8278	Guard Gp - Spring	226-4937
2P-3598	Shaft - Output	215-1676	2S-2781	Plunger - Relief	311-9435	2S-8356	Rod Gp - Track Adjustable	226-0199
2P-3669	Pinion - Bevel	215-1677	2S-3188	Plate	299-2041	2S-8892	Pulley - Fan Drive	264-5874
2P-3992	Gear - Bevel	219-9666	2S-3443	Drum - Steer	219-9689 (Drum), 230-7113 (Steering Clutch Kit)	2S-8961	Pulley - Tightener	264-5875
2P-4370	Plate - Clutch	325-6166	2S-3803	Gear	226-6106	2V-0705	Pin As	241-2524
2P-4404	Housing As	226-8027	2S-3804	Gear - Sliding	226-6107	2V-0707	Bearing - Sleeve	360-2328
2P-4409	Gear - Ring	226-7981	2S-3913	Cage - Gear Bearing	217-7722	2V-0812	Pinion - Final Drive	231-0250
2P-4435	Plate	275-5295	2S-3946	Gear - Final Drive	215-1678	2V-0813	Gear - Sec Cluster	231-0232
2P-4443	Coupling - Flywheel	301-0233	2S-3966	Ring - Seal	297-7237	2V-0814	Gear - Output	231-0233
2P-4510	Piston - Clutch	275-5293	2S-4015	Plunger As - Valve	311-9438	2V-0816	Pinion - Swing Drive	231-0017
2P-4701	Shaft As - Gear	297-7257	2S-4357	Pinion - Final Drive	217-7706	2V-0817	Gear - Cluster	231-0234
2P-5081	Muffler As	360-7872	2S-4365	Retainer As	216-3554	2V-0961	Driver	231-0255
2P-5609	Muffler As	247-2665	2S-6263	Guard Gp - Spring	226-0192	2V-1722	Pin As	241-2525
2P-5680	Turbine - Converter	308-9942	2S-6264	Guard Gp - Spring	226-0193	2V-3687	Gear - Diff Bevel	308-9849
2P-5693	Housing - Rotating	308-9866	2S-6265	Rod Gp - Recoil	226-0197	2V-4332	Collar	299-1993
2P-6128	Pulley	264-5872	2S-6344	Gear - Final Drive	297-7173	2V-4374	Joint Gp - Slip	308-9872
2P-6159	Pulley - Fan Drive	264-5873	2S-6346	Shoe -Track	188-5311	2V-4700	Pin	308-9894
2P-6245	Shaft As - Pump	325-6197	2S-6347	Shoe -Track	188-5613	2V-5551	Pinion - Final Drive	216-7822
2P-6255	Muffler As	247-2666	2S-6357	Shoe -Track	281-6373	2V-5552	Gear & Pinion - Final Drive	216-7823
2P-7622	Bolt - Spring	226-4850	2S-6364	Shoe -Track	188-5615	2V-5697	Cover As	299-1999
2P-7828	Pan - Oil	314-8691	2S-6739	Pulley - Tightener	298-2794	2V-5709	Shaft - Axle	299-2056
2P-7830	Pump Gp	314-8533	2S-7062	Shaft - Sprocket	219-9673	2V-5714	Gear - Ring	288-8716
2P-7984	Yoke As - Idler	226-0220	2S-7063	Nut	300-2584	2V-5715	Bushing	299-1987
2P-9037	Drum - Steering Clutch	219-9696	2S-7064	Cap - Shaft Bearing	299-1991	2V-5722	Carrier - Planet	297-7164
2P-9038	Drum - Steering	216-7821	2S-7099	Hub - Gear	219-2962	2V-5881	Gear - Bevel Ring	253-1434
2P-9039	Hub - Steering	219-9697	2S-7264	Pump As - Fuel Injector	311-9442	2V-6220	Shaft - Planet	221-9073
2P-9632	Damper As	299-2004	2S-7527	Flange - Drum	213-8163	2V-6221	Shaft - Planet	221-9108
2P-9660	Gear - Final Drive	226-5995	2S-7596	Retainer	215-1679	2V-6551	Pin	297-7212
2P-9667	Cage - Shaft Bearing	226-7971	2S-7603	Drum	213-6951	2V-7083	Yoke	224-1302
2P-9669	Shoe -Track Master	188-5604	2S-7873	Pump Gp	226-0162	2V-7170	Yoke	308-9948
2P-9670	Bolt Master	188-5637	2S-7917	Gear - Pump Drive	247-4119	2V-7198	Pilot As - Recoil Spring	302-2709
2P-9672	Cage - Pinion Bearing	226-7972	2S-7920	Pump Gp - Scavenge	217-2594	2V-7393	Retainer	308-9914
2R-0179	Pin As	325-6127	2S-8277	Guard Gp - Spring	226-4936	2W-1086	Cover As - Cylinder Head	325-6049
2S-1273	Chamber As	319-3434						
2S-1477	Holder As - Cage	226-7985						

(Continued)

Part Numbers Beginning with 2 (Continued)

Original Part Number	Part Name	Classic Part Number
2W-2621	Valve - Inlet	247-6892 (Valve), 241-3381 (Valve Kit)
2W-3211	Valve - Exhaust	311-9471
2W-3428	Muffler As	298-2784

Original Part Number	Part Name	Classic Part Number
2W-6030	Tube	314-8729
2W-6757	Trunnion As	295-5678
2W-7255	Shaft - Water Pump	325-6203
2W-7458	Crankshaft As	242-3439

Original Part Number	Part Name	Classic Part Number
2W-7678	Gear - Water Pump	325-6088
2W-8494	Pulley - Alt	295-5692
2W-9094	Adapter - Exhaust	299-2534
2W-9978	Core As - Oil Cooler	279-4983
2Y-4213	Pulley	314-8703

Part Numbers Beginning with 3

Original Part Number	Part Name	Classic Part Number
307-1303	Muffler As	361-6574
312-0782	Worm - Circle Drive	282-6623
323-8756	Link As.	257-1992
323-8757	Link As.	257-1990
323-8758	Link As.	257-1994
323-8759	Link As.	257-1991
3B-1464	Cap - Bearing	226-0206
3B-5067	Shaft - Shift Worm	228-8907
3B-6217	Muffler As	247-2671
3B-6218	Muffler As	247-2672
3B-6695	Gear - Worm	228-9448
3B-9970	Worm	228-8908
3D-0409	Arm - Pitman	228-9397
3D-2136	Sprocket	228-9398
3D-2149	Pinion	228-9450
3D-2236	Sprocket As	228-9399
3D-4442	Shaft - Rev Worm	243-0354
3D-4443	Shaft - Rev Worm	243-0351
3D-4498	Shaft - Lower	243-0348
3D-4718	Bearing - Sleeve	245-5795
3D-5315	Pinion - Diff Bevel	308-9856
3D-5457	Cage - Bearing	228-9400
3D-6672	Gear	229-1586
3D-9194	Gear	245-5796
3D-9502	Bolt - Draft	243-0332
3D-9786	Ballstud	228-9559
3D-9932	Cage - Bearing	228-9401
3F-0017	Gear - Coupling	229-1587
3F-0018	Gear - Coupling	229-1588

Original Part Number	Part Name	Classic Part Number
3F-0019	Collar - Coupling	229-1589
3F-1537	Nut - Spanner	226-6098
3F-1956	Cap - Frame Sup	226-7987
3F-1972	Retainer As	226-7988
3F-4971	Pin	295-5693
3F-6149	Pin	299-2033
3F-6185	Pin	295-5694
3F-6334	End-tie Rod - Rh	228-9451
3F-6338	End-tie Rod - Lh	228-9452
3F-6446	Pivot - Push Pole	256-4827
3F-6523	Pin - Clevis	256-4818
3F-6561	Arm As - Brace	256-4828
3F-6611	Socket - Joint	256-4829
3F-6612	Cap - Ball Joint	297-7155
3F-7445	Bearing - Sleeve	314-8508
3G-0034	Trunnion	361-1712
3G-0910	Cap - Bearing	325-6037
3G-1525	Bearing - Sleeve	325-6006
3G-2665	Cover	308-9842
3G-4929	Pin	325-6139
3G-6313	Bearing	325-6007
3G-6565	Bearing - Sleeve	325-6008
3G-8900	Pin	325-6140
3G-8917	Pin	325-6141
3G-8932	Pin	325-6143
3H-3378	Gear As - Pump	298-2795
3H-7161	Pin	256-4819
3H-7162	Collar	256-4830

Original Part Number	Part Name	Classic Part Number
3H-7164	Pin - Pivot	256-4820
3J-2452	Cap - Ball Joint	297-7156
3J-2682	Bracket	296-1345
3J-3493	Ballstud	256-4832
3J-4284	Cap - Bearing	314-8656
3J-4352	Arm As - Brace	297-7137
3J-5190	Cap - Bearing	256-4837
3J-5432	Pin - Pivot	297-7213
3J-6043	Trunnion	319-3477
3J-6167	Bearing - Sleeve	299-1960
3J-6173	Pin	325-6144
3J-6182	Pin As	325-6128
3J-6204	Pin As	325-6129
3J-6442	Bearing - Sleeve	299-1961
3J-6497	Screw - Adjusting	256-4825
3J-6502	Pin	319-3453
3J-6559	Cap - Bearing	296-1346
3J-6560	Screw - Adjustable	297-7240
3J-6561	Screw - Adjustable	297-7241
3J-6570	Support - Bearing	299-2069
3J-6573	Screw - Adjusting	302-2714
3J-6575	Trunnion	297-7265
3J-6576	Bearing	256-4833
3J-9133	Bearing - Sleeve	361-1691
3J-9710	Bearing - Sleeve	256-4793
3K-0963	Pin - Lock	308-9895
3K-2230	Gear - Planet	219-9658

(Continued)

Part Numbers Beginning with 3 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
3K-2280	Carrier - Transmission	223-6317	3P-0618	Shoe - Track Master	188-5602	3P-3890	Shoe - Track Master	175-8366
3K-2498	Shaft - Planet	216-7824	3P-0620	Shoe - Track Master	188-5606	3P-3891	Shoe - Track Master	175-8368
3K-3124	Muffler - Trap	247-2673	3P-0628	Link As.	175-8759	3P-3892	Shoe - Track Master	175-8674
3K-3774	Gear - Final Drive	217-7716	3P-0651	Seal - o-Ring	314-8541	3P-3896	Shoe - Track Master	175-8023
3K-3814	Gear & Pinion - Final Drive	216-7825	3P-0726	Shaft As	275-5298	3P-3935	Shaft	299-2053
3K-5461	Wheel - Steering	308-9945	3P-0785	Hub As - Clutch	302-2688	3P-4002	Pump Gp - Gear	217-2595
3K-7020	Gear - Planet	221-9074	3P-0862	Carrier - Input	301-4764	3P-4089	Gear As - Ring	239-7952
3K-7021	Gear - Ring	221-9075	3P-0894	Shaft As - Planet	302-3446	3P-4094	Housing As	239-7954
3K-7110	Gear - Planet	253-1435	3P-1609	Carrier - Planet	302-4292	3P-4096	Gear As - Ring	239-7953
3K-7111	Gear - Sun	253-1436	3P-1626	Hub As - Clutch	302-2687	3P-4142	Plate As	299-2039
3K-7112	Gear - Ring	253-1437	3P-1651	Piston As	302-4296	3P-4157	Yoke As - Idler	226-0221
3L-1425	Bearing - Ball	311-9356	3P-1757	Yoke As - Idler	226-2729	3P-4197	Guard As - Idler	226-0189
3N-2078	Pump Gp - Fuel Transfer	311-9444	3P-1849	Ring - Sealing	360-2259	3P-4850	Gear As - Oil Pump	308-9848
3N-3148	Tube As	311-9461	3P-2274	Bolt Master	200-9133	3P-4855	Pump Gp	217-2596
3N-3368	Pipe - Exhaust	311-9434	3P-2685	Piston - Clutch	308-9908	3P-5349	Piston As	275-5292
3N-6815	Shoe - Track	288-6681	3P-2692	Cage - Bearing	302-2663	3P-5359	Piston - Clutch	299-2037
3N-6841	Tube As - Inlet Rh	311-9464	3P-2768	Piston - Clutch	308-9909	3P-5672	Yoke	223-6313
3N-7326	Thrower - Camshaft Oil	311-9458	3P-2769	Support As	299-2064	3P-5736	Hub - Gear	219-2975
3N-7327	Thrower - Camshaft Oil	311-9459	3P-2811	Flange	239-7976	3P-5737	Shaft As - Clutch	275-5273
3N-9160	Ring - Camshaft Seal	311-9447	3P-2852	Clutch - Hub	301-4902	3P-5754	Hub - Gear	219-2976
3P-0114	Elbow - Exhaust	314-8516	3P-2856	Plate - Clutch	302-2693	3P-5755	Extension - Final Drive	226-7990
3P-0165	Pulley - Fan Drive	298-2775	3P-2859	Drum As	301-4644	3P-5762	Link As.	257-8022
3P-0214	Gear - Transfer	219-9681	3P-3059	Gear - Sun	308-9861	3P-6269	Cage - Pinion Bearing	239-7972
3P-0215	Gear - Transfer	219-9682	3P-3060	Gear - Sun	308-9862	3P-6293	Pump Gp	217-2597
3P-0297	Shaft As	275-5297	3P-3096	Gear - Sun	308-9863	3P-6318	Flange - Drum	213-8165
3P-0307	Cage As - Bearing	300-2572	3P-3208	Flange - Joint	301-4647	3P-6560	Stop - Recoil Spring	226-0232
3P-0324	Coupling	301-0234	3P-3241	Plate - Pressure	325-6167	3P-6561	Stop - Recoil Spring	226-0233
3P-0335	Platepress	297-7228	3P-3242	Shaft - Planet	308-9923	3P-6814	Pump Gp	226-0163
3P-0395	Cage - Carrier Bearing	217-7723	3P-3245	Shaft - Planet	308-9924	3P-6816	Pump Gp	226-0164
3P-0615	Shoe - Track Master	188-5601	3P-3246	Shaft - Planet	308-9925	3P-6880	Housing As	302-2685
3P-0616	Shoe - Track Master	175-8881	3P-3259	Cage - Bearing	217-7728	3P-7482	Cap - Drive Bearing	226-2731
3P-0617	Shoe - Track Master	188-5246	3P-3450	Yoke	229-8225	3P-7623	Pump Gp	217-2598
			3P-3623	Lock - Adjustable Nut	226-7989	3P-7640	Gear - Ctrshft	325-6093
			3P-3713	Gear As	275-5288	3P-7641	Gear - Ctrshft	325-6094
			3P-3755	Guard As	226-2721	3P-7642	Gear - Ctrshft	302-2668
			3P-3757	Guard As	226-2722			
			3P-3889	Shoe - Track Master	175-8021			

(Continued)

Part Numbers Beginning with 3 (Continued)

Original Part Number	Part Name	Classic Part Number
3P-7643	Gear - Pinion Shft	302-2669
3P-7644	Gear - Pinion Shft	302-2706
3P-8283	Spacer	325-6215
3P-9394	Shaft - Planet	215-1680
3Q-5391	Shoe - Track	292-5634
3S-0311	Rod Gp	226-4953
3S-0777	Bearing - Roller Frame	229-8226
3S-1167	Gear - Planet	221-9101
3S-1261	Shaft - Center	239-7958
3S-1262	Retainer	308-9915
3S-1274	Shaft - Center	215-1681
3S-1691	Disc - Steering	302-2705
3S-2252	Manifold - Exhaust	261-0887
3S-2337	Shaft - Output	231-8765
3S-2420	Pilot As - Spring	226-2733
3S-2616	Pump Gp - Transmission	226-0165
3S-2710	Shaft - Planet	260-0779
3S-2712	Gear - Transfer	226-7977
3S-3917	Guard As - Sprocket	226-0188
3S-3918	Guard As - Sprocket	226-4950
3S-4386	Pump Gp - Steering	217-2599
3S-5396	Shaft - Fly-wheel	226-8015
3S-6907	Gear - Transfer	217-9774
3S-6908	Gear - Transfer	217-9775
3S-6989	Nut - Spanner	219-9701
3S-7153	Gear - Sliding	227-0024
3S-7306	Flange - Drum	216-7827
3S-7308	Cage - Pinion Bearing	219-9702
3S-7504	Gear - Idler	226-6084
3S-7517	Pulley - Belt Adjustable	264-5876
3S-7519	Pulley - Damper As	264-5877
3S-7987	Shaft - Planet	226-6074
3S-7996	Gear - Ring	226-6087
3S-8007	Coupling	226-6088
3S-8034	Shaft - Planet	308-9926

Original Part Number	Part Name	Classic Part Number
3S-8634	Hub - Gear	219-2977
3S-8735	Guard As	226-2723
3S-8736	Guard As	226-9992
3S-8800	Gear - Driven	325-6090
3S-9199	Hub - Sprocket	224-1310
3S-9466	Bearing - Sleeve	314-8509
3S-9919	Shaft As	239-7959
3S-9975	Piston - Clutch	260-0778
3T-0996	Bearing - Sleeve	295-5695
3T-0997	Bearing - Sleeve	307-1524
3T-1162	Sleeve - Wear	325-6209
3T-1446	Pump Gp	325-6178
3T-1554	Guard As	295-5696
3T-1898	Drum	219-9674
3T-1899	Drum	219-9690 (Drum), 230-7114 (Steering Clutch Kit)
3T-1900	Drum - Steering Clutch	226-7991 (Drum), 230-7111 (Steering Clutch Kit)
3T-1921	Drum - Inner	229-8227 (Drum), 230-7116 (Steering Clutch Kit)
3T-2145	Carrier As	325-6041
3T-2481	Strip	295-5448
3T-2849	Strip	295-5697
3T-3203	Gear - Transfer	302-2675
3T-3206	Roller Gp - Carrier	188-5590
3T-3447	Gear As - Sun	302-2676
3T-3690	Shoe -Track	175-8553
3T-4008	Gear - Planet	295-5444
3T-4011	Shaft As - Planet	295-5698
3T-4223	Gear - Transfer	319-3438
3T-4224	Gear - Transfer	297-7175
3T-4299	Joint Gp - Univ	325-6114
3T-4308	Bearing - Sleeve	296-1341

Original Part Number	Part Name	Classic Part Number
3T-4482	Guide - Front Idler	226-0248
3T-4516	Trunnion As	325-6226
3T-4568	Shaft - Planet	314-8712
3T-4824	Gear - Planet	295-5699
3T-5021	Carrier - Planet	295-5700
3T-5200	Carrier - Planet	295-5701
3T-5294	Spacer	325-6216
3T-5297	Pin	325-6145
3T-5672	Gear As - Oil Pump	295-5447
3T-5674	Gear As - Oil Pump	295-5449
3T-5929	Gear	288-8718
3T-6247	Shaft	314-8713
3T-6795	Piston - Clutch	281-1693
3T-7192	Guard As	325-6100
3T-7195	Guard As	325-6101
3T-7399	Piston	325-6159
3T-7701	Cylinder As	325-6058
3T-7710	Guide	325-6102
3T-7711	Guide	325-6103
3T-9152	Rim - Sprocket	322-6377
3T-9153	Rim - Sprocket	322-6303
3T-9496	Plate - Retainer	299-2042
3V-1025	Shaft - Pinion	226-6109
3V-1133	Strip	226-0203
3V-2042	Hub - Gear	217-7735
3V-2281	Link As	299-2023
3V-2337	Pin As	319-3440
3V-2771	Retainer	216-7830
3V-4527	Sprocket - Track	289-2209
3V-4622	Bracket - Carriage Roller	297-7148
3V-4874	Pin	241-2544
3V-5148	Pinion - Swing Gr	231-0251
3V-5257	Bracket - Carriage Roller	297-7149
3V-5317	Gear	231-0010
3V-5378	Gear - Output	231-0235
3V-5604	Pinion - Final Drive	216-7832

(Continued)

Part Numbers Beginning with 3 (Continued)

Original Part Number	Part Name	Classic Part Number
3V-5605	Gear - Final Drive & Pinion	216-7833
3V-5778	Shaft - Sprocket	216-7834
3V-5916	Plate As - Press	226-8025
3V-5918	Gear - Final Drive	217-7717
3V-5920	Hub - Gear	222-1762
3V-6648	Pin As	308-9884

Original Part Number	Part Name	Classic Part Number
3V-7365	Hub - Gear	219-2965
3V-7427	Housing As	297-7197
3V-8777	Gear - Spiral	297-7176
3V-8927	Pin	241-2545
3V-9025	Link As.	289-4946
3V-9281	Bearing	314-8631
3V-9285	Pin	241-2546
3V-9439	Retainer As	231-0257
3W-0630	Pin	307-1525
3W-0640	Piston	325-6160

Original Part Number	Part Name	Classic Part Number
3W-0643	Cylinder	325-6061
3W-3284	Strip	296-1368
3W-3285	Strip	296-1369
3W-3628	Guard As	295-5677
3W-6551	Shaft	295-5702
3W-6555	Shaft	295-5703
3W-8239	Sleeve - Wear	360-2342
3Y-9984	Manifold - Exhaust	325-6123
3Y-9985	Manifold - Exhaust	325-6124

Part Numbers Beginning with 4

Original Part Number	Part Name	Classic Part Number
4B-1455	Cap As - Filter	361-1719
4B-5806	Shaft - Upper	243-0347
4B-7064	Shaft - Worm	245-5803
4D-0913	Arm - Steering	228-9402
4D-0926	Pin	247-4439
4D-0929	Rod End - Tie	228-9403
4D-0930	Rod End - Tie	228-9404
4D-1626	Shaft - Lift Arm	245-5805
4D-2184	Shaft - Low Pinion	229-1592
4D-2185	Shaft - Rev Idler	229-1593
4D-2198	Cage - Bearing	229-1594
4D-2218	Gear - Coupling	229-1595
4D-2219	Gear - Reverse	229-1597
4D-2220	Pinion - Transmission & Bevel	228-8920
4D-2227	Pinion	228-9453
4D-2229	Cage - Bearing	229-1598
4D-2268	Cover - Shaft	228-9454
4D-3462	Pin - Pivot	247-4440
4D-3898	Gear - Bevel	228-8921
4D-3966	Gear - Reduction	228-8924
4D-4863	Pinion	229-1599
4D-5997	Pinion	245-5809
4D-6664	Coupling - Shaft	243-0338

Original Part Number	Part Name	Classic Part Number
4D-6665	Shaft - Circle Rev	243-0349
4D-6680	Shaft - Steering Rear	228-9560
4D-6698	Bearing - Tandem Housing	228-9405
4D-6926	Segment - Control	228-9455
4D-7213	Coupling	228-9406
4D-7282	Shaft - Axle	228-9408
4D-9934	Trunnion	229-1601
4E-0183	Pin	301-7976
4E-0403	Gear - Planet	260-0781
4E-1035	Pin	241-2553
4E-1065	Pin As	241-2538
4E-1285	Link As	299-2021
4E-3196	Pin As	361-1697
4E-5213	Cover As	299-2000
4E-5882	Shaft - Axle	308-9921
4E-8500	Idler Gp -Track	288-3691
4E-8534	Retainer - Seal	300-2588
4E-8535	Retainer - Seal	300-2589
4E-9426	Collar	231-0000
4F-1121	Bracket	299-1981
4F-1252	Pin	295-5704
4F-4974	Clamp	311-9373
4H-2029	Gear - Reverse	229-1602
4H-4021	Plate As - Loading	229-8219

Original Part Number	Part Name	Classic Part Number
4H-7969	Bearing - Worm	245-5811
4H-9040	Nut	226-7996
4I-0453	Bearing - Sleeve	360-2331
4I-0704	Bearing Sleeve	360-2332
4I-3954	Tube As	301-4779
4I-3955	Tube As	301-4802
4I-3956	Tube As	301-4780
4I-3957	Tube As	301-4801
4I-8881	Tube As	301-4777
4J-0121	Cap - Bearing	360-2344
4J-1612	Pin	308-9896
4J-1614	Pin - Pivot	297-7214
4J-1616	Bracket	299-1982
4J-1641	Trunnion	314-8725
4J-1999	Ballstud	314-8625
4J-2414	Trunnion	296-1370
4J-2585	Pin	299-2034
4J-2590	Bearing	299-1958
4J-2847	Trunnion As	297-7267
4J-3015	Shaft	325-6204
4J-3583	Screw - Adjusting	297-7242
4J-3589	Cap - Ball Joint	297-7157
4J-3590	Bearing	297-7139
4J-3591	Bracket - Rh	299-1983
4J-6167	Bearing - Sleeve	325-6009
4J-6374	Bearing - Sleeve	295-6407
4J-6899	Bearing - Sleeve	308-9815

(Continued)

Part Numbers Beginning with 4 (Continued)

Original Part Number	Part Name	Classic Part Number
4K-0255	Retainer As	226-6102
4K-0299	Bearing - Sleeve	308-9816
4K-0300	Bearing - Sleeve	308-9817
4K-1102	Bearing - Sleeve	325-6010
4K-1328	Drum - Steering	216-7840 (Drum), 230-7112 (Steering Clutch Kit)
4K-3004	Bearing - Trunnion Support	314-8632
4K-3128	Bearing - Sleeve	314-8633
4K-4460	Pin	241-2609
4K-4632	Gear - Bevel	216-7842
4K-4780	Strip As - Wear	299-2063
4K-5074	Pinion	215-1683
4K-5086	Yoke	215-1684
4K-5109	Gear - Reverse	219-9659
4K-6212	Shaft - Bevel Pinion	223-4806
4K-6558	Pin - Lower	302-2710
4K-6702	Pin	241-2573
4K-6736	Drum - Brake	223-6320
4K-6737	Gear - Ring	221-9097
4K-6760	Cap - Lower	300-2574
4K-6761	Cap - Upper	300-2575
4K-6810	Retainer - Seal	300-2586
4K-6835	Gear - Output	226-5994
4K-7251	Cover	299-2003
4K-7269	Support	299-2067
4K-7386	Plate - Guide	226-4851
4K-7420	Retainer	297-7234
4K-8225	Pin - Cylinder	297-7215
4K-8416	Shaft	308-9927
4K-8561	Pin	299-2036
4K-8734	Bearing - Sleeve	299-1962
4K-9559	Hub - Gear	219-2978
4K-9598	Retainer	297-7235
4L-3307	Elbow - Manifold Inlet	311-9387
4L-3756	Bearing - Thrust	311-9366
4L-4653	Plate - Thrust	311-9440

Original Part Number	Part Name	Classic Part Number
4L-7820	Rod Assembly	311-9449
4M-0433	Shaft - Steer	239-7960
4M-0503	Gear As - Oil Pump	297-7184
4M-1001	Pump Gp - Final Drive Oil	226-0166
4M-7099	Gear - Ring	214-0521
4M-7100	Gear - Ring	214-0522
4M-7102	Gear - Ring	214-0523
4M-8845	Shaft - Planet	215-1685
4M-8967	Gear - Sun	219-9661
4M-9214	Shaft - Pump Drive	314-8543
4M-9215	Gear - Pump Idler	311-9391
4M-9216	Gear - Pump Drive	311-9390
4N-2954	Sleeve - Camshaft	299-2059
4N-3281	Line As - Fuel Injector	247-3362
4N-3282	Line As - Fuel Injector	247-3363
4N-3283	Line As - Fuel Injector	247-3364
4N-3284	Line As - Fuel Injector	247-3365
4N-3664	Guide - Valve	314-8524
4N-4356	Pulley - Camshaft	264-5878
4N-4539	Sleeve	314-8720
4N-4577	Muffler As	308-9877
4N-4782	Pulley	325-6176
4N-4864	Pump Gp - Fuel Transfer	242-3442
4N-4880	Pump Gp - Fuel Transfer	256-4758
4N-5184	Muffler As	360-7874
4N-5191	Muffler As	298-2785
4N-5390	Pulley - Alt Drive	264-5879
4N-5503	Adapter - Exhaust	299-1954
4N-6302	Belt Set - Vee	314-8495
4N-6638	Muffler As	360-7875
4N-7000	Head As - Cylinder	325-6105
4N-7526	Seal As - Pump	311-9454
4N-7692	Crankshaft As	242-3440
4N-7693	Crankshaft As	242-3439

Original Part Number	Part Name	Classic Part Number
4N-7977	Shaft As - Balance	314-8709
4N-7978	Shaft As - Balance	314-8710
4N-7982	Pulley	264-5880
4N-8591	Coupling - Exhaust	325-6053
4N-8809	Chamber As	247-3297
4N-8814	Line As - Fuel Injector	247-3366
4N-8942	Muffler As	298-2786
4N-9180	Seal As - Pump	311-9455
4N-9587	Shield - Heat	297-7260
4P-0660	Muffler As	298-2787
4P-1463	Muffler As	360-7876
4P-3546	Valve As - Relief	325-6236
4P-4010	Muffler As	298-2788
4P-9381	Line As - Fuel Injector	279-4984
4P-9382	Line As - Fuel Injector	279-4985
4P-9385	Line As - Fuel Injector	279-4986
4P-9386	Line As - Fuel Injector	279-4987
4P-9961	Line As - Fuel Injector	325-6115
4P-9962	Line As - Fuel Injector	325-6116
4P-9963	Line As - Fuel Injector	298-2777
4P-9964	Line As - Fuel Injector	298-2778
4S-5049	Guard As - Rh	226-0183
4S-5050	Guard As - Lh	226-0184
4S-5833	Spacer	239-7961
4S-5943	Piston - Clutch	221-9112
4S-5944	Gear - Sun	221-9078
4S-5945	Gear - Sun	221-9079
4S-5946	Shaft - Center	229-8238
4S-5947	Gear - Ring	221-9080
4S-5948	Gear - Ring	221-9082
4S-5979	Carrier As	216-7843
4S-5981	Gear - Ring	221-9084
4S-6189	Pinion - Reverse	226-6077
4S-6190	Pinion - Forward	226-6078

(Continued)

Part Numbers Beginning with 4 (Continued)

Original Part Number	Part Name	Classic Part Number
4S-6256	Nut - Bearing Adjustable	235-8008
4S-6559	Tube	325-6234
4S-6707	Piston - Clutch	215-1686
4S-8005	Pinion - Final Drive	226-6076
4S-8472	Hood As	296-1355
4S-8530	Shaft - Planet	221-9111
4S-8534	Shaft As - Planet	221-9116
4S-8660	Pump Gp - Transmission	226-0167
4S-8670	Shaft - Planet	300-2590
4S-8687	Piston - Clutch	226-8008
4S-8707	Shaft & Sun Gear	226-6089
4S-8708	Housing - Clutch	216-3557
4S-8713	Gear - Ring	226-6090
4S-8716	Gear - Transfer	226-7978
4S-8718	Cage - Carrier Bearing	217-7724
4S-8906	Insert	311-9397
4S-8908	Insert	311-9399
4S-8909	Insert - Valve Seat	311-9400
4S-9062	Cap - Final Drive Bearing	226-0204
4T-0202	Pin As	325-6130
4T-0732	Bracket	314-8627
4T-0998	Lever	314-8687
4T-1504	Trunnion	314-8727

Original Part Number	Part Name	Classic Part Number
4T-5172	Seal As	325-6189
4T-5405	Trunnion As	319-3476
4T-5495	Ballstud	314-8626
4T-6151	Trunnion	295-5671
4T-8088	Screw	325-6188
4T-9444	Pin	325-6146
4V-0015	Plate - Lock	282-6563
4V-0381	Bearing - Sleeve	299-1963
4V-2518	Shaft	297-7243
4V-2744	Gear	224-1303
4V-3044	Plate - Lock	308-9911
4V-3396	Hub - Gear	222-1763
4V-3397	Hub - Gear	219-2979
4V-3603	Pin As	319-3441
4V-3680	Bellcrank	308-9802
4V-5100	Support - Trunnion	299-2068
4V-5213	Spindle	299-2060
4V-5388	Shaft - Bevel Pinion	297-7244
4V-5393	Gear - Bevel	297-7189
4V-5394	Gear - Diff Bevel	297-7177
4V-5454	Link	299-2025
4V-5608	Pin As	241-2529
4V-6040	Drum	297-7168
4V-6156	Saddle As	299-2052
4V-6421	Pin As	319-3442
4V-6430	Bracket As	299-1974
4V-7099	Pin As	361-1698
4V-7105	Pin As	361-1699
4V-7344	Pin	241-2574

Original Part Number	Part Name	Classic Part Number
4V-7543	Retainer	281-1699
4V-8519	Bearing - Sleeve	307-1526
4V-8520	Bearing - Sleeve	307-1527
4V-8534	Shaft - Planet	281-1700
4V-8538	Gear - Ring	288-8720
4V-8673	Bearing - Sleeve	307-1528
4V-8674	Bearing - Bushing	307-1529
4V-8687	Boss	299-1971
4V-8690	Boss	299-1972
4V-9236	Plate - Pressure	231-0260
4V-9577	Shaft - Planet	231-0001
4W-0452	Seal As - Camshaft	325-6191
4W-2042	Spacer	325-6217
4W-2446	Damper As	279-4990
4W-2606	Seal Gp - Camshaft	311-9452
4W-2607	Seal Gp - Camshaft	311-9453
4W-5053	Muffler As	360-7881
4W-5549	Core As - Oil Cooler	311-9376
4W-5550	Core As - Oil Cooler	311-9377
4W-5551	Core As - Oil Cooler	311-9378
4W-9771	Gear - Crankshaft	302-2674
4W-9989	Gear As - Idler	302-2677
4Y-2817	Ejector As	295-6423

Part Numbers Beginning with 5

Original Part Number	Part Name	Classic Part Number
5A-3187	Bolt Master	257-7773
5A-4003	Shaft - Sprocket	229-8228
5A-5196	Hub - Gear	221-1066
5A-5740	Gear - Sliding	229-8229
5A-6897	Guard - Idler Rh	226-4951
5A-6898	Guard - Idler Lh	226-4952
5A-7840	Shaft - Track Sprocket	215-1687
5A-7841	Hub - Gear	219-2966

Original Part Number	Part Name	Classic Part Number
5A-8374	Roller Gp - Carrier	200-9185
5A-9551	Gear - Final Drive	226-7979
5B-0577	Collar	299-1992
5C-0451	Gear Gp - Bearing	235-5053
5C-0949	Link As.	290-3452
5C-1834	Gear	231-0002
5C-3712	Gear	231-0003
5C-3714	Gear	231-0222
5C-3715	Gear	231-0223

Original Part Number	Part Name	Classic Part Number
5C-3716	Gear	231-0224
5C-3717	Gear	231-0225
5C-3784	Pin As	241-2512
5C-5038	Pin As	241-2506
5C-5153	Cartridge	231-0011
5C-5236	Gear	231-0226
5C-5829	Pin As	241-2510
5C-5837	Retainer - Pin	299-2047
5C-5937	Gear	231-0004
5C-6690	Pin As	241-2508
5C-8172	Pin As	241-2515

(Continued)

Part Numbers Beginning with 5 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5C-8582	Shaft - Planet	231-0241	5H-1719	Pump Gp - Final Drive Oil	226-0168	5K-3968	Cage - Bearing	308-9804
5C-8583	Gear - Ring	231-0005	5H-5500	Collar - Fly-wheel	302-2704	5K-4079	Cage - Bearing	308-9805
5C-8584	Gear - Planet	231-0006	5H-5553	Screw - Tap-pet Adjustable	311-9451	5K-4180	Gear - Planet	308-9854
5C-8586	Gear	231-0007	5I-7619	Pulley	301-4772	5K-4268	Retainer - Bearing	308-9916
5C-8587	Cover	231-0243	5I-7694	Impeller	301-4763	5K-4305	Support As	308-9937
5C-8966	Gear	231-0227	5I-7959	Pulley As	301-5256	5K-4426	Bushing	308-9831
5C-9207	Drum	301-4623	5I-8628	Plate - Valve	301-4771	5K-4787	Bearing - Sleeve	308-9819
5D-0034	Plate - Retainer	228-9456	5J-0698	Pin	319-3456	5K-4801	Pin	308-9899
5D-0395	Bracket - Rail Rh	243-0335	5J-1204	Pin As	325-6131	5K-4802	Pin	308-9900
5D-0396	Bracket - Rail Lh	243-0334	5J-2602	Plate As - Trunnion	256-4838	5K-4819	Pin	308-9901
5D-0470	Valve Gp	314-8549	5J-3492	Bearing - Sleeve	308-9879	5K-5927	Boss	299-1973
5D-0927	Shaft - Reduction	229-1605	5J-4321	Trunnion	302-2700	5K-5933	Cover As	247-4125
5D-3283	Coupling - Shaft	243-0339	5J-4542	Bearing - Sleeve	308-9818	5K-6090	Flange	216-7844
5D-3961	Block - Brake	245-5813	5J-4798	Bearing As	256-4840	5K-6142	Cage - Final Drive Gear Bearing	223-4811
5D-4010	Rack	228-8909	5J-4924	Shaft - Pivot	256-4777	5K-6377	Pin	241-2610
5D-5039	Ballstud	228-8910	5J-4929	Bearing	256-4796	5K-6382	Pin	241-2611
5D-6201	Shoe - Yoke	243-0356	5J-5643	Connector	325-6043	5K-6383	Pin	241-2612
5D-6375	Shaft - Final Drive Pinion	228-9409	5J-6417	Bearing	256-4798	5K-7027	Pin	241-2575
5D-7339	Coupling	245-5816	5J-6418	Bearing - Sleeve	256-4799	5K-7995	Bearing - Sleeve	308-9820
5D-7461	Pin	247-4441	5J-6419	Bearing - Sleeve	256-4800	5K-8265	Pin	241-2590
5D-7462	Pin	247-4442	5J-6421	Bearing	256-4801	5K-8330	Holder - Tooth	299-2013
5D-9548	Hub - Final Drive Gear	228-9412	5J-7980	Pin	256-4783	5K-8606	Cage - Gear Bearing	223-6310
5D-9906	Shaft - Axle	228-9413	5J-7981	Pin	256-4784	5K-8628	Cage	216-7845
5D-9972	Shaft	229-1607	5J-7983	Pin	256-4785	5K-9367	Pin	241-2613
5F-0689	Pin	256-4821	5J-8052	Trunnion	256-4843	5L-2648	Bearing - Sleeve	311-9362
5F-0706	Pin	256-4822	5K-0609	Cover	308-9843	5L-2660	Bearing - Sleeve	311-9363
5F-0707	Collar	256-4831	5K-0871	Pin - Lower	282-6630	5L-2894	Bearing - Sleeve	311-9364
5F-0736	Pin - Pivot	256-4823	5K-0989	Cap - Upper	297-7158	5L-3980	V - Belt Set	314-8498
5F-1401	Pin - Pivot	297-7216	5K-0990	Pin	299-2035	5L-5656	Belt Set - Vee	314-8499
5F-2256	Cage - Bearing	226-7973	5K-0991	Cap - Lower	319-3433	5L-8856	Coupling - Exhaust	311-9379
5F-6393	Shaft	308-9928	5K-1068	Retainer - Seal	260-0786	5L-9370	Elbow - Manifold Inlet	311-9388
5F-7404	Nut - Bearing Lock	308-9878	5K-2570	Spacer	226-5996	5L-9371	Connector - Inlet	311-9375
5F-7993	Pin	319-3454	5K-2888	Hub - Gear	219-2967	5L-9738	Coupling - Exhaust	311-9380
5G-3612	Cap Gp	295-6419	5K-2893	Shaft - Sprocket	221-7953	5M-0549	Gear - Transmission	215-1689
5G-9075	Strip	295-0412	5K-3490	Spacer	308-9933	5M-1127	Countershaft	216-3558
5G-9076	Strip	295-0413	5K-3491	Spacer	308-9934	5M-1133	Gear - Idler	214-0524
5H-0049	Hub - Fly-wheel	229-1608	5K-3497	Pin	308-9897			
5H-0051	Plate - Fly-wheel	229-1610	5K-3499	Pin - Lower	308-9898			
5H-0057	Ring - Bearing Thrust	229-1613	5K-3502	Cap - Lower	308-9835			
			5K-3967	Yoke As	308-9946			

(Continued)

Part Numbers Beginning with 5 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
5M-1137	Gear As - Ctrshft	214-0960	5M-6670	Shaft - Sprocket	216-7847	5N-8501	Head As - Cylinder	256-4762
5M-1139	Gear As - Ctrshft	214-0961	5M-6673	Guard - F Idler Rh	226-2735	5N-8657	Manifold - Exhaust	261-0886
5M-1141	Gear As - Ctrshft	214-0962	5M-6674	Guard - F Idler Lh	226-2736	5N-8879	Manifold - Exhaust	261-0898
5M-1143	Gear As	214-0963	5M-6690	Hub - Steering	215-1695	5N-9055	Manifold - Exhaust	261-0890
5M-1145	Gear As - Forward	214-0964	5M-7290	Cage - Bearing	216-7848	5P-7807	Bearing - Ball	314-8502
5M-1147	Gear As - Reverse	214-0965	5M-7306	Cylinder	226-2737	5P-8194	Ring - Retaining	308-9920
5M-1988	Piston - Steer	219-9691	5M-7336	Retainer - Washer	325-6181	5S-0073	Plate - Steering	302-2692
5M-1990	Pilot - Piston	229-8233	5M-7340	Cage - Bearing	325-6034	5S-0135	Cage - Pinion Bearing	222-1766
5M-1998	Drum Steering	213-6952	5M-7342	Flange - Shaft	215-1696	5S-0160	Strip - Guard	226-2738
5M-2026	Hubdriving	216-4471	5M-7344	Gear - Bevel	213-8741	5S-0161	Strip - Guard	226-2739
5M-2971	Guard As - Front Idler	226-0190	5M-7345	Gear - Bevel	214-0957	5S-0162	Guard As - Guiding	226-2740
5M-3470	Gear - Transmission	224-1305	5M-7346	Gear - Bevel	214-0958	5S-0163	Guard As - Guiding	226-2741
5M-3474	Shaft - Output	215-1690	5M-7348	Gear - Bevel	215-1699	5S-0192	Pinion - Final Drive	215-1698
5M-3499	Shaft - Planet	319-3475	5M-7349	Gear - Bevel	213-8742	5S-0464	Gear - First Reduction	216-7852
5M-3906	Gear - Ring	214-0526	5M-7352	Gear - Bevel	217-7713	5S-0465	Pinion - Reduction	216-7853
5M-3907	Carrier - Planet	210-8475	5M-7353	Gear - Bevel	217-7714	5S-0726	Hub As - Sprocket	227-4769
5M-3941	Shaft - Planet	215-1691	5M-7355	Gear - Reverse	216-3581	5S-0821	Shoe - Track	175-8020
5M-3942	Shaft - Planet	215-1692	5M-7740	Gear - Bevel	213-8216	5S-0822	Shoe - Track	175-8365
5M-3947	Shaft - Planet	223-6318	5M-7841	Gear - Ring	214-0525	5S-0823	Shoe - Track	175-8367
5M-3996	Gear - Ring	214-0527	5M-7864	Pump Gp - Scavenge	226-0169	5S-0884	Gear - Ring	226-7982
5M-3998	Gear - Ring	214-0528	5M-7869	Gear - Ring	214-0530	5S-0885	Plate - Front	229-8234
5M-3999	Shaft - Transmission	215-1693	5M-7875	Carrier - Front	213-4495	5S-0894	Shaft - Center	226-6075
5M-4427	Gear - Sun	214-0529	5M-7882	Joint Gp - Univ	297-7210	5S-1211	Cover - Valve	314-8665
5M-5037	Hub - Gear	219-2980	5M-7900	Bolt - Hex Head	311-9349	5S-1757	Insert - Seat	311-9401
5M-5073	Joint Gp - Univ	325-6113	5M-7923	Shaft - Output	215-1697	5S-1822	Chamber As	248-5406
5M-5243	Hub - Gear	219-2981	5M-7953	Carrier As	239-7977	5S-1833	Chamber As	247-3298
5M-5244	Hub - Gear	219-2982	5M-7990	Gear - Sun	239-7938	5S-4023	Gear	229-8230
5M-5822	Gear - Pump Drive	247-4120	5M-8007	Gear - Ring	239-7932	5S-4359	Pump Gp - Transmission	226-0157
5M-6120	Gear - Sun	213-8740	5N-2691	Elbow - Air Transfer	311-9383	5S-4470	Gear - Transfer	224-1304
5M-6198	Shaft - Planet	297-7245	5N-2692	Elbow - Air Transfer	311-9384	5S-4493	Carrier - Planet	223-6321
5M-6199	Shaft As - Planet	215-1694	5N-2902	Seal - Oil	314-8540	5S-4557	Bearing	311-9360
5M-6208	Gear - Ring	247-4121	5N-3009	Tube As - Inlet Lh	311-9465	5S-4863	Holder As - Cage	215-1732
5M-6210	Shaft - Planet	219-9683	5N-3012	Tube As - Inlet	311-9466	5S-5746	Retainer - Guard	319-3472
5M-6211	Shaft - Planet	219-9684	5N-3050	Elbow - Outlet	311-9389			
5M-6636	Support - Frame	235-8007	5N-4378	Shaft As - Pump	311-9456			
5M-6651	Hub - Gear	211-2135						

(Continued)

Part Numbers Beginning with 5 (Continued)

Original Part Number	Part Name	Classic Part Number
5S-6513	Guard As - Roller	226-4938
5S-6531	Holder As - Cage	214-2078
5S-6795	Chamber As	242-3437
5S-6796	Drum - Inner	213-6953 (Drum), 230-7115 (Steering Clutch Kit)
5S-6910	Shoe -Track	188-5603
5S-6911	Shoe -Track	188-5605
5S-6972	Gear - Sun	221-9087
5S-6978	Shaft - Planet	221-9103
5S-7009	Plate As - End	226-4957
5S-7010	Shaft - Planet	221-9104
5S-7013	Gear - Ring	221-9088
5S-7023	Carrier - Planet	226-5986
5S-7609	Pulley - Alt Drive	264-5881
5S-7888	Retainer - Bearing	226-5988

Original Part Number	Part Name	Classic Part Number
5S-7894	Flange As	216-7854
5S-7944	Shaft - Planet	297-7246
5S-7945	Shaft As - Planet	275-5299
5S-8038	Pulley - Crankshaft	264-5882
5S-8767	Gear - First	226-6085
5S-9080	Pulley - Alt Drive	264-5883
5T-0906	Cover	282-6625
5T-1362	Bearing - Spider	325-6011
5T-2925	Strip - Wear	282-6564
5T-2926	Shoe - Circle Guide	302-2699
5T-3475	Shaft	297-7247
5T-5222	Shoe - Circle Guide	297-7261
5T-6298	Lever	299-2018
5T-8500	Shoe - Circle Drive	243-0359

Original Part Number	Part Name	Classic Part Number
5T-8501	Shoe - Circle Drive	243-0358
5V-1271	Diff Gp	299-2008
5V-1480	Gear - Sun	288-8721
5V-1508	Pin As	361-1703
5V-1509	Pin As	319-3443
5V-1510	Pin As	252-6876
5V-1882	Pin As	361-1700
5V-4075	Gear - Planet	288-8722
5V-4969	Sprocket - Track	289-2205
5V-5279	Bearing - Sleeve	299-1966
5V-5661	Bearing - Sleeve	299-1965
5V-5866	Pin As	361-1707
5V-5917	Pinion - Diff Bevel	297-7224
5V-7207	Pinion - Final Drive	231-0252
5V-7214	Pin As	241-2522
5V-7222	Gear - Final Drive	231-0237
5V-8782	Lever As	299-2014

Part Numbers Beginning with 6

Original Part Number	Part Name	Classic Part Number
6A-4701	Gear	231-0231
6A-7129	Bearing - Sleeve	301-3130
6A-7534	Retainer	231-0244
6A-7539	Sprocket - Track	322-6304
6B-3158	Shoe - Yoke Lh	243-0357
6B-6911	Worm - Rh	245-5819
6B-6912	Worm - Lh	245-5820
6B-6941	Bearing - Worm	245-5812
6B-7178	Fork - Band Adjustable	299-2009
6C-0739	Carrier As	231-0012
6C-1573	Rod	297-7238
6C-3495	Sprocket - Track	322-6302
6C-3740	Shaft As	231-0013
6C-5062	Pinion	231-0016
6C-6374	Tube As	301-4778
6D-0217	Bearing - Sleeve	325-6022

Original Part Number	Part Name	Classic Part Number
6D-0687	Gear - Bevel	228-8922
6D-0708	Pinion	228-8923
6D-1599	Block - Link Pivot	228-9414
6D-1644	Shaft - Rod Pivot	228-9562
6D-1777	Gear - Planet	245-5799
6D-1778	Gear - Planet	245-5800
6D-1779	Gear - Planet	245-5801
6D-2362	Worm	243-0361
6D-4909	Cap - Pivot	297-7159
6D-6114	Cap	245-5822
6D-6201	Ballstud	228-9103
6D-6943	Housing - Axle	228-9416
6D-8671	Bolt - Draft	243-0333
6D-9164	Shaft - Pinion	243-0353
6D-9193	Hub - Final Drive Gear	228-9417
6D-9294	Shaft	228-9418
6E-1108	Bearing - Sleeve	325-6023
6E-1500	Piston	346-5677

Original Part Number	Part Name	Classic Part Number
6E-3535	Bearing - Sleeve	360-2333
6E-6153	Plate - Port	346-5678
6E-6163	Shaft	346-5679
6F-2904	Bearing	295-5673
6F-3183	Cap - Bearing	325-6038
6F-5201	Gear - Worm	245-5797
6F-6992	Cap - Ball-socket	297-7160
6F-7523	Cap - Bearing	325-6039
6G-1100	Shaft - Drive	297-7248
6G-1633	Chain Gp	282-6565
6G-1664	Adapter	297-7135
6G-1908	Housing As - Drive	297-7198
6G-1919	Cap - Pivot	243-0337
6G-2947	Shaft	243-0346
6G-4525	Strip - Wear	282-6624
6G-4680	Adapter	302-2633
6G-6241	Gear - Worm	299-2010
6H-3217	Shaft As - Rocker	311-9457
6H-3957	Bearing - Ball	311-9358

(Continued)

Part Numbers Beginning with 6 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
6I-0341	Line As - Fuel Injector	325-6117	6K-4617	Shaft - Sprocket	221-7951	6L-6482	Elbow - Air Outlet	311-9386
6I-0342	Line As - Fuel Injector	325-6118	6K-5448	Pin	252-6856	6L-6491	Pipe - Cross-over	311-9433
6I-0343	Line As - Fuel Injector	325-6119	6K-5472	Pin	252-6857	6L-7816	Seal - o-Ring	314-8542
6I-0344	Line As - Fuel Injector	325-6120	6K-5513	Pin	241-2558	6L-8585	Gear - Gov Drive	314-8526
6I-0345	Line As - Fuel Injector	325-6121	6K-5619	Shaft	253-1429	6L-8968	Coupling - Exhaust	311-9381
6I-0346	Line As - Fuel Injector	325-6122	6K-5621	Retainer - Oil Seal	253-1443	6L-9210	Idler Gp (Complete Idler Group)	175-8038 (Idler As.), 200-9236
6I-1346	Pump Gp - Oil	295-5674	6K-5625	Gear - Bevel Ring	253-1438	6L-9211	Idler Gp	200-9237
6I-8132	Pinion	226-6080	6K-6001	Pin	308-9902	6L-9212	Idler Gp	200-9238
6I-8736	Guard As	295-6434	6K-6046	Pin	241-2602	6N-0714	Pulley - Alt	264-5884
6I-9034	Guard As	295-6435	6K-6047	Pin	241-2603	6N-0762	Pulley - Fan	264-5885
6I-9454	Shoe -Track	286-9826	6K-6051	Pin	252-6858	6N-1036	Gear - Oil Pump	279-4991
6J-0774	Trunnion	256-4844	6K-6053	Pin	241-2604	6N-1553	Coupling - Exhaust	295-6422
6J-0800	Bearing	297-7140	6K-6054	Pin	241-2605	6N-1572	Mount As	308-9876
6J-2326	Pin	319-3458	6K-6175	Pin	241-2606	6N-1878	Muffler As	360-7883
6J-5342	Retainer	325-6182	6K-6185	Pin - Cylinder	252-6859	6N-1965	Line As - Fuel Injector	250-7535
6J-5354	Bearing	297-7142	6K-6349	Pin	252-6860	6N-1966	Line As - Fuel Injector	250-7536
6J-6229	Pin	299-2030	6K-7161	Pin	241-2559	6N-2789	Pulley	264-5886
6J-7563	Pin	319-3459	6K-7162	Pin	241-2560	6N-3256	Mount As	314-8688
6J-8805	Bearing As	256-4841	6K-7164	Pin	241-2561	6N-3964	Muffler As	360-7884
6J-9258	Trunnion As	256-4846	6K-7165	Pin	241-2562	6N-5437	Muffler As	247-2674
6J-9474	Pin As	319-3444	6K-7166	Pin - Arm Pivot	241-2563	6N-6969	Chamber As	247-3299
6J-9793	Bearing	256-4835	6K-7167	Pin	241-2569	6N-7295	Manifold - Exhaust	261-0903
6K-0053	Housing	297-7191	6K-7284	Pin	241-2591	6N-8413	Housing - Pump	325-6110
6K-1983	Pin	241-2614	6K-7285	Pin	252-6861	6N-8847	Guide - Valve	314-8523
6K-2034	Shaft	297-7249	6K-7286	Pin	241-2592	6N-9743	Support - Muffler	308-9940
6K-2036	Rack	299-2045	6K-7287	Pin	241-2564	6P-0169	Hub - Fly-wheel Clutch	297-7204
6K-2085	Shaft - Bevel Pinion	221-9102	6K-7288	Pin	252-6862	6P-0549	Guard - Final Drive Wear	223-4812
6K-2703	Pin - Lower	252-6853	6K-8307	Pin	241-2593	6P-1382	Pin	241-2615
6K-2704	Pin - Upper	252-6873	6K-8308	Pin	241-2594	6P-1383	Pin	241-2616
6K-2707	Plate - Lock	319-3470	6K-8309	Pin	241-2595	6P-2233	Gear - Planet	281-1690
6K-3447	Pin	241-2576	6K-8311	Pin	241-2599	6P-2776	Gear - Final Drive	217-7718
6K-3674	Shaft - Bevel Pinion	253-1427	6K-8314	Pin	252-6863	6P-3593	Support	229-8231
6K-3937	Pin	241-2557	6K-8316	Pin	252-6865	6P-3596	Hub	222-1764
6K-4180	Pin - Upper	252-6854	6K-8542	Pin	252-6867	6P-3597	Retainer	222-1770
6K-4190	Cap - Lower	297-7161	6K-8544	Pin	252-6874	6P-4948	Cap - Final Drive Bearing	226-0205
6K-4191	Cap - Upper	300-2576	6K-8546	Pin	252-6868			
6K-4192	Pin - Lower	252-6855	6K-8897	Bracket As	299-1977			
6K-4193	Plate - Lock	282-6566	6K-9841	Cam & Lever As	226-5997			
6K-4498	Bracket As - Lh	299-1976	6L-3902	Line As - Fuel	311-9423			
6K-4600	Yoke	226-5993	6L-3910	Line As - Fuel	311-9424			
			6L-4714	Panel - Air Cleaner Filter	314-8532			
			6L-6481	Elbow - Air Inlet	311-9385			

(Continued)

Part Numbers Beginning with 6 (Continued)

Original Part Number	Part Name	Classic Part Number
6P-5172	Guard Gp - Recoil	226-0196
6P-5173	Guard Gp - Recoil	229-8617
6P-5343	Rod Gp - Track Adjustable	226-0200
6P-5404	Plate & Brake	325-6168
6P-6556	Carrier As	308-9836
6P-6653	Plate - Guide	226-0208
6P-6739	Shaft - Planet	308-9929
6P-7358	Pump Gp	308-9913
6P-7625	Guard As - Track Roller	226-0185
6P-7626	Guard As - Track Roller	226-0186
6P-7627	Guard As - Track Roller	226-0187
6P-7704	Carrier - Ring	314-8658
6P-7742	Shaft - Planet	281-1695
6P-7743	Shaft - Planet	281-1696
6P-8003	Gear - Planet	281-1689
6P-8005	Gear - Planet	281-1691
6P-8884	Guard As - Idler	226-2742
6P-8904	Guard Gp - Track Adjustable	226-2744
6S-3457	Pin	325-6147
6S-3609	Roller - Carrier	275-3578
6S-3759	Pin As	241-2543
6T-0064	Shaft - Planet	295-6442
6T-0234	Retainer	325-6183
6T-0240	Retainer	325-6184
6T-0241	Piston	325-6161
6T-0243	Plate - Thrust	325-6169
6T-0248	Ring - Seal	295-6440
6T-0443	Pinion - Shaft & Bevel	226-7999
6T-0511	Link As.	290-3449
6T-0830	Housing As	297-7199
6T-1702	Support As	299-2065
6T-1705	Shaft - Pump Drive	283-5201
6T-1706	Gear - Pump Drive	283-5202
6T-1724	Bar As - Equalizer	283-5223

Original Part Number	Part Name	Classic Part Number
6T-1933	Collar - Idler End	226-2746
6T-1980	Collar - Idler End	226-0210
6T-3009	Piston - Clutch	297-7226
6T-3080	Plate & Brake	325-6170
6T-3285	Shaft - Track Idler	325-6205
6T-4481	Shaft - Planet	221-7946
6T-6053	Pinion - Shaft & Gear	226-6079
6T-6782	Segment Gp - Sprocket	188-5641 (sprocket)
6T-6987	Piston - Clutch	297-7227
6T-7882	Gear - Planet	296-1352
6T-8250	Retainer	319-3473
6W-0240	Bearing - Brace	297-7143
6W-1629	Shaft - Bevel Pinion	297-7250
6W-2398	Retainer	231-0014
6W-2451	Sprocket - Track	322-6376
6W-3674	Gear	231-0228
6W-4281	Yoke - Flange	308-9949
6W-4284	Cage - Bearing	308-9832
6W-7290	Shaft - Planet	308-9930
6W-7331	Cover As	308-9845
6Y-0305	Cage As - Bearing	297-7150
6Y-0580	Carrier - Planet	301-4768
6Y-0710	Gear	226-6104
6Y-0926	Gear - Planet	295-6427
6Y-0984	Gear - Ring	295-6428
6Y-1381	Shoe - Track	275-3564
6Y-1382	Shoe - Track	275-3565
6Y-1385	Shoe - Track	275-3570
6Y-1386	Shoe - Track	275-3571
6Y-1711	Link As.	261-8008
6Y-1713	Link As.	257-1993
6Y-2054	Plate As	302-2695
6Y-2192	Shoe - Track	288-6668
6Y-3896	Pin As	325-6132
6Y-4027	Pin	325-6148

Original Part Number	Part Name	Classic Part Number
6Y-4819	Carrier - Planet	296-1348
6Y-4840	Plate As	297-7233
6Y-5344	Shoe - Track	275-3566
6Y-5345	Shoe - Track	275-3567
6Y-5812	Bearing - Sleeve	325-6012
6Y-6126	Plate - Wear	325-6174
6Y-6127	Plate - Wear	325-6175
6Y-6134	Bearing - Sleeve	325-6013
6Y-6234	Bearing - Sleeve	325-6014
6Y-6236	Bearing - Sleeve	325-6024
6Y-6289	Shoe - Track	188-5270
6Y-6290	Shoe - Track Master	175-8728
6Y-6291	Shoe - Track	175-8031
6Y-6292	Shoe - Track Master	175-8032
6Y-6293	Shoe - Track	175-8369
6Y-6294	Shoe - Track Master	175-8370
6Y-6295	Shoe - Track	175-8371
6Y-6296	Shoe - Track Master	175-8372
6Y-6394	Shoe - Track Master	188-5591
6Y-6395	Shoe - Track	188-5396
6Y-6397	Shoe - Track Master	188-5594
6Y-6398	Shoe - Track	188-5593
6Y-6405	Shoe - Track	290-9938
6Y-6407	Shoe - Track	288-6679
6Y-6411	Shoe - Track	188-5397
6Y-6412	Shoe - Track Master	188-5592
6Y-6751	Pin	325-6149
6Y-6752	Pin	325-6150
6Y-6775	Pin	325-6151
6Y-6931	Shaft As	325-6206
6Y-7471	Pin - Pivot	325-6152
6Y-7474	Pin - Pivot	325-6153
6Y-7877	Housing As	297-7200
6Y-8184	Link As.	289-4948
6Y-8248	Pin	325-6154
6Y-9468	Retainer As	325-6185
6Y-9930	Mount As	360-2353

Part Numbers Beginning with 7

Original Part Number	Part Name	Classic Part Number
7B-0503	Ballstud	308-9801
7B-2420	Ferrule - Director	314-8517
7B-5036	Shaft - Bracket	297-7251
7B-5088	Drum - Steering	223-4813
7C-0942	Adapter As	302-2636
7C-3567	Mount As	314-8689
7C-4297	Seal As - Camshaft	325-6192
7C-5851	Muffler As	298-2790
7C-5920	Insert - Seat	314-8528
7C-5921	Insert - Seat	314-8529
7C-5922	Insert - Seat	314-8530
7C-6398	Muffler As	360-7885
7D-2199	Sleeve As	228-9563
7D-2267	Link As	228-9564
7D-2637	Gear - Worm	231-8761
7D-3815	Gear - Final Drive	228-9419
7D-4519	Shaft	245-5807
7D-4523	Coupling	245-5817
7D-4688	Shaft As - Steering	228-9565
7D-5446	Shaft As - Control Drive	229-1616
7D-5813	Gear - Worm	228-8911
7D-5847	Pinion	228-8912
7D-5859	Adapter	297-7136
7D-5861	Adapter	243-0364
7D-6436	Pinion - Reverse	243-0344
7D-6516	Pinion - Reverse	243-0343
7D-6524	Shaft - Axle	228-8917
7D-6568	Cover As	228-9457
7D-6588	Worm	243-0362
7D-6841	Joint As - Univ	228-9566
7D-7075	Worm	243-0363
7D-7078	Shaft - Rev Worm	243-0355
7D-7289	Hub As Brake	229-1617
7D-7385	Shaft	228-9420
7D-7386	Shaft	228-9567
7D-7427	Sprocket	228-9458
7D-7442	Hub - Final Drive Gear	228-8918
7D-7854	Support - Rack	228-8913

Original Part Number	Part Name	Classic Part Number
7D-7889	Gear - Ring	275-5276
7E-0853	Muffler As	360-7887
7E-5663	Muffler As	247-2667
7F-6269	Gear - Worm	245-5798
7F-9263	Cap - Pivot	243-0336
7F-9541	Pin As - Drawbar	296-1361
7F-9547	Pin As - Drawbar	295-0414
7G-1013	Pump Gp	226-0170
7G-2037	Joint Gp - Univ	226-8017
7G-2038	Tube - Univ Joint	297-7268
7G-2474	Gear - Planet	300-2577
7G-2475	Gear - Planet	223-4815
7G-2476	Gear - Planet	223-4816
7G-2477	Gear - Planet	221-9090
7G-2480	Gear - Planet	226-6091
7G-2481	Gear - Planet	226-6092
7G-2485	Gear - Planet	226-7983
7G-2487	Gear - Planet	221-9092
7G-2492	Gear - Planet	239-7933
7G-2500	Gear - Planet	296-1350
7G-2511	Gear - Planet	260-0782
7G-2513	Gear - Planet	215-1734
7G-2516	Gear - Planet	283-5203
7G-2517	Gear - Planet	213-8747
7G-2520	Gear - Planet	221-9094
7G-2521	Gear - Planet	213-8749
7G-2522	Gear - Planet	216-7855
7G-2824	Piston	295-6439
7G-2828	Plate - Clutch	325-6171
7G-2830	Ring - Seal	295-6441
7G-3450	Gear - Planet	275-5289
7G-3451	Gear - Planet	297-7188
7G-3452	Gear - Planet	275-5290
7G-3454	Gear - Planet	300-2578
7G-3455	Gear - Planet	300-2582
7G-3456	Gear - Planet	300-2583
7G-3457	Gear - Planet	308-9857
7G-3461	Gear - Planet	275-5291
7G-3707	Piston - Clutch	302-2691
7G-3708	Piston - Clutch	300-2585
7G-3815	Pump Gp	226-0171
7G-4281	Housing As - Support	297-7201

Original Part Number	Part Name	Classic Part Number
7G-4302	Housing - Clutch	302-2708
7G-4306	Plate - Center	297-7229
7G-4758	Gear - Planet	288-8723
7G-5301	Pump Gp	217-2600
7G-5323	Pinion - Final Drive	231-8767
7G-5444	Carrier - Planet	297-7165
7G-5572	Gear - Sun	300-2580
7G-5589	Gear - Ring	281-1692
7G-5593	Gear - Sun	300-2581
7G-5614	Shaft - Planet	281-1697
7G-5618	Manifold As	283-5204
7G-5776	Shaft - Planet	325-6195
7G-5780	Shaft - Planet	325-6196
7G-5783	Gear - Planet	288-8724
7G-5784	Gear - Planet	288-8725
7G-6042	Cage As	216-7856
7G-6044	Cage As	216-7857
7G-6060	Plate - Center	302-2694
7G-6062	Gear - Ring	302-2678
7G-6489	Spring - Recoil	314-8722
7G-6576	Cage As	216-7859
7G-6681	Cage As	216-7860
7G-7013	Coupling - Pump Drive	295-5450
7G-7218	Carrier - Planet	283-5205
7G-7681	Shaft As	307-1530
7G-7724	Piston - Clutch	283-5206
7G-8389	Guard	226-0202
7G-8459	Hub - Gear	221-1070
7G-8513	Guard As	361-1714
7G-8517	Guard As	361-1715
7G-9555	Bearing - Spider	314-8721
7G-9721	Gear As - Oil Pump	297-7178
7G-9722	Gear - Pump Drive	297-7179
7H-0602	Dog - Clutch	314-8515
7H-1318	Coupling - Steering	226-8002
7H-2424	Sleeve - Spring	226-4852
7H-2742	Nut	229-8220
7H-3598	Bolt - Track	188-5636
7H-3599	Bolt - Track	188-5639

(Continued)

Part Numbers Beginning with 7 (Continued)

Original Part Number	Part Name	Classic Part Number
7H-4710	Bushing - Sleeve	299-1990
7H-7630	Spacer	239-7962
7I-6843	Pin	301-4766
7J-0086	Bearing As	256-4842
7J-1185	Bearing As	297-7146
7J-1309	Bearing - Aligning	360-2275
7J-1333	Bearing - Sleeve	295-6408
7J-1334	Bearing - Sleeve	325-6015
7J-3390	Pin - Hitch	256-4786
7J-4827	Yoke	299-2070
7J-5131	Trunnion	296-1371
7J-6461	Crown	325-6054
7J-6883	Shaft	256-4778
7J-6886	Pin	256-4787
7J-7488	Bearing	256-4836
7J-9344	Bearing - Sleeve	360-2334
7J-9366	Bearing - Sleeve	299-1985
7J-9682	Bearing - Sleeve	360-2335
7J-9707	Bearing - Sleeve	308-9821
7J-9708	Bearing - Sleeve	299-1964
7J-9731	Bearing - Sleeve	308-9822
7J-9732	Bearing - Sleeve	308-9823
7J-9814	Bearing - Sleeve	308-9824
7J-9842	Bearing - Sleeve	299-1968
7J-9884	Bearing - Sleeve	325-6016
7K-0078	Bearing - Sleeve	308-9825
7K-0252	Gear - Ring	231-0008
7K-0373	Pin As	308-9885
7K-0374	Pin As	308-9886
7K-0449	Yoke As	297-7271
7K-0450	Yoke As	297-7272
7K-0686	Trunnion - Rear	297-7266
7K-1311	Hub As - Sprocket	224-1313
7K-1818	Cover	308-9844

Original Part Number	Part Name	Classic Part Number
7K-3582	Nut - Adjusting	226-6099
7K-4458	Gear - Final Drive	226-6093
7K-4512	Pinion - Final Drive	226-6081
7K-4770	Pinion	226-6082
7K-4771	Gear	229-8221
7K-5213	Pin	252-6869
7K-6260	Shaft - Sector	308-9931
7K-6497	Pin	252-6870
7K-7102	Pin	308-9903
7K-7176	Pin	241-2570
7K-7195	Bearing - Sleeve	325-6025
7K-7200	Pin	241-2600
7K-7237	Gear - Planet	231-0009
7K-7613	Joint Gp - Slip	302-2689
7K-8237	Drum	226-6100
7K-8238	Flange	213-8166
7K-9343	Pin	241-2571
7K-9344	Pin	241-2607
7K-9345	Pin	241-2608
7K-9346	Pin	252-6871
7K-9347	Pin	252-6875
7K-9348	Pin	252-6872
7K-9360	Pin	319-3461
7K-9361	Pin	241-2565
7K-9366	Pin	241-2617
7K-9370	Pin	241-2618
7K-9371	Pin	241-2619
7K-9372	Pin	241-2577
7K-9373	Pin	241-2620
7K-9375	Pin	241-2621
7K-9488	Pin	241-2578
7K-9499	Pin	241-2579
7K-9502	Pin	241-2580
7K-9503	Pin	241-2581
7K-9504	Pin	241-2582
7K-9505	Pin	241-2583
7K-9506	Pin	241-2584
7K-9513	Pin	241-2596
7K-9514	Pin	241-2597
7K-9515	Pin	241-2589
7K-9528	Bearing - Sleeve	308-9828
7K-9530	Bearing - Sleeve	299-1967
7K-9593	Bearing - Sleeve	360-2337

Original Part Number	Part Name	Classic Part Number
7K-9601	Bearing - Sleeve	360-2338
7K-9602	Bearing - Sleeve	360-2339
7K-9604	Bearing - Sleeve	308-9829
7K-9639	Bearing - Sleeve	314-8643
7K-9642	Bearing - Sleeve	360-2340
7K-9644	Bearing - Sleeve	360-2341
7K-9981	Pin As	308-9887
7K-9988	Pin	308-9904
7K-9989	Pin	308-9905
7K-9990	Pin	308-9906
7K-9992	Pin	308-9907
7L-0104	Impeller - Pump	311-9395
7M-0457	Guard - Frame	226-0217
7M-0665	Bar As - Equalizer	231-3312
7M-0699	Cap - Brace Bearing	247-4123
7M-0820	Gear - Sliding	226-6086
7M-0859	Fork As - Shift	297-7172
7M-1184	Housing As	219-9704
7M-1185	Housing As	219-9705
7M-1186	Housing As	219-9706
7M-1195	Housing - Clutch	219-9707
7M-1249	Piston - Clutch	215-1748
7M-1776	Plate - Idler Guide	226-0222
7M-1840	Gear As - Ctrshft	214-0966
7M-1842	Gear As-ctr - Shft	214-0967
7M-1851	Bolt - Spring	226-0223
7M-1856	Pilot - Recoil Spring	226-0225
7M-1859	Pilot As - Spring	226-0207
7M-1861	Stop - Spring Rh	226-0228
7M-1862	Stop - Spring Lh	226-0229
7M-1889	Guard As	213-9108

(Continued)

Part Numbers Beginning with 7 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
7M-1890	Guard As - Final Drive Wear	213-9109	7N-3486	Manifold - Exhaust	261-0899	7S-6538	Guard As - Lh Basic	226-4942
7M-2167	Ring - Governor Control	308-9919	7N-3515	Gear - Camshaft	314-8669	7S-6723	Bracket - Alternator	299-1978
7M-2531	Rod - Tie	297-7239	7N-3536	Gear - Fuel	279-4993	7S-6875	Pump Gp - Transmission	217-2601
7M-4204	Manifold - Exhaust	261-0901	7N-4515	Body As - Piston	311-9346	7S-6902	Gear - Sun	229-1619
7M-4358	Manifold - Exhaust	261-0907	7N-5503	Gear - Camshaft Rr	233-2182	7S-6964	Gear - Ring	214-0532
7M-4603	Body - Fuel Valve	311-9348	7N-5511	Gear As - Idler	233-2180	7S-7070	Head As - Cylinder	325-6107
7M-4926	Retainer - Pin	314-8538	7N-5810	Gear As - Idler	233-2179	7S-7400	Pump Gp	226-0173
7M-5002	Drum - Steering	226-7992	7N-5815	Gear - Camshaft Rr	233-2181	7S-7602	Pump Gp	226-0174
7M-5050	Collar - Front Idler	226-4958	7N-5819	Gear - Hyd Pump Drive	215-1758	7S-7625	Support As	226-6095
7M-5289	Hub - Steering	217-7736	7N-5825	Gear - Drive	215-1759	7S-7809	Cap As - Radiator	295-6417
7M-5756	Gear - Ring	214-0531	7N-5910	Impeller - Pump	314-8686	7S-7973	Guard - Final Drive Wear	213-9110
7M-6621	Pump Gp - Oil	226-0172	7N-6677	Core As - Oil Cooler	299-1995	7S-7975	Guard - Final Drive Wear	239-7966
7M-7358	Valve - Inlet	298-2774	7N-8117	Muffler As	247-2668	7S-8213	Guard As - Final Drive Wear	226-4943
7M-7431	Service Gp - Valve	314-8550	7N-9145	Gear - Flywheel	279-4994	7S-8214	Guard As - Final Drive Wear	226-4944
7M-7817	Valve - Inlet	311-9474	7N-9146	Gear - Flywheel Starter	279-4995	7S-8443	Muffler	247-2675
7M-8395	Piston - Clutch	223-6322	7N-9312	Damper As - Camshaft	299-2005	7S-8572	Gear - Ring	221-9095
7M-8397	Housing As	239-7956	7N-9674	Muffler As	360-7892	7S-8631	Shaft As	275-5296
7M-8453	Piston - Clutch	215-1755	7N-9805	Pin - Piston	295-6438	7S-8660	Pump Gp - Transmission	226-0175
7M-9398	Plate - Guide	297-7230	7N-9810	Pin - Piston	311-9432	7S-9093	Shoe -Track	188-5617
7N-0061	Muffler As	360-7889	7P-6596	Bearing - Sleeve	295-6409	7S-9094	Shoe -Track	188-5313
7N-0110	Core As - Oil Cooler	319-3435	7P-8370	Bearing	295-6410	7S-9096	Shoe -Track	281-6370
7N-0128	Core As - Oil Cooler	299-1994	7S-0706	Shoe -Track	175-8673	7S-9101	Shoe -Track	281-6372
7N-0165	Core As - Oil Cooler	295-5670	7S-1579	Nut - Spanner	239-7964	7S-9567	Shoe -Track	175-8022
7N-1164	Mount As	295-5451	7S-2980	Plate - Reaction	226-5998	7S-9749	Pulley - Gen Drive	264-5888
7N-2871	Line As - Fuel Injector	319-8172	7S-3033	Hub - Clutch	226-5985	7T-0119	Support As	299-2066
7N-2872	Line As - Fuel Injector	319-8173	7S-3161	Lifter - Valve	279-4996	7T-0203	Guide	226-4959
7N-2874	Line As - Fuel Injector	298-2779	7S-4494	Piston - Clutch	226-5999	7T-0204	Bearing - Brace	247-4126
7N-2875	Line As - Fuel Injector	298-2780	7S-4629	Pump Gp - Transfer	226-0158	7T-0205	Bearing - Brace	247-4127
7N-2876	Line As - Fuel Injector	298-2781	7S-5787	Chamber As	247-3300	7T-0206	Bearing - Brace	297-7144
7N-2949	Pulley	264-5887	7S-6104	Gear - Sun	239-7934	7T-1285	Gear - Planet	297-7190
7N-3350	Gear As - Pump Drive	319-3437	7S-6531	Guard As - Rh	226-4939	7T-1310	Rim -Track Sprocket	290-0861
			7S-6532	Guard As - Lh	226-4940	7T-2036	Cap As - Filter	361-1721
			7S-6537	Guard As - Rh Basic	226-4941	7T-2092	Washer - Thrust	325-6238
						7T-3173	Piston	346-5680

(Continued)

Part Numbers Beginning with 7 (Continued)

Original Part Number	Part Name	Classic Part Number
7T-3194	Yoke	346-5681
7T-3343	Plate - Clutch	297-7231
7T-3370	Yoke As	302-2702
7T-3952	Gear - Transfer	295-6429
7T-4562	Idler As.	175-8263
7T-5038	Housing As	297-7202
7T-6427	Pin	319-3462
7T-8136	Shaft - Planet	314-8714
7T-9272	Gear - Sun	296-1354
7T-9370	Gear - Sun	283-5207
7T-9586	Bearing	314-8645
7T-9647	Piston - Clutch	275-5294
7T-9931	Countershaft	215-1760
7T-9963	Case As - Transfer Gear	219-9665
7V-5249	Shaft - Steering	215-1761
7V-5979	Gear	231-0238
7V-5981	Driver	231-0256
7V-6790	Shaft - Bevel Pinion	308-9922
7V-6898	Pin As	241-2539
7V-7017	Pinion Swing	231-0018
7V-7973	Gear Final Drive	231-0239
7V-7974	Pinion Final Drive	231-0253
7V-7976	Pinion - Swing Drive	231-0254
7W-0450	Gear - Water Pump	279-4997
7W-0507	Gear - Oil Pump Drive	279-4998
7W-0508	Gear - Fuel Pump Drive	296-1351

Original Part Number	Part Name	Classic Part Number
7W-1902	Adapter - Fuel Nozzle	299-1955
7W-2164	Core As - Oil Cooler	299-1996
7W-3042	Tube As - Drain	325-6231
7W-5194	Muffler As	346-5682
7W-5684	Pulley - Camshaft	298-2771
7W-5685	Pulley - Camshaft	298-2772
7W-5687	Hub - Camshaft	314-8684
7W-5698	Pulley - Camshaft	295-5679
7Y-0212	Gear - Ring	301-4681
7Y-0213	Gear - Planet	301-4760
7Y-0221	Gear - Planet	301-4758
7Y-0223	Shaft - Planet	301-4625
7Y-0224	Gear - Planet	301-4759
7Y-0225	Shaft - Planet	301-4571
7Y-0228	Carrier As	301-5239
7Y-0238	Gear - Sun	301-4689
7Y-0241	Carrier	301-4635
7Y-0242	Carrier	301-4637
7Y-0249	Gear - Sun	301-4694
7Y-0680	Piston	360-2262
7Y-1427	Gear - Sun	288-8727
7Y-1428	Gear - Planet	288-8728
7Y-1430	Gear - Sun	314-8671
7Y-1431	Gear - Planet	288-8729
7Y-1432	Carrier	314-8659
7Y-1461	Coupling	301-4649
7Y-1513	Pipe As - Exhaust	301-5249
7Y-1517	Pipe As - Tail	301-5246

Original Part Number	Part Name	Classic Part Number
7Y-1643	Gear - Sun	314-8670
7Y-1644	Gear - Planet	301-3406
7Y-1646	Shaft - Planet	301-4624
7Y-1687	Piston As	360-2266
7Y-1751	Carrier - Planet	314-8660
7Y-1752	Carrier - Planet	314-8661
7Y-1764	Shaft - Planet	314-8717
7Y-1775	Shaft - Pinion	314-8718
7Y-1780	Cylinder	360-2261
7Y-2348	Pin	314-8697
7Y-2349	Pin	301-4556
7Y-2357	Pin	301-4564
7Y-2391	Link As	301-5240
7Y-2392	Link - Rh	301-4765
7Y-2395	Bearing - Sleeve	314-8646
7Y-2396	Bearing - Sleeve	314-8634
7Y-3427	Bearing - Sleeve	314-8635
7Y-3428	Bearing - Sleeve	314-8647
7Y-3549	Pin	360-2349
7Y-3550	Pin	360-2350
7Y-3553	Bearing - Sleeve	301-0433
7Y-4666	Bearing - Sleeve	314-8636
7Y-5128	Bearing - Sleeve	314-8648
7Y-5131	Bearing - Sleeve	301-4626
7Y-6608	Bearing	314-8649
7Y-6626	Bearing	314-8650
7Y-6627	Pin As	314-8693

Part Numbers Beginning with 8

Original Part Number	Part Name	Classic Part Number
8B-5972	Bearing - Ball	314-8503
8D-0527	Gear	229-1621
8D-0682	Shaft	245-5806
8D-0926	Rod As - Tie Lh	228-9422
8D-0994	Rod As - Tie Rh	228-9459
8D-0995	Rod As - Tie Lh	228-9460

Original Part Number	Part Name	Classic Part Number
8D-1769	Plate - Driving	229-1622
8D-1784	Pin	282-6567
8D-2351	Pin	297-7217
8D-2429	Pin As	319-3445
8D-2452	Gear - Sun	297-7180
8D-2459	Gear - Planet	297-7181
8D-2469	Shaft - Drive	275-5280
8D-2519	Shaft - Planet	300-2591

Original Part Number	Part Name	Classic Part Number
8D-2532	Carrier - Planet	301-4773
8D-2628	Nut	299-2027
8D-3591	Carrier - Planet	301-4769
8D-3665	Pin	297-7218
8D-3744	Shaft - Drive	275-5283
8D-3877	Gear - Sun	275-5278
8D-4673	Pin - Cylinder	302-2711
8D-5344	Gear - Worm	243-0341

(Continued)

Part Numbers Beginning with 8 (Continued)

Original Part Number	Part Name	Classic Part Number
8D-5346	Shaft - Drive Pinion	243-0350
8D-5347	Shaft - Drive Pinion	243-0352
8D-7096	Pin - Axle Leaning	297-7219
8D-7174	Cover As	299-1997
8D-7427	Shaft - Drive Pinion	282-6568
8D-8633	Shaft - Drive	275-5281
8D-8634	Gear - Planet	275-5275
8D-8638	Gear - Sun	275-5279
8D-8639	Gear - Ring	275-5277
8D-8805	Cover	299-2002
8D-8829	Bearing - Sleeve	361-1692
8D-9479	Gear - Diff Bevel	302-2670
8D-9482	Gear - Diff Bevel	302-2673
8D-9804	Housing - Drive	302-2682
8D-9815	Pin - Cylinder	297-7220
8E-3332	Shoe - Track	175-8184
8E-4275	Link As.	288-3694
8E-4365	Segment Gp - Sprocket	188-5635 (sprocket group), 188-5589 (segment)
8E-4426	Shoe -Track	288-6671
8E-4427	Shoe -Track	288-6670
8E-4428	Shoe -Track	288-6669
8E-4429	Shoe - Track	288-6677
8E-4430	Shoe - Track	288-6676
8E-4434	Shoe -Track	188-5263
8E-4435	Shoe -Track Master	188-5264
8E-4436	Shoe -Track	188-5261
8E-4437	Shoe -Track Master	188-5262
8E-4499	Shoe -Track	188-5383
8E-4500	Shoe -Track Master	188-5387
8E-4501	Shoe -Track	188-5381
8E-4502	Shoe -Track Master	188-5385
8E-4576	Roller Gp - SF	288-3690
8E-4579	Roller Gp - SF	175-8216

Original Part Number	Part Name	Classic Part Number
8E-4675	Segment Gp - Sprocket	188-5599 (sprocket), 188-5638 (sprocket group)
8E-4713	Link As.	288-3705
8E-4714	Link As.	288-3693
8E-5450	Seal - Ebar	325-6190
8E-5600	Roller Gp - Carrier	286-9824
8E-5993	Gear As - Idler	215-1903
8E-6135	Idler Gp -Track	288-3691
8E-6221	Pin	325-6155
8E-6754	Connector As	325-6044
8E-6755	Bearing - Sleeve	325-6026
8E-6756	Bearing - Sleeve	325-6027
8E-7455	Gear - Planet	221-7947
8E-7456	Gear - Planet	221-7948
8E-7494	Roller Gp - SF	175-8185
8E-7857	Link As.	290-0819
8E-7868	Shoe - Track	290-9940
8E-8643	Link As.	288-5754
8E-8644	Link As.	288-5755
8E-9214	Pin	325-6156
8E-9795	Connector As	256-4851
8E-9805	Sprocket	286-9821
8F-5104	Screen As - Oil Pan	314-8539
8F-7422	Gear - Worm	228-9461
8F-8858	Button Valve	314-8511
8F-9365	Pin	319-3463
8G-1682	Pin	241-2585
8G-3102	Piston	325-6162
8G-4187	Pin As	295-5676
8G-4189	Bearing - Aligning	295-6411
8G-4190	Seal - Ebar	296-1366
8G-8311	Bearing - Sleeve	295-6412
8H-1174	Drum - Steering	226-6101 (Drum), 231-1937 (Steering Clutch Kit)
8H-1383	Rod - Tie	299-2051
8H-1993	Valve - Inlet	256-4765
8H-1994	Valve - Exhaust	256-4765

Original Part Number	Part Name	Classic Part Number
8H-2300	Pinion - Final Drive	226-6083
8H-2434	Drum - Steering	216-7862
8H-2810	Case As - Filter	314-8512
8H-7810	Gear	213-8753
8H-7813	Collar	215-1780
8H-7980	Piston	226-0249
8H-9379	Nut - Brake Band Adjustable	299-2029
8H-9806	Gear - Shaft Drive	325-6091
8J-1300	Pin As	256-4788
8J-2652	Shaft	299-2054
8J-2653	Lever As	299-2015
8J-2654	Lever As	299-2016
8J-2880	Cap - Bearing	295-6420
8J-3431	Pin	256-4789
8J-5654	Bearing - Sleeve	325-6028
8J-7596	Bearing - Sleeve	361-1693
8K-0042	Gear - Differential Bevel	308-9850
8K-0323	Link As.	290-3450
8K-0393	Pin	241-2548
8K-0442	Gear	231-0240
8K-0455	Pin	241-2547
8K-0518	Pin	241-2549
8K-0533	Bearing - Sleeve	314-8637
8K-0576	Cage - Bearing	231-0261
8K-0578	Spacer	231-0248
8K-0579	Retainer	231-0245
8K-0665	Cage - Bearing	231-0262
8K-1107	Rack - Disconnect	231-0264
8K-1317	Shaft	231-0019
8K-1749	Shaft - Sprocket	231-0242
8K-1754	Spacer	231-0247
8K-1755	Retainer - Cap	231-0246
8K-1756	Cage - Bearing	231-0263
8K-1940	Retainer As	231-0258
8K-1944	Case As - Swing Drive	231-0265

(Continued)

Part Numbers Beginning with 8 (Continued)

Original Part Number	Part Name	Classic Part Number
8K-1945	Shaft As - Output	231-0266
8K-1946	Retainer As	231-0259
8K-2518	Joint As	231-0267
8K-2682	Adapter	231-0268
8K-2743	Sprocket - Track	289-2206
8K-2779	Cage - Bearing	231-0483
8K-2860	Flange - Coupling	297-7171
8K-2956	Pin	241-2550
8K-3712	Pin As	241-2541
8K-4127	Gear Gp - Bearing & Basic	235-5055
8K-4296	Pin	241-2555
8K-4699	Link As.	290-3451
8K-4753	Link As.	290-0837
8K-4764	Pin	241-2556
8K-5283	Plate	299-2043
8K-5334	Pin	241-2598
8K-5587	Rod Gp - Recoil	226-4954
8K-5758	Pin	241-2566
8K-5991	Gear - Diff Bevel	253-1439
8K-5999	Gear - Sun	253-1440
8K-6015	Gear - Bevel Ring	221-9076
8K-6282	Gear - Sun	281-1698
8K-6283	Gear - Sun	221-9077
8K-6285	Shaft - Axle	299-2057
8K-6320	Shaft - Axle	253-1430
8K-6321	Gear - Sun	253-1441
8K-6357	Pin	241-2586
8K-6358	Pin	241-2587
8K-6359	Pin	241-2588
8K-9661	Gear - Bevel	213-8218
8L-3972	Baffle	311-9345
8L-4529	Pulley - Alternator	264-5889
8M-0493	Cage - Outer Bearing	216-7866
8M-0874	Plunger As - Valve	311-9439
8M-2549	Rod As - Connector	314-8537
8M-3224	Muffler	247-2676
8M-4014	Insert - Seat Exhaust	311-9398

Original Part Number	Part Name	Classic Part Number
8M-6191	Sleeve - Bolt	226-0234
8M-6219	Spring - Equalizer	293-7606
8M-6615	Leaf - Spring	293-7607
8M-6616	Leaf - Spring	293-7608
8M-6676	Cylinder - Adjustable	226-4960
8M-7166	Housing - Screen	297-7192
8M-7207	Guard As - Rh	226-0236
8M-7208	Guard As - Frame	226-0237
8M-8161	Flange - Shaft	215-1781
8M-8619	Cage - Bearing	217-7725
8M-8623	Gear - Sun	213-8755
8M-8628	Flange - Joint	217-9776
8M-8642	Housing - Clutch	219-9669
8M-8644	Housing - Clutch	215-1782
8M-8646	Plate As - Center	216-3583
8M-8649	Piston - Clutch	217-9777
8M-8650	Piston - Clutch	217-9778
8M-8652	Shaft	297-7252
8M-8677	Carrier - Planet	213-4449
8N-0002	Trunnion As	314-8728
8N-0597	Pulley	264-5890
8N-0875	Valve - Exhaust	247-6893 (Valve), 241-3381 (Valve Kit)
8N-1187	Head Gp - Cylinder	242-3435
8N-1188	Head Gp - Cylinder	242-3436
8N-1214	Mount As	325-6125
8N-1721	Rod As - Conn	269-5291
8N-1965	Tube - Disposal	325-6235
8N-1984	Rod As - Conn	242-3441
8N-2275	Bearing - Sleeve	311-9365
8N-2510	Shaft	325-6208
8N-2641	Sleeve	325-6210

Original Part Number	Part Name	Classic Part Number
8N-3181	Piston Gp - Basic	250-6555 (Liner Kit)
8N-3183	Piston Gp - Basic	250-6556 (Liner Kit)
8N-3251	Shaft As - Rocker Arm	314-8711
8N-3311	Shaft As - Rocker Arm	325-6199
8N-3312	Shaft As - Rocker Arm	325-6200
8N-3325	Arm Gp - Rocker	314-8623
8N-3327	Arm Gp - Rocker	314-8624
8N-3723	Valve - Exhaust	311-9472
8N-5388	Muffler As	360-7895
8N-5779	Coupling - Exhaust	325-6047
8N-5929	Cover - Water Pump	296-1349
8N-6004	Head As - Cylinder	247-3369
8N-6796	Head Gp - Cylinder	269-5290
8N-7315	Tube As - Outlet	325-6232
8N-7769	Bearing - Conn Rod	314-8505
8N-7770	Bearing - Conn Rod	314-8506
8N-7771	Bearing - Conn Rod	314-8507
8N-7780	Shield - Oil	314-8544
8N-8225	Bearing - Main	314-8652
8N-9174	Liner - Cylinder	314-8531
8N-9402	Coupling	325-6048
8N-9489	Chamber As	247-3301
8N-9733	Line As - Fuel Injector	319-8174
8P-0025	Gear - Idler	217-7721
8P-0187	Nut - Adjusting	219-9676
8P-0203	Drum	226-8004
8P-0514	Yoke As	308-9947
8P-0605	Gear - First Reduction	213-8453
8P-0606	Pinion - Sec Reduction	215-1783
8P-0622	Hub - Sprocket	288-8731

(Continued)

Part Numbers Beginning with 8 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
8P-0769	Hub - Turbine	308-9870	8P-5849	Plate As	223-6323	8S-0392	Shoe -Track Master	188-5314
8P-0953	Turbine - Converter	297-7269	8P-6256	Roller Gp - Carrier	188-5612	8S-0394	Shoe -Track Master	315-6693
8P-0957	Impeller - Converter	297-7209	8P-6274	Guard As - Lh	226-4949	8S-0395	Bolt Master	188-5640
8P-1121	Ring - Clamp	299-2049	8P-6275	Guard As - Rh	226-0191	8S-0493	Shaft As - Pump	325-6198
8P-1182	Shaft	227-4771	8P-6495	Drum	213-6954 (Drum), 227-9302 (Steering Clutch Kit)	8S-0556	Coupling	221-9114
8P-1183	Gear - Bevel	226-7980	8P-6803	Shaft As	215-1842	8S-0569	Gear - Transfer	213-8754
8P-1324	Cage - Gr Shft Bearing	229-8239	8P-6949	Plate - Retainer	260-0787	8S-0573	Gear - Transfer	215-1844
8P-1325	Hub - Steering	226-8005	8P-7396	Hub - Planet Gear	239-7967	8S-0905	Muffler As	302-2690
8P-1326	Pilot - Piston	226-6097	8P-7595	Washer - Thrust	239-7940	8S-0915	Shoe -Track Master	281-6374
8P-1327	Pinion - Final Drive	226-8000	8P-7639	Gear - Planet	239-7935	8S-1061	Pilot As - Spring	226-0227
8P-1328	Flange - Drive Drum	226-8006	8P-7790	Valve Gp - Press	247-4437	8S-1194	Shaft - Sprocket	217-7733
8P-1353	Piston - Steering	226-8007	8P-8221	Plate - Guide	226-2748	8S-1198	Hub - Gear	219-2969
8P-1774	Pinion - Final Drive	226-8001	8P-8570	Pilot As - Piston	226-6097	8S-1831	Guard As - Sprocket	226-4947
8P-1851	Hub As - Sprocket	224-1314	8P-8677	Hub - Impeller	297-7205	8S-1832	Guard As - Sprocket	226-4948
8P-1853	Nut - Adjusting	226-7997	8P-9507	Piston - Clutch	283-5212	8S-2123	Cage - Final Drive Bearing	217-7726
8P-1855	Hub As - Sprocket	227-4770	8P-9657	Pin	241-2622	8S-2126	Spacer - Hub Bearing	222-1767
8P-1865	Bar As - Equalizer	231-3313	8P-9658	Pin	241-2623	8S-2140	Trunnion - Gear	226-8020
8P-1892	Piston - Clutch	283-5208	8R-0931	Housing - Pinion	302-4300	8S-2560	Idler Gp, Idler As.	200-9235 (Complete Idler Group), 175-8255 (Idler As.)
8P-1916	Gear - Planet	283-5209	8R-3252	Shaft - Planet	297-7259	8S-2809	Muffler	247-2677
8P-1918	Gear - Planet	283-5210	8R-3787	Shaft	299-2058	8S-3487	Gear As - Ring	221-7949
8P-1919	Gear - Planet	300-2579	8R-3921	Collet	308-9839	8S-3491	Housing As	221-7950
8P-2042	Shaft - Planet	283-5211	8R-3943	Collet	308-9840	8S-3617	Chamber As	247-3302
8P-2430	Shaft As	297-7258	8R-3946	Collet	308-9841	8S-3970	Chamber As	242-3438
8P-3252	Pin	319-3464	8R-4821	Carrier - Planet	308-9837	8S-5438	Muffler As	360-7896
8P-4111	Guard As	226-4945	8R-7336	Bearing	301-3394	8S-5722	Plate - Pressure	226-8009
8P-4112	Guard As	226-4946	8R-7425	Retainer	308-9917	8S-7716	Manifold - Exhaust	295-0415
8P-4537	Pinion - Reduction	216-7867	8R-9798	Plate - Lock	308-9912	8S-7717	Manifold - Exhaust	261-0894
8P-4538	Gear - First Reduction	216-7868	8S-0248	Breather As	325-6033	8S-7718	Manifold - Exhaust	295-0416
8P-4539	Pinion - Final Drive	217-7711	8S-0386	Shoe -Track Master	188-5312	8S-7818	Bracket	226-0211
8P-4734	Housing As	239-7955	8S-0387	Shoe -Track Master	188-5614	8S-9070	Carrier - Front	213-4464
8P-4735	Piston - Clutch	239-7949	8S-0388	Shoe -Track Master	188-5616			
8P-5117	Rod Gp - Track Adjustable	226-2747	8S-0390	Shoe -Track Master	281-6371			
8P-5197	Bearing As	295-6413	8S-0391	Shoe -Track Master	188-5618			

(Continued)

Part Numbers Beginning with 8 (Continued)

Original Part Number	Part Name	Classic Part Number
8S-9071	Cage - Bearing	216-7869
8S-9184	Gear As	260-0785
8V-1613	Lever	299-2017
8V-1624	Lever	299-2019
8V-2631	Pin As	241-2526
8V-2632	Pin As	241-2523
8V-2634	Pin As	241-2518
8V-2639	Pin As	241-2542
8V-3134	Pinion - Bevel	260-0788
8V-3135	Gear - Differential Bevel	260-0783
8V-3136	Gear - Differential Bevel	253-1442
8V-5439	Pin As	241-2531

Original Part Number	Part Name	Classic Part Number
8V-6382	Hub As	308-9868
8V-6384	Spacer As	308-9935
8V-7175	Pin	241-2567
8V-7176	Pin	241-2568
8V-7659	Pin As	361-1702
8V-7884	Housing - Support	302-2681
8V-7885	Housing - Support	297-7193
8W-1751	Bracket As	288-8732
8W-1752	Bracket - Rail	288-8733
8W-1753	Bracket - Rail	288-8734
8W-2307	Shaft - Planet	275-5284
8W-2308	Shaft - Planet	275-5285
8W-4066	Bracket - Rail	288-8735
8W-4067	Bracket - Rail	288-8736

Original Part Number	Part Name	Classic Part Number
8W-4167	Bearing - Sleeve	361-1694
8W-5092	Pinion - Circle Drive	282-6569
8W-5293	Pin	282-6570
8W-6497	Pin	319-3465
8W-8286	Sprocket	299-2061
8W-8288	Sprocket	299-2062
8W-8289	Sprocket	282-6629
8W-8317	Sprocket	275-5287
8W-8628	Spindle - Front Axle	282-6571
8Y-1198	Strip	325-6220
8Y-1199	Strip	325-6221
8Y-1624	Guard As	295-6432
8Y-1625	Guard As	295-6433

Part Numbers Beginning with 9

Original Part Number	Part Name	Classic Part Number
9C-0624	Pin As	361-1709
9C-0625	Pin As	308-9888
9C-1484	Pin As	319-3446
9C-1528	Gear - Planet	223-4802
9C-1618	Gear	231-0229
9C-2646	Sprocket - Track	289-9674
9C-3187	Pin As	314-8694
9C-4080	Yoke - Brake	302-2703
9C-4211	Pin As	241-2519
9C-4737	Pin As	241-2520
9C-4811	Hub As	224-1300
9C-4912	Pin As	241-2517
9C-5060	Link As - Bearing	299-2022
9C-5852	Hub As	297-7208
9C-6015	Pinion - Diff Bevel	297-7225
9C-6017	Gear - Diff Bevel	297-7187
9C-6027	Carrier - Planet	297-7166
9C-6187	Pin As	241-2521
9C-6244	Gear	231-0230
9C-6544	Drum - Brake	297-7169
9C-8074	Gear - Planet	308-9858
9C-8075	Gear - Sun	308-9864
9C-8204	Shaft - Bevel Pinion	319-3474

Original Part Number	Part Name	Classic Part Number
9C-8205	Gear - Bevel	319-8175
9C-8218	Shaft - Bevel Pinion	302-2697
9C-8219	Gear - Bevel	297-7186
9C-8277	Gear - Bevel	308-9851
9C-9191	Trunnion	302-2701
9C-9748	Gear - Differential Bevel	302-2671
9C-9773	Gear - Differential Bevel	302-2672
9D-0120	Gear - Planet	288-8737
9D-0127	Gear - Sun	288-8738
9D-1177	Shaft - Drive Pinion	297-7253
9D-1487	Housing - Drive	297-7194
9D-2716	Spindle - Wheel	228-9463
9D-2731	Spindle - Wheel	228-9423
9D-4441	Housing	297-7195
9D-5741	Worm - Circle Drive	297-7270
9D-5746	Gear - Worm	299-2011
9D-5921	Shaft - Drive Pinion	297-7254
9D-6638	Strip - Wear	297-7263
9D-7924	Mounting	360-2356
9D-9665	Bracket - Cylinder Mtg	299-1980

Original Part Number	Part Name	Classic Part Number
9F-5224	Gear - Final Drive	226-6094
9F-7101	Bushing - Collar	299-1988
9G-0280	Piston - Clutch	283-5213
9G-0284	Housing - Clutch	283-5214
9G-0285	Piston - Clutch	283-5215
9G-0289	Shaft - Planet	283-5216
9G-0290	Hub - Clutch	283-5217
9G-0383	Hub - Gear	221-1064
9G-1231	Plate	297-7232
9G-1491	Carrier - Planet	281-1685
9G-1499	Gear - Oil Pump	295-6424
9G-2413	Shaft - Output	297-7255
9G-3526	Gear - Pump Drive	231-8763
9G-6476	Rod Gp - Idler Recoil	226-0198
9G-7411	Gear - Oil Pump Drive	297-7182
9G-7412	Gear As - Oil Pump	297-7183
9G-7993	Cage - Gr Bearing Rh	239-7973
9G-8117	Housing As	302-2686

(Continued)

Original Part Number	Part Name	Classic Part Number
9G-8246	Rod Gp - Idler Recoil	226-4955
9G-8302	Guide	226-4853
9G-8303	Collar - Idler End	226-0242
9G-8638	Gear - Planet	295-6425
9G-9174	Gear - Sun	295-6430
9G-9178	Spindle	295-6443
9G-9180	Hub - Sprocket	295-6436
9G-9183	Shaft	295-0417
9G-9349	Retainer	295-0411
9G-9543	Gear - Oil Pump	295-6426
9G-9764	Yoke As	319-3478
9H-1918	Gear - Bevel	219-9698
9H-1980	Pinion - Bevel	219-9699
9H-2256	Pump Gp	311-9443
9H-4104	Pilot - Spring	226-4962
9H-5233	Piston - Clutch	219-9708
9H-5433	Spacer	239-7963
9H-6980	Shaft - Pinion	226-6110
9H-7670	Piston	226-4961
9J-0123	Trunnion	325-6227
9J-0940	Pin	319-3467
9J-1105	Pin As	256-4790
9J-2332	Bearing - Pivot	299-1969
9J-2365	Retainer	325-6186
9J-3346	Plate As - Trunnion	256-4839
9J-5273	Trunnion As	256-4848
9J-5875	Bearing - Sleeve	308-9830
9J-7964	Bearing - Spherical	325-6017
9J-8323	Trunnion	361-1713
9J-8427	Bracket	299-1984
9J-9147	Nut	299-2028
9J-9427	Bearing - Sleeve	361-1695
9J-9543	Pin As	256-4791
9J-9598	Pin	296-1362
9K-0092	Pinion	231-0484
9K-0198	Gear - Sun	308-9865
9K-0424	Shaft - Pinion	215-1874
9K-0447	Shaft - Bevel Pinion	216-7870
9K-1193	Gear - Sun	221-9099

Original Part Number	Part Name	Classic Part Number
9K-1759	Carrier - Planet	221-9113
9K-1773	Gear - Ring	221-9100
9K-3413	Gear - Bevel Ring	223-4807
9K-3565	Shoe - Track	290-9941
9K-3568	Shoe - Track	290-9942
9K-6841	Cage As	216-7871
9K-6842	Cage As	216-7872
9K-8425	Bearing - Sleeve	314-8638
9K-8427	Pin As	241-2527
9K-8428	Pin As	241-2533
9K-8430	Pin As	241-2540
9K-8435	Pin	241-2552
9K-8757	Rod End - Bearing	311-9361
9K-9156	Retainer As	297-7236
9K-9158	Bearing - Sleeve	299-1970
9K-9271	Holder As - Cage	217-7730
9K-9273	Nut - Adjusting	226-7998
9M-0701	Piston - Steer	219-9692
9M-0702	Pilot - Piston	229-8232
9M-1328	Bearing - Aligning	325-6018
9M-1500	Shaft - Planet	219-9685
9M-1502	Cage - Bearing	219-9686
9M-1995	Gear - Sun	213-8756
9M-1996	Shaft - Planet	215-1875
9M-2013	Housing As	216-3585
9M-2028	Gear - Sun	214-0959
9M-2038	Gear - Transfer Driven	215-1876
9M-2039	Gear - Transfer Driving	219-9672
9M-2045	Pinion - Bevel	215-1878
9M-2049	Gear - Ring	214-0533
9M-3025	Cover As	299-2001
9M-4163	Valve - Exhaust	298-2773
9M-4789	Shaft - Gov Control	297-7256
9M-4955	Pump Gp - Fuel Transfer	242-3443
9M-5045	Guard As - Wear	213-9111
9M-8117	Shaft - Fly-wheel Clutch	226-6073

9M-8119	Retainer - Inlet	226-8022
9M-8281	Gear As - Oil Pump	325-6089
9M-8284	Pump Gp - Transmission	226-0159
9N-4460	Housing As	297-7203
9N-4622	Pin	319-3468
9N-5251	Piston Gp - Basic	250-6557 (Liner Kit)
9N-5404	Piston Gp - Basic	250-6558 (Liner Kit)
9N-5769	Cover - Housing	325-6050
9N-6611	Pulley	325-6177
9P-0418	Cage	223-6311
9P-0620	Cage - Pinion Bearing	221-1052
9P-1779	Bearing - Sleeve	325-6029
9P-3242	Plate - Clutch	325-6172
9P-3436	Holder As - Cage	216-7875
9P-3663	Carrier - Planet	213-6939
9P-3731	Carrier - Planet	301-4767
9P-4859	Cage As - Bearing	297-7151
9P-5363	Piston - Clutch	219-9687
9P-5379	Housing - Clutch	215-1904
9P-6592	Gear - Planet	215-1915
9P-6594	Gear - Planet	215-1921
9P-6888	Shaft - Output	221-9105
9P-7757	Gear - Sun	283-5218
9P-8283	Plate - Clutch	296-1364
9P-8452	Hub - Output	297-7206
9P-8455	Cage As - Bearing	297-7152
9P-8521	Gear - Ring	296-1353
9P-8623	Shaft - Planet	314-8719
9P-8624	Shaft - Planet	295-5446
9P-8626	Gear - Sun	283-5219
9P-8866	Gear - Transfer	299-2012
9P-9000	Shaft - Steering	217-7738
9P-9031	Gear - Sun	283-5220
9P-9360	Gear - First Reduction	213-8454

(Continued)

Part Numbers Beginning with 9 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
9P-9361	Gear - Final Drive	223-4809	9R-8715	Spider and Bearing As	346-5716	9S-8257	Guard As - Guiding	226-0238
9P-9362	Pinion - Final Drive	215-1944	9R-9049	Pin	346-5717	9S-8258	Guard As - Guiding	226-0239
9P-9363	Pinion - Reduction	219-9677	9R-9190	Rod Gp - Tie	346-5718	9S-8353	Strip - Track	226-4854
9P-9517	Stator - Converter	297-7262	9R-9400	Case As	346-5719	9S-8354	Strip - Track	226-4855
9P-9575	Cage - Bevel Gr Bearing	216-7876	9R-9402	Seal - Rax	347-0476	9S-8358	Guard As - Guiding	226-4856
9P-9610	Pump Gp	283-5221	9R-9403	Pinion	347-0477	9S-8359	Guard As - Guiding	226-4857
9P-9742	Cage As - Bearing	297-7153	9R-9631	Pin	347-0467	9S-8493	Bolt - Connecting Rod	311-9351
9P-9790	Shaft - Output	302-2696	9R-9812	Pin	347-0468	9S-8679	Chamber As	325-6042
9R-0080	Coupling	346-5683	9S-1026	Cage - Gear Bearing	216-7873	9S-8789	Plate - Clutch	302-2712
9R-0097	Pin	346-5684	9S-1043	Guard As - Guiding	226-0240	9S-8802	Gear - Ring	214-0952
9R-0237	Pin As	346-5685	9S-1044	Guard As - Guiding	226-0241	9S-9385	Gear As - Oil Pump	297-7185
9R-0424	Pin	346-5686	9S-1045	Strip - Guard	226-0246	9T-0066	Trunnion	325-6228
9R-1726	Washer	346-5687	9S-1046	Strip - Guard	226-0247	9T-2373	Head	347-0461
9R-2410	Retainer As	346-5688	9S-1838	Bolt Master	188-5634	9T-4761	Head	325-6108
9R-2421	Shaft	346-5689	9S-2354	Manifold - Exhaust	261-0888	9T-4762	Head	325-6109
9R-2424	Gear - Planet Sun	346-5690	9S-2355	Manifold - Exhaust	261-0891	9T-8424	Bearing - Sleeve	325-6030
9R-2476	Disc - Bk Rear	346-5691	9S-2356	Manifold - Exhaust	261-0905	9U-0654	Coupling	297-7167
9R-2477	Disc As	346-5692	9S-3321	Cage - Pinion Bearing	226-7974	9U-2400	Housing As	231-0249
9R-2491	Spider	346-5693	9S-3955	Cage - Gear Bearing	216-7874	9U-3124	Gear - Planet	288-8806
9R-2846	Pin	346-5694	9S-4732	Guard Gp - Spring	226-0195	9U-3125	Gear - Sun	288-8807
9R-2956	Pin	346-5695	9S-5265	Shaft As	215-1945	9U-8481	Pin As	295-5675
9R-3161	Shaft - Sun Gear	346-5696	9S-5277	Gear - Transfer	213-8758	9V-2410	Housing - Bearing	302-2679
9R-3933	Pin	346-5697	9S-6129	Pulley - Alternator Drive	264-5891	9V-2411	Housing - Bearing	302-2680
9R-6158	Pin	346-5698	9S-6590	Pump Gp - Oil	226-0176	9V-3853	Pin	319-3469
9R-6159	Pin	346-5699	9S-6743	Chamber As	247-3303	9V-4333	Gear - Oil Pump Input	226-6105
9R-6160	Pin	346-5700	9S-6788	Pump Gp - Oil	217-2602	9V-6523	Cap	297-7162
9R-6163	Pin	346-5701	9S-6875	Pinion - Final Drive	217-7705	9V-6524	Cap	297-7163
9R-6475	Pad As	346-5702	9S-6948	Shaft - Center	213-9966	9V-6775	Drum	226-7994
9R-6545	Pin	346-5703	9S-7079	Muffler As	247-2669	9V-7860	Support As - Front	308-9938
9R-7158	Pin As	346-5704	9S-7221	Idler As.	188-5610	9W-0099	Bearing - Sleeve	314-8639
9R-7696	Pin	346-5705	9S-8245	Strip - Track	226-0243	9W-0318	Spacer	325-6218
9R-7894	Pin As	346-5706	9S-8246	Strip - Track	226-0244	9W-0517	Carrier - Planet	281-1686
9R-7895	Pin As	346-5707	9S-8251	Guard As - Roller	226-0180	9W-0550	Shaft - Transmission Upper	226-6000
9R-8202	Pin	346-5708	9S-8252	Guard As - Roller	226-0181	9W-0552	Shaft - Pinion	226-6001
9R-8206	Pin	346-5709	9S-8253	Guard As - Roller	226-0182	9W-0876	Bearing - Sleeve	325-6031
9R-8523	Pin	346-5710				9W-1677	Bearing	297-7145
9R-8579	Pin	346-5711						
9R-8639	Cylinder	346-5712						
9R-8662	Pin	346-5713						
9R-8707	Pin	346-5714						
9R-8709	Pin	346-5715						

(Continued)

Part Numbers Beginning with 9 (Continued)

Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number	Original Part Number	Part Name	Classic Part Number
9W-2344	Coupling - Pump Drive	314-8666	9W-6358	Drum - Steering	226-7995	9W-8433	Shaft As - Output	302-4249
9W-2579	Plate	314-8701	9W-6433	Impeller - Converter	308-9871	9W-8437	Gear - Sun	283-5222
9W-3361	Nut - Track	200-9127	9W-6435	Flange - Drive	308-9846	9W-8937	Link As.	188-5310
9W-3605	Carrier - Ring	314-8662	9W-6483	Shoe - Track	288-6672, 288-6673	9W-9069	Shaft - Input	302-2715
9W-3619	Bolt - Track	286-9828	9W-7481	Gear - Planet	295-6431	9W-9351	Shoe - Track	286-9825
9W-4702	Stator - Converter	308-9939	9W-7839	Carrier - Planet	295-6421	9W-9930	Mount As	295-6437
9W-4897	Bracket As	295-6414	9W-8270	Gear - Ring	308-9859	9Y-2988	Breather As	361-1716
9W-4949	Carrier - Planet	281-1687	9W-8384	Hub - Turbine	297-7207	9Y-2992	Bearing - Sleeve	325-6032
9W-4950	Gear - Sun	281-1688				9Y-9431	Precleaner As	361-1718

PECJ0051-02
www.cat.com

© 2010 Caterpillar • All Rights Reserved • Printed in USA

CAT, CATERPILLAR, their respective logos, "Caterpillar Yellow" and the "Power Edge" trade dress, as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission.

