



TM-8200s


Earth Fault Relay

Model: TM-8200s

- 1 - Ig =
- 2 - I_{sc} (sec)
- 3 - Ig min
- 4 - Specimen No. x 1000 (mm)
- 5 - Trip Mode, 2 (ohm)
- 6 - Software lock setting
- 7 - Relay #2 function

Fault

I_{ph} I_{pM}
Trip



HP/WA : 0852-195-111-00

NUMERICAL DSSGO

EARTH
FAULT
RELAY (DTL)



TM-8200s

POWER SUPPLY

240V AC

SERIAL NO.

TM-4471-B

Email : ipowersolution@hotmail.com

