

DELAB

NV-7

Power Factor Controller

INSTRUCTIONS

- 1 - P.F.C. + Meter
- 2 - Set Point
- 3 - Stop Interval
- 4 - Program Sequence
- 5 - Number of corrected step
- 6 - V_r (overshoot)

- 7 - Voltage (V) / s. Freq. (Hz) 240
- 8 - 1 Sec. (N) / s. THD (1%) 240
- 9 - Capacitor (n) x 1000 240
- R - Alarm 240

Program Sequence

P.C	Linear
P-1	1 1 1 1 1
P-2	1 2 1 1 1
P-3	1 1 2 1 1
P-4	1 1 1 2 2
P-5	1 2 4 4 4
P-6	1 1 2 2 4

Auto 1 2 3 4 5 6 7

COS ϕ



led

Cap

- +C
- Manual
- -C



Mode Selection Setting

1000 2 sec. for Manual Mode



Navigator
POWER
FACTOR
CONTROLLER



MODEL

NV-7

POWER SUPPLY

240V AC

SERIAL NO.

TM-38044-N

www.tokoelektrikmurah.com

HP/WA : 0852-195-111-00

Email : ipowersolution@hotmail.com