

 **BELARUS**
MINSK TRACTOR WORKS


KOBEXINDO
PT BELARUS TRAKTOR INDONESIA

BELARUS 892.2



Pictures of Belarus products may show other than standard equipment

BELARUS 892.2

ENGINE

Type	diesel mechanical engine Euro 2, with turbocharging, direct injection
Model	D-245.5C
Power, kW (h. p.)	66 (90)
Crankshaft rated speed, rpm	1800
Number of cylinders, pcs.	4
Bore/stroke, mm	110 x 125
Displacement, l	4.75
Maximum torque, N·m	397
Fuel tanks capacity, l	135

DIMENSIONS AND WEIGHTS

Overall length, mm	4130
Width, mm	1970
Cab height, mm	2850
Tractor base, mm	2450
Tread, mm:	
front wheels	1420-1970
rear wheels	1500-2100
Agrotechnical clearance, mm	510
Min turning radius, m	4.5
Operating weight, kg	4250
Tire sizes (standard):	
front wheels	360/70R24
rear wheels	18.4R34

TRANSMISSION

Clutch	dry, single-disk, spring-loaded
Gearbox	mechanical, fixed-ratio
Number of gears:	
forward/reverse	18/4
Travel speed, km/h:	
forward/reverse	2.26-41.1/4.76-11.04
Rear PTO:	
independent I, rpm	540
independent II, rpm	1000
synchronous, rpm of track	3.3

HYDRAULIC HITCH SYSTEM

Versatile, unit-principle, with draft, position and height depth control; optional – combined control.

Lifting capacity	
at lift point, kg	3200
Maximum pressure, MPa	20
Pump capacity, l/min	45
Hydraulic system capacity, l	25

Rear axle differential lock: with hydro-mechanical control, has two modes (disengaged; forced engaged).

PT BELARUS TRAKTOR INDONESIA

Subsidiary of PT KOBEXINDO TRACTORS Tbk

Head Office :

Kobexindo Tower
Jl. Pasir Putih Raya Blok E-S-D
Ancol Timur - Jakarta Utara 14430
Phone : (+62-21) 64700800, 64700808 (hunting)
Fax : (+62-21) 64700900, 64700909
Email : info@kobexindo.com
Web : www.kobexindo.com

Branch Offices :

Pekanbaru
Jl. Soekarno Hatta No. 1A
Pekanbaru 28291
Riau
Phone : (+62-761) 37808
Fax : (+62-761) 34030
Email : pekanbaru@kobexindo.com

Bengkulu
Jl. May. Jend. Soetriso No. 155,
Tanah Patah, Bengkulu
Phone : (+62-736) 346955
Fax : (+62-736) 346955
Email : info@kobexindo.com

Palembang
Kompleks Pergudangan
Palembang Star
Jl. Letjen Harun Schar AA
No. 11 RT 18 / RW 07
Kebun Bunga 763
Sukarami - Palembang
Phone : (+62-711) 5612609
Fax : (+62-711) 5610421

Surabaya (Sidoarjo)
Jl. Bandara Juanda KM. 3 Sedati Agung, Sedati
Sidoarjo 61253
Jawa Timur
Phone : (+62-31) 8688808
Fax : (+62-31) 8661888
Email : surabaya@kobexindo.com

Pontianak
Jl. Purnama Komp. Purnama Town House
Blok I C, RT. 01 / RW. 14
Kel. Paritokaya Kec. Pontianak Selatan
Pontianak 78121
Kalimantan Barat
Phone : (+62-561) 767988
Fax : (+62-561) 767989
Email : info@kobexindo.com

Ketapang
Jl. Gajah Mada
Kel. Kalinilam, Kec. Delta Pawa
Ketapang - Kalimantan Barat
Phone : (+62-534) 3036147
Fax : (+62-534) 3036137
Email : info@kobexindo.com

Product Support Center :

Gedung Kobexindo
Jl. Raya Bekasi - Karawang KM 58,
Cikarang Timur, Bekasi - Jawa Barat 17823
Phone : (+62-21) 89140888 (hunting)
Fax : (+62-21) 89140055

Banjarmasin (Banjarbaru)
Jl. A. Yani KM 21, Kel. Landasan Ulin Barat
Kec. Ujung Anjungan, Banjarbaru 70112
Kalimantan Selatan
Phone : (+62-511) 4707878
Fax : (+62-511) 4708459
Email : banjarmasin@kobexindo.com

Batu Licin
Jl. Raya Batu Licin
Desa Batu Licin No. 52 RT. 15
Kec. Batu Licin Kab. Tanah Bumbu 72171
Kalimantan Selatan
Phone : (+62-518) 71454
Fax : (+62-518) 70337
Email : batulicin@kobexindo.com

Tarakan
Jl. P. Diponegoro RT. 16
Kel. Sebangkok Kec. Tarakan Tengah
Kota Tarakan, Kalimantan Timur
Phone : (+62-551) 25355
Fax : (+62-551) 25454
Email : info@kobexindo.com

Balikpapan
Jl. Kol. Syarifudin Yos RT. 03 No. 91
Sepinggan, Balikpapan 76115
Kalimantan Timur
Phone : (+62-542) 760989
Fax : (+62-542) 761728
Email : balikpapan@kobexindo.com

Samarinda
Jl. Pelita Komp. Perum Pesona Mahakam No. 1
Samarinda Sebrang 75131
Kalimantan Timur
Phone : (+62-541) 7268086
Fax : (+62-541) 7268057
Email : samarinda@kobexindo.com

KOBEXINDO
we grow together.

