

 **BELARUS**
MINSK TRACTOR WORKS


KOBEXINDO
PT. BELARUS TRACTOR INDONESIA



BELARUS 1025.3

*Standart Unit Canopy

*Cabin Optional

BELARUS 1025.3

ENGINE

Type	diesel with turbocharging and direct injection
Model	D-245S2
Power, kW (h. p.)	81 (110)
Crankshaft rated speed, rpm	2200
Number of cylinders, pcs.	4
Bore/stroke, mm	110 x 125
Displacement, l	4.75
Maximum torque, N·m	429
Factor of torque backup, %	25
Fuel tanks capacity, l	135

TRANSMISSION

Clutch	dry, double disk
Gearbox	mechanical, synchronized
Number of gears:	
forward/reverse	16/8
Travel speed, km/h:	
forward/reverse	2.3–36.6/4.1–17.2
Rear PTO:	
independent I, rpm	540
independent II, rpm	1000
synchronous, rpm of track	3.5

Rear axle differential lock: with electrohydraulic control, three operating modes (disengaged; lock engaged with automatic disengagement when front wheels turn more than 13 degree; forced engaged).

DIMENSIONS AND WEIGHTS

Overall length, mm	4600
Width, mm	1970
Cab height, mm	2820
Wheelbase, mm	2570
Tread, mm:	
front wheels	1420–2000
rear wheels	1400–2100
Agrotechnical clearance, mm	645
Min turning radius, m	5.3
Operating weight, kg	4665
Tire sizes (standard):	
front wheels	360/70R24
rear wheels	18.4R34

HYDRAULIC HITCH SYSTEM

Unit-principle with hydraulic lift, providing draft, position, combined and height position control of implements.

Lifting capacity	
at lift point, kg	4300
Maximum pressure, MPa	20
Pump capacity, l/min	45
Hydraulic system capacity, l	25

PT BELARUS TRAKTOR INDONESIA

Subsidiary of PT Kobexindo Tractors Tbk

Head Office

Kobexindo Tower

Jl. Pasir Putih Raya Blok E-5-D
Ancol Timur – Jakarta Utara 14430
Phone : (+62-21) 64700800, 64700808 (hunting)
Fax : (+62-21) 64700900, 64700909
Email : info@kobexindo.com
website : www.kobexindo.com

Product Support Center :

Gedung Kobexindo

Jl. Raya Bekasi – Karawang KM 58
Cikarang Timur, Bekasi – Jawa Barat 17823
Phone : (+62-21) 89140888 (hunting)
Fax : (+62-21) 89140055

Branch Offices :

Pekalongan

Jl. Soekarno Hatta No.1A
Pekalongan 26291 P.01
Phone : (+62-761) 312888
Fax : (+62-761) 34950,
Email : pekalongan@kobexindo.com

Palembang

Korps. Perangko Palembang Star
Jl. Leti Manan Sohar AA No. 11 RT.18/RW.07
Kel. Bun Bang, Sukelimo, Palembang 30211
Phone : (+62-711) 5612609
Fax : (+62-711) 5610451

Surabaya (Sidoarjo)

Jl. Bendara Juanda KM 3
Sedeji Agung, Sedat – Sidoarjo 61252
Jawa Timur
Phone : (+62-31) 6688808
Fax : (+62-31) 6681688
Email : surabaya@kobexindo.com

Pontianak

Jl. Purnama, Komp. Ruko Purnama Townhouse
No. 1C, Kel. Font Tokaya Kiri, Fontanak Selatan
Fontanak / RT 21, Kalimantan Barat
Phone : (+62-561) 927968
Fax : (+62-561) 767969
Email : pontianak@kobexindo.com

Ketapang

Jl. Gajah Meda
Kel. Kalimem, Kec. Delta Pasiran
Ketapang – Kalimantan Barat
Phone : (+62-294) 3988147
Fax : (+62-294) 3986137
Email : info@kobexindo.com

Banjarmasin (Banjarbaru)

Jl. Yari KM 21
Kel. Landasan Ulin Tengah
Kec. Lings Anggang
Kota Banjarbaru 73112
Kalimantan Selatan
Phone : (+62-511) 4707678
Fax : (+62-511) 4708459
Email : banjarmasin@kobexindo.com

Batu Licin

Jl. Raya Batu Licin RT III
Kel. Karang Baku, Kec. Batu Licin
Kab. Tanah Bumbu 72171
Kalimantan Selatan
Phone : (+62-918) 71434
Fax : (+62-918) 70337
Email : batulicin@kobexindo.com

Terakan

Jl. P. Diponegoro RT. 16
Kel. Seberok, Kec. Tarakan Tengah
Kota Tarakan, Kalimantan Timur
Phone : (+62-551) 25355
Fax : (+62-551) 25454
Email : info@kobexindo.com

Balikpapan

Jl. Kri. Syarifudin Yasa RT 03 No.31
Sperigan, Balikpapan 76115
Kalimantan Timur
Phone : (+62-541) 760989
Fax : (+62-541) 761778
Email : balikpapan@kobexindo.com

Samarinda

Jl. Polta, Komp. Kemahajaan Pasoria Mahakam No.1
Samarinda Sebering 73151, Kalimantan Timur
Phone : (+62-541) 7268096
Fax : (+62-541) 7268057
Email : samarinda@kobexindo.com

Makassar

Kompleks Ruko 237 No. 10
Jl. Pemuda Kemahabekaan, Sudjang, Biringkanyas
Makassar, Sulawesi Selatan
Phone : (+62-411) 4815640
Fax : (+62-411) 4815636