

 **BELARUS**  
MINSK TRACTOR WORKS

  
**KOBEXINDO**  
PT BELARUS TRAKTOR INDONESIA

## **BELARUS 892.2**



Pictures of Belarus products may show other than standard equipment.

# BELARUS 892.2

## ENGINE

Type	diesel mechanical engine Euro 2, with turbocharging, direct injection
Model	D-245.5C
Power, kW (h. p.)	66 (90)
Crankshaft rated speed, rpm	1800
Number of cylinders, pcs.	4
Bore/stroke, mm	110 x 125
Displacement, l	4.75
Maximum torque, N·m	397
Fuel tanks capacity, l	135

## DIMENSIONS AND WEIGHTS

Overall length, mm	4130
Width, mm	1970
Cab height, mm	2850
Tractor base, mm	2450
Tread, mm:	
front wheels	1420–1970
rear wheels	1500–2100
Agrotechnical clearance, mm	510
Min turning radius, m	4.5
Operating weight, kg	4250
Tire sizes (standard):	
front wheels	360/70R24
rear wheels	18.4R34

## TRANSMISSION

Clutch	dry, single-disk, spring-loaded
Gearbox	mechanical, fixed-ratio
Number of gears:	
forward/reverse	18/4
Travel speed, km/h:	
forward/reverse	2.26–41.1/4.76–11.04
Rear PTO:	
independent I, rpm	540
independent II, rpm	1000
synchronous, rpm of track	3.3

## HYDRAULIC HITCH SYSTEM

Versatile, unit-principle, with draft, position and height depth control; optional – combined control.

Lifting capacity	
at lift point, kg	3200
Maximum pressure, MPa	20
Pump capacity, l/min	45
Hydraulic system capacity, l	25

Rear axle differential lock: with hydro-mechanical control, has two modes (disengaged; forced engaged).

## PT BELARUS TRAKTOR INDONESIA

Subsidiary of PT KOBEXINDO TRACTORS Tbk

### Head Office

**Kobexindo Tower**  
Jl. Pasir Putih Raya Blok E-5-D  
Ancol Timur – Jakarta Utara 14430  
Phone: (+62-21) 64700800, 64700808 (hunting)  
Fax: (+62-21) 64700900, 64700909  
Email: info@kobexindo.com  
website: www.kobexindo.com

### Branch Offices :

**Pekalongan**  
J. Soekarno Hatta No.1A  
Pekalongan 28291 Rias  
Phone: (+62-74) 37858 (hunting)  
Fax: (+62-74) 34250  
Email: pekalongan@kobexindo.com

**Palembang**  
Kompleks Pergudang Palembang Star  
Jl. Lentera Hasan Soeha AA No. 11  
RT. 1B / RW.07 Sebauh Banga  
Sukaraja, Palembang 30311  
Phone: (+62-711) 5812068 (hunting)  
Fax: (+62-711) 5610431

**Sukabaga (Sukaraja)**  
J. Bandara Juanda PM 3  
Setelah Agung, Setela / Sukabaga 81251  
Jawa Timur  
Phone: (+62-371) 8688808 (hunting)  
Fax: (+62-371) 8681888  
Email: sukabaga@kobexindo.com

**Pontianak**  
J. Purnama Karya, Ruko Purnama  
Towhous No. 1C, Kal. Panti Tokaya  
Kec. Pontianak Selatan – Pontianak 79121  
Kalimantan Barat  
Phone: (+62-561) 707988  
Fax: (+62-561) 767999  
Email: pontianak@kobexindo.com

**Kotagwang**  
Jl. Cahaya Muda  
Kel. Kalimantan, Kec. Delta Power  
Kotagwang – Kalimantan Barat  
Phone: (+62-534) 3030147  
Fax: (+62-534) 3036137  
Email: info@kobexindo.com

**Benjarmasin (Banjarkasa)**  
Jl. Yani KM 21  
Kel. Lendah Ulin Tengah  
Soc. Liang Anggang  
Kota Banjarbaru 70712  
Kalimantan Selatan  
Phone: (+62-511) 4207878  
Fax: (+62-511) 4208459  
Email: banjarmasin@kobexindo.com

### Product Support Center :

**Gedung Kobexindo**  
Jl. Raya Bekasi – Karawang KM 58  
Cikarang Timur, Bekasi – Jawa Barat 17823  
Phone: (+62-21) 89140888 (hunting)  
Fax: (+62-21) 89140055

**Batu Licin**  
Jl. Raya Batu Licin RT 01  
Kel. Kemuning Bersi, Kec. Batu Licin  
Kab. Tanah Karim 72171  
Kalimantan Selatan  
Phone: (+62-518) 71434  
Fax: (+62-518) 70317  
Email: batulicin@kobexindo.com

**Terenan**  
Jl.P. Diponegoro, RT. 16  
Kel. Sebangkok, Kec. Terenan Tengah  
Kota Terenan, Kalimantan Timur  
Phone: (+62-551) 25255  
Fax: (+62-551) 25454  
Email: terenan@kobexindo.com

**Balikpapan**  
Jl. Kal. Syarifuddin Yon RT 05 No 51  
Sejanggan, Balikpapan 76511  
Kalimantan Timur  
Phone: (+62-542) 749205  
Fax: (+62-542) 761738  
Email: balikpapan@kobexindo.com

**Samarinda**  
J. Pelita Korus, Perumahan Perona  
Matukari No. 1 Samarinda Seberang 75111  
Kalimantan Timur  
Phone: (+62-541) 7168286  
Fax: (+62-541) 7288037  
Email: samarinda@kobexindo.com

**Makassar**  
Kompleks Ruko 237 No. 10  
Jl. Perintis Kemerdekaan, Selayang  
Biringkajene – Makassar  
Sulawesi Selatan  
Phone: (+62-411) 4813645  
Fax: (+62-411) 4813638





## **BELARUS 1025.3**

\*Standart Unit Canopy

\*Cabin Optional

# BELARUS 1025.3

## ENGINE

Type	diesel with turbocharging and direct injection
Model	D-245S2
Power, kW (h. p.)	81 (110)
Crankshaft rated speed, rpm	2200
Number of cylinders, pcs.	4
Bore/stroke, mm	110 x 125
Displacement, l	4.75
Maximum torque, N-m	429
Factor of torque backup, %	25
Fuel tanks capacity, l	135

## TRANSMISSION

Clutch	dry, double disk
Gearbox	mechanical, synchronized
Number of gears:	
forward/reverse	16/8
Travel speed, km/h:	
forward/reverse	2.3-36.6/4.1-17.2
Rear PTO:	
independent I, rpm	540
independent II, rpm	1000
synchronous, rpm of track	3.5

Rear axle differential lock: with electrohydraulic control, three operating modes (disengaged; lock engaged with automatic disengagement when front wheels turn more than 13 degree; forced engaged).

## DIMENSIONS AND WEIGHTS

Overall length, mm	4600
Width, mm	1970
Cab height, mm	2820
Wheelbase, mm	2570
Tread, mm:	
front wheels	1420-2000
rear wheels	1400-2100
Agrotechnical clearance, mm	645
Min turning radius, m	5.3
Operating weight, kg	4665
Tire sizes (standard):	
front wheels	360/70R24
rear wheels	18.4R34

## HYDRAULIC HITCH SYSTEM

Unit-principle with hydraulic lift, providing draft, position, combined and height position control of implements.

Lifting capacity	
at lift point, kg	4300
Maximum pressure, MPa	20
Pump capacity, l/min	45
Hydraulic system capacity, l	25

## PT BELARUS TRAKTOR INDONESIA

Subsidiary of PT Kobexindo Tractors Tbk

### Head Office

#### Kobexindo Tower

Jl. Pasir Putih Raya Blok E-5-D  
Ancol Timur - Jakarta Utara 14430  
Phone : (+62-21) 64700800, 64700808 (hunting)  
Fax : (+62-21) 64700900, 64700909  
Email : info@kobexindo.com  
website : www.kobexindo.com

### Product Support Center :

#### Gedung Kobexindo

Jl. Raya Bekasi - Karawang KM 58  
Cikarang Timur, Bekasi - Jawa Barat 17823  
Phone : (+62-21) 89140888 (hunting)  
Fax : (+62-21) 89140055

### Branch Offices :

#### Pekalongan

Jl. Soekarno Hatta No.1A  
Pekalongan 25351 Fax  
Phone : (+62-281) 32788  
Fax : (+62-281) 34350  
Email : pekalongan@kobexindo.com

#### Palembang

Komp. Pergudang Palembang Star  
P. Ling. Mawo Sohai AA No. 11 RT.16 RW.07  
Kiburi Rumpo, Sukarasa, Palembang 30111  
Phone : (+62-311) 5613500  
Fax : (+62-311) 5613497

#### Surabaya (Sidorejo)

Jl. Bandara Juanda KM 3,  
Sedati Agung, Sidoarjo - Sidoarjo 61231  
Jawa Timur  
Phone : (+62-31) 8688300  
Fax : (+62-31) 8661988  
Email : surabaya@kobexindo.com

#### Pontianak

Jl. Panania, Komp. Ruko Panania Towerhouse  
No. 1C, Kel. Pant. Tokaya Pac, Pontianak Selatan  
Pontianak 78121, Kalimantan Barat  
Phone : (+62-561) 767088  
Fax : (+62-561) 767089  
Email : pontianak@kobexindo.com

#### Katagung

Jl. Gajah Mada  
Kel. Kaliniam, Kec. Delta Pawan  
Kotagayang - Kalimantan Barat  
Phone : (+62-534) 3038147  
Fax : (+62-534) 3038137  
Email : katagung@kobexindo.com

#### Banjarmasin (Banjarsari)

Jl. Yarsi KM 21  
Kel. Landasan Ulin Tengah  
Kec. Lings Anggang  
Kota Banjarmasin 70112  
Kalimantan Selatan  
Phone : (+62-511) 4707878  
Fax : (+62-511) 4706453  
Email : banjarmasin@kobexindo.com

#### Batu Licin

Jl. Raya Batu Ulin RT. 8  
Kel. Karang Baru, Kec. Batu Licin  
Kab. Tanah Bumbu, 72171  
Kalimantan Selatan  
Phone : (+62-518) 71454  
Fax : 362-5181-70317  
Email : batu@kobexindo.com

#### Tarakan

Jl. P. Diponegoro, RT. 10  
Kel. Sebangkok, Kec. Tarakan Tengah,  
Kota Tarakan, Kalimantan Tengah  
Phone : (+62-551) 25355  
Fax : 302-5511-25454  
Email : tarakan@kobexindo.com

#### Balikpapan

Jl. P. Syarifuddin, RT. 03 No. 31,  
Sepayan, Balikpapan 76115  
Kalimantan Tengah  
Phone : (+62-542) 760983  
Fax : (+62-543) 761728  
Email : balikpapan@kobexindo.com

#### Samarinda

Jl. Indira, Komp. Perumahan Persewa Mahakam No. 1,  
Samarinda Seberang 75111, Kalimantan Tengah  
Phone : (+62-541) 7268066  
Fax : (+62-541) 7268057  
Email : samarinda@kobexindo.com

#### Makassar

Kompleks Ruko 237 No. 10  
K. Perintis Kemerdekaan, Sulawesi, Makassar  
Makassar, Sulawesi Selatan  
Phone : (+62-411) 4813540  
Fax : (+62-411) 4813638



 **BELARUS**  
MINSK TRACTOR WORKS

  
**KOBEXINDO**  
PT BELARUS TRAKTOR INDONESIA



# **BELARUS 1523.3**

\* Cabin & Canopy Available

[www.kobexindo.com](http://www.kobexindo.com)

# BELARUS 1523.3

## ENGINE

	1523.3
Type	diesel with direct injection turbo charging after cooling
Model	D260.1S2
Power, kW (hp)	116 (158)
Crankshaft rated speed, rpm	2100
Number of cylinders, pcs.	6
Bore/stroke, mm	110x125
Displacement, l	7.12
Maximum torque, N-m	647
Fuel rate at rated power, g/kW-h	250
Factor of torque backup, %	25
Fuel tank capacity, l	250

## TRANSMISSION

Clutch	dry, double-disk, spring-loaded
Gearbox	mechanical, synchronized, fixed-ratio
Gear shifting	by synchronized clutches
Number of gears:	
forward/reverse	16/8
Travel speed, km/h:	
forward/reverse	1.73-32.34/2.7-15.5/1.7-32.3/2.7-17.1
Rear PTO:	independent, double-speed, with hydromechanical control system
independent I, rpm	540
independent II, rpm	1000
synchronous, rpm of track	3.8

Differential lock: friction-type, automatic with hydraulic drive, has 3 operation modes (disengaged; automatic engagement (at turn) and disengagement; forced engaged). Rear axle with close-type bevel gear differential and planetary final drives.

## DIMENSIONS AND WEIGHTS

Overall length, mm	4710
Width, mm	2250
Cab height, mm	3000
Wheelbase, mm	2760
Tread, mm:	
front wheels	1540-2115
rear wheels	1520-2435
Agrotechnical clearance, mm	620
Min turning radius (without breaking), m	5.5
Weight with front ballast, kg	6250
Tire sizes:	
front wheels	420/70R24
rear wheels	520/70R38

## HYDRAULIC HITCH SYSTEM

Electrohydraulic system with automatic depth control system, with draft, position and combined control.

Lifting capacity at lift point, kg	6500
Maximum pressure, MPa	20
Pump capacity, l/min	55
Hydraulic system capacity, l	35

## PT BELARUS TRAKTOR INDONESIA

Subsidiary of PT Kobexindo Tractors Tbk

### Head Office

#### Kobexindo Tower

Jl. Pasir Putih Raya Blok E-5-D  
Ancol Timur - Jakarta Utara 14430  
Phone : (+62-21) 64700800, 64700808 (hunting)  
Fax : (+62-21) 64700900, 64700909  
Email : info@kobexindo.com  
website : www.kobexindo.com

### Product Support Center :

#### Gedung Kobexindo

Jl. Raya Bekasi - Karawang KM 58  
Cikarang Timur, Bekasi - Jawa Barat 17823  
Phone : (+62-21) 89140888 (hunting)  
Fax : (+62-21) 89140055

### Branch Offices :

**Pekalongan**  
Jl. Soekarno Hatta No. 14  
Pekalongan 28291 Esau  
Phone : (+62-261) 37808  
Fax : (+62-261) 37855  
Email : pekalongan@kobexindo.com

**Palembang**  
Kemp. Pengembang Palembang Stai  
Jl. Lemp. Harau-Sohar KM No. 11 RT.18/39807  
Kotabunga, Sukram, Palembang 30311  
Phone : (+62-311) 5612699  
Fax : (+62-311) 5610431

**Sorabaya (Sidorejo)**  
Jl. Randa Janda KM 1  
Sidoarjo, Sidorejo - Sidoarjo 61253  
Jawa Timur  
Phone : (+62-31) 8688288  
Fax : (+62-31) 8681888  
Email : sorabaya@kobexindo.com

**Pontianak**  
Jl. Purnama, Kemp. Rako Purnama Towerhouse  
Roo. 1C, Rpt. Panti Tokaya, Kec. Pontianak Selatan  
Pontianak 78125, Kalimantan Barat  
Phone : (+62-561) 767968  
Fax : (+62-561) 767889  
Email : pontianak@kobexindo.com

**Ketapang**  
Jl. Gajah Mada  
Kel. Kalimantan, Kec. Delta Power  
Ketapang - Kalimantan Barat  
Phone : (+62-534) 3031147  
Fax : (+62-534) 3030137  
Email : info@kobexindo.com

**Banjarmasin (Banjarbaru)**  
Jl. A. Yani KM 21  
Kel. Kalimantan, Kec. Delta Power  
Kec. Ujung Kranggan  
Kota Banjarmasin 70112  
Kalimantan Selatan  
Phone : (+62-511) 4737876  
Fax : (+62-511) 4738459  
Email : banjarmasin@kobexindo.com

**Batu Lintang**  
Jl. Raya Belukir ke HT 14  
Kel. Kangkong Baru, Kec. Batu Lintang  
Kab. Tanah Bumbu 72171  
Kalimantan Selatan  
Phone : (+62-518) 77454  
Fax : (+62-518) 70327  
Email : batulintang@kobexindo.com

**Terenan**  
Jl. P. O. Dikorenggoro, RT. 16  
Kel. Sebangkok, Kec. Terenan Tengah  
Kota Terenan, Kabupaten Terenan  
Phone : (+62-551) 25355  
Fax : (+62-551) 25454  
Email : info@kobexindo.com

**Balikpapan**  
Jl. Rd. Sudi Pudin Ives, RT. 03 No. 81  
Sepanggang, Balikpapan 76115  
Kalimantan Timur  
Phone : (+62-542) 762989  
Fax : (+62-542) 761728  
Email : balikpapan@kobexindo.com

**Samarinda**  
Jl. Pivisa, Kemp. Perumahan Permana Mahakam No. 1  
Samarinda Seberang 75131, Kalimantan Timur  
Phone : (+62-541) 726896  
Fax : (+62-541) 7268057  
Email : samarinda@kobexindo.com

**Makassar**  
Kemp. Rako ZST Fls. 10  
Jl. Perintis Kemerdekaan, Sukang, Binangkaya  
Makassar, Sulawesi Selatan  
Phone : (+62-411) 4813640  
Fax : (+62-411) 4813638

