

HID Proximity Credentials

ProxCARD II Card - 1326

Ensure each required option has been checked with the appropriate choice to fulfill a completed order form.

1326 Base Model

Programming (Select one option)

- L - Programmed, Low Frequency (125 kHz) HID. Specify Programming Information.
- N - Non-Programmed, Low Frequency (125 kHz). Programming Information Not Required.

Front Packaging (Select one option)

- S - ProxCARD II Artwork - Vinyl with Matte Finish
- M - Plain White Vinyl with Matte Finish
- G - Plain White PVC with Gloss Finish
- C - Custom Artwork - Specify Custom Artwork Number¹

Back Packaging (Select one option)

- S - Base with Molded HID Logo
- C - Custom Artwork - Specify Custom Artwork Number¹

Card Numbering² (Select one option)

- M - Sequential Matching Encoded/Printed (Inkjetted)
- N - No Printed Card Numbering
- S - Sequential Encoded/Sequential Non-Matching Printed (Inkjetted)
- R - Random Encoded/Non-Matching Sequential Printed (Inkjetted)

Slot Punch

- V - Vertical Slot Punch

Option - Custom Artwork²


_____ (Specify Artwork Number - Refer to the Custom Artwork Forms for new Artwork)

Enter your final card options from check boxes above. Example: 1326LSSMV

Final Part Number	1326	L	M	S	M	V	-	(Options #)
--------------------------	-------------	---	---	---	---	---	---	--------------------

125 kHz Card Programming Information

Format Number H10301 (example: H10301) Bit Numbers 26 (example: 26 bit) Facility Code 88
 Encoded Card # Start 48503 Stop 48702 Printed Card # Start 48503 Stop 48702
 HID Elite ICE Number (if applicable) - _____ (Custom Format) Site Code _____ City Code _____ OEM Code _____
 Special Instructions: _____



12345 = Card ID Number
 YYYYYYYY-YY = Sales Order Number

¹ For new artwork files, contact Customer Service for custom artwork number, lead-times, and cost.
² The Printed card number is placed in the top left-hand corner on the back of the card. HID logo molded into base on back.